FF manual GB

force60BS

CE

industrial sectional door operator.

INSTALLATION / MAINTENANCE

© All rights reserved. FlexiForce®, 2011



force60BS.indd 1 11-01-11 11:09

FF manual GB

ATTENTION! GENERAL WARNINGS!

To install, use and maintain this operator safely, a number of precautions must be taken. For the safety of all concerned pay heed to the warnings and instructions given below! If in doubt, contact your supplier.

- This manual has been written for use by experienced fitters and as such is not suitable for d.i.y. purposes or for use by trainee fitters.
- This manual describes the installation of the electrical operator. Be sure to supplement this manual if needed with instructions for any additional components not described in this manual.
- Before starting, read this manual carefully!
- Certain components may be sharp or have jagged edges. As such you are advised to wear safety gloves.
- All the components which have been supplied are designed for use with this specific electrical operator. Replacement or adding additional components may have an adverse effect on the safety of, and the guarantee on, the electrical operator. Also the CE-approval which has been granted to this electrical operator will be cancelled when components are changed or installation is not done according to this manual! Installer is responsible for this.
- During tensioning, springs can exert large forces. Work carefully. Use the proper equipment. Ensure that you are standing in a steady position.
- Ensure that there is sufficient light during installation. Remove obstacles and dirt. Make sure that there is no one else present other than the fitters. Other people (children!) may get in the way or endanger themselves during the installation.

WARRANTY, TERMS & CONDITIONS

The general terms and conditions of delivery and payment issued by the Metaalunie and designated as METAALUNIE CONDITIONS are fully applicable to all our quotations, contracts and their implementation. We expressly reject all other terms and conditions. On request we will send you a copy of these terms and conditions free of charge. A copy may also be downloaded from our website www.flexiforce.nl.


CONTACT


FlexiForce Group B.V., P.O. Box 37, 3770 AA Barneveld, The Netherlands
Tel. +31-(0)342-427777, info@flexiforce.nl

force60BS.indd 2 11-01-11 11:09

FF manual GB

CONTENT OF PACKAGING






1x




1x



1x




1x




1x



2x



1x




1x



1x





4x




4x

TOOLS REQUIRED FOR CORRECT AND RAPID ASSEMBLY







Bit 4.0 mm
Bit 4.5 mm
Bit 6.5 mm




(−)
(+)





13 mm



8 mm
13 mm

force60BS.indd 3 11-01-11 11:09

FF manual

ASSEMBLY OPERATOR

Fig. 1




Fig. 2




Fig. 3




Fig. 4





Fig. 5



Remarks:

force60BS.indd 4 11-01-11 11:09

FF manual

ASSEMBLY RELEASE

Fig. 6




Fig. 7




Fig. 8






Fig. 9




LIMIT SWITCH ADJUSTMENT

Fig. 10



force60BS.indd 5 11-01-11 11:09

WIRING




Note: With the provided push button the control panel isn't necessary.

force60BS.indd 6 11-01-11 11:09

FF manual

DIMENSIONS



MAIN FEATURES

Travel control system	Mechanical rotary limit switch
Control type	HOLD-TO-RUN only
Duty class	4-heavy
Duty cycles	S2=30 min / S3=50%
Power supply	230V~/50Hz
Insulation class	class 1
Input	3A
Torque	60Nm
Drive shaft RPM	22 RPM
Release system	By cable
Operating temperature	-20˚C/ +55˚C / (-35˚C/ +55˚C with NIO enabled)
Protection class	IP 54

force60BS.indd 7
11-01-11 11:09

Power is not all that is needed to operate your doors.....



Operators for overhead doors can be bought from anyone at any quality and any price. However, we believe that the key in being successful in selling operators with your doors, is in the ultimate combination of a good product, a good price, from local warehouses, with very good after sales back up. If you add to this combination the "one-stop-shop: operators + hardware", you will agree with us that FlexiForce offers you the best solution for your operator business. Challenge us for becoming your supplier!

I: www.flexiforce.com

E: info@flexiforce.nl

flexiforce FF
innovations for overhead doors

force60BS.indd 8 11-01-11 11:09