SPARE PART LIST

SR NO	PART NAME	MATERIAL
1	SLAT	Galvanised Steel
2	BRACKET	MS
3	GUIDE	MS
4	SHAFT	MS
5	BOTTOM	MS
6	HOOD COVER	GI
7	MS BOLT	HIGH TENSILE
8	MS BOLT	
9	GREESE	
10	ANGLE	MS
11	RUBBER BOTTOM	EPDM
12	TENSION SPRING	MS
13	RING WITH PLATE	MS
14	RING	MS
15	BUSH	MS
16	U - CLAMP FOR BRACKET	MS
17	FLAT	MS
18	NUT & BOLT WITH	MS
19	WASHER	
20	COLOR	POWDER COAT
21	GEAR BOX ASSLY	STD
22	BOTTOM LOCK & HANDLE	MS