



A physical Teams busylight for your desk — user guide

What it is

onIT drives a small round LCD on your desk that shows whether you are available, in a call, or presenting. A menu bar app (macOS) or system tray app (Windows) follows your Microsoft Teams presence and keeps the light in sync over USB.

What you need

Part	Notes
Waveshare ESP32-S3-Touch-LCD-1.28	1.28" round LCD; onIT flashes its firmware for you over USB — a brand-new board works out of the box
USB-C cable	Must be a data cable; it powers the device and carries the signal
onIT app	Latest release from the project's Releases page

Install — macOS

1. Download `onIT-<version>-macos-arm64.pkg` (Apple-silicon Mac, macOS 11 or later) and run it. It installs `onIT.app` to Applications and the `onitctl` command-line agent to `/usr/local/bin`.
2. First launch only: right-click `onIT.app` → **Open** (the package is unsigned, so macOS asks once).
3. onIT adds itself to your login items; the **Start at login** checkbox turns that off.

Install — Windows

1. Download `onIT-<version>-windows-amd64.zip` and extract it anywhere — keep the three files together.
2. Run `onIT.exe`. SmartScreen warns once: **More info** → **Run anyway**.
3. The app lives in the system tray (bottom-right). It registers itself to start at login on first run.

Connect your Teams presence

onIT reads your presence from Microsoft Graph. Open the app window → **Presence setup...**

Normal sign-in (most people)

1. Click **Sign in to Microsoft**.

2. A short code appears. Click **Open sign-in page** (or go to `microsoft.com/devicelogin`), enter the code, and approve.
3. That's it. onIT only receives permission to read your own presence (`Presence.Read`) — it cannot see chats, mail, or anyone else's status. The approval screen may show “Microsoft Graph Command Line Tools”: that is the built-in Microsoft sign-in client onIT uses.

If your organization requires admin approval, the sign-in page says so. An administrator approves the onIT app once; after that, everyone in the organization can sign in normally.

Advanced: registering your own Azure app

Only needed if your organization blocks third-party apps, or you want the app registration under your own control. You need rights to create app registrations in your Microsoft tenant.

1. Go to `portal.azure.com` → search **App registrations** → **New registration**.
2. Name it (e.g. *onIT*). For account types, *Accounts in this organizational directory only* is fine for one company; choose *any organizational directory* to share it across tenants. Leave Redirect URI empty. Click **Register**.
3. On the Overview page, copy the **Application (client) ID**.
4. **Authentication** → scroll to **Advanced settings** → set **Allow public client flows** to **Yes** → Save. (*Skipping this is the most common mistake — sign-in fails without it.*)
5. **API permissions** → **Add a permission** → **Microsoft Graph** → **Delegated permissions** → search *Presence* → tick **Presence.Read** → **Add permissions**. If the status shows *Not granted*, click **Grant admin consent** (or ask an admin).
6. In onIT: **Presence setup...** → expand **Advanced: own app registration** → paste the Client ID (and your Directory/tenant ID if sign-in asks for it) → **Sign in**.

If Teams on your machine still offers the legacy third-party app API (Teams Settings → Privacy), onIT uses it automatically until you sign in to Graph — no setup at all. Microsoft is retiring that API, so Graph sign-in is the durable path.

The light

State	When (Auto)	On the screen
 Available	free, busy without a call, away	dark face, green ring and dot
 Meeting	in a call or meeting	solid red, microphone icon
 Sharing	presenting, or do-not-disturb	purple, pulsing ring, “Do not disturb”
 Off	offline or no presence source	near-black dotted ring

Manual control: the window buttons (or the tray menu) force any state; the choice stays until you click **Auto** (**Teams**). onIT returns to Auto when it restarts.

Firmware updates

Each onIT release carries the matching device firmware inside the app — there is nothing separate to download. When the device reports an older version (or none, on a factory-fresh board), the window shows **Firmware <old> -> <new>** with an **Update firmware** button.

During the update the device shows a red pulsing “**Flashing — do not power off**” screen, then goes dark for about half a minute while it is written. Leave the cable alone until the light comes back.

A **Reflash firmware** button is always available when versions already match — use it if the device ever gets into a weird state. The device cannot be bricked: the built-in bootloader always allows another flash.

App updates

Tray menu → **Check for updates...** compares your version with the latest release, downloads it, and opens the installer. When the new version first starts, it stops the old one automatically.

Uninstall

The **Uninstall onIT...** button removes the login item, sign-in tokens, all settings, and the app itself (macOS asks for your password). The device keeps its firmware and works again the moment you reinstall.

Troubleshooting

Symptom	Check
Light not found	Use a data-capable USB cable and a direct port. <code>onitctl -ports</code> lists what the computer sees; the device shows VID <code>1A86</code> or <code>303A</code> .
Sign-in fails mentioning “public client”	Advanced registration only: <i>Allow public client flows</i> was not enabled (step 4 above).
“Needs admin approval” at sign-in	Your org restricts consent — an admin approves once.
Firmware update fails	The error dialog shows the reason. Full logs: <code>~/Library/Logs/onIT.log</code> (macOS) or <code>%LOCALAPPDATA%\onIT\onIT.log</code> (Windows).
Two copies fighting over the port	Can't happen since v1.2.3 — a starting onIT stops any running one and tells you.