

Fictional Pump Handbook

Operation

The fictional booster pump 20-P-201B moves water to the cooling loop. Its normal suction pressure is 2 bar. This is synthetic training material.

Maintenance

Inspect the seal of 20-P-201B every 30 days. Vibration above 7 mm/s requires a stop.