







1 2 3 4



5V TO 3V3



P_SDA	1	2	GND
P_SCL	3	4	P_TX
P4	5	6	P_RX
GND	7	8	P17
P17	9	10	P18
P27	11	12	GND
P22	13	14	P23
	15	16	P24
P_MOSI	17	18	GND
P_MISO	19	20	P25
P_SCK	21	22	P_CE0
GND	23	24	P_CE1
ID_SD	25	26	ID_SC
P5	27	28	GND
P6	29	30	P12
P13	31	32	GND
P19	33	34	P16
P26	35	36	P20
GND	37	38	P21
	39	40	CON40_DD

Title Raspberry Pi Servo Driver
Size A4 **Number** 1/1 **Revision** V1.0

Date:	16/01/2020	Sheet of
File:	E:\DEEPAK DATA\Sheet1.SchDoc	Drawn By: Deepak Singh

1 2 3 4