

v 0.11

* Add duplicate multimodule in center v 0.12


* Reorient voltage adjust pot
* Add voltage adjust TP
v 0.12


v 0.13


* Moved anode resistors to keep away fingers


TODO: * MWAIT support - look at the PLD for info

* Int2 button









CAPACIONE PROPRIENDE NECONDE DE LOR CONDO DE