



✨ AquaGlow Semi-Gloss

Product Type:

PRODUCT MANUAL: MOISTURE-RESISTANT INTERIOR SEMI-GLOSS FINISH

Product Overview

Recommended For:

- Kitchens
- Bathrooms
- Trim
- Cabinets

This finish combines durability and aesthetic appeal, making it an ideal choice for areas prone to humidity and frequent cleaning. Its semi-gloss sheen highlights architectural details and provides a moisture barrier to protect interior surfaces.

Surface Preparation

Proper surface preparation is essential for optimal adhesion and a long-lasting finish. Carefully follow these steps before application:

1. Deglossing:
All previously painted surfaces must be deglossed. Glossy surfaces can prevent proper bonding. Use fine-grit sandpaper or a chemical deglosser to create a dull, uniform surface.
2. Priming:
If applying over glossy or bare surfaces, prime using EcoGuard Primer. This will enhance adhesion and coverage.
3. Cleaning:
Ensure that all surfaces are free from dust, dirt, grease, and mildew.
 - Dust: Use a clean, damp cloth to wipe away debris.
 - Grease: Use a mild household detergent and rinse thoroughly.
 - Mildew: Treat with a solution of one part bleach to three parts water, rinse, and allow to dry completely.
4. Repair:



✨ AquaGlow Semi-Gloss

Fill imperfections such as holes or cracks with a suitable filler. Allow repairs to dry and smooth them with fine sandpaper.

Application Instructions

To achieve a beautiful, smooth semi-gloss finish, carefully follow the application steps below:

1. Tools:
 - High-density foam roller
 - Quality nylon paint brush
2. Stirring:

Stir the paint thoroughly before use. This ensures color consistency and optimal performance.
3. Painting:
 - Begin at the edges with a brush, then use the roller for larger areas.
 - Work in small sections to maintain a wet edge, helping to prevent lap marks.
 - Apply paint with steady, even strokes.
 - Avoid over-brushing or re-rolling once the paint begins to dry to maintain finish integrity and smoothness.
4. Environmental Considerations:
 - Do not paint in temperatures below 50°F (10°C) or above 90°F (32°C).
 - Avoid application during high humidity, which may affect drying and final appearance.
 - Use painter's tape to protect adjacent surfaces from splatters and drips.

Product Coverage

- 375–425 sq. ft. per gallon
- Actual coverage may vary based on substrate texture, porosity, and application method. Highly absorbent or rough surfaces will reduce coverage rate.

Dry Times

- Touch dry: 45 minutes (at 70°F/21°C and 50% relative humidity)
- Recoat: After 2–3 hours



✨ AquaGlow Semi-Gloss

- Do not expose freshly painted surfaces to moisture for at least 24 hours after application to prevent defects in the finish.

Cleanup and Disposal

1. Cleanup:

- Clean brushes, rollers, and other tools with soap and warm water immediately after use.
- For stubborn residue, a brush comb or scrub pad may be helpful.

2. Disposal:

- Never pour leftover paint or rinse water down drains or sewers.
- Allow excess paint to dry and dispose of according to local regulations.

Pro Tips for Best Results

- Always stir paint thoroughly before and during application.
- Work in small sections to keep a "wet edge," preventing visible lines.
- Apply even, overlapping strokes to ensure consistent coverage.
- Use quality painter's tape on adjacent areas such as hardware, windows, and edges for sharp, clean lines.
- Avoid painting in extreme weather conditions; optimal temperature is 70°F with low to moderate humidity.

Frequently Asked Questions & Support Topics

Surface Prep:

- What if my surface is glossy? Degloss or sand all glossy surfaces; prime with EcoGuard Primer for best adhesion.

Application Method:

- Can I use a sprayer? For best results, use a high-density foam roller or quality nylon brush. If spraying, thin and adjust the equipment as the manufacturer recommends.

Coverage:



✨ AquaGlow Semi-Gloss

- How do I estimate paint needed? Calculate the square footage and divide by the coverage rate (375–425 sq. ft./gallon).

Dry Time:

- When can I recoat? Recoat in 2–3 hours under standard conditions.

Cleanup:

- How do I clean tools? Wash all brushes and rollers with soap and warm water immediately after use.

For further assistance, contact product support or visit our website for detailed troubleshooting guides and video tutorials.