MUSTANG
MOTORCYCLE SEATS

MOUNTING SUGGESTIONS

Harley-Davidson® FL Wrap-Around Backrest 2014-2018

Hardware: 1/4"-20 nuts x3
1" zinc washer
Rubber bumpers x3

Tools needed: 7/16" nutdriver or wrench

Installation of Mustang backrest:

Note: Mustang warp-around backrest installs ONLY on King Tourpaks and not on leather or chopped paks.



Back view of wrap-around

1. Open Tourpak, locate and remove the three hex nuts holding stock wrap-around unit in place and remove.

2. Note locations of mounting holes in lid. Mustang wrap-around uses the two outermost holes and the upper center hole only.



3. Remove all supplied hardware from studs on the back of the Mustang wrap-around except the rubber bumpers.

4. Align the studs with the holes in the Tourpak and push through.

5. Place one zinc washer and one hex nut on the studs inside of the lid. Tighten all three securely.

Enjoy the comfort and custom look of your new Mustang seat!

These steps are guidelines to help you install your new Mustang product. If you need further assistance, please call us at 800-243-1392 or 413-668-1100, Monday through Friday 8:30 - 5:00 Eastern or send an e-mail to tech@mustangseats.com or visit our website at www.mustangseats.com.

For care and maintenance of our seats, please go to our website under "Support".

Refers to part numbers: 76850, 76851, 76852, 76853, 76854, 76855, 79014



Products made by Mustang Motorcycle Products, LLC are warranted for one year against defects in material and workmanship. Mustang must first be notified of any apparent defect. A return authorization will be issued. Carefully pack the product and return prepaid. Upon receipt, Mustang will make a fair, prompt decision regarding repair or replacement. Incidental and consequential damages arising from or in connection with the installation or use of a Mustang product are not covered by this warranty. An original purchase receipt must be provided to obtain a warranty repair or replacement.