2017-2021 Milwaukee 8 Oil Cooled Installation Guide



3302 Airport Rd.
Helena, MT 59601
406.457.1234

info@harleyoilcoolers.com
https://www.harleyoilcoolers.com

1. Remove oil pump cover
2. Remove lower hose clamp off of the oil line going to the head. Then cut clamp off the other oil line on the other side at the bottom of the oil cooler.
3. Now take off the electrical plug off the regulator on the left side.
4. Remove the Torx screws at bottom of the OEM oil cooler/regulator bracket and allen screws at the top of the bracket. Remove oil line and set oil cooler/regulator assembly aside.

INSTALL ADAPTER

5. Remove oil filter and nut that holds on the filter with a 7/8" socket.
6. Take the supplied tube nut and install the inner adapter plate with the large o-ring in place between engine and plate. Then clock the plate until it touches the cylinder fins. Tighten to 40 ft.lbs. and then back the plate 1/8" from the cylinder fins carefully with a larger screw driver.
7. Make sure o-rings are in place both large and small on outer face of inner adapter plate.
8. Take the outer plate and attach to the inner plate. The short 1" allens go in the outer plate. The longer screws go in the back side of the inner plate. Tighten in a balanced manner. A wobble allen wrench will be required on the back side. You should also loosen the exhaust shroud. That will help with angle. It's tight but doable.

RUN HOSES AND INSTALL COOLER ELEMENTS

9. Take the long hose and run it between engine and brace member that oil cooler/ regulator assembly bolts too. Then run along inside of frame rail over the frame cross brace.
10. Hook up the hose to the fitting on the inner adapter plate.
11. Take exhaust bracket off of the crossover tube and set aside.
12. Take the rear element (double one) with the hook pointing down. Then push and tap into place in-between the cross member and the oil pan. Make sure it all the way forward. You might have to tap in place.
13. Hook up rear line and leave loose.
14. Now take middle element and install short line and tighten. Now put the tab of the element over the right side of the frame. Then thread hose to front of the bike. There is a zip tie and a plastic tab that holds the wire harness at front of the frame that needs to be removed to free it up to make room for hoses.
15. Attach the front element to the middle element hose and tighten.
16. Now attach the middle and rear element together on the left side.
17. Take the aluminum wedge looking clamp and put over tube on rear cooler. Tighten it up. It will hold the rear and middle element solid and leave little space between the bottom of pan and element.
18. Now tighten all hoses and fittings.
19. There is a plastic cover over some electrical plugs. It is located under the front section of the frame. Remove the cover and detach the plug in the front. The plug has to be zip tied back and out of the way. This will allow the front element to mount properly.

INSTALL OIL COOLER REGULATOR ASSEMBLY

20. Take the oil cooler/regulator assembly bracket and hook up right regulator electrical plug then install the left Torx screw on the right and allen screws at the top of the bracket.
21. Screw on the front cooler element were the left Torx screws goes.
22. Hook up the hoses to the cooler. We use a heavy duty heat shrink on the bottom hose. Put the clamp on the top hose going the cylinder head.
23. Put on the right regulator plug .
24. Now tighten all fitting and check all the fasteners.
25. Install K&P Engineering oil filter.
26. Start motorcycle and check for leaks. Now put zip tie's to hold hoses from chaffing against frame and wiring.
27. GO RIDE!!!

NOTE: After a couple of miles stop and check again for leaks.

NOTE: We are providing this guide to you while we are updating it, therefore we have not included photos at this time.

For questions or concerns regarding installation, please call Bud at 406-594-1234.