

# Welcome to our site!

Electro Tech is an online community (with over 170,000 members) who enjoy talking about and building electronic circuits, projects and gadgets. To participate you need to register. Registration is free. Click here to register now.

Register

Log in

Forums > Electronics Forums > General Electronics Chat >

# LM317 Calculating =)

& Corday · **(**) Jun 18, 2011

A Not open for further replies.



Next ▶



## **Corday**

**New Member** 

Jun 18, 2011

& #1

I have just made an adjustable voltage-regulator with a LM317, but i am still abit confused about the calculations...

This is the official formula provided by the manufacturers:

Vout = 1,25\*(1+(R2/R1)) + Iadj\*R2

However, since I must have missed the classes where breaking out variables was explained - i am real stuck.

Vague sources has led me to the following tho:

R2 = R1\*((Vout/1,25)-1)

\* Note that Iadj\*R2 from the original formula is missing here

and

 $R1 = (R2*1,25)/(Vout-((50*10^-6)*R2))$ 

\* Iadj\*R2 included

Trying these formulas in excel shows that the formulas for **Vout** and **R1** renders matching results, whereas R2 differs by the amount that ladj\*R2 would give.. However, i am mathematically incapable of inserting that into the formula =(

I know that the TI-datasheet says "*Because IAdj typically is 50 mA, it is negligible in most applications.*" However i find that ignoring it entirely (which all online calculators does), is pretty rough... Because lets say i use a 10k potentiometer for R2. That will result in: (50\*10^-6)\*10000 equals 0,5v. Which can be alot to some electronics...

Plus, i want all the formulas to match up =)



# audioguru

Well-Known Member

Most Helpful Member

The LM317 uses a 120 ohm resistor from the output to the ADJ pin, the more expensive LM117 can use a 240 ohm resistor.

Then the other resistor is calculated using Ohm's Law since the ADJ current is extremely small (it is typically 50uA, not 50mA which is 1000 times higher).

You forgot to tell us the range of output voltages that you want.

If you use 120 ohms for R1 and a 10k pot for R2 then the max output will try to be 104V which is impossible. So the 10k pot value is much too high.

Uncle \$crooge



## Corday

New Member

Yeah mA was a typo obviously... The correct "uA" is in the datasheet...

Hmm how do you mean "it uses"? I can use any resistor i'd like afaik.. I use 680+680 for R1 which equals 1360. Then i use a 10k pot for R2 which results in a max output of 10,94v. Tested and verified aswell.

But my question was not regarding what output voltage i want, but a correct formula for breaking out R2 from "Vout = 1,25\*(1+(R2/R1)) + Iadj\*R2".

Last edited: Jun 18, 2011



The 317 must produce at least 10ma of current for it to work properly. That is why there is almost always a  $120\Omega$  resistor for R1 (with a constant 1.25v developed across the Vout pin and the ADJ pin the current will be E/R =  $1.25/120 \approx 10$ ma.) This means there will also be 10ma across R2. Using E = IR to figure the voltage developed across R2 this is the voltage from GND to the ADJ pin. Add that to the constant 1.25v from ADJ to Vout and you will have the output voltage from Vout to GND.

(1.25 + 0.01\*R2 = Vout) with a 120  $\Omega$  R1.

You can make R1 smaller than  $120\Omega$  but not larger. If you do, rhe 317 will not produce the 10ma it needs to run.

Recursion [ri kur shon] n. See recursion





# Corday

New Member

But it runs just fine: / im sitting next to it watching the voltage output



# Corday

New Member

And Afrotechmods uses a  $510\Omega$  R1 with a 10k pot in his tutorial for the LM317. That gives him a voltage-span of 1,25v to 25v.

https://www.youtube.com/watch?v=IjJWWGPjc-w&feature=player\_embedded#at=82



## audioguru

Well-Known Member

Most Helpful Member

Jun 18, 2011  $\ll$  #7

Every IC has a range of currents for it to work properly. Some LM317 ICs need 120 ohms or less for R1 to prevent the output voltage from rising when the load current is not much but other LM317 ICs work fine with 240 ohms or more. The problem gets worse when the input voltage is high. The datasheet explains it.

You should design circuits so that all passing ICs work, not just some of them.

Uncle \$crooge



Jun 19, 2011 % #8

Oki, great information! I will consider it in the future. Although i have spent countless hours reading about the LM317, I am yet to find any information that says to use max  $120\Omega$ . Quite the contrary actually, as you can see in guides and tutorials for the LM317, people use resistors hugely different to  $120\Omega$ . But thanks for pointing it out nonetheless.

So, if we put all that aside now, I would be really happy for a solution to my original topic.

### And to clarify, i will make a recap.

- **√ Vout** can be calculated knowing the values of R1 and R2.
- $\sqrt{R1}$  can be calculated knowing the Vout i want and R2.

**X R2** can be calculated the same way but knowing the Vout and value of R1, however, i need help with breaking out R1 from the original formula Vout = 1,25\*(1+(R2/R1)) + Iadj\*R2

To make it even clearer, lets put values for Vout and R1.

**Vout** = 12,5v**R1** =  $120\Omega$ **R2** = **x** 

Which makes:  $12,5=1,25*(1+(x/120))+((50*10^-6)*x)$ 

Solve X

Last edited: Jun 19, 2011

Forget about ladj because it is negligible.

Resistor R1 has typically 1.25V across it and R2 has the remaining output voltage across it. So for an output of 12.5V, R1 has 1.25V across it and its current is 1.25V/120 ohms= 10.42mA. R2 also has 10.42mA and has a voltage of 12.5V - 1.25V= 11.25V across it. Ohm's Law calculates the value of R2 to be 11.25V/10.42mA= 1080 ohms.

Uncle \$crooge



If you think that ladj(R2) is a significant term then you may want to look at the data sheet for the 317 and see that the permissable value of ladj can be anything up to 100ua.

Then you may also want to look at the permissable variation in Vref which can be as low as 1.2v and as high as 1.3v.

You will need to know these values to accurately predict Vout or ignore the above and calculate the worst case conditions and use a trimpot to give you exactly what you want. Set it and forget it.

R2 = (R1)(Vout - Vref)/(Vref + Iadj \* R1)

Recursion [ri kur shon] n. See recursion



Oki! Done with calculations =)

Hmm.. While testing i tried a fixed Vout of ~11 using  $27\Omega$  for R1 and  $220\Omega$  for R2...

Everything works Ok, im getting 10,94Vout but R2 is getting really warm, really quick:/ I tried both 24v and 14v for Vin, but effect is the same.. It takes around 15s for it to become too hot to touch, even without anything connected to Vout..

This cant be normal right? Could it be because i used so low values of R1 and R2? Any ideas?

Edit: Both R1 and R2 are 1/4w with 5% tolerance

Edit2: LM317 IC is not getting warm

Last edited: Jun 19, 2011



With Vout at 11v, and Vref at 1.25v, there is 11 - 1.25 or 9.75v across R2.  $P = E^2/R = (9.75)(9.75)/220 = 0.43$  watts dissipated. This is a lot higher than the 0.25 watt rating of your resistor. To operate with a reasonable margin, resistor wattage should always be derated by at least a factor of 2. I was taught 2.5 and I stick with that. The nearest whole value for a derated 0.433 watt dissipation is 1 watt.

Tweaking the input voltage to the regulator has no effect on R1/R2 because by definition, the regulator maintains a regulated (fixed) voltage at its output where the two resistors hang out. What does happen is the heat generated inside the 317 rises with increasing input voltage.

Recursion [ri kur shon] n. See recursion



# audioguru

Well-Known Member

Most Helpful Member

I cannot post a quick reply. It says "my reply is too short" but twice it was fairly long.

You need to learn that voltage times current equals heating.

Uncle \$crooge



#### Mr RB

Well-Known Member

# Corday said: ①

... but R2 is getting really warm, really quick ...

Could it be because i used so low values of R1 and R2? Any ideas?

•••

You got it.

Try changing R1 to about 120 ohms as AG suggested. Then R2 should be about the same ratio. so 220 / 27 = 8.1

120 ohms \* 8.1 = 977 ohms (use 1k?)

a good idea is to use a pot for R2 so you can adjust the voltage.

If you use a fixed resistor of 680 ohms and a 500 ohm pot in series, this makes an "R2" that is adjustable from 680 ohms to 1180 ohms.

Roman Black - PICs and electronics. Author of <u>BTc</u> PIC-sound encoder, <u>Shift1-LCD</u> project, the <u>TalkBotBrain</u> talking PIC controller, <u>LiniStepper</u> open-source microstepping motor driver, the <u>Black Regulator</u> 2-transistor SMPS, and probably some other stuff; <u>www.RomanBlack.com</u>



## Corday

New Member

Thanks all! Its getting clearer and clearer =)

Hmmm... I see why a potentiometer is strongly preferred... Am i right if i take it that the calculations is more of a "pointer" than the actual truth? Because I had to try a whole bunch of different resistors for R2 in order to get the final Vout that i wanted.. Ended up with 3 in serial connection.



### audioguru

Well-Known Member

Most Helpful Member

The "1.25V" reference of an LM317 can be anywhere from 1.2V to 1.3V.

The resistors might be 5% low or 5% high.

Then the output voltage will not be what you want without using a trimpot.

Uncle \$crooge





#### Corday

New Member

Got the voltage regulator working as I wanted now and feel thoroughly enlightened by all information you have provided!

I would like to say thanks to audioguru, Jaguarjoe and mr RB for having patience and helping me

understand the fundamentals of a LM317 =)

And although i have concluded i may not be able to use it for the intended purpose, it was great practice and will come to good use for other stuff.

If you have some time spare, please have a look at my new thread that will regard my actual project =)



# **Corday**

New Member

https://www.electro-tech-online.com/threads/led-lights-in-a-car.119742/



#### **MrAl**

Well-Known Member

Most Helpful Member

Hi,

Here are a couple formulas that might help:

R2=((4\*Vout-5)\*R1)/(4\*Iadj\*R1+5)

R1 = -(5\*R2)/(4\*Iadj\*R2-4\*Vout+5)

or if you want to adjust Vref then:

R1=(Vref\*R2)/(Vout-ladj\*R2-Vref)

R2=((Vout-Vref)\*R1)/(ladj\*R1+Vref)

Stated another way:

R2/R1+(ladj\*R2)/Vref=Vout/Vref-1

so if we take ladj to be zero we get:

R2/R1=Vout/Vref-1

so we can see the ratio of resistor values is equal to the ratio of voltages minus 1.

Last edited: Jun 20, 2011

One test is worth a thousand expert opinions, but one expert specification is worth a thousand tests. Mathematics is the shortcut to understanding nature.

If i miss something you posted or something you think is important, feel free to PM me.





Jun 21, 2011 % #20

Wow that is whoopin cool MrAl =) I love this kind of stuff! Admirable!

I have tested and they work!! Big creds to you!



A Not open for further replies.

# Similar threads

## LM317

Gregory · Sep 27, 2019 · General Electronics Chat

Replies: 2 · Sep 28, 2019



### Lm317

mgeno216  $\cdot$  May 22, 2010  $\cdot$  General Electronics Chat

Replies: 2 · May 22, 2010



# Lm317

axro · Jul 15, 2009 · General Electronics Chat

Replies: 54 · Mar 8, 2012



## Lm317

eng.majeed · Jun 28, 2009 · General Electronics Chat

Replies: 1 · Jun 29, 2009



# LM317 Router Power

Guyabano · Sep 7, 2020 · General Electronics Chat

Replies: 5 · Sep 8, 2020









# **Q** Latest Threads



# DMM test leads that can also fit into 4mm terminals?

Started by Flyback · Today at 3:54 AM · Replies: 1 Electronic Projects Design/Ideas/Reviews

LTSpice - Digital - Pulse Generator on Edge? (monostable) Started by ACharnley · Today at 2:00 AM · Replies: 4 Circuit Simulation & PCB Design LTSpice - Digital A - Hysteresis with Ref Started by ACharnley · Today at 1:50 AM · Replies: 2 Circuit Simulation & PCB Design PIC ADC scaling/conversion help please Started by augustinetez · Yesterday at 6:15 PM · Replies: 7 Microcontrollers Electrolytic Cap Question. Started by DavidMil · Yesterday at 12:28 PM · Replies: 5 General Electronics Chat Vishay enchances its series of automotive-grade, thin-film chip resistors Fri, 28 Jan 2022 15:48:01 PST Microchip launches new time-sensitive networking Ethernet switches Fri, 28 Jan 2022 15:35:29 PST Vishay offers automotive-grade, silicon PIN photodiode in surface-mount package Wed, 26 Jan 2022 08:53:49 PST Microchip advances family of non-hybrid, space-grade power converters Wed. 26 Jan 2022 08:44:07 PST Arduino-based RFID door lock Tue, 25 Jan 2022 10:35:10 PST

# Forums > Electronics Forums > **General Electronics Chat** >

Copyright © 2022 WTWH Media, LLC. All Rights Reserved.

Contact us  $\,$  Terms and rules  $\,$  Privacy policy  $\,$  Help  $\,$   $\,$   $\,$