

Triac gate current understanding


Asked 2 years, 1 month ago Active 6 months ago Viewed 2k times



I am trying to understand how does the Triac gate current sinking work. Please consider the following circuit example:







source: http://www.electronics-tutorials.ws/power/solid-state-relay.html

the question is about resistor R2. The author states:

Consider that the output triac of the opto-isolator has switched ON at the peak value (90o) of the 120VRMS AC supply voltage. This peak voltage has a value of: 120 x 1.414 = 170Vpk. If the opto-triacs maximum current (ITSM) is 1 ampere peak, then the minimum value of series resistance require is $170/1 = 170\Omega$'s, or 180Ω 's to the nearest preferred value. This value of 180Ω's will protect the opto-coupler output triac, as well as the gate of the BTA06-600B triac on a 120VAC supply.

If the triac of the opto-isolator switches ON at the zero crossover value (0o) of the 120VRMS AC supply voltage, then the minimum voltage required to supply the required 50mA gate drive current forcing the switching triac into conduction will be: $180\Omega \times 50 \text{mA} = 9.0 \text{ volts}$. Then the triac fires into conduction when the sinusoidal Gate-to-MT1 voltage is greater than 9 volts.

As I understand this, if the MOC3020 is turned on when the AC is at at least 9V, the triac will be turned ON and 0.5W will dissipate on R2. But what happens If I leave the MOC3020 ON? The voltage will arise to 120 V and the current will reach 1A on the triacs gate driver. Does this circuit assume that MOC3020 will be turned off as soon as as possible after the firing pulse and will be never turned on later than when the sin voltage reaches 9 V? Or does the current on gate driver diminish as soon as the triac start conducting? I would appreciate an explanation.

opto-isolator triac



If for some reason the triac does not fire (say there's a gate to MT1 short) R2 will dissipate almost 80W and

will built out with a certain amount of drama when the opto-mac turns on. If the main that lifes it will be much less than 0.5W. – Spehro Pefhany Aug 24 '17 at 13:40 /*

What is the role of resistor R3? - WonderfullOT Dec 18 '18 at 16:33

1 Answer



When the triac fires into conduction, there will be only minimal voltage over it (these 120 V will be over the load (heating element)), so no significant current flowing through optocoupler. When power triac is off, there will be full line voltage over optotriac, of course, but no current as optotriac is off.



As soon as optotriac is switched on and the current through it reaches threshold, power triac starts conducting, voltage over it drops to one volt or so and there is no more significant current flowing through optotriac.



