Network Working Group Request for Comments: 4319

Obsoletes: 3276 Category: Standards Track

C. Sikes **Zhone Technologies, Inc. B**. Ray PESA Switching Systems, Inc. R. Abbi **Alcatel USA** December 2005

Definitions of Managed Objects for High Bit-Rate DSL - 2nd generation (HDSL2) and Single-Pair High-Speed Digital Subscriber Line (SHDSL) Lines

Status of This Memo

This document specifies an Internet standards track protocol for the Internet community, and requests discussion and suggestions for improvements. Please refer to the current edition of the "Internet Official Protocol Standards" (STD 1) for the standardization state and status of this protocol. Distribution of this memo is unlimited.

Copyright Notice

Copyright (C) The Internet Society (2005).

Abstract

This document defines a Management Information Base (MIB) module for use with network management protocols in the Internet community. particular, it describes objects used for managing High Bit-Rate Digital Subscriber Line (DSL) - 2nd generation (HDSL2) and Single-Pair High-Speed Digital Subscriber Line (SHDSL) interfaces. This document introduces extensions to several objects and textual conventions defined in HDSL2-SHDSL-Line MIB (RFC 3276). This document obsoletes RFC 3276.

Table of Contents

1.	The Internet-Standard Management Framework
2.	Overview
	2.1. Relationship to Other MIBs
	2.1.1. General IF-MIB Integration (RFC 2863)
	2.1.2. Usage of ifTable
	2.2. IANA Considerations4
	2.3. Conventions Used in the MIB Module
	2.3.1. Naming Conventions
	2.3.2. Textual Conventions
	2.4. Structure
	2.5. Line Topology
	2.6. Counters, Interval Buckets, and Thresholds
	2.7. Profiles
	2.8. Notifications
3	Definitions
4.	Implementation Analysis
	Security Considerations
6.	Acknowledgements
	References
/ .	7.1. Normative References
	7.1. Normative References
	/.2. IIIIUI alive

1. The Internet-Standard Management Framework

For a detailed overview of the documents that describe the current Internet-Standard Management Framework, please refer to Section 7 of RFC 3410 [RFC3410].

Managed objects are accessed via a virtual information store, termed the Management Information Base or MIB. MIB objects are generally accessed through the Simple Network Management Protocol (SNMP). Objects in the MIB are defined using the mechanisms defined in the Structure of Management Information (SMI). This memo specifies a MIB module that is compliant to the SMIv2, which is described in STD 58, RFC 2578 [RFC2578], STD 58, RFC 2579 [RFC2579] and STD 58, RFC 2580 [RFC2580].

The key words "MUST", "MUST NOT", "REQUIRED", "SHALL", "SHALL NOT", "SHOULD", "SHOULD NOT", "RECOMMENDED", "MAY", and "OPTIONAL" in this document are to be interpreted as described in RFC 2119 [RFC2119].

2. Overview

This document defines a Management Information Base (MIB) module for use with network management protocols in the Internet community for the purpose of managing HDSL2/SHDSL lines.

Sikes, et al.

Standards Track

[Page 2]

The MIB module described in RFC 3276 [RFC3276] describes objects used for managing High Bit-Rate DSL - 2nd generation (HDSL2) [T1E1.4] and Single-Pair High-Speed Digital Subscriber Line (SHDSL) interfaces [G.991.2]. These object descriptions are based upon the specifications for the HDSL2 and SHDSL Embedded Operations Channel (EOC), as defined in the American National Standards Institute (ANSI) T1E1.4/2000-006 [T1E1.4] and International Telecommunication Union (ITU) G.991.2 [G.991.2].

This document obsoletes RFC 3276 [RFC3276], which supports G.shdsl in that the MIB module described herein supports G.shdsl.bis as described in the G.991.2 [G.991.2]. In addition, objects have been added to improve the management of SHDSL lines.

The MIB module is located in the MIB tree under MIB 2 transmission, as discussed in the MIB-2 Integration (RFC 2863 [RFC2863]) section of this document.

2.1. Relationship to Other MIBs

This section outlines the relationship of this MIB module with other MIB modules described in RFCs. Specifically, the IF-MIB, as presented in RFC 2863 [RFC2863], is discussed.

2.1.1. General IF-MIB Integration (RFC 2863)

The HDSL2/SHDSL line MIB specifies the detailed attributes of a data interface. As such, it needs to integrate with RFC 2863 [RFC2863]. The IANA has assigned the following ifTypes to HDSL2 and SHDSL:

```
IANAifType ::= TEXTUAL-CONVENTION

SYNTAX INTEGER {
    hdsl2 (168), -- High Bit-Rate DSL, 2nd generation shdsl (169), -- Multirate HDSL2
    ;
}
```

Note that the ifFixedLengthGroup from RFC 2863 [RFC2863] MUST be supported and that the ifRcvAddressGroup does not apply to this MIB module.

2.1.2. Usage of ifTable

The MIB branch identified by this ifType contains tables appropriate for this interface type. Most such tables extend the ifEntry table and are indexed by ifIndex. For interfaces in systems implementing

Sikes, et al.

Standards Track

[Page 3]

this MIB module, those table entries indexed by ifIndex MUST be persistent.

The following attributes are part of the mandatory ifGeneralInformationGroup in RFC 2863 [RFC2863] and are not duplicated in the HDSL2/SHDSL line MIB.

ifIndex	Interface	index.
ITINGEX	Intertace	index

ifDescr See interfaces MIB [RFC2863].

ifType hdsl2(168) or shdsl(169).

ifSpeed Set as appropriate.

(This is fixed at 1552000 for HDSL2

lines)

ifPhysAddress This object MUST have an octet string

with zero length.

ifAdminStatus See interfaces MIB [RFC2863].

ifOperStatus See interfaces MIB [RFC2863].

ifLastChange See interfaces MIB [RFC2863].

ifName See interfaces MIB [RFC2863].

ifAlias See interfaces MIB [RFC2863].

ifLinkUpDownTrapEnable Default to enabled(1).

ifHighSpeed Set as appropriate.

(For HDSL2 lines, this is fixed at 2)

ifConnectorPresent Set as appropriate.

Figure 1: Use of ifTable Objects

2.2. IANA Considerations

The HDSL2-SHDSL-LINE-MIB module requires the allocation of a single object identifier for its MODULE-IDENTITY. The IANA has allocated this object identifier in the transmission subtree (48), defined in the SNMPv2-SMI MIB module.

Sikes, et al.

Standards Track

[Page 4]

The assignment was in fact done when RFC 3276 was published, and this revision of the RFC does not require any new action from IANA.

Conventions Used in the MIB Module

2.3.1. **Naming Conventions**

- xtuC refers to a central site terminal unit; H2TU-C for HDSL2, or STU-C for SHDSL.
- xtuR refers to a remote site terminal unit; В. H2TU-R for HDSL2, or STU-R for SHDSL.
- xtu refers to a terminal unit; either an xtuC or xtuR. С.
- xru refer to a regenerator unit;
 H2RU for HDSL2, or SRU for SHDSL.
 xU refers to any HDSL2/SHDSL unit; either an xtu or xru.
 CRC is Cyclic Redundancy Check [G.991.2].
 ES means Errored Second [G.991.2].
- Ε.

- LOSW means Loss of Sync Word [G.991.2]. J.
- LOSWS means LOSW Seconds [G.991.2]. I.
- SES means Severely Errored Second [G.991.2]. SNR means Signal-to-Noise Ratio [G.991.2]. UAS means Unavailable Second [G.991.2]. J.

2.3.2. Textual Conventions

The following textual conventions are defined to reflect the line topology in the MIB module (further discussed in the following section) and to define the behavior of the statistics to be maintained by an agent.

o Hdsl2ShdslUnitId:

Attributes with this syntax uniquely identify each unit in an HDSL2/SHDSL span. It mirrors the EOC addressing mechanism:

```
xtuC(1)
                         - central office (CO) terminal unit
                         - customer premises equipment (CPE) terminal unit
xtuR(2)
xru1(3) .. xru8(10)
                         - regenerators, numbered from
                           central office side
```

o Hdsl2ShdslUnitSide:

Attributes with this syntax reference the two sides of a unit:

```
networkSide(1) - N in figure 2, below
customerSide(2) - C in figure 2, below
```

o Hdsl2ShdslWirePair:

Attributes with this syntax reference the wire pairs connecting the units:

```
wirePair1(1) - First pair for HDSL2/SHDSL.
wirePair2(2) - Optional second pair for SHDSL only.
wirePair3(3) - Optional third pair for SHDSL.bis only.
wirePair4(4) - Optional fourth pair for SHDSL.bis only.
```

o Hdsl2ShdslTransmissionModeType:

Attributes with this syntax specify the regional setting for an SHDSL line. Specified as a BITS construct, the two mode types are:

```
region1 - ITU-T G.991.2 Annex A region2 - ITU-T G.991.2 Annex B
```

o Hdsl2ShdslPerfCurrDayCount:

Attributes with this syntax define the behavior of the 1-day (24 hour) gauges found in the MIB module.

o Hdsl2Shdsl1DayIntervalCount:

Attributes with this syntax define the behavior of the 1-day (24 hour) interval counters found in the MIB module.

o Hdsl2ShdslPerfTimeElapsed:

Attributes with this syntax define the behavior of the elapsed time counters found in the MIB module.

o Hdsl2ShdslPerfIntervalThreshold:

Attributes with this syntax define the behavior of the alarm thresholds found in the MIB module.

o Hdsl2ShdslClockReferenceType:

Attributes with this syntax define the clock references for the HDSL2/SHDSL span.

2.4. Structure

The MIB module is structured into the following MIB groups:

o Span Configuration Group:

This group supports MIB objects for configuring parameters for the HDSL2/SHDSL span. It contains the following table:

- hdsl2ShdslSpanConfTable
- o Span Status Group:

This group supports MIB objects for retrieving span status information. It contains the following table:

- hdsl2ShdslSpanStatusTable
- o Unit Inventory Group:

This group supports MIB objects for retrieving unit inventory information about units in HDSL2/SHDSL lines via the EOC. It contains the following table:

- hdsl2ShdslInventoryTable
- o Segment Endpoint Configuration Group:

This group supports MIB objects for configuring parameters for the HDSL2/SHDSL segment endpoints. It contains the following table:

- hdsl2ShdslEndpointConfTable
- o Segment Endpoint Current Status/Performance Group:

This group supports MIB objects that provide the current status/performance information relating to segment endpoints. It contains the following table:

- hdsl2ShdslEndpointCurrTable
- o Segment Endpoint 15-Minute Interval Status/Performance Group:

This group supports MIB objects that provide historic status/ performance information relating to segment endpoints in 15-minute intervals. It contains the following table:

- hdsl2Shdsl15MinIntervalTable

Sikes, et al.

Standards Track

[Page 7]

o Segment Endpoint 1-Day Interval Status/Performance Group:

This group supports MIB objects that provide historic status/performance information relating to segment endpoints in 1-day intervals. It contains the following table:

- hdsl2Shdsl1DayIntervalTable
- o Maintenance Group:

This group supports MIB objects for performing maintenance operations such as loopbacks for HDSL2/SHDSL lines. It contains the following table(s):

- hdsl2ShdslEndpointMaintTable
- hdsl2ShdslUnitMaintTable
- o Span Configuration Profile Group:

This group supports MIB objects for defining configuration profiles for HDSL2/SHDSL spans. It contains the following table:

- hdsl2ShdslSpanConfProfileTable
- o Segment Endpoint Alarm Configuration Profile Group:

This group supports MIB objects for defining alarm configuration profiles for HDSL2/SHDSL segment endpoints. It contains the following table:

- hdsl2ShdslEndpointAlarmConfProfileTable
- o Notifications Group:

This group defines the notifications supported for HDSL2/SHDSL lines:

- hdsl2ShdslLoopAttenCrossing
- hdsl2ShdslSNRMarginCrossing
- hdsl2ShdslPerfESThresh
- hdsl2ShdslPerfSESThresh
- hdsl2ShdslPerfCRCanomaliesThresh
- hdsl2ShdslPerfLOSWSThresh
- hdsl2ShdslPerfUASThresh
- hdsl2ShdslSpanInvalidNumRepeaters
- hdsl2ShdslLoopbackFailure
- hdsl2ShdslpowerBackoff
- hdsl2ShdsldeviceFault

- hdsl2ShdsldcContinuityFault
- hdsl2ShdslconfigInitFailure
- hdsl2ShdslprotocolInitFailure
- hdsl2ShdslnoNeighborPresent
- hdsl2ShdslLocalPowerLoss

o SHDSL Wire Pair Group:

This group supports MIB objects that provide status of the SHDSL-specific wire pairs.

- hdsl2ShdslEndpointCurrTipRingReversal
- hdsl2ShdslEndpointCurrActivationState

o Payload Group:

This group supports MIB objects for retrieving payload rates that exclude any framing overhead.

- hdsl2ShdslStatusMaxAttainablePayloadRate
- hdsl2ShdslStatusActualPayloadRate

2.5. Line Topology

An HDSL2/SHDSL line consists of a minimum of two units: xtuC (the central termination unit) and an xtuR (the remote termination unit). The line may optionally support up to 8 repeater/regenerator units (xru) as shown in the figure below.

<-- Network Side Customer Side --> |<///// HDSL2/SHDSL Span //////////////>| <~~~> HDSL2/SHDSL Segments <~~~> +----+ +----+ +----+ Key: <///> HDSL2/SHDSL span <~~~> HDSL2/SHDSL segment =1= HDSL2/SHDSL wire-pair-1 =2= SHDSL optional wire-pair-2 (Not applicable to HDSL2) Customer side segment endpoint (modem) C Network side segment endpoint (modem) N

Figure 2: General Topology for an HDSL2/SHDSL Line

2.6. Counters, Interval Buckets, and Thresholds

For SNR Margin, Loop Attenuation, ES, SES, CRC anomalies, LOSW, and UAS, there are event counters, current 15-minute and 0 to 96 15-minute history bucket(s) of "interval-counters", as well as current and 0 to 30 previous 1-day interval-counter(s). Each current 15-minute event bucket has an associated threshold notification.

Unlike RFC 3593 [RFC3593] and RFC 2662 [RFC2662], there is no representation in the MIB module for invalid buckets. In those cases where the data for an interval is suspect or known to be invalid, the agent MUST NOT report the interval. If the current 15-minute event bucket is determined to be invalid, notifications based upon the value of the event bucket MUST NOT be generated.

Not reporting an interval will result in holes in the associated table. For example, the table hdsl2Shdsl15MinIntervalTable is indexed by { ifIndex, hdsl2ShdslInvIndex, hdsl2ShdslEndpointSide, hdsl2ShdslEndpointWirePair, hdsl2Shdsl15MinIntervalNumber}. If interval 12 is determined to be invalid but intervals 11 and 13 are valid, a Get Next operation on the indices .1.1.1.1.11 would return indicés .1.1.1.1.13.

There is no requirement for an agent to ensure a fixed relationship between the start of a 15-minute interval and any wall clock; however, some implementations may align the 15-minute intervals with quarter hours. Likewise, an implementation may choose to align 1-day intervals with the start of a day.

Counters are not reset when an xU is reinitialized, only when the agent is reset or reinitialized (or under specific request outside the scope of this MIB module).

2.7. Profiles

As a managed node can handle a large number of xUs (e.g., hundreds or perhaps thousands of lines), provisioning every parameter on every xU may become burdensome. Moreover, most lines are provisioned identically with the same set of parameters. To simplify the provisioning process, this MIB module makes use of profiles. A profile is a set of parameters that can be shared by multiple lines using the same configuration.

The following profiles are used in this MIB module:

o Span Configuration Profiles - Span configuration profiles contain parameters for configuring HDSL2/SHDSL spans. They are defined in the hdsl2ShdslSpanConfProfileTable. Since span configuration parameters are only applicable for SHDSL, the support for span configuration profiles is optional for HDSL2 interfaces.

Note that the configuration of the span dictates the behavior for each individual segment endpoint in the span. If a different configuration is provisioned for any given segment endpoint within the span, the new configuration for this segment endpoint will override the span configuration for this segment endpoint only.

 Segment Endpoint Alarm Configuration Profiles - These profiles contain parameters for configuring alarm thresholds for HDSL2/ SHDSL segment endpoints. These profiles are defined in the hdsl2ShdslEndpointAlarmConfProfileTable.

The index value for this profile is a locally-unique administratively-assigned name for the profile having the textual convention 'SnmpAdminString' (RFC 3411 [RFC3411]).

One or more lines may be configured to share parameters of a single profile (e.g., hdsl2ShdslEndpointAlarmConfProfile = 'silver') by setting its hdsl2ShdslEndpointAlarmConfProfile objects to the value of this profile. If a change is made to the profile, all lines that refer to it will be reconfigured to the changed parameters. Before a profile can be deleted or taken out of service, it must be first unreferenced from all associated lines.

Implementations MUST provide a default profile whose name is 'DEFVAL' for each profile type. The values of the associated parameters will be vendor specific unless otherwise indicated in this document. Before a line's profiles have been set, these profiles will be automatically used by setting hdsl2ShdslEndpointAlarmConfProfile and hdsl2ShdslSpanConfProfile to 'DEFVAL' where appropriate. This default profile name, 'DEFVAL', is considered reserved in the context of profiles defined in this MIB module.

Profiles are created, assigned, and deleted dynamically using the profile name and profile row status in each of the four profile tables.

Profile changes MUST take effect immediately. These changes MAY result in a restart (hard reset or soft restart) of the units on the line.

2.8. Notifications

The ability to generate the SNMP notifications coldStart/warmStart (per [RFC3418]), which are per agent (e.g., per Digital Subscriber Line Access Multiplexer, or DSLAM, in such a device), and linkUp/linkDown (per [RFC2863]), which are per interface (i.e., HDSL2/SHDSL line) is required.

A linkDown notification MAY be generated whenever any ES, SES, CRC anomaly, LOSW, or UAS event occurs. The corresponding linkUp notification MAY be sent when all link failure conditions are cleared.

The notifications defined in this MIB module are for initialization failure and for the threshold crossings associated with the following events: ES, SES, CRC anomaly, LOSW, and UAS. Each threshold has its own enable/threshold value. When that value is 0, the notification is disabled.

The hdsl2ShdslEndpointCurrStatus is a bitmask representing all outstanding error conditions associated with a particular segment endpoint. Note that since the status of remote endpoints is obtained via the EOC, this information may be unavailable for units that are unreachable via EOC during a line error condition. Therefore, not all conditions may always be included in its current status. Notifications corresponding to the bit fields in this object are defined.

Two alarm conditions, SNR Margin Alarm and Loop Attenuation Alarm, are organized in a manner slightly different from that implied in the EOC specifications. In the MIB module, these alarm conditions are

Sikes, et al.

Standards Track

[Page 12]

tied to the two thresholds, hdsl2ShdslEndpointThreshSNRMargin and hdsl2ShdslEndpointThreshLoopAttenuation, found in the hdsl2ShdslEndpointAlarmConfProfileTable. In the EOC, the alarm conditions associated with these thresholds are per unit. In the MIB module, these alarm conditions are per endpoint. For terminal units, this has no impact. For repeaters, this implies an implementation variance where the agent in the terminal unit is responsible for detecting a threshold crossing. As the reporting of a repeater detected alarm condition to the polling terminal unit occurs in the same EOC message as the reporting of the current SNR Margin and Loop Attenuation values, it is anticipated that this will have very little impact on agent implementation.

A threshold notification occurs whenever the corresponding current 15-minute interval error counter becomes equal to, or exceeds, the threshold value. Only one notification SHOULD be sent per interval per interface. Since the current 15-minute counter is reset to 0 every 15 minutes, and if the condition persists, the notification may recur as often as every 15 minutes. For example, to get a notification whenever a "loss of" event occurs (but at most once every 15 minutes), set the corresponding threshold to 1. The agent will generate a notification when the event originally occurs.

Notifications, other than the threshold notifications listed above, SHOULD be rate limited (throttled) such that there is at least a 1-minute gap between the generation of consecutive notifications of the same event. When notifications are rate limited, they are dropped and not queued for sending at a future time. This is intended to be a general rate-limiting statement for notifications that have no explicit rate-limiting assertions in this document otherwise.

Note that the Network Management System, or NMS, may receive a linkDown notification as well, if enabled (via ifLinkUpDownTrapEnable [RFC2863]). At the beginning of the next 15-minute interval, the counter is reset. When the first second goes by and the event occurs, the current interval bucket will be 1, which equals the threshold, and the notification will be sent again.

An hdsl2ShdslSpanInvalidNumRepeaters notification may be generated following completion of the discovery phase if the number of repeaters discovered on the line differs from the number of repeaters specified in hdsl2ShdslSpanConfNumRepeaters. For those conditions where the number of provisioned repeaters is greater than those encountered during span discovery, all table entries associated with the nonexistent repeaters are to be discarded. For those conditions where the number of provisioned repeaters is less than those

HDSL2-SHDSL-LINE-MIB DEFINITIONS ::= BEGIN

encountered during span discovery, additional table entries are to be created using the default span configuration profile.

3. Definitions

```
IMPORTS
   MODULE-IDENTITY,
   OBJECT-TYPE,
   Counter32,
   Unsigned32,
   Gauge32
   NOTIFICÁTION-TYPE,
   Integer32,
   transmission
      FROM SNMPv2-SMI
   RowStatus.
   TEXTUAL-CONVENTION
      FROM SNMPv2-TC
   ifIndex
      FROM IF-MIB
   PerfCurrentCount,
   PerfIntervalCount
      FROM PerfHist-TC-MIB
   SnmpAdminString
      FROM SNMP-FRAMEWORK-MIB
   MODULE-COMPLIANCE,
   OBJECT-GROUP,
   NOTIFICATION-GROUP
      FROM SNMPv2-CONF;
hdsl2ShdslMIB MODULE-IDENTITY
   LAST-UPDATED "200512070000Z" -- December 7, 2005
   ORGANIZATION "ADSLMIB Working Group"
   CONTACT-INFO "WG-email: adslmib@ietf.org
      WG-URL:
         http://www.ietf.org/html.charters/adslmib-charter.html
      Info:
                  https://www1.ietf.org/mailman/listinfo/adslmib
      Chair:
                  Mike Sneed
                  Sand Channel Systems
                  1210-203 Westview Ln
      Postal:
                  Raleigh NC 27605 USA
      Email:
                  sneedmike@hotmail.com
      Phone:
                 +1 206 600 7022
      Co-Chair
                  Bob Ray
                  PESA Switching Systems, Inc.
```

Postal 330-A Wynn Drive

Huntsville, AL 35805 USA +1 256 726 9200 ext. 142

Co-editor: Clay Sikes

Phone

Zhone Technologies, Inc.

8545 126th Ave. N. Largo, FL 33772 USA Postal:

Email: csikes@zhone.com Phone: +1 727 530 8257

Co-editor: Bob Ray

PESA Switching Systems, Inc.

Postal:

330-A Wynn Drive Huntsville, AL 35805 USA

Email: rray@pesa.com

Phone: +1 256 726 9200 ext. 142

Co-editor: Rajesh Abbi

Alcatel USA

2301 Sugar Bush Road Postal:

Raleigh, NC 27612-3339 USA

Email: Raiesh.Abbi@alcatel.com

Phone: +1 919 850 6194"

DESCRIPTION

"This MIB module defines a collection of objects for managing HDSL2/SHDSL lines. An agent may reside at either end of the line; however, the MIB module is designed to require no management communication between the modems beyond that inherent in the low-level EOC line protocol as defined in ANSI T1E1.4/2000-006 (for HDSL2 lines) or in ITU G.991.2 (for SHDSL lines).

Copyright (C) The Internet Society (2005). This version of this MIB module is part of RFC 4319; see the RFC itself for full legal notices.

REVISION "200512070000Z" -- December 7, 2005 DESCRIPTION "This version, published as RFC 4319.

The following changes have been made in this version:
1. Added a 3rd and 4th wire pair.

Modified all rates such that their rates are only constrained by an unsigned 32-bit value and not by what today's perceived technology limitations are.

- Clarified that the rates from RFC 3276 include payload and any applicable framing and added objects for payload-only rates.
- 4. Added an object to indicate whether the tip and ring are reversed on a wire pair.
- 5. Added an object to display the activation state of a wire pair.
- 6. Added references as necessary for clarification.
- 7. Added display hints to textual conventions as necessary.
- Updated conformance statements as necessary.
- 9. Some changes were due to IETF requirements and RFC generation tools."

```
REVISION "200205090000Z" -- May 9, 2002
DESCRIPTION "Initial version, published as RFC 3276."

::= { transmission 48 }

hdsl2ShdslMibObjects OBJECT IDENTIFIER ::= { hdsl2ShdslMIB 1 }

-- Textual Conventions used in this MIB module
--

Hdsl2ShdslPerfCurrDayCount ::= TEXTUAL-CONVENTION
    DISPLAY-HINT "d"
    STATUS    current
    DESCRIPTION
```

"A gauge associated with interface performance measurements in a current 1-day (24 hour) measurement interval.

The value of this gauge starts at zero at the beginning of an interval and is increased when associated events occur, until the end of the 1-day interval. At that time, the value of the gauge is stored in the previous 1-day history interval, as defined in a companion object of type Hdsl2Shdsl1DayIntevalCount, and the current interval gauge is restarted at zero.

In the case where the agent has no valid data available for this interval, the corresponding object instance is not available, and upon a retrieval request, a corresponding error message shall be returned to indicate that this instance does not exist. Please note that zero is a valid value." SYNTAX Gauge32

Hdsl2Shdsl1DayIntervalCount ::= TEXTUAL-CONVENTION
 DISPLAY-HINT "d"

STATUS current DESCRIPTION

"A counter associated with interface performance measurements during the most previous 1-day (24 hour) measurement interval. The value of this gauge is equal to the value of the current day gauge, as defined in a companion object of type Hdsl2ShdslPerfCurrDayCount, at the end of its most recent interval.

In the case where the agent has no valid data available for this interval, the corresponding object instance is not available, and upon a retrieval request, a corresponding error message shall be returned to indicate that this instance does not exist."

SYNTAX Gauge32

Hdsl2ShdslPerfTimeElapsed ::= TEXTUAL-CONVENTION

DISPLAY-HINT "d" STATUS current

DESCRIPTION

"The number of seconds that have elapsed since the beginning of the current measurement period. If, for some reason, such as an adjustment in the system's time-of-day clock or the addition of a leap second, the current interval exceeds the maximum value, the agent will return the maximum value.

For 15-minute intervals, the range is limited to (0..899).
For 24-hour intervals, the range is limited to (0..86399)."
SYNTAX Unsigned32(0..86399)

Hdsl2ShdslPerfIntervalThreshold ::= TEXTUAL-CONVENTION

DISPLAY-HINT "d" STATUS current

DESCRIPTION

"This convention defines a range of values that may be set in a fault threshold alarm control. As the number of seconds in a 15-minute interval numbers at most 900, objects of this type may have a range of 0...900, where the value of 0 disables the alarm."

SYNTAX Unsigned32(0..900)

Hdsl2ShdslUnitId ::= TEXTUAL-CONVENTION

STATUS current

DESCRIPTION

"This is the unique identification for all units in an HDSL2/SHDSL span. It is based on the EOC unit addressing scheme with reference to the xtuC."

SYNTAX INTEGER

```
xtuC(1),
           xtuR(2),
           xru1(3),
           xru2(4),
           xru3(5),
           xru4(6),
           xru5(7),
           xru6(8),
           xru7(9),
           xru8(10)
Hdsl2ShdslUnitSide ::= TEXTUAL-CONVENTION
   STATUS
            current
   DESCRIPTION
      'This is the referenced side of an HDSL2/SHDSL unit - Network
      or Customer side. The side facing the Network is the Network
      side, while the side facing the Customer is the Customer side."
   SYNTAX
             INTEGER
           networkSide(1),
           customerSide(2)
Hdsl2ShdslWirePair ::= TEXTUAL-CONVENTION
   STATUS current
   DESCRIPTION
      'This is the referenced pair of wires in an HDSL2/SHDSL segment.
      HDSL2 only supports a single pair (wirePair1 or two wire),
      SHDSL lines support an optional second pair (wirePair2 or four
      wire), and G.shdsl.bis support an optional third pair
      (wirePair3 or six wire) and an optional fourth pair
      (wirePair4 or eight wire)."
   SYNTAX
             INTEGER
           wirePair1(1), -- two wire
           wirePair2(2), -- four wire wirePair3(3), -- six wire wirePair4(4) -- eight wire
Hdsl2ShdslTransmissionModeType ::= TEXTUAL-CONVENTION
             current
   STATUS
   DESCRIPTION
     "Contains the regional setting of the HDSL2/SHDSL span,
      represented as a bit-map of possible settings. The various
      bit positions are as follows:
```

```
Description
      Bit
            Meaning
            region 1
                          Indicates ITU-T G.991.2 Annex A.
      1
                          Indicates ITU-T G.991.2 Annex B."
      2
            region 2
   SYNTAX
               BITS
           region1(0),
           region2(1)
Hdsl2ShdslClockReferenceType ::= TEXTUAL-CONVENTION
   STATUS
             current
   DESCRIPTION
     "The various STU-C symbol clock references for the
      HDSL2/SHDSL span, represented as an enumeration.
   SYNTAX
             INTEGER
          {
localClk(1)
                                 -- Mode-1 per G991.2
          networkClk(2), -- Mode-2 per G991.2 dataOrNetworkClk(3), -- Mode-3a per G991.2 dataClk(4)
                                 -- Mode-3b per G991.2
          dataClk(4)
-- Span Configuration Group
hdsl2ShdslSpanConfTable OBJECT-TYPE
             SEQUENCE OF Hdsl2ShdslSpanConfEntry
   SYNTAX
   MAX-ACCESS not-accessible
   STATUS
              current
   DESCRIPTION
     "This table supports overall configuration of HDSL2/SHDSL
              Entries in this table MUST be maintained in a
      spans.
      persistent manner."
   ::= { hdsl2ShdslMibObjects 1 }
hdsl2ShdslSpanConfEntry OBJECT-TYPE
   SYNTAX
               Hdsl2ShdslSpanConfEntry
   MAX-ACCESS not-accessible
   STATUS
               current
   DESCRIPTION
     "An entry in the hdsl2ShdslSpanConfTable. Each entry
      represents the complete span in a single HDSL2/SHDSL line.
      It is indexed by the ifIndex of the associated HDSL2/SHDSL
      line."
   INDEX { ifIndex }
   ::= { hdsl2ShdslSpanConfTable 1 }
```

```
Hdsl2ShdslSpanConfEntry ::=
   SEQUENCE
   hdsl2ShdslSpanConfNumRepeaters
                                              Unsigned32.
   hdsl2ShdslSpanConfProfile
                                              SnmpAdminString,
   hdsl2ShdslSpanConfAlarmProfile
                                              SnmpAdminString
   hdsl2ShdslSpanConfNumRepeaters OBJECT-TYPE
   SYNTAX
                Unsigned32(0..8)
                "repeaters"
   UNITS
   MAX-ACCESS read-write
   STATUS
                current
   DESCRIPTION
     "This object provisions the number of repeaters/regenerators in this HDSL2/SHDSL span."
   ::= { hdsl2ShdslSpanConfEntry 1 }
hdsl2ShdslSpanConfProfile OBJECT-TYPE
   SYNTAX SnmpAdminString (SIZE(1..32)) MAX-ACCESS read-write
               current
   STATUS
   DESCRIPTION
     "This object is a pointer to a span configuration profile in
      the hdsl2ShdslSpanConfProfileTable, which applies to this
      span. The value of this object is the index of the referenced profile in the hdsl2ShdslSpanConfProfileTable. Note that span
      configuration profiles are only applicable to SHDSL lines.
      HDSL2 lines MUST reference the default profile, 'DEFVAL'.
      By default, this object will have the value 'DEFVAL'
      (the index of the default profile).
      Any attempt to set this object to a value that is not the value
      of the index for an active entry in the profile table,
      hdsl2ShdslSpanConfProfileTable, MUST be rejected."
   ::= { hdsl2ShdslSpanConfEntry 2 }
hdsl2ShdslSpanConfAlarmProfile OBJECT-TYPE
                SnmpAdminString (SIZE(1..32))
   SYNTAX
   MAX-ACCESS read-write
   STATUS
                current
   DESCRIPTION
     "This object is a pointer to an alarm configuration profile in
      the hdsl2ShdslEndpointAlarmConfProfileTable. The value of
      this object is the index of the referenced profile in the
      hdsl2ShdslEndpointAlarmConfProfileTable. The alarm
      threshold configuration in the referenced profile will be
```

```
used by default for all segment endpoints in this span.
      Individual endpoints may override this profile by explicitly
      specifying some other profile in the
      hdsl2ShdslEndpointConfTable. By default, this object will
      have the value 'DEFVAL' (the index of the default
      profile).
      Any attempt to set this object to a value that is not the value
      of the index for an active entry in the profile table, hdsl2ShdslEndpointAlarmConfProfileTable, MUST be rejected."
   ::= { hdsl2ShdslSpanConfEntry 3 }
-- Span Status Group
hdsl2ShdslSpanStatusTable OBJECT-TYPE
              SEQUENCE OF Hdsl2ShdslSpanStatusEntry
   SYNTAX
   MAX-ACCESS not-accessible
   STATUS
              current
   DESCRIPTION
      This table provides overall status information of
      HDSL2/SHDSL spans. This table contains live data from
      equipment. As such, it is NOT persistent."
   ::= { hdsl2ShdslMibObjects 2 }
hdsl2ShdslSpanStatusEntry OBJECT-TYPE
            Hdsl2ShdsĺSpanStatusEntry
   SYNTAX
   MAX-ACCESS not-accessible
               current
   STATUS
   DESCRIPTION
     "An entry in the hdsl2ShdslSpanStatusTable.
      represents the complete span in a single HDSL2/SHDSL line.
      It is indexed by the ifIndex of the associated HDSL2/SHDSL
      line."
   INDEX { ifIndex }
   ::= { hdsl2ShdslSpanStatusTable 1 }
Hdsl2ShdslSpanStatusEntry ::=
   SEQUENCE
   hdsl2ShdslStatusNumAvailRepeaters
                                              Unsigned32,
                                              Unsigned32,
   hdsl2ShdslStatusMaxAttainableLineRate
   hdsl2ShdslStatusActualLineRate
                                              Unsigned32,
   hdsl2ShdslStatusTransmissionModeCurrent
                         Hdsl2ShdslTransmissionModeType,
   hdsl2ShdslStatusMaxAttainablePayloadRate Unsigned32,
   hdsl2ShdslStatusActualPayloadRate
                                              Unsigned32
```

```
hdsl2ShdslStatusNumAvailRepeaters OBJECT-TYPE
               Unsigned32(0..8)
   SYNTAX
   MAX-ACCESS read-only
   STATUS
               current
   DESCRIPTION
     "Contains the actual number of repeaters/regenerators
      discovered in this HDSL2/SHDSL span.
   ::= { hdsl2ShdslSpanStatusEntry 1 }
hdsl2ShdslStatusMaxAttainableLineRate OBJECT-TYPE
               Unsigned32(0..4294967295)
   SYNTAX
               "bps"
   UNITS
   MAX-ACCESS read-only
   STATUS
               current
   DESCRIPTION
     "Contains the maximum attainable line rate in this HDSL2/SHDSL
            This object provides the maximum rate the line is
      capable of achieving. This is based upon measurements made
      during line probing. This rate includes payload (user data)
      and any applicable framing overhead."
   ::= { hdsl2ShdslSpanStatusEntry 2 }
hdsl2ShdslStatusActualLineRate OBJECT-TYPE
               Unsigned32(0..4294967295)
   SYNTAX
   UNITS
               "bps"
   MAX-ACCESS read-only
   STATUS
               current
   DESCRIPTION
     'Contains the actual line rate in this HDSL2/SHDSL span. This
      SHOULD equal ifSpeed. This rate includes payload (user data)
      and any applicable framing overhead"
   ::= { hdsl2ShdslSpanStatusEntry 3 }
hdsl2ShdslStatusTransmissionModeCurrent OBJECT-TYPE
   SYNTAX
               Hdsl2ShdslTransmissionModeType
   MAX-ACCESS read-only
   STATUS
              current
   DESCRIPTION
     "Contains the current Power Spectral Density (PSD) regional
      setting of the HDSL2/SHDSL span."
   ::= { hdsl2ShdslSpanStatusEntry 4 }
hdsl2ShdslStatusMaxAttainablePayloadRate OBJECT-TYPE
               Unsigned32(0..4294967295)
   SYNTAX
               "bps
   UNITS
   MAX-ACCESS
               read-only
               current
   STATUS
   DESCRIPTION
```

```
"Contains the maximum attainable payload (user data) line rate in this HDSL2/SHDSL span. This object provides
      the maximum rate the line is capable of achieving. This
      is based upon measurements made during line probing. Any
      framing overhead is not included."
   ::= { hdsl2ShdslSpanStatusEntry 5 }
hdsl2ShdslStatusActualPayloadRate OBJECT-TYPE
                Unsigned32(0..4294967295)
   SYNTAX
                "bps
   UNITS
   MAX-ACCESS read-only
               current
   STATUS
   DESCRIPTION
     "Contains the actual line rate in this HDSL2/SHDSL span. Any framing overhead is not included."
   ::= { hdsl2ShdslSpanStatusEntry 6 }
-- Unit Inventory Group
hdsl2ShdslInventoryTable OBJECT-TYPE
   SYNTAX
               SEQUENCE OF Hdsl2ShdslInventoryEntry
   MAX-ACCESS not-accessible
   STATUS
            current
   DESCRIPTION
     "This table supports retrieval of unit inventory information
      available via the EOC from units in an HDSL2/SHDSL line.
      Entries in this table are dynamically created during the
      line discovery process. The life cycle for these entries
      is as follows:
          - xtu discovers a device, either a far-end xtu or an xru
         an inventory table entry is created for the devicethe line goes down for whatever reason
         - inventory table entries for unreachable devices are
            destroyed
      As these entries are created/destroyed dynamically, they
      are NOT persistent."
   ::= { hdsl2ShdslMibObjects 3 }
hdsl2ShdslInventoryEntry OBJECT-TYPE
               Hds12ShdslInventoryEntry
   SYNTAX
   MAX-ACCESS not-accessible
   STATUS
               current
   DESCRIPTION
     "An entry in the hdsl2ShdslInventoryTable. Each entry
```

```
represents inventory information for a single unit in an HDSL2/SHDSL line. It is indexed by the ifIndex of the
      HDSL2/SHDSL line and the Hdsl2ShdslUnitId of the
      associated unit."
   INDEX { ifIndex, hdsl2ShdslInvIndex }
   ::= { hdsl2ShdslInventoryTable 1 }
Hdsl2ShdslInventoryEntry ::=
   SEQUENCE
   hdsl2ShdslInvIndex
                                                Hdsl2ShdslUnitId,
   hdsl2ShdslInvVendorID
                                                OCTET STRING,
                                                OCTET STRING, OCTET STRING,
   hdsl2ShdslInvVendorModelNumber
   hdsl2ShdslInvVendorSerialNumber
   hdsl2ShdslInvVendorEOCSoftwareVersion
                                                Integer32,
   hdsl2ShdslInvStandardVersion
                                                Integer32
   hdsl2ShdslInvVendorListNumber
                                                OCTEŤ STRÍNG,
                                                OCTET STRING,
   hdsl2ShdslInvVendorIssueNumber
                                                OCTET STRING,
   hdsl2ShdslInvVendorSoftwareVersion
                                                OCTET STRING, OCTET STRING,
   hdsl2ShdslInvEquipmentCode
   hdsl2ShdslInvVendorOther
   hdsl2ShdslInvTransmissionModeCapability
                           Hdsl2ShdslTransmissionModeType
   }
hdsl2ShdslInvIndex OBJECT-TYPE
               Hdsl2ShdslUnitId
   SYNTAX
   MAX-ACCESS not-accessible
                current
   STATUS
   DESCRIPTION
      "Each entry in this table corresponds to a physical element in an HDSL2/SHDSL span. It is based on the EOC unit addressing
      scheme with reference to the xtuC."
   ::= { hdsl2ShdslInventorvEntrv 1 }
hdsl2ShdslInvVendorID OBJECT-TYPE
            OCTET STRING(SIZE(8))
   SYNTAX
   MAX-ACCESS read-only
   STATUS
                current
   DESCRIPTION
     "Vendor ID as reported in an Inventory Response message."
   REFERENCE
     "G.991.2, Section 9.5.5.7.4, Inventory response - Message ID
      130, Octets 25-32."
   ::= { hdsl2ShdslInventoryEntry 2 }
hdsl2ShdslInvVendorModelNumber OBJECT-TYPE
                OCTET STRING(SIZE(12))
   SYNTAX
```

```
MAX-ACCESS read-only
   STATUS
               current
   DESCRIPTION
     "Vendor model number as reported in an Inventory Response
      message."
   REFERENCE
     "G.991.2, Section 9.5.5.7.4, Inventory response - Message ID
      130, Octets 33-44."
   ::= { hdsl2ShdslInventoryEntry 3 }
hdsl2ShdslInvVendorSerialNumber OBJECT-TYPE
               OCTET STRING(SIZE(12))
   SYNTAX
   MAX-ACCESS read-only
   STATUS
               current
   DESCRIPTION
     'Vendor serial number as reported in an Inventory Response
      message.'
   REFERENCE
     "G.991.2, Section 9.5.5.7.4, Inventory response - Message ID
      130, Octets 45-56."
   ::= { hdsl2ShdslInventoryEntry 4 }
hdsl2ShdslInvVendorEOCSoftwareVersion OBJECT-TYPE
   SYNTAX
               Integer32
   MAX-ACCESS read-only
   STATUS
              current
   DESCRIPTION
     'Vendor EOC version as reported in a Discovery Response
      message.'
   REFERENCE
     "G.991.2, Section 9.5.5.7.2, Discovery response - Message ID
      129, Octet 12."
   ::= { hdsl2ShdslInventoryEntry 5 }
hdsl2ShdslInvStandardVersion OBJECT-TYPE
   SYNTAX
               Integer32
   MAX-ACCESS
              read-onlv
   STATUS
               current
   DESCRIPTION
     "Version of the HDSL2/SHDSL standard implemented, as reported
      in an Inventory Response message."
   REFERENCE
     "G.991.2, Section 9.5.5.7.4, Inventory response - Message ID
      130, Octet 2."
   ::= { hdsl2ShdslInventoryEntry 6 }
hdsl2ShdslInvVendorListNumber OBJECT-TYPE
   SYNTAX
               OCTET STRING(SIZE(3))
```

```
MAX-ACCESS read-only
   STATUS
               current
   DESCRIPTION
     "Vendor list number as reported in an Inventory Response
      message."
   REFERENCE
     "G.991.2, Section 9.5.5.7.4, Inventory response - Message ID
      130, Octets 3-5."
   ::= { hdsl2ShdslInventoryEntry 7 }
hdsl2ShdslInvVendorIssueNumber OBJECT-TYPE
               OCTET STRING(SIZE(2))
   SYNTAX
   MAX-ACCESS read-only
   STATUS
               current
   DESCRIPTION
     'Vendor issue number as reported in an Inventory Response
      message.'
   REFERENCE
     "G.991.2, Section 9.5.5.7.4, Inventory response - Message ID
      130, Octets 6-7."
   ::= { hdsl2ShdslInventoryEntry 8 }
hdsl2ShdslInvVendorSoftwareVersion OBJECT-TYPE
               OCTET STRING(SIZE(6))
   SYNTAX
   MAX-ACCESS read-only
   STATUS
              current
   DESCRIPTION
     'Vendor software version as reported in an Inventory Response
      message.'
   REFERENCE
     "G.991.2, Section 9.5.5.7.4, Inventory response - Message ID
      130, Octets 8-13."
   ::= { hdsl2ShdslInventoryEntry 9 }
hdsl2ShdslInvEquipmentCode OBJECT-TYPE
               OCTET STRING(SIZE(10))
   SYNTAX
   MAX-ACCESS
              read-only
   STATUS
               current
   DESCRIPTION
     "Equipment code conforming to ANSI T1.213, Coded Identification
      of Equipment Entities."
   REFERENCE
     "G.991.2, Section 9.5.5.7.4, Inventory response - Message ID
      130, Octets 14-23."
   ::= { hdsl2ShdslInventoryEntry 10 }
hdsl2ShdslInvVendorOther OBJECT-TYPE
   SYNTAX
               OCTET STRING(SIZE(12))
```

```
MAX-ACCESS read-only
   STATUS
                current
   DESCRIPTION
     "Other vendor information as reported in an Inventory Response
      message."
   REFERENCE
     "G.991.2, Section 9.5.5.7.4, Inventory response - Message ID
      130, Octets 57-68."
   ::= { hdsl2ShdslInventoryEntry 11 }
hdsl2ShdslInvTransmissionModeCapability OBJECT-TYPE
                Hdsl2ShdslTransmissionModeType
   SYNTAX
   MAX-ACCESS
               read-only
   STATUS
                current
   DESCRIPTION
     "Contains the transmission mode capability of the SHDSL unit."
   ::= { hdsl2ShdslInventoryEntry 12 }
-- Segment Endpoint Configuration Group
hdsl2ShdslEndpointConfTable OBJECT-TYPE
                SEQUENCE OF Hdsl2ShdslEndpointConfEntry
   SYNTAX
   MAX-ACCESS not-accessible
   STATUS
                current
   DESCRIPTION
     "This table supports configuration parameters for segment endpoints in an HDSL2/SHDSL line. As this table is indexed
      by ifIndex, it MUST be maintained in a persistent manner.
   ::= { hdsl2ShdslMibObjects 4 }
hdsl2ShdslEndpointConfEntry OBJECT-TYPE
               Hdsl2ShdslEndpointConfEntry
   SYNTAX
   MAX-ACCESS not-accessible
   STATUS
                current
   DESCRIPTION
      'An entry in the hdsl2ShdslEndpointConfTable. Each entry
      represents a single segment endpoint in an HDSL2/SHDSL line.
      It is indexed by the ifIndex of the HDSL2/SHDSL line, the UnitId of the associated unit, the side of the unit, and the
   wire pair of the associated modem."

INDEX { ifIndex, hdsl2ShdslInvIndex, hdsl2ShdslEndpointSide,
            hdsl2ShdslEndpointWirePair}
   ::= { hdsl2ShdslEndpointConfTable 1 }
Hdsl2ShdslEndpointConfEntry ::=
   SEQUENCE
```

```
hdsl2ShdslEndpointSide
                                                   Hdsl2ShdslUnitSide,
   hdsl2ShdslEndpointWirePair
                                                   Hdsl2ShdslWirePair,
   hdsl2ShdslEndpointAlarmConfProfile
                                                   SnmpAdminString
hdsl2ShdslEndpointSide OBJECT-TYPE
   SYNTAX Hdsl2ShdslUnitSide MAX-ACCESS not-accessible
                current
   STATUS
   DESCRIPTION
      "The side of the unit associated with this segment endpoint --
       Network/Customer side -- as per the Hdsl2ShdslUnitSide textual
       convention."
   ::= { hdsl2ShdslEndpointConfEntry 1 }
hdsl2ShdslEndpointWirePair OBJECT-TYPE
               Hdsl2ShdslWirePair
   SYNTAX
   MAX-ACCESS not-accessible
   STATUS
                 current
   DESCRIPTION
      'The wire pair of the modem associated with this segment
       endpoint as per the Hdsl2ShdslWirePair textual convention."
   ::= { hdsl2ShdslEndpointConfEntry 2 }
hdsl2ShdslEndpointAlarmConfProfile OBJECT-TYPE
                SnmpAdminString (SIZE(0..32))
   SYNTAX
   MAX-ACCESS read-write
   STATUS
                 current
   DESCRIPTION
      'This object configures the alarm threshold values to be used
       for this segment endpoint. The values are obtained from the
       alarm configuration profile referenced by this object. The
       value of this object is the index of the referenced profile in
      the hdsl2ShdslEndpointAlarmConfProfileTable, or NULL (a zero-length SnmpAdminString). If the value is a zero-length SnmpAdminString, the endpoint uses the default Alarm Configuration Profile for the associated span as per the
       hdsl2ŠhdslSpanConfAlarmProfile object in the
       hdsl2ShdslSpanConfTable. The default value of this object is
       a zero-length SnmpAdminString.
       Any attempt to set this object to a value that is not the value
      of the index for an active entry in the profile table, hdsl2ShdslEndpointAlarmConfProfileTable, MUST be rejected."
   ::= { hdsl2ShdslEndpointConfEntry 3 }
-- Segment Endpoint Current Status/Performance Group
```

```
hdsl2ShdslEndpointCurrTable OBJECT-TYPE
                   SEQUENCE OF Hdsl2ShdslEndpointCurrEntry
   SYNTAX
   MAX-ACCESS not-accessible
   STATUS
                   current
   DESCRIPTION
      "This table contains current status and performance information for segment endpoints in HDSL2/SHDSL lines. As with other tables in this MIB module indexed by ifIndex, entries in this table MUST be maintained in a persistent manner."
    ::= { hdsl2ShdslMibObjects 5 }
hdsl2ShdslEndpointCurrEntry OBJECT-TYPE
                 Hdsl2ShdslEndpointCurrEntry
   SYNTAX
   MAX-ACCESS not-accessible
   STATUS
                  current
   DESCRIPTION
      "An entry in the hdsl2ShdslEndpointCurrTable.
                                                                 Each entry
       contains status and performance information relating to a
   single segment endpoint. It is indexed by the ifIndex of the HDSL2/SHDSL line, the UnitId of the associated unit, the side of the unit, and the wire pair of the associated modem."

INDEX { ifIndex, hdsl2ShdslInvIndex, hdsl2ShdslEndpointSide,
              hdsl2ShdslEndpointWirePair }
    ::= { hdsl2ShdslEndpointCurrTable 1 }
Hdsl2ShdslEndpointCurrEntry ::=
   SEQUENCE
   hdsl2ShdslEndpointCurrAtn
                                                       Integer32,
   hdsl2ShdslEndpointCurrSnrMgn
                                                       Integer32,
   hdsl2ShdslEndpointCurrStatus
                                                       BITS,
   hdsl2ShdslEndpointES
                                                       Counter32,
   hdsl2ShdslEndpointSES
                                                       Counter32,
   hdsl2ShdslEndpointCRCanomalies
                                                       Counter32.
   hdsl2ShdslEndpointLOSWS
                                                        Counter32,
   hdsl2ShdslEndpointUAS
                                                       Counter32,
   hdsl2ShdslEndpointCurr15MinTimeElapsed
                                   Hdsl2ShdslPerfTimeElapsed,
   hdsl2ShdslEndpointCurr15MinES
                                                        PerfCurrentCount,
   hdsl2ShdslEndpointCurr15MinSES
                                                       PerfCurrentCount,
   hdsl2ShdslEndpointCurr15MinCRCanomalies
                                                       PerfCurrentCount,
   hdsl2ShdslEndpointCurr15MinLOSWS
                                                       PerfCurrentCount,
   hdsl2ShdslEndpointCurr15MinUAS
                                                       PerfCurrentCount,
   hdsl2ShdslEndpointCurr1DayTimeElapsed
                                            Hdsl2ShdslPerfTimeElapsed.
   hdsl2ShdslEndpointCurr1DayES
                                           Hdsl2ShdslPerfCurrDayCount,
   hdsl2ShdslEndpointCurr1DaySES
```

```
Hdsl2ShdslPerfCurrDayCount,
   hdsl2ShdslEndpointCurr1DayCRCanomalies
                                    Hdsl2ShdslPerfCurrDayCount,
   hdsl2ShdslEndpointCurr1DayLOSWS
                                    Hdsl2ShdslPerfCurrDayCount,
   hdsl2ShdslEndpointCurr1DayUAS
                                    Hdsl2ShdslPerfCurrDavCount.
                                              INTEGER,
   hdsl2ShdslEndpointCurrTipRingReversal
   hdsl2ShdslEndpointCurrActivationState
                                              INTEGER
hdsl2ShdslEndpointCurrAtn OBJECT-TYPE
   SYNTAX
               Integer32(-127..128)
                "dB"
   UNITS
   MAX-ACCESS
               read-only
   STATUS
               current
   DESCRIPTION
     "The current loop attenuation for this endpoint as reported in
      a Network or Customer Side Performance Status message."
   REFERENCE "HDSL2 Section 7.5.3.7; SHDSL Section 9.5.5.7" ::= { hdsl2ShdslEndpointCurrEntry 1 }
   REFERENCE
hdsl2ShdslEndpointCurrSnrMgn OBJECT-TYPE
               Integer32(-127..128)
   SYNTAX
                "dB"
   UNITS
   MAX-ACCESS
               read-only
   STATUS
               current
   DESCRIPTION
      'The current SNR margin for this endpoint as reported in a
      Status Response/SNR message.
               "HDSL2 Section 7.5.3.7; SHDSL Section 9.5.5.7"
   ::= { hdsl2ShdslEndpointCurrEntry 2 }
hdsl2ShdslEndpointCurrStatus OBJECT-TYPE
   SYNTAX
               BITS
               {
               noDefect(0),
               powerBackoff(1),
               deviceFault(2),
               dcContinuityFault(3),
               snrMarginAlarm(4),
               loopAttenuationAlarm(5),
               loswFailureAlarm(6),
               configInitFailure(7)
               protocolInitFailure(8),
               noNeighborPresent(9),
                loopbackActive(10)
```

MAX-ACCESS read-only STATUS current DESCRIPTION

"Contains the current state of the endpoint. This is a bit-map of possible conditions. The various bit positions are as follows:

noDefect There are no defects on the line.

powerBackoff Indicates enhanced Power Backoff.

deviceFault Indicates that a vendor-dependent

diagnostic or self-test fault

has been detected.

dcContinuityFault Indicates vendor-dependent

conditions that interfere with span powering such as short and

open circuits.

snrMarginAlarm Indicates that the SNR margin

has dropped below the alarm threshold.

loopAttenuationAlarm Indicates that the loop attenuation

exceeds the alarm threshold.

loswFailureAlarm Indicates a forward LOSW alarm.

configInitFailure Endpoint failure during initialization

due to paired endpoint not able to support requested configuration.

due to incompatible protocol used by

the paired endpoint.

noNeighborPresent Endpoint failure during initialization

due to no activation sequence detected

from paired endpoint.

loopbackActive A loopback is currently active at this

segment endpoint.

This is intended to supplement ifOperStatus. Note that there is a 1:1 relationship between the status bits defined in this object and the notification thresholds defined elsewhere in this MIB module."

REFERENCE "HDSL2 Section 7.5.3.7; SHDSL Section 9.5.5.7"

```
::= { hdsl2ShdslEndpointCurrEntry 3 }
hdsl2ShdslEndpointES OBJECT-TYPE
   SYNTAX
                 Counter32
                 "seconds"
   UNITS
   MAX-ACCESS
                 read-only
                 current
   STATUS
   DESCRIPTION
      'Count of Errored Seconds (ES) on this endpoint since the xU
      was last restarted.'
                 "HDSL2 Section 7.5.3.7; SHDSL Section 9.5.5.7"
   ::= { hdsl2ShdslEndpointCurrEntry 4 }
hdsl2ShdslEndpointSES OBJECT-TYPE
   SYNTAX
                  Counter32
   UNITS
                  "seconds"
   MAX-ACCESS
                  read-only
   STATUS
                  current
   DESCRIPTION
     "Count of Severely Errored Seconds (SES) on this endpoint since the xU was last restarted."
   REFERENCE "HDSL2 Section 7.5.3.7; SHDSL Section 9.5.5.7"
::= { hdsl2ShdslEndpointCurrEntry 5 }
hdsl2ShdslEndpointCRCanomalies OBJECT-TYPE
                  Counter32
   SYNTAX
                  "detected CRC Anomalies"
   UNITS
   MAX-ACCESS
                  read-only
   STATUS
                  current
   DESCRIPTION
      "Count of CRC anomalies on this endpoint since the xU was
      last restarted."
   REFERENCE
                 "HDSL2 Section 7.5.3.7; SHDSL Section 9.5.5.7"
   ::= { hdsl2ShdslEndpointCurrEntry 6 }
hdsl2ShdslEndpointLOSWS OBJECT-TYPE
   SYNTAX
                  Counter32
                  "seconds"
   UNITS
   MAX-ACCESS
                  read-only
                  current
   STATUS
   DESCRIPTION
      "Count of Loss of Sync Word (LOSW) Seconds on this endpoint since the xU was last restarted."
   REFERENCE "HDSL2 Section 7.5.3.7; SHDSL Section 9.5.5.7" 
::= { hdsl2ShdslEndpointCurrEntry 7 }
hdsl2ShdslEndpointUAS OBJECT-TYPE
                  Counter32
   SYNTAX
```

```
UNITS
                "seconds"
   MAX-ACCESS
                read-only
   STATUS
                current
   DESCRIPTION
     "Count of Unavailable Seconds (UAS) on this endpoint since
      the xU was last restarted."
   REFERENCE "HDSL2 Section 7.5.3.7; SHDSL Section 9.5.5.7" ::= { hdsl2ShdslEndpointCurrEntry 8 }
hdsl2ShdslEndpointCurr15MinTimeElapsed OBJECT-TYPE
                Hdsl2ShdslPerfTimeElapsed
   SYNTAX
   UNITS
                "seconds"
   MAX-ACCESS
                read-only
   STATUS
                current
   DESCRIPTION
     "Total elapsed seconds in the current 15-minute interval."
   ::= { hdsl2ShdslEndpointCurrEntry 9 }
hdsl2ShdslEndpointCurr15MinES OBJECT-TYPE
   SYNTAX
                PerfCurrentCount
                "seconds"
   UNITS
   MAX-ACCESS
                read-only
   STATUS
                current
   DESCRIPTION
     "Count of Errored Seconds (ES) in the current 15-minute
      interval."
   REFERENCE "HDSL2 Section 7.5.3.7; SHDSL Section 9.5.5.7"
   ::= { hdsl2ShdslEndpointCurrEntry 10 }
hdsl2ShdslEndpointCurr15MinSES OBJECT-TYPE
                PerfCurrentCount
   SYNTAX
                "seconds"
   UNITS
   MAX-ACCESS
                read-only
   STATUS
                current
   DESCRIPTION
      'Count of Severely Errored Seconds (SES) in the current
      15-minute interval.'
               "HDSL2 Section 7.5.3.7; SHDSL Section 9.5.5.7"
   REFERENCE
   ::= { hdsl2ShdslEndpointCurrEntry 11 }
hdsl2ShdslEndpointCurr15MinCRCanomalies OBJECT-TYPE
   SYNTAX
                PerfCurrentCount
                 "detected CRC Anomalies"
   UNITS
   MAX-ACCESS
                read-only
   STATUS
                current
   DESCRIPTION
     "Count of CRC anomalies in the current 15-minute interval."
               "HDSL2 Section 7.5.3.7; SHDSL Section 9.5.5.7"
   REFERENCE
```

```
::= { hdsl2ShdslEndpointCurrEntry 12 }
hdsl2ShdslEndpointCurr15MinLOSWS OBJECT-TYPE
                PerfCurrentCount
   SYNTAX
                "seconds"
   UNITS
   MAX-ACCESS
                read-only
   STATUS
                current
   DESCRIPTION
     'Count of Loss of Sync Word (LOSW) Seconds in the current
      15-minute interval."
               "HDSL2 Section 7.5.3.7; SHDSL Section 9.5.5.7"
   ::= { hdsl2ShdslEndpointCurrEntry 13 }
hdsl2ShdslEndpointCurr15MinUAS OBJECT-TYPE
   SYNTAX
                PerfCurrentCount
   UNITS
                "seconds"
   MAX-ACCESS
                read-only
   STATUS
                current
   DESCRIPTION
     "Count of Unavailable Seconds (UAS) in the current 15-minute
      interval."
              . "HDSL2 Section 7.5.3.7; SHDSL Section 9.5.5.7"
   REFERENCE
   ::= { hdsl2ShdslEndpointCurrEntry 14 }
hdsl2ShdslEndpointCurr1DavTimeElapsed OBJECT-TYPE
                Hdsl2ShdslPerfTimeElapsed
   SYNTAX
   UNITS
                "seconds"
   MAX-ACCESS
                read-only
   STATUS
                current
   DESCRIPTION
     "Number of seconds that have elapsed since the beginning of
      the current 1-day interval."
   ::= { hdsl2ShdslEndpointCurrEntry 15 }
hdsl2ShdslEndpointCurr1DayES OBJECT-TYPE
                Hdsl2ShdslPerfCurrDayCount
   SYNTAX
                "seconds"
   UNITS
   MAX-ACCESS read-only
   STATUS
                current
   DESCRIPTION
     "Count of Errored Seconds (ES) during the current day as
      measured by hdsl2ShdslEndpointCurr1DayTimeElapsed.
               "HDSL2 Section 7.5.3.7; SHDSL Section 9.5.5.7"
   REFERENCE
   ::= { hdsl2ShdslEndpointCurrEntry 16 }
hdsl2ShdslEndpointCurr1DaySES OBJECT-TYPE
                Hdsl2ShdslPerfCurrDayCount
   SYNTAX
                "seconds"
   UNITS
```

```
MAX-ACCESS
                 read-only
   STATUS
                 current
   DESCRIPTION
     "Count of Severely Errored Seconds (SES) during the current
      day as measured by hdsl2ShdslEndpointCurr1DayTimeElapsed."
   REFERÉNCE "HDSL2 Section 7.5.3.7; SHDSL Section 9.5.5.7" ::= { hdsl2ShdslEndpointCurrEntry 17 }
   REFERENCE
hdsl2ShdslEndpointCurr1DayCRCanomalies OBJECT-TYPE
                 Hdsl2ShdslPerfCurrDayCount
   SYNTAX
                 "detected CRC Anomalies"
   UNITS
   MAX-ACCESS
                 read-only
   STATUS
                 current
   DESCRIPTION
     "Count of CRC anomalies during the current day as measured by hdsl2ShdslEndpointCurr1DayTimeElapsed."
                "HDSL2 Section 7.5.3.7; SHDSL Section 9.5.5.7"
   REFERENCE
   ::= { hdsl2ShdslEndpointCurrEntry 18 }
hdsl2ShdslEndpointCurr1DayLOSWS OBJECT-TYPE
   SYNTAX
                 Hdsl2ShdslPerfCurrDayCount
   UNITS
                 "seconds"
   MAX-ACCESS
                 read-only
   STATUS
                 current
   DESCRIPTION
     "Count of Loss of Sync Word (LOSW) Seconds during the current
      day as measured by hdsl2ShdslEndpointCurr1DayTimeElapsed."
                "HDSL2 Section 7.5.3.7; SHDSL Section 9.5.5.7"
   REFERENCE
   ::= { hdsl2ShdslEndpointCurrEntry 19 }
hdsl2ShdslEndpointCurr1DayUAS OBJECT-TYPE
   SYNTAX
                 Hdsl2ShdslPerfCurrDayCount
   UNITS
                 "seconds"
   MAX-ACCESS
                 read-only
   STATUS
                 current
   DESCRIPTION
      'Count of Unavailable Seconds (UAS) during the current day as
      measured by hdsl2ShdslEndpointCurr1DayTimeElapsed.
                "HDSL2 Section 7.5.3.7; SHDSL Section 9.5.5.7"
   REFERENCE
   ::= { hdsl2ShdslEndpointCurrEntry 20 }
hdsl2ShdslEndpointCurrTipRingReversal OBJECT-TYPE
   SYNTAX
                INTEGER
                normal(1)
                reversed(2)
   MAX-ACCESS
                read-only
```

```
STATUS
               current
   DESCRIPTION
     'This object indicates the state of the tip/ring for the
      wire pair.
   ::= { hdsl2ShdslEndpointCurrEntry 21 }
hdsl2ShdslEndpointCurrActivationState OBJECT-TYPE
   SYNTAX
               INTEGER
               preActivation(1), -- PreTrain
               activation(2),
                                  -- Training
                                  -- Trained
               data(3)
   MAX-ACCESS read-only
   STATUS
               current
   DESCRIPTION
     "This object indicates the activation or training state of
      the wire pair."
   REFERENCE
               "ITU-T G.991.2, Section 6.2 PMD Activation Sequence"
   ::= { hdsl2ShdslEndpointCurrEntry 22 }
-- Segment Endpoint 15-Minute Interval Status/Performance Group
hdsl2Shdsl15MinIntervalTable OBJECT-TYPE
           SEQUENCE OF Hdsl2Shdsl15MinIntervalEntry
   SYNTAX
   MAX-ACCESS not-accessible
   STATUS
               current
   DESCRIPTION
     'This table provides one row for each HDSL2/SHDSL endpoint
   performance data collection interval. This table contains
  live data from equipment. As such, it is NOT persistent."
::= { hdsl2ShdslMibObjects 6 }
hdsl2Shdsl15MinIntervalEntry OBJECT-TYPE
             Hdsl2Shdsl15MinIntervalEntrv
   SYNTAX
   MAX-ACCESS not-accessible
   STATUS
              current
   DESCRIPTION
     "An entry in the hdsl2Shdsl15MinIntervalTable."
  Hdsl2Shdsl15MinIntervalEntry ::=
   SEOUENCE
   hdsl2Shdsl15MinIntervalNumber
                                         Unsigned32,
```

```
hdsl2Shdsl15MinIntervalES
                                             PerfIntervalCount,
   hdsl2Shdsl15MinIntervalSES
                                             PerfIntervalCount,
   hdsl2Shdsl15MinIntervalCRCanomalies
                                             PerfIntervalCount,
   hdsl2Shdsl15MinIntervalLOSWS
                                             PerfIntervalCount,
   hdsl2Shdsl15MinIntervalUAS
                                             PerfIntervalCount
   }
hdsl2Shdsl15MinIntervalNumber OBJECT-TYPE
                Unsigned32(1..96)
   SYNTAX
   MAX-ACCESS not-accessible
   STATUS
               current
   DESCRIPTION
     "Performance Data Interval number. Interval 1 is the most
      recent previous interval; interval 96 is 24 hours ago. Intervals 2..96 are optional."
   ::= { hdsl2Shdsl15MinIntervalEntry 1 }
hdsl2Shdsl15MinIntervalES OBJECT-TYPE
   SYNTAX
                PerfIntervalCount
   UNITS
                "seconds"
   MAX-ACCESS read-only
               current
   STATUS
   DESCRIPTION
     "Count of Errored Seconds (ES) during the interval."
                "HDSL2 Section 7.5.3.7; SHDSL Section 9.5.5.7"
   ::= { hdsl2Shdsl15MinIntervalEntry 2 }
hdsl2Shdsl15MinIntervalSES OBJECT-TYPE
   SYNTAX
                PerfIntervalCount
                "seconds"
   UNITS
   MAX-ACCESS read-only
                current
   STATUS
   DESCRIPTION
     "Count of Severely Errored Seconds (SES) during the interval." FERENCE "HDSL2 Section 7.5.3.7; SHDSL Section 9.5.5.7"
   REFERENCE
   ::= { hdsl2Shdsl15MinIntervalEntry 3 }
hdsl2Shdsl15MinIntervalCRCanomalies OBJECT-TYPE
   SYNTAX
                PerfIntervalCount
                "detected CRC Anomalies"
   UNITS
   MAX-ACCESS read-only
   STATUS
                current
   DESCRIPTION
   "Count of CRC anomalies during the interval."

REFERENCE "HDSL2 Section 7.5.3.7; SHDSL Section 9.5.5.7"
   ::= { hdsl2Shdsl15MinIntervalEntry 4 }
hdsl2Shdsl15MinIntervalLOSWS OBJECT-TYPE
```

```
SYNTAX
              PerfIntervalCount
              "seconds"
  UNITS
  MAX-ACCESS read-only
  STATUS
              current
  DESCRIPTION
     "Count of Loss of Sync Word (LOSW) Seconds during the
      interval."
              . "HDSL2 Section 7.5.3.7; SHDSL Section 9.5.5.7"
  REFERENCE
   ::= { hdsl2Shdsl15MinIntervalEntry 5 }
hdsl2Shdsl15MinIntervalUAS OBJECT-TYPE
  SYNTAX
              PerfIntervalCount
              "seconds"
  UNITS
  MAX-ACCESS read-only
  STATUS
              current
  DESCRIPTION
     "Count of Unavailable Seconds (UAS) during the interval."
             "HDSL2 Section 7.5.3.7; SHDSL Section 9.5.5.7"
   ::= { hdsl2Shdsl15MinIntervalEntry 6 }
-- Segment Endpoint 1-Day Interval Status/Performance Group
hdsl2Shdsl1DayIntervalTable OBJECT-TYPE
              SEOUENCE OF Hdsl2Shdsl1DavIntervalEntry
  MAX-ACCESS not-accessible
  STATUS
              current
  DESCRIPTION
     'This table provides one row for each HDSL2/SHDSL endpoint
     performance data collection interval. This table contains
   live data from equipment. As such, it is NOT persistent.'
::= { hdsl2ShdslMibObjects 7 }
hdsl2Shdsl1DayIntervalEntry OBJECT-TYPE
              Hdsl2Shdsl1DayIntervalEntry
  SYNTAX
  MAX-ACCESS not-accessible
              current
   STATUS
  DESCRIPTION
     "An entry in the hdsl2Shdsl1DayIntervalTable."
  Hdsl2Shdsl1DayIntervalEntry ::=
   SEQUENCE
   hdsl2Shdsl1DayIntervalNumber
                                       Unsigned32.
  hdsl2Shdsl1DayIntervalMoniSecs
                                       Hdsl2ShdslPerfTimeElapsed,
```

```
hdsl2Shdsl1DayIntervalES
                                        Hdsl2Shdsl1DayIntervalCount,
   hdsl2Shdsl1DayIntervalSES
                                        Hdsl2Shdsl1DayIntervalCount,
   hdsl2Shdsl1DayIntervalCRCanomalies
                                        Hdsl2Shdsl1DayIntervalCount,
   hdsl2Shdsl1DayIntervalLOSWS
                                        Hdsl2Shdsl1DayIntervalCount,
   hdsl2Shdsl1DayIntervalUAS
                                        Hdsl2Shdsl1DayIntervalCount
hdsl2Shdsl1DayIntervalNumber OBJECT-TYPE
   SYNTAX
               Unsigned32(1..30)
   MAX-ACCESS not-accessible
   STATUS
               current
   DESCRIPTION
     "History Data Interval number. Interval 1 is the most
      recent previous day; interval 30 is 30 days ago. Intervals
      2..30 are optional.
   ::= { hdsl2Shdsl1DayIntervalEntry 1 }
hdsl2Shdsl1DayIntervalMoniSecs OBJECT-TYPE
   SYNTAX
                Hdsl2ShdslPerfTimeElapsed
   UNITS
                "seconds"
   MAX-ACCESS
                read-only
   STATUS
                current
   DESCRIPTION
     "The amount of time in the 1-dav interval over which the
      performance monitoring information is actually counted.
      This value will be the same as the interval duration except
      in a situation where performance monitoring data could not
      be collected for any reason.
   ::= { hdsl2Shdsl1DayIntervalEntry 2 }
hdsl2Shdsl1DayIntervalES OBJECT-TYPE
   SYNTAX
                Hdsl2Shdsl1DayIntervalCount
   UNITS
                "seconds"
   MAX-ACCESS
                read-only
   STATUS
                current
   DESCRIPTION
     'Count of Errored Seconds (ES) during the 1-day interval as
      measured by hdsl2Shdsl1DayIntervalMoniSecs.'
               "HDSL2 Section 7.5.3.7; SHDSL Section 9.5.5.7"
   REFERENCE
   ::= { hdsl2Shdsl1DayIntervalEntry 3 }
hdsl2Shdsl1DayIntervalSES OBJECT-TYPE
   SYNTAX
                Hdsl2Shdsl1DayIntervalCount
   UNITS
                "seconds"
   MAX-ACCESS
                read-only
   STATUS
                current
   DESCRIPTION
     "Count of Severely Errored Seconds (SES) during the 1-day
```

```
interval as measured by hdsl2Shdsl1DayIntervalMoniSecs."
ERENCE "HDSL2 Section 7.5.3.7; SHDSL Section 9.5.5.7"
   ::= { hdsl2Shdsl1DayIntervalEntry 4 }
hdsl2Shdsl1DayIntervalCRCanomalies OBJECT-TYPE
   SYNTAX
                  Hdsl2Shdsl1DayIntervalCount
   UNITS
                   "detected CRC Anomalies'
   MAX-ACCESS
                  read-only
                  current
   STATUS
   DESCRIPTION
      "Count of CRC anomalies during the 1-day interval as
      measured by hdsl2Shdsl1DayIntervalMoniSecs."
   REFERENCE "HDSL2 Section 7.5.3.7; SHDSL Section 9.5.5.7" 
::= { hdsl2Shdsl1DayIntervalEntry 5 }
   REFERENCE
hdsl2Shdsl1DayIntervalLOSWS OBJECT-TYPE
                  Hdsl2Shdsl1DayIntervalCount
   SYNTAX
                   "seconds"
   UNITS
   MAX-ACCESS
                  read-only
   STATUS
                  current
   DESCRIPTION
      'Count of Loss of Sync Word (LOSW) Seconds during the 1-day
       interval as measured by hdsl2Shdsl1DayIntervalMoniSecs.
   REFERENCE "HDSL2 Section 7.5.3.7; SHDSL Section 9.5.5.7" ::= { hdsl2Shdsl1DayIntervalEntry 6 }
hdsl2Shdsl1DayIntervalUAS OBJECT-TYPE
                  Hdsl2Shdsl1DayIntervalCount
   SYNTAX
   UNITS
                  "seconds"
   MAX-ACCESS
                  read-only
   STATUS
                  current
   DESCRIPTION
      "Count of Unavailable Seconds (UAS) during the 1-day interval
   as measured by hdsl2Shdsl1DayIntervalMoniSecs."

REFERENCE "HDSL2 Section 7.5.3.7; SHDSL Section 9.5.5.7"

::= { hdsl2Shdsl1DayIntervalEntry 7 }
-- Maintenance Group
hdsl2ShdslEndpointMaintTable OBJECT-TYPE
   SYNTAX
                SEQUENCE OF Hdsl2ShdslEndpointMaintEntry
   MAX-ACCESS not-accessible
   STATUS
                 current
   DESCRIPTION
      "This table supports maintenance operations (e.g., loopbacks)
       to be performed on HDSL2/SHDSL segment endpoints. This table
       contains live data from equipment. As such, it is NOT
```

```
persistent."
   ::= { hdsl2ShdslMibObjects 8 }
hdsl2ShdslEndpointMaintEntry OBJECT-TYPE
               Hdsl2ShdslEndpointMaintEntry
   SYNTAX
   MAX-ACCESS not-accessible
   STATUS
               current
   DESCRIPTION
      'An entry in the hdsl2ShdslEndpointMaintTable. Each entry
      corresponds to a single segment endpoint and is indexed by the
      ifIndex of the HDSL2/SHDSL line, the UnitId of the associated
      unit, and the side of the unit.
   INDEX { ifIndex, hdsl2ShdslInvIndex, hdsl2ShdslEndpointSide }
::= { hdsl2ShdslEndpointMaintTable 1 }
Hdsl2ShdslEndpointMaintEntry ::=
   SEQUENCE
   hdsl2ShdslMaintLoopbackConfig
                                        INTEGER,
   hdsl2ShdslMaintTipRingReversal
                                        INTEGER,
   hdsl2ShdslMaintPowerBackOff
                                        INTEGER,
   hdsl2ShdslMaintSoftRestart
                                        INTEGER
hdsl2ShdslMaintLoopbackConfig OBJECT-TYPE
   SYNTAX
               INTEGER
               noLoopback(1),
               normalLoopback(2)
               specialLoopback(3)
   MAX-ACCESS read-write
   STATUS
               current
   DESCRIPTION
      'This object controls configuration of loopbacks for the
      associated segment endpoint. The status of the loopback
      is obtained via the hdsl2ShdslEndpointCurrStatus object."
   ::= { hdsl2ShdslEndpointMaintEntry 1 }
hdsl2ShdslMaintTipRingReversal OBJECT-TYPE
   SYNTAX
               INTEGER
               normal(1)
               reversed(2)
   MAX-ACCESS
               read-only
               current
   STATUS
   DESCRIPTION
```

```
"This object indicates the state of the tip/ring pair at the
      associated segment endpoint.
   ::= { hdsl2ShdslEndpointMaintEntry 2 }
hdsl2ShdslMaintPowerBackOff OBJECT-TYPE
   SYNTAX
               INTEGER
               default(1),
               enhanced(2)
   MAX-ACCESS
               read-write
   STATUS
               current
   DESCRIPTION
      This object configures the receiver at the associated
      segment endpoint to operate in default or enhanced power
      backoff mode."
   ::= { hdsl2ShdslEndpointMaintEntry 3 }
hdsl2ShdslMaintSoftRestart OBJECT-TYPE
               INTEGER
   SYNTAX
               ready(1)
               restart(2)
   MAX-ACCESS read-write
   STATUS
               current
   DESCRIPTION
      This object enables the manager to trigger a soft restart
      of the modem at the associated segment endpoint. The
      manager may only set this object to the 'restart(2)'
      value, which initiates a restart. The agent will perform a
      restart after approximately 5 seconds. Following the 5 second period, the agent will restore the object to the 'ready(1)'
      state."
   ::= { hdsl2ShdslEndpointMaintEntry 4 }
hdsl2ShdslUnitMaintTable OBJECT-TYPE
               SEOUENCE OF Hdsl2ShdslUnitMaintEntry
   SYNTAX
   MAX-ACCESS not-accessible
   STATUS
               current
   DESCRIPTION
     "This table supports maintenance operations for units in a
      HDSL2/SHDSL line. Entries in this table MUST be maintained
      in a persistent manner."
   ::= { hdsl2ShdslMibObjects 9 }
hdsl2ShdslUnitMaintEntry OBJECT-TYPE
               Hdsl2ShdslUnitMaintEntry
   SYNTAX
```

```
MAX-ACCESS not-accessible
   STATUS
               current
   DESCRIPTION
     "An entry in the hdsl2ShdslUnitMaintTable.
      corresponds to a single unit and is indexed by the
      ifIndex of the HDSL2/SHDSL line and the UnitId of the associated unit."
   INDEX { ifIndex, hdsl2ShdslInvIndex }
   ::= { hdsl2ShdslUnitMaintTable 1 }
Hdsl2ShdslUnitMaintEntry ::=
   SEQUENCE
   hdsl2ShdslMaintLoopbackTimeout
                                       Integer32,
   hdsl2ShdslMaintUnitPowerSource
                                       INTEGER
hdsl2ShdslMaintLoopbackTimeout OBJECT-TYPE
   SYNTAX
               Integer32(0..4095)
   UNITS
               "minutes"
   MAX-ACCESS read-write
              current
   STATUS
   DESCRIPTION
     "This obiect configures the timeout value for loopbacks
      initiated at segments endpoints contained in the associated
      unit. A value of 0 disables the timeout."
   ::= { hdsl2ShdslUnitMaintEntry 1 }
hdsl2ShdslMaintUnitPowerSource OBJECT-TYPE
   SYNTAX
               INTEGER
               local(1),
               span(2)
   MAX-ACCESS
               read-only
   STATUS
               current
   DESCRIPTION
     "This object indicates the DC power source being used by the
      associated unit."
   ::= { hdsl2ShdslUnitMaintEntry 2 }
-- Span Configuration Profile Group
hdsl2ShdslSpanConfProfileTable OBJECT-TYPE
               SEQUENCE OF Hdsl2ShdslSpanConfProfileEntry
   SYNTAX
   MAX-ACCESS not-accessible
   STATUS
               current
```

```
DESCRIPTION
      'This table supports definitions of span configuration
      profiles for SHDSL lines. HDSL2 does not support these
      configuration options. This table MUST be maintained in a persistent manner."
   ::= { hdsl2ShdslMibObjects 10 }
hdsl2ShdslSpanConfProfileEntry OBJECT-TYPE
   SYNTAX
             Hdsl2ShdslSpanConfProfileEntry
   MAX-ACCESS not-accessible
   STATUS
              current
   DESCRIPTION
     "Each entry corresponds to a single span configuration profile. Each profile contains a set of span configuration
      parameters. The configuration parameters in a profile are
      applied to those lines referencing that profile (see the
      hdsl2ShdslSpanConfProfile object). Profiles may be
      created/deleted using the row creation/deletion mechanism via hdsl2ShdslSpanConfProfileRowStatus. If an active
      entry is referenced in hdsl2ShdslSpanConfProfile, the
   entry MUST remain active until all references are removed."
INDEX { IMPLIED hdsl2ShdslSpanConfProfileName }
   ::= { hdsl2ShdslSpanConfProfileTable 1 }
Hdsl2ShdslSpanConfProfileEntry ::=
   SEQUENCE
   hdsl2ShdslSpanConfProfileName
                                                    SnmpAdminString,
   hdsl2ShdslSpanConfWireInterface
                                                    INTÉGER,
   hdsl2ShdslSpanConfMinLineRate
                                                    Unsigned32,
   hdsl2ShdslSpanConfMaxLineRate
                                                    Unsigned32,
   hdsl2ShdslSpanConfPSD
                                                    INTEGER,
   hdsl2ShdslSpanConfTransmissionMode
                              Hdsl2ShdslTransmissionModeTvpe.
   hdsl2ShdslSpanConfRemoteEnabled
                                                     INTEGER,
   hdsl2ShdslSpanConfPowerFeeding
                                                     INTEGER,
   hdsl2ShdslSpanConfCurrCondTargetMarginDown
                                                     Integer32,
   hdsl2ShdslSpanConfWorstCaseTargetMarginDown Integer32,
   hdsl2ShdslSpanConfCurrCondTargetMarginUp
                                                     Integer32,
   hdsl2ShdslSpanConfWorstCaseTargetMarginUp
                                                    Integer32,
   hdsl2ShdslSpanConfUsedTargetMargins
                                                    BITS,
   hdsl2ShdslSpanConfReferenceClock
                                Hdsl2ShdslClockReferenceType,
   hdsl2ShdslSpanConfLineProbeEnable
                                                    INTEGER,
   hdsl2ShdslSpanConfProfileRowStatus
                                                    RowStatus
```

hdsl2ShdslSpanConfProfileName OBJECT-TYPE

```
SYNTAX
                SnmpAdminString (SIZE(1..32))
   MAX-ACCESS
                not-accessible
   STATUS
                current
   DESCRIPTION
     "This object is the unique index associated with this profile.
      Entries in this table are referenced via the object
   hdsl2ShdslSpanConfProfile in Hdsl2ShdslSpanConfEntry."
::= { hdsl2ShdslSpanConfProfileEntry 1 }
hdsl2ShdslSpanConfWireInterface OBJECT-TYPE
   SYNTAX
                INTEGER
                twoWire(1)
                fourWire(2),
                sixWire(3),
                eightWire(4)
   MAX-ACCESS
               read-create
   STATUS
                current
   DESCRIPTION
      'This object configures the two-wire or optional four-wire,
      six-wire, or eight-wire operation for SHDSL lines."
   DEFVAL
                { twoWire }
   ::= { hdsl2ShdslSpanConfProfileEntry 2 }
hdsl2ShdslSpanConfMinLineRate OBJECT-TYPE
                Unsigned32(0..4294967295)
   SYNTAX
                "bps
   UNITS
   MAX-ACCESS
                read-create
   STATUS
                current
   DESCRIPTION
     "This object configures the minimum transmission rate for
      the associated SHDSL Line in bits-per-second (bps) and includes
      both payload (user data) and any applicable framing overhead. If the minimum line rate equals the maximum line rate
      (hdsl2ShdslSpanMaxLineRate), the line rate is considered
       fixed'. If the minimum line rate is less than the
      maximum line rate, the line rate is considered
       'rate-adaptive'."
                { 1552000 }
   ::= { hdsl2ShdslSpanConfProfileEntry 3 }
hdsl2ShdslSpanConfMaxLineRate OBJECT-TYPE
                Unsigned32(0..4294967295)
   SYNTAX
                "bps
   UNITS
   MAX-ACCESS
                read-create
                current
   STATUS
   DESCRIPTION
```

```
"This object configures the maximum transmission rate for
      the associated SHDSL Line in bits-per-second (bps) and includes
      both payload (user data) and any applicable framing overhead.
      If the minimum line rate equals the maximum line rate
      (hdsl2ShdslSpanMaxLineRate), the line rate is considered
       fixed'. If the minimum line rate is less than the
      maximum line rate, the line rate is considered
       rate-adaptive'."
               { 1552000 }
   ::= { hdsl2ShdslSpanConfProfileEntry 4 }
hdsl2ShdslSpanConfPSD OBJECT-TYPE
   SYNTAX
               INTEGER
               symmetric(1)
               asymmetric(2)
   MAX-ACCESS
              read-create
   STATUS
               current
   DESCRIPTION
     'This object configures use of symmetric/asymmetric PSD (Power
      Spectral Density) Mask for the associated SHDSL Line. Support
      for symmetric PSD is mandatory for all supported data rates.
      Support for asymmetric PSD is optional.
              { symmetric }
   ::= { hdsl2ShdslSpanConfProfileEntry 5 }
hdsl2ShdslSpanConfTransmissionMode OBJECT-TYPE
   SYNTAX
               Hdsl2ShdslTransmissionModeType
   MAX-ACCESS read-create
   STATUS
               current
   DESCRIPTION
     "This object specifies the regional setting for the SHDSL
      line."
               { { region1 } }
   ::= { hdsl2ShdslSpanConfProfileEntry 6 }
hdsl2ShdslSpanConfRemoteEnabled OBJECT-TYPE
   SYNTAX
               INTEGER
               enabled(1).
               disabled(2)
   MAX-ACCESS
              read-create
   STATUS
               current
   DESCRIPTION
     "This object enables/disables support for remote management
      of the units in an SHDSL line from the STU-R via the EOC."
```

```
DEFVAL
              { enabled }
   ::= { hdsl2ShdslSpanConfProfileEntry 7 }
hdsl2ShdslSpanConfPowerFeeding OBJECT-TYPE
   SYNTAX
               INTEGER
               noPower(1),
powerFeed(2),
               wettingCurrent(3)
   MAX-ACCESS
               read-create
   STATUS
               current
   DESCRIPTION
     'This object enables/disables support for optional power
      feeding in an SHDSL line.'
              { noPower }
   ::= { hdsl2ShdslSpanConfProfileEntry 8 }
hdsl2ShdslSpanConfCurrCondTargetMarginDown OBJECT-TYPE
   SYNTAX
               Integer32(-10..21)
               "dB"
   UNITS
   MAX-ACCESS
               read-create
   STATUS
               current
   DESCRIPTION
     "This object specifies the downstream current condition target
      SNR margin for an SHDSL line. The SNR margin is the difference
      between the desired SNR and the actual SNR. Target SNR margin
      is the desired SNR margin for a unit.'
               { 0 }
   ::= { hdsl2ShdslSpanConfProfileEntry 9 }
hdsl2ShdslSpanConfWorstCaseTargetMarginDown OBJECT-TYPE
   SYNTAX
               Integer32(-10..21)
               "dB"
   UNITS
   MAX-ACCESS
               read-create
              current
   STATUS
   DESCRIPTION
     "This object specifies the downstream worst-case target SNR
      margin for an SHDSL line. The SNR margin is the difference
      between the desired SNR and the actual SNR. Target SNR
      margin is the desired SNR margin for a unit."
               { 0 }
   ::= { hdsl2ShdslSpanConfProfileEntry 10 }
hdsl2ShdslSpanConfCurrCondTargetMarginUp OBJECT-TYPE
               Integer32(-10..21)
   SYNTAX
               "dB"
   UNITS
   MAX-ACCESS read-create
```

```
current
   STATUS
   DESCRIPTION
      'This object specifies the upstream current-condition target
      SNR margin for an SHDSL line. The SNR margin is the difference
      between the desired SNR and the actual SNR. Target SNR margin
      is the desired SNR margin for a unit."
   DEFVAL { 0 }
::= { hdsl2ShdslSpanConfProfileEntry 11 }
   DEFVAL
hdsl2ShdslSpanConfWorstCaseTargetMarginUp OBJECT-TYPE
               Integer32(-10..21)
   SYNTAX
               "dB"
   UNITS
   MAX-ACCESS read-create
   STATUS
               current
   DESCRIPTION
     'This object specifies the upstream worst-case target SNR
      margin for an SHDSL line. The SNR margin is the difference
      between the desired SNR and the actual SNR. Target SNR margin
      is the desired SNR margin for a unit."
               { 0 }
   ::= { hdsl2ShdslSpanConfProfileEntry 12 }
hdsl2ShdslSpanConfUsedTargetMargins OBJECT-TYPE
   SYNTAX
               BITS
               currCondDown(0)
               worstCaseDown(1),
               currCondUp(2)
               worstCaseUp(3)
   MAX-ACCESS read-create
   STATUS
               current
   DESCRIPTION
     "Indicates whether a target SNR margin is enabled or
      disabled. This is a bit-map of possible settings.
      various bit positions are as follows:
                     - current-condition downstream target SNR
      currCondDown
                       margin enabled

    worst-case downstream target SNR margin

      worstCaseDown
                       enabled
      currCondUp
                     - current-condition upstream target SNR
                       margin enabled
                     - worst-case upstream target SNR margin
      worstCaseUp
                       enabled.'
```

```
DEFVAL
              { { currCondDown } }
   ::= { hdsl2ShdslSpanConfProfileEntry 13 }
hdsl2ShdslSpanConfReferenceClock OBJECT-TYPE
               Hdsl2ShdslClockReferenceType
   SYNTAX
   MAX-ACCESS read-create
   STATUS
               current
   DESCRIPTION
      'This object configures the clock reference for the STU-C
      in an SHDSL Line.
                { localClk }
   ::= { hdsl2ShdslSpanConfProfileEntry 14 }
hdsl2ShdslSpanConfLineProbeEnable OBJECT-TYPE
   SYNTAX
                INTEGER
                disable(1),
                enable(2)
   MAX-ACCESS
                read-create
   STATUS
                current
   DESCRIPTION
     "This object enables/disables support for Line Probe of
      the units in an SHDSL line. When Line Probe is enabled, the system performs Line Probing to find the best possible
             If Line Probe is disabled, the rate adaptation phase
      is skipped to shorten set up time."
VAL      { disable }
   DEFVAL
   ::= { hdsl2ShdslSpanConfProfileEntry 15 }
hdsl2ShdslSpanConfProfileRowStatus OBJECT-TYPE
   SYNTAX
                RowStatus
   MAX-ACCESS read-create
   STATUS
                current
   DESCRIPTION
      'This object controls creation/deletion of the associated
      entry in this table per the semantics of RowStatus. If an
      active entry is referenced in hdsl2ShdslSpanConfProfile, the
      entry MUST remain active until all references are removed."
   ::= { hdsl2ShdslSpanConfProfileEntry 16 }
-- Segment Endpoint Alarm Configuration Profile group
hdsl2ShdslEndpointAlarmConfProfileTable OBJECT-TYPE
                SEQUENCE OF Hdsl2ShdslEndpointAlarmConfProfileEntry
   SYNTAX
   MAX-ACCESS not-accessible
   STATUS
               current
```

```
DESCRIPTION
      'This table supports definitions of alarm configuration
      profiles for HDSL2/SHDSL segment endpoints.
                                                        This table
      MUST be maintained in a persistent manner."
   ::= { hdsl2ShdslMibObjects 11 }
hdsl2ShdslEndpointAlarmConfProfileEntry OBJECT-TYPE
                Hdsl2ShdslEndpointAlarmConfProfileEntry
   SYNTAX
   MAX-ACCESS
                not-accessible
   STATUS
                current
   DESCRIPTION
     "Each entry corresponds to a single alarm configuration profile.
      Each profile contains a set of parameters for setting alarm thresholds for various performance attributes monitored at
      HDSL2/SHDSL segment endpoints. Profiles may be created/deleted
      using the row creation/deletion mechanism via
      hdsl2ShdslEndpointAlarmConfProfileRowStatus.
                                                         If an active
      entry is referenced in either hdsl2ShdslSpanConfAlarmProfile
   or hdsl2ShdslEndpointAlarmConfProfile, the entry MUST remain active until all references are removed."

INDEX { IMPLIED hdsl2ShdslEndpointAlarmConfProfileName }
   ::= { hdsl2ShdslEndpointAlarmConfProfileTable 1 }
Hdsl2ShdslEndpointAlarmConfProfileEntry ::=
   SEOUENCE
   hdsl2ShdslEndpointAlarmConfProfileName
                                                     SnmpAdminString,
                                                     Integer32,
   hdsl2ShdslEndpointThreshLoopAttenuation
   hdsl2ShdslEndpointThreshSNRMargin
                                                     Integer32,
   hdsl2ShdslEndpointThreshES
                                   Hdsl2ShdslPerfIntervalThreshold,
   hdsl2ShdslEndpointThreshSES
                                   Hdsl2ShdslPerfIntervalThreshold,
   hdsl2ShdslEndpointThreshCRCanomalies
                                                     Integer32.
   hdsl2ShdslEndpointThreshLOSWS
                                   Hdsl2ShdslPerfIntervalThreshold,
   hdsl2ShdslEndpointThreshUAS
                                   Hdsl2ShdslPerfIntervalThreshold.
   hdsl2ShdslEndpointAlarmConfProfileRowStatus RowStatus
hdsl2ShdslEndpointAlarmConfProfileName OBJECT-TYPE
                SnmpAdminString (SIZE(1..32))
   SYNTAX
   MAX-ACCESS not-accessible
   STATUS
                current
   DESCRIPTION
     "This object is the unique index associated with this profile."
   ::= { hdsl2ShdslEndpointAlarmConfProfileEntry 1 }
```

```
hdsl2ShdslEndpointThreshLoopAttenuation OBJECT-TYPE
                  Integer32(-127..128)
   SYNTAX
                  "dB"
   UNITS
   MAX-ACCESS
                 read-create
   STATUS
                 current
   DESCRIPTION
      "This object configures the loop attenuation alarm threshold. When the current value of hdsl2ShdslEndpointCurrAtn reaches
       or exceeds this threshold, an hdsl2ShdslLoopAttenCrossing
       MAY be generated."
                  { 0 }
   ::= { hdsl2ShdslEndpointAlarmConfProfileEntry 2 }
hdsl2ShdslEndpointThreshSNRMargin OBJECT-TYPE
   SYNTAX
                  Integer32(-127..128)
   UNITS
                  "dB"
   MAX-ACCESS
                 read-create
   STATUS
                  current
   DESCRIPTION
      "This object configures the SNR margin alarm threshold.
       When the current value of hdsl2ShdslEndpointCurrSnrMgn reaches or drops below this threshold, a
       hdsl2ShdslSNRMarginCrossing MAY be generated."
   ::= { hdsl2ShdslEndpointAlarmConfProfileEntry 3 }
hdsl2ShdslEndpointThreshES OBJECT-TYPE
                 Hdsl2ShdslPerfIntervalThreshold
   SYNTAX
   UNITS
                  "seconds"
   MAX-ACCESS
                 read-create
   STATUS
                  current
   DESCRIPTION
      "This object configures the threshold for the number of
      Errored Seconds (ES) within any given 15-minute performance data collection interval. If the value of Errored Seconds in a particular 15-minute collection interval reaches/
       exceeds this value, an hdsl2ShdslPerfESThresh MAY be
       generated. At most, one notification will be sent per
       interval per endpoint."
                  { 0 }
   DEFVAL
   ::= { hdsl2ShdslEndpointAlarmConfProfileEntry 4 }
hdsl2ShdslEndpointThreshSES OBJECT-TYPE
                 Hdsl2ShdslPerfIntervalThreshold
   SYNTAX
                  "seconds"
   UNITS
   MAX-ACCESS
                 read-create
                 current
   STATUS
   DESCRIPTION
```

```
"This object configures the threshold for the number of
       Severely Errored Seconds (SES) within any given 15-minute
       performance data collection interval. If the value of
       Severely Errored Seconds in a particular 15-minute collection
       interval reaches/exceeds this value, an hdsl2ShdslPerfSESThresh MAY be generated. At most, one notification will be sent per
       interval per endpoint."
VAL { 0 }
   DEFVAL
   ::= { hdsl2ShdslEndpointAlarmConfProfileEntry 5 }
hdsl2ShdslEndpointThreshCRCanomalies OBJECT-TYPE
   SYNTAX
                  Integer32
                  "detected CRC Anomalies"
   UNITS
   MAX-ACCESS read-create
   STATUS
                  current
   DESCRIPTION
      'This object configures the threshold for the number of
       CRC anomalies within any given 15-minute performance data collection interval. If the value of CRC anomalies in a
       particular 15-minute collection interval reaches/exceeds this value, an hdsl2ShdslPerfCRCanomaliesThresh MAY be
       generated. At most, one notification will be sent per
       interval per endpoint."
                  { 0 }
   ::= { hdsl2ShdslEndpointAlarmConfProfileEntry 6 }
hdsl2ShdslEndpointThreshLOSWS OBJECT-TYPE
   SYNTAX
                  Hdsl2ShdslPerfIntervalThreshold
   UNITS
                  "seconds"
   MAX-ACCESS read-create
   STATUS
                  current
   DESCRIPTION
      "This object configures the threshold for the number of
       Loss of Sync Word (LOSW) Seconds within any given 15-minute performance data collection interval. If the value of LOSW in a particular 15-minute collection interval reaches/exceeds
       this value, an hdsl2ShdslPerfLOSWSThresh MAY be generated.
       At most, one notification will be sent per interval per endpoint."
   DEFVAL
   ::= { hdsl2ShdslEndpointAlarmConfProfileEntry 7 }
hdsl2ShdslEndpointThreshUAS OBJECT-TYPE
                  Hdsl2ShdslPerfIntervalThreshold
   SYNTAX
                  "seconds"
   UNITS
   MAX-ACCESS read-create
   DESCRIPTION CUrrent
```

```
"This object configures the threshold for the number of
      Unavailable Seconds (UAS) within any given 15-minute performance data collection interval. If the value of UAS
      in a particular 15-minute collection interval reaches/exceeds
      this value, an hdsl2ShdslPerfUASThresh MAY be generated.
      At most, one notification will be sent per interval per endpoint."
   DEFVAL
   ::= { hdsl2ShdslEndpointAlarmConfProfileEntry 8 }
hdsl2ShdslEndpointAlarmConfProfileRowStatus OBJECT-TYPE
   SYNTAX
                RowStatus
   MAX-ACCESS read-create
   STATUS
                current
   DESCRIPTION
      'This object controls creation/deletion of the associated
      entry in this table as per the semantics of RowStatus.
      If an active entry is referenced in either hdsl2ShdslSpanConfAlarmProfile or
      hdsl2ShdslEndpointAlarmConfProfile, the entry MUST remain
      active until all references are removed."
   ::= { hdsl2ShdslEndpointAlarmConfProfileEntry 9 }
-- Notifications Group
hdsl2ShdslNotifications OBJECT IDENTIFIER ::= { hdsl2ShdslMIB 0 }
hdsl2ShdslLoopAttenCrossing NOTIFICATION-TYPE
   OBJECTS
   hdsl2ShdslEndpointCurrAtn,
   hdsl2ShdslEndpointThreshLoopAttenuation
   STATUS
               current
   DESCRIPTION
      'This notification indicates that the loop attenuation
      threshold (as per the hdsl2ShdslEndpointThreshLoopAttenuation
      value) has been reached/exceeded for the HDSL2/SHDSL segment
      endpoint."
   ::= { hdsl2ShdslNotifications 1 }
hdsl2ShdslSNRMarginCrossing NOTIFICATION-TYPE
   OBJECTS
   hdsl2ShdslEndpointCurrSnrMgn,
   hdsl2ShdslEndpointThreshSNRMargin
```

```
STATUS
              current
   DESCRIPTION
     'This notification indicates that the SNR margin threshold (as
      per the hdsl2ShdslEndpointThreshSNRMargin value) has been
      reached/exceeded for the HDSL2/SHDSL segment endpoint."
   ::= { hdsl2ShdslNotifications 2 }
hdsl2ShdslPerfESThresh NOTIFICATION-TYPE
   OBJECTS
   hdsl2ShdslEndpointCurr15MinES.
   hdsl2ShdslEndpointThreshES
   STATUS
              current
   DESCRIPTION
     'This notification indicates that the errored seconds
      threshold (as per the hdsl2ShdslEndpointThreshES value)
      has been reached/exceeded for the HDSL2/SHDSL segment
      endpoint."
   ::= { hdsl2ShdslNotifications 3 }
hdsl2ShdslPerfSESThresh NOTIFICATION-TYPE
   OBJECTS
   hdsl2ShdslEndpointCurr15MinSES.
   hdsl2ShdslEndpointThreshSES
   STATUS
              current
   DESCRIPTION
     'This notification indicates that the severely errored seconds
      threshold (as per the hdsl2ShdslEndpointThreshSES value) has
      been reached/exceeded for the HDSL2/SHDSL segment endpoint.
   ::= { hdsl2ShdslNotifications 4 }
hdsl2ShdslPerfCRCanomaliesThresh NOTIFICATION-TYPE
   OBJECTS
   hdsl2ShdslEndpointCurr15MinCRCanomalies.
   hdsl2ShdslEndpointThreshCRCanomalies
   STATUS
            current
   DESCRIPTION
     "This notification indicates that the CRC anomalies threshold
      (as per the hdsl2ShdslEndpointThreshCRCanomalies value) has
      been reached/exceeded for the HDSL2/SHDSL segment endpoint."
   ::= { hdsl2ShdslNotifications 5 }
hdsl2ShdslPerfLOSWSThresh NOTIFICATION-TYPE
```

```
OBJECTS
   hdsl2ShdslEndpointCurr15MinLOSWS,
   hdsl2ShdslEndpointThreshL0SWS
   STATUS
              current
   DESCRIPTION
     "This notification indicates that the LOSW Seconds threshold
      (as per the hdsl2ShdslEndpointThreshLOSWS value) has been
      reached/exceeded for the HDSL2/SHDSL segment endpoint.
   ::= { hdsl2ShdslNotifications 6 }
hdsl2ShdslPerfUASThresh NOTIFICATION-TYPE
   OBJECTS
   hdsl2ShdslEndpointCurr15MinUAS,
   hdsl2ShdslEndpointThreshUAS
   STATUS
              current
   DESCRIPTION
      'This notification indicates that the unavailable seconds
      threshold (as per the hdsl2ShdslEndpointThreshUAS value) has
      been reached/exceeded for the HDSL2/SHDSL segment endpoint."
   ::= { hdsl2ShdslNotifications 7 }
hdsl2ShdslSpanInvalidNumRepeaters NOTIFICATION-TYPE
   OBJECTS
   hdsl2ShdslSpanConfNumRepeaters
   STATUS
               current
   DESCRIPTION
     "This notification indicates that a mismatch has been detected
      between the number of repeater/regenerator units configured for an HDSL2/SHDSL line via the hdsl2ShdslSpanConfNumRepeaters
      object and the actual number of repeater/regenerator units
      discovered via the EOC."
   ::= { hdsl2ShdslNotifications 8 }
hdsl2ShdslLoopbackFailure NOTIFICATION-TYPE
   OBJECTS
   hdsl2ShdslMaintLoopbackConfig
   STATUS
               current
   DESCRIPTION
     "This notification indicates that an endpoint maintenance
      loopback command failed for an HDSL2/SHDSL segment."
```

```
::= { hdsl2ShdslNotifications 9 }
hdsl2ShdslpowerBackoff NOTIFICATION-TYPE
   OBJECTS
   hdsl2ShdslEndpointCurrStatus
   STATUS
              current
   DESCRIPTION
      'This notification indicates that the bit setting for
      powerBackoff in the hdsl2ShdslEndpointCurrStatus object for
      this endpoint has changed."
   ::= { hdsl2ShdslNotifications 10 }
hdsl2ShdsldeviceFault NOTIFICATION-TYPE
   OBJECTS
   hdsl2ShdslEndpointCurrStatus
   STATUS
             current
   DESCRIPTION
     "This notification indicates that the bit setting for
      deviceFault in the hdsl2ShdslEndpointCurrStatus object for
      this endpoint has changed."
   ::= { hdsl2ShdslNotifications 11 }
hdsl2ShdsldcContinuityFault NOTIFICATION-TYPE
   OBJECTS
   hdsl2ShdslEndpointCurrStatus
   STATUS
              current
   DESCRIPTION
     "This notification indicates that the bit setting for
      dcContinuityFault in the hdsl2ShdslEndpointCurrStatus object for this endpoint has changed."
   ::= { hdsl2Shds\Notifications 12 }
hdsl2ShdslconfigInitFailure NOTIFICATION-TYPE
   OBJECTS
   hdsl2ShdslEndpointCurrStatus
   STATUS
             current
   DESCRIPTION
     "This notification indicates that the bit setting for
      configInitFailure in the hdsl2ShdslEndpointCurrStatus object for this endpoint has changed."
```

```
::= { hdsl2ShdslNotifications 13 }
hdsl2ShdslprotocolInitFailure NOTIFICATION-TYPE
   OBJECTS
   hdsl2ShdslEndpointCurrStatus
   STATUS
             current
   DESCRIPTION
     "This notification indicates that the bit setting for
      protocolInitFailure in the hdsl2ShdslEndpointCurrStatus
      object for this endpoint has changed."
   ::= { hdsl2ShdslNotifications 14 }
hdsl2ShdslnoNeighborPresent NOTIFICATION-TYPE
   OBJECTS
   hdsl2ShdslEndpointCurrStatus
   STATUS
             current
   DESCRIPTION
     "This notification indicates that the bit setting for
      noNeighborPresent in the hdsl2ShdslEndpointCurrStatus object
      for this endpoint has changed."
   ::= { hdsl2ShdslNotifications 15 }
hdsl2ShdslLocalPowerLoss NOTIFICATION-TYPE
   OBJECTS
   hdsl2ShdslInvVendorID
   STATUS
             current
   DESCRIPTION
     "This notification indicates impending unit failure due to
      loss of local power (last gasp).'
   ::= { hdsl2ShdslNotifications 16 }
-- conformance information
hdsl2ShdslConformance OBJECT IDENTIFIER ::= { hdsl2ShdslMIB 3 }
hdsl2ShdslGroups OBJECT IDENTIFIER ::=
             { hdsl2ShdslConformance 1 }
hdsl2ShdslCompliances OBJECT IDENTIFIER ::=
             { hdsl2ShdslConformance 2 }
-- agent compliance statements
```

```
hdsl2ShdslLineMibCompliance MODULE-COMPLIANCE
   STATUS deprecated
   DESCRIPTION
     "The compliance statement for SNMP entities that implement
     HDSL2 and SHDSL. The version of SHDSL supported in this
     compliance statement is q.shdsl.
     **** This compliance statement is deprecated. ****"
   MANDATORY-GROUPS
   hdsl2ShdslSpanConfGroup,
   hdsl2ShdslSpanStatusGroup,
   hdsl2ShdslInventoryGroup,
   hdsl2ShdslEndpointConfGroup,
   hdsl2ShdslEndpointCurrGroup,
   hdsl2Shdsl15MinIntervalGroup,
   hdsl2Shdsl1DayIntervalGroup,
   hdsl2ShdslMaintenanceGroup,
   hdsl2ShdslEndpointAlarmConfGroup.
   hdsl2ShdslNotificationGroup
GROUP hdsl2ShdslInventorvShdslGroup
   DESCRIPTION
     "Support for this group is only required for implementations supporting SHDSL lines."
GROUP hdsl2ShdslSpanShdslStatusGroup
   DESCRIPTION
     "Support for this group is only required for implementations supporting SHDSL lines."
GROUP hdsl2ShdslSpanConfProfileGroup
   DESCRIPTION
     "Support for this group is only required for implementations
     supporting SHDSL lines.'
OBJECT hdsl2ShdslSpanConfWireInterface
   SYNTAX
               INTEGER
                twoWire(1)
                fourWire(2)
   DESCRIPTION
     "An implementation only has to support the range as
     applicable for the original g.shdsl specification defined
     in RFC 3276."
```

```
OBJECT hdsl2ShdslStatusMaxAttainableLineRate
   SYNTAX
                Unsigned32(0..4112000)
   DESCRIPTION
     "An implementation only has to support the range as
     applicable for the original q.shdsl specification defined
     in RFC 3276."
OBJECT hdsl2ShdslStatusActualLineRate
               Unsigned32(0..4112000)
   SYNTAX
   DESCRIPTION
     "An implementation only has to support the range as
     applicable for the original g.shdsl specification defined
     in RFC 3276."
OBJECT hdsl2ShdslSpanConfMinLineRate
   SYNTAX
                Unsigned32(0..4112000)
   DESCRIPTION
     "An implementation only has to support the range as
     applicable for the original g.shdsl specification defined
     in RFC 3276."
OBJECT hdsl2ShdslSpanConfMaxLineRate
   SYNTAX
               Unsigned32(0..4112000)
   DESCRIPTION
     "An implementation only has to support the range as
     applicable for the original q.shdsl specification defined
     in RFC 3276."
   ::= { hdsl2ShdslCompliances 1 }
hdsl2GshdslbisLineMibCompliance MODULE-COMPLIANCE
   STATUS current
   DESCRIPTION
     "The compliance statement for SNMP entities that implement HDSL2 and SHDSL. The version of SHDSL supported in this compliance statement is g.shdsl.bis."
   MODULE
   MANDATORY-GROUPS
   hdsl2ShdslSpanConfGroup,
   hdsl2ShdslSpanStatusGroup,
   hdsl2ShdslInventoryGroup,
   hdsl2ShdslEndpointConfGroup,
   hdsl2ShdslEndpointCurrGroup,
   hdsl2Shdsl15MinIntervalGroup,
   hdsl2Shdsl1DayIntervalGroup,
   hdsl2ShdslMaintenanceGroup,
   hdsl2ShdslEndpointAlarmConfGroup,
```

```
hdsl2ShdslNotificationGroup
GROUP hdsl2ShdslInventoryShdslGroup
   DESCRIPTION
     "Support for this group is only required for implementations supporting SHDSL lines."
GROUP hdsl2ShdslSpanShdslStatusGroup
   DESCRIPTION
     "Support for this group is only required for implementations supporting SHDSL lines."
GROUP hdsl2ShdslSpanConfProfileGroup
   DESCRIPTION
     "Support for this group is only required for implementations supporting SHDSL lines."
GROUP hdsl2ShdslWirePairGroup
   DESCRIPTION
     "Support for this group is only required for implementations supporting SHDSL lines."
GROUP hdsl2ShdslPavloadRateGroup
   DESCRIPTION
     "Support for this group is only required for implementations supporting SHDSL lines."
   ::= { hdsl2ShdslCompliances 2 }
-- units of conformance
hdsl2ShdslSpanConfGroup OBJECT-GROUP
   OBJECTS
   hdsl2ShdslSpanConfNumRepeaters,
   hdsl2ShdslSpanConfProfile,
   hdsl2ShdslSpanConfAlarmProfile
   STATUS
                current
   DESCRIPTION
      "This group supports objects for configuring span-related
      parameters for HDSL2/SHDSL lines."
   ::= { hdsl2ShdslGroups 1 }
hdsl2ShdslSpanStatusGroup OBJECT-GROUP
   OBJECTS
```

```
hdsl2ShdslStatusNumAvailRepeaters
   STATUS
               current
   DESCRIPTION
     "This group supports objects for retrieving span-related
      status for HDSL2/SHDSL lines."
   ::= { hdsl2ShdslGroups 2 }
hdsl2ShdslInventoryShdslGroup OBJECT-GROUP
   OBJECTS
   hdsl2ShdslInvTransmissionModeCapability
              current
   STATUS
   DESCRIPTION
     "This group supports objects for retrieving SHDSL-specific
      inventory information.
   ::= { hdsl2ShdslGroups 3 }
hdsl2ShdslSpanShdslStatusGroup OBJECT-GROUP
   hdsl2ShdslStatusMaxAttainableLineRate,
   hdsl2ShdslStatusActualLineRate.
   hdsl2ShdslStatusTransmissionModeCurrent
   STATUS
               current
   DESCRIPTION
     "This group supports objects for retrieving SHDSL-specific
      span-related status."
   ::= { hdsl2ShdslGroups 4 }
hdsl2ShdslInventorvGroup OBJECT-GROUP
   OBJECTS
   hdsl2ShdslInvVendorID,
   hdsl2ShdslInvVendorModelNumber.
   hdsl2ShdslInvVendorSerialNumber,
   hdsl2ShdslInvVendorEOCSoftwareVersion,
   hdsl2ShdslInvStandardVersion,
   hdsl2ShdslInvVendorListNumber,
   hdsl2ShdslInvVendorIssueNumber,
   hdsl2ShdslInvVendorSoftwareVersion,
   hdsl2ShdslInvEquipmentCode,
   hdsl2ShdslInvVendorOther
   STATUS
            current
```

```
DESCRIPTION
     "This group supports objects that provide unit inventory
      information about the units in HDSL2/SHDSL lines.'
   ::= { hdsl2ShdslGroups 5 }
hdsl2ShdslEndpointConfGroup OBJECT-GROUP
   OBJECTS
   hdsl2ShdslEndpointCurrAtn
   STATUS
               current
   DESCRIPTION
     "This group supports objects for configuring parameters for
      segment endpoints in HDSL2/SHDSL lines.'
   ::= { hdsl2ShdslGroups 6 }
hdsl2ShdslEndpointCurrGroup OBJECT-GROUP
   OBJECTS
   hdsl2ShdslEndpointCurrAtn,
   hdsl2ShdslEndpointCurrSnrMgn,
   hdsl2ShdslEndpointCurrStatus,
   hdsl2ShdslEndpointES,
   hdsl2ShdslEndpointSES.
   hdsl2ShdslEndpointCRCanomalies,
   hdsl2ShdslEndpointLOSWS,
   hdsl2ShdslEndpointUAS,
   hdsl2ShdslEndpointCurr15MinTimeElapsed.
   hdsl2ShdslEndpointCurr15MinES,
   hdsl2ShdslEndpointCurr15MinSES,
   hdsl2ShdslEndpointCurr15MinCRCanomalies.
   hdsl2ShdslEndpointCurr15MinLOSWS,
   hdsl2ShdslEndpointCurr15MinUAS
   hdsl2ShdslEndpointCurr1DavTimeElapsed.
   hdsl2ShdslEndpointCurr1DayES
   hdsl2ShdslEndpointCurr1DaySES,
   hdsl2ShdslEndpointCurr1DayCRCanomalies,
   hdsl2ShdslEndpointCurr1DayLOSWS,
   hdsl2ShdslEndpointCurr1DayUAS
   STATUS
               current
   DESCRIPTION
     "This group supports objects that provide current status and
      performance measurements relating to segment endpoints in
      HDSL2/SHDSL lines."
   ::= { hdsl2ShdslGroups 7 }
hdsl2Shdsl15MinIntervalGroup OBJECT-GROUP
```

```
OBJECTS
   hdsl2Shdsl15MinIntervalES
   hdsl2Shdsl15MinIntervalSES,
   hdsl2Shdsl15MinIntervalCRCanomalies,
   hdsl2Shdsl15MinIntervalLOSWS,
   hdsl2Shdsl15MinIntervalUAS
   STATUS
              current
   DESCRIPTION
     "This group supports objects that maintain historic
      performance measurements relating to segment endpoints in
      HDSL2/SHDSL lines in 15-minute intervals."
   ::= { hdsl2ShdslGroups 8 }
hdsl2Shdsl1DayIntervalGroup OBJECT-GROUP
   OBJECTS
   hdsl2Shdsl1DayIntervalMoniSecs,
   hdsl2Shdsl1DayIntervalES
   hdsl2Shdsl1DayIntervalSES
   hdsl2Shdsl1DayIntervalCRCanomalies,
   hdsl2Shdsl1DayIntervalLOSWS,
   hdsl2Shdsl1DayIntervalUAS
   STATUS
               current
   DESCRIPTION
     "This group supports objects that maintain historic
      performance measurements relating to segment endpoints in
      HDSL2/SHDSL lines in 1-day intervals.
   ::= { hdsl2ShdslGroups 9 }
hdsl2ShdslMaintenanceGroup OBJECT-GROUP
   OBJECTS
   hdsl2ShdslMaintLoopbackConfig,
   hdsl2ShdslMaintTipRingReversal,
   hdsl2ShdslMaintPowerBackOff,
   hdsl2ShdslMaintSoftRestart,
   hdsl2ShdslMaintLoopbackTimeout,
   hdsl2ShdslMaintUnitPowerSource
   STATUS
               current
   DESCRIPTION
     "This group supports objects that provide support for
      maintenance actions for HDSL2/SHDSL lines."
   ::= { hdsl2ShdslGroups 10 }
```

```
hdsl2ShdslEndpointAlarmConfGroup OBJECT-GROUP
   OBJECTS
   hdsl2ShdslEndpointAlarmConfProfile,
   hdsl2ShdslEndpointThreshLoopAttenuation,
   hdsl2ShdslEndpointThreshSNRMargin,
   hdsl2ShdslEndpointThreshES,
   hdsl2ShdslEndpointThreshSES
   hdsl2ShdslEndpointThreshCRCanomalies,
   hdsl2ShdslEndpointThreshLOSWS,
   hdsl2ShdslEndpointThreshUAS.
   hdsl2ShdslEndpointAlarmConfProfileRowStatus
   STATUS
               current
   DESCRIPTION
     'This group supports objects that allow configuration of alarm
      thresholds for various performance parameters for HDSL2/SHDSL
   ::= { hdsl2ShdslGroups 11 }
hdsl2ShdslNotificationGroup NOTIFICATION-GROUP
   NOTIFICATIONS
   hdsl2ShdslLoopAttenCrossing.
   hdsl2ShdslSNRMarginCrossing,
   hdsl2ShdslPerfESThresh,
   hdsl2ShdslPerfSESThresh
   hdsl2ShdslPerfCRCanomaliesThresh,
   hdsl2ShdslPerfLOSWSThresh,
   hdsl2ShdslPerfUASThresh,
   hdsl2ShdslSpanInvalidNumRepeaters,
   hdsl2ShdslLoopbackFailure,
   hdsl2ShdslpowerBackoff,
   hdsl2ShdsldeviceFault,
   hdsl2ShdsldcContinuityFault,
   hdsl2ShdslconfigInitFailure,
   hdsl2ShdslprotocolInitFailure,
   hdsl2ShdslnoNeighborPresent,
   hdsl2ShdslLocalPowerLoss
   STATUS
               current
   DESCRIPTION
     "This group supports notifications of significant conditions
      associated with HDSL2/SHDSL lines.'
   ::= { hdsl2ShdslGroups 12 }
hdsl2ShdslSpanConfProfileGroup OBJECT-GROUP
   OBJECTS
```

```
hdsl2ShdslSpanConfWireInterface,
   hdsl2ShdslSpanConfMinLineRate,
   hdsl2ShdslSpanConfMaxLineRate,
   hdsl2ShdslSpanConfPSD,
   hdsl2ShdslSpanConfTransmissionMode,
   hdsl2ShdslSpanConfRemoteEnabled,
   hdsl2ShdslSpanConfPowerFeeding,
   hdsl2ShdslSpanConfCurrCondTargetMarginDown,
   hdsl2ShdslSpanConfWorstCaseTargetMarginDown,
   hdsl2ShdslSpanConfCurrCondTargetMarginUp,
   hdsl2ShdslSpanConfWorstCaseTargetMarginUp,
   hdsl2ShdslSpanConfUsedTargetMargins,
   hdsl2ShdslSpanConfReferenceClock,
   hdsl2ShdslSpanConfLineProbeEnable,
   hdsl2ShdslSpanConfProfileRowStatus
   STATUS
                current
   DESCRIPTION
     "This group supports objects that constitute configuration profiles for configuring span-related parameters in SHDSL
   ::= { hdsl2ShdslGroups 13 }
hdsl2ShdslWirePairGroup OBJECT-GROUP
   OBJECTS
   hdsl2ShdslEndpointCurrTipRingReversal,
   hdsl2ShdslEndpointCurrActivationState
   STATUS
                current
   DESCRIPTION
     "This group supports objects that provide the status
   of SHDSL-specific wire pairs."
::= { hdsl2ShdslGroups 14 }
hdsl2ShdslPayloadRateGroup OBJECT-GROUP
   OBJECTS
   hdsl2ShdslStatusMaxAttainablePayloadRate,
   hdsl2ShdslStatusActualPayloadRate
   STATUS
               current
   DESCRIPTION
     "This group supports objects for retrieving payload rates
      that exclude any framing overhead."
   ::= { hdsl2ShdslGroups 15 }
```

END

4. Implementation Analysis

A management application that supports RFC 3276 could mistakenly flag a unit that responds with a rate or wire pair that exceeds the ranges and/or enumerations specified in RFC 3276. For example, a G.shdsl.bis line with four wire pairs would report statistics for wire pairs that do not exist in RFC 3276. That is, a GET-NEXT request issues with the object identifier:

hdsl2ShdslEndpointCurrAtn.1.1.1.2

might return

hdsl2ShdslEndpointCurrAtn.1.1.1.3 = 0

with a G.shdsl.bis unit and

hdsl2ShdslEndpointCurrSnrMgn.1.1.1.1 = 0

with an HDSL2 unit as these objects are indexed by

A management application intended to manage G.shdsl.bis agents SHOULD be modified to accept this sequence.

One should note that this same unmodified management application is still capable of managing G.shdsl.bis agents albeit to the degree of G.SHDSL (non-bis) limitations. That is, it can create and monitor configurations limited to two wire pairs with an upper-rate limit of 4112000 bits/second.

5. Security Considerations

There are a number of management objects defined in this MIB module with a MAX-ACCESS clause of read-write and/or read-create. Such objects may be considered sensitive or vulnerable in some network environments. The support for SET operations in a non-secure environment without proper protection can have a negative effect on network operations. These are the tables and objects and their sensitivity/vulnerability:

o hdsl2ShdslSpanConfTable

The table consists of the following objects that support SET operations:

- * hdsl2ShdslSpanConfNumRepeaters
- * hdsl2ShdslSpanConfProfile
- * hdsl2ShdslSpanConfAlarmProfile

Unauthorized changes to hdsl2ShdslSpanConfNumRepeaters could result in an hdsl2ShdslSpanInvalidNumRepeaters notification. Note the discussion on hdsl2ShdslSpanInvalidNumRepeaters in the Notifications section above.

Unauthorized changes to hdsl2ShdslSpanConfProfile could have an adverse operational effect on a span. Reference the hdsl2ShdslSpanConfProfileTable discussion below.

Unauthorized changes to hdsl2ShdslSpanConfAlarmProfile could have a contrary effect on notifications. Reference the hdsl2ShdslEndpointAlarmConfProfileTable discussion below.

o hdsl2ShdslEndpointConfTable

This table contains one object, hdsl2ShdslEndpointAlarmConfProfile, that supports SET operations. Unauthorized changes could have an undesirable notifications. Reference the hdsl2ShdslEndpointAlarmConfProfileTable discussion below.

o hdsl2ShdslEndpointMaintTable

The table consists of the following objects that support SET operations:

- * hdsl2ShdslMaintLoopbackConfig
- * hdsl2ShdslMaintPowerBackoff
- * hdsl2ShdslMaintSoftRestart

Unauthorized changes to hdsl2ShdslMaintLoopbackConfig could prevent end-to-end data transfer due to an activation of a loopback.

Unauthorized changes to hdsl2ShdslMaintPowerBackoff could result in an increased in bundle interference.

Unauthorized changes to hdsl2ShdslMaintSoftRestart could result in a temporary interruption of end-to-end data transfer as the result of the triggering of a soft restart.

hdsl2ShdslUnitMaintTable

This table contains one object, hdsl2ShdslMaintLoopbackTimeout, that supports SET operations. An unauthorized change to this object could result in the timeout value for loopbacks being increased, decreased, or disabled.

hdsl2ShdslSpanConfProfileTable

The table consists of the following objects that support SET operations:

- hdsl2ShdslSpanConfWireInterface
- hdsl2ShdslSpanConfMinLineRate
- hdsl2ShdslSpanConfMaxLineRate
- hdsl2ShdslSpanConfPSD
- hdsl2ShdslSpanConfTransmissionMode
- hdsl2ShdslSpanConfRemoteEnabled
- hdsl2ShdslSpanConfPowerFeeding
- hdsl2ShdslSpanConfCurrCondTargetMarginDown
- hdsl2ShdslSpanConfWorstCaseTargetMarginDown
- hdsl2ShdslSpanConfCurrCondTargetMarginUp
- hdsl2ShdslSpanConfWorstCaseTargetMarginUp
- hdsl2ShdslSpanConfUsedTargetMargins hdsl2ShdslSpanConfReferenceClock
- hdsl2ShdslSpanConfLineProbeEnable
- hdsl2ShdslSpanConfProfileRowStatus

Setting any of the objects to an incorrect value could have an adverse operational effect on a span.

Unauthorized changes to the hdsl2ShdslSpanConfWireInterface could result in the failure of a span to achieve activation to a state that would permit data flow. For example, setting this object to six-wire or eight-wire operation when one of the units in the span only supports two-wire or four-wire operation would likely prevent an expected end-to-end data transfer capability.

Unauthorized changes to hdsl2ShdslSpanConfMinLineRate or hdsl2ShdslSpanConfMaxLineRate could have an adverse effect on performance. The range of allowable line rates could be altered such that the span may not be able to train to a line rate that would permit any end-user data to traverse the span or the span could train to a line rate that is either greater than or less than the line rate that the provider has pledged.

Unauthorized changes to hdsl2ShdslSpanConfPSD or hdsl2ShdslSpanConfTransmissionMode could have a detrimental effect on loop reach, performance, or spectral compatibility.

Unauthorized changes to hdsl2ShdslSpanConfRemoteEnable could alter the remote management ability of units.

Unauthorized changes to hdsl2ShdslSpanConfPowerFeeding could shutdown units that are expected to be fed power remotely. Changing the configuration such that wetting current is not supplied may result in corrosion of electrical contacts.

Unauthorized changes to hdsl2ShdslSpanConfCurrCondTargetMarginDown, hdsl2ShdslSpanConfWorstCaseTargetMarginDown, hdsl2ShdslSpanConfCurrCondTargetMarginUp, hdsl2ShdslSpanConfWorstCaseTargetMarginUp, or hdsl2ShdslSpanConfUsedTargetMargins could result in invalid parameters used to determine if a data rate can be supported under current and worst-case noise.

Unauthorized changes to hdsl2ShdslSpanConfReferenceClock could result in the selection of a clock source that might either prevent any data from being transferred or impair data transfer. In addition, an increase in CRC anomalies may be experienced.

Unauthorized changes to hdsl2ShdslSpanConfLineProbeEnable could have a negative effect on selecting the optimum rate or power level based on current line conditions.

Unauthorized changes to row status could result in unwanted profiles being created or brought into service. Also, changes to the row status could result in profiles being inadvertently deleted or taken out of service.

o hdsl2ShdslEndpointAlarmConfProfileTable

The table consists of the following objects that support SET operations:

- * hdsl2ShdslEndpointThreshLoopAttenuation
- * hdsl2ShdslEndpointThreshSNRMargin
- * hdsl2ShdslEndpointThreshES
- * hdsl2ShdslEndpointThreshSES

- * hdsl2ShdslEndpointThreshCRCanomalies
- * hdsl2ShdslEndpointThreshLOSWS
- * hdsl2ShdslEndpointThreshUAS
- * hdsl2ShdslEndpointAlarmConfProfileRowStatus

Increasing any of the threshold values could result in a notification being suppressed or deferred. Setting a threshold to 0 could result in a notification being suppressed. Suppressing or deferring a notification could prevent the timely delivery of important diagnostic information. Decreasing any of the threshold values could result in a notification being sent from the network falsely reporting a threshold crossing.

Changing a threshold value could also have an impact on the amount of notifications the agent sends. This document adds a paragraph, which was not in RFC 3276 [RFC3276], to the Notifications section that provides general guidance to the rate limiting of notifications. Agent implementations not adhering to the rate-limiting desires could result in notifications being generated at an uncontrolled rate. Unauthorized changes to a threshold value could result in an undesired notification rate.

Unauthorized changes to row status could result in unwanted profiles being created or brought into service. Also, changes to the row status could result in profiles being inadvertently deleted or taken out of service.

Some of the readable objects in this MIB module (i.e., objects with a MAX-ACCESS other than not-accessible) may be considered sensitive or vulnerable in some network environments. It is thus important to control even GET and/or NOTIFY access to these objects and possibly to even encrypt the values of these objects when sending them over the network via SNMP. These are the tables and objects and their sensitivity/vulnerability:

o hdsl2ShdslInventoryTable

Access to these objects would allow an intruder to obtain information about which vendor's equipment is in use on the network. Further, such information is considered sensitive in many environments for competitive reasons.

- * hdsl2ShdslInvVendorID
- * hdsl2ShdslInvVendorModelNumber
- * hdsl2ShdslInvVendorSerialNumber
- * hdsl2ShdslInvVendorEOCSoftwareVersion
- * hdsl2ShdslInvStandardVersion
- * hdsl2ShdslInvVendorListNumber

- * hdsl2ShdslInvVendorIssueNumber
- * hdsl2ShdslInvVendorSoftwareVersion
- * hdsl2ShdslInvEquipmentCode
- * hdsl2ShdslInvVendorOther
- * hdsl2ShdslInvTransmissionModeCapability

SNMP versions prior to SNMPv3 did not include adequate security. Even if the network itself is secure (for example by using IPsec), even then, there is no control as to who on the secure network is allowed to access and GET/SET (read/change/create/delete) the objects in this MIB module.

It is RECOMMENDED that implementers consider the security features as provided by the SNMPv3 framework (see [RFC3410], Section 8), including full support for the SNMPv3 cryptographic mechanisms (for authentication and privacy).

Further, deployment of SNMP versions prior to SNMPv3 is NOT RECOMMENDED. Instead, it is RECOMMENDED to deploy SNMPv3 and to enable cryptographic security. It is then a customer/operator responsibility to ensure that the SNMP entity giving access to an instance of this MIB module is properly configured to give access to the objects only to those principals (users) that have legitimate rights to indeed GET or SET (change/create/delete) them.

6. Acknowledgements

The authors are deeply grateful to the authors of the ADSL LINE MIB (RFC 2662 [RFC2662]), Gregory Bathrick and Faye Ly, as much of the text and structure of this document originate in their documents.

The authors are also grateful to the authors of FR MFR MIB (RFC 3020 [RFC3020]), Prayson Pate, Bob Lynch, and Kenneth Rehbehn, as the majority of the Security Considerations section was lifted from their document.

The authors also acknowledge the importance of the contributions and suggestions regarding interface indexing structures received from David Horton of CITR.

The authors are extremely thankful to Bert Wijnen, Randy Presuhn, and C. M. Heard for their extensive review and the many suggestions they provided.

Other contributions were received from the following:

Matt Beanland (Extel Communications)
Philip Bergstresser (Adtran)
Steve Blackwell (Centillium)
Umberto Bonollo (NEC Australia)
John Egan (Metalink BroadBand)
Yagal Hachmon (RAD)
Mark Johnson (Red Point)
Sharon Mantin (Orckit)
Moti Morgenstern (ECI)
Raymond Murphy (Ericsson)
Lee Nipper (Verilink)
Randy Presuhn (BMC Software)
Katy Sherman (Orckit)
Mike Sneed (ECI)
Jon Turney (DSL Solutions)
Aron Wahl (Memotec)
Bert Wijnen (Lucent)
Jim Wilson (for Mindspeed)
Michael Wrobel (Memotec)

7. References

7.1. Normative References

- [G.991.2] Blackwell, S., "Single-Pair High-Speed Digital Subscriber Line (SHDSL) Transceivers", ITU-T G.991.2, December 2003.
- [RFC2119] Bradner, S., "Key words for use in RFCs to Indicate Requirement Levels", BCP 14, RFC 2119, March 1997.

- [RFC2580] McCloghrie, K., Perkins, D., and J. Schoenwaelder, "Conformance Statements for SMIv2", STD 58, RFC 2580, April 1999.
- [RFC2863] McCloghrie, K. and F. Kastenholz, "The Interfaces Group MIB", RFC 2863, June 2000.

- [RFC3411] Harrington, D., Presuhn, R., and B. Wijnen, "An Architecture for Describing Simple Network Management Protocol (SNMP) Management Frameworks", STD 62, RFC 3411, December 2002.
- [RFC3593] Tesink, K., "Textual Conventions for MIB Modules Using Performance History Based on 15 Minute Intervals", RFC 3593, September 2003.
- [T1E1.4] American National Standards Institute, "ANSI T1E1.4/2000-006", February 2000.

7.2. Informative References

- [RFC2662] Bathrick, G. and F. Ly, "Definitions of Managed Objects for the ADSL Lines", RFC 2662, August 1999.
- [RFC3020] Pate, P., Lynch, B., and K. Rehbehn, "Definitions of Managed Objects for Monitoring and Controlling the UNI/NNI Multilink Frame Relay Function", RFC 3020, December 2000.
- [RFC3276] Ray, B. and R. Abbi, "Definitions of Managed Objects for High Bit-Rate DSL - 2nd generation (HDSL2) and Single-Pair High-Speed Digital Subscriber Line (SHDSL) Lines Processing", RFC 3276, May 2002.
- [RFC3410] Case, J., Mundy, R., Partain, D., and B. Stewart,
 "Introduction and Applicability Statements for InternetStandard Management Framework", RFC 3410, December 2002.
- [RFC3418] Presuhn, R., "Management Information Base (MIB) for the Simple Network Management Protocol (SNMP)", STD 62, RFC 3418, December 2002.

Authors' Addresses

Clay Sikes Zhone Technologies, Inc. Florida Design Center 8454 126th Ave. N. Largo, FL 33773 US

Phone: +1 727 530 8257 Fax: +1 727 532 5698 EMail: csikes@zhone.com

Bob Ray PESA Switching Systems, Inc. 330-A Wynn Drive Huntsville, AL 35805 US

Phone: +1 256 726 9200 ext. 142 Fax: +1 256 726 9271

EMail: rray@pesa.com

Rajesh Abbi Alcatel USA 2301 Sugar Bush Road Raleigh, NC 27612 US

Phone: +1 919-850-6194 Fax: +1 919-850-6670

EMail: Rajesh.Abbi@alcatel.com

Full Copyright Statement

Copyright (C) The Internet Society (2005).

This document is subject to the rights, licenses and restrictions contained in BCP 78, and except as set forth therein, the authors retain all their rights.

This document and the information contained herein are provided on an "AS IS" basis and THE CONTRIBUTOR, THE ORGANIZATION HE/SHE REPRESENTS OR IS SPONSORED BY (IF ANY), THE INTERNET SOCIETY AND THE INTERNET ENGINEERING TASK FORCE DISCLAIM ALL WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY WARRANTY THAT THE USE OF THE INFORMATION HEREIN WILL NOT INFRINGE ANY RIGHTS OR ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

Intellectual Property

The IETF takes no position regarding the validity or scope of any Intellectual Property Rights or other rights that might be claimed to pertain to the implementation or use of the technology described in this document or the extent to which any license under such rights might or might not be available; nor does it represent that it has made any independent effort to identify any such rights. Information on the procedures with respect to rights in RFC documents can be found in BCP 78 and BCP 79.

Copies of IPR disclosures made to the IETF Secretariat and any assurances of licenses to be made available, or the result of an attempt made to obtain a general license or permission for the use of such proprietary rights by implementers or users of this specification can be obtained from the IETF on-line IPR repository at http://www.ietf.org/ipr.

The IETF invites any interested party to bring to its attention any copyrights, patents or patent applications, or other proprietary rights that may cover technology that may be required to implement this standard. Please address the information to the IETF at ietf-ipr@ietf.org.

Acknowledgement

Funding for the RFC Editor function is currently provided by the Internet Society.