Network Working Group Request for Comments: 3433 Category: Standards Track A. Bierman
Cisco Systems, Inc.
D. Romascanu
Avaya Inc.
K.C. Norseth
L-3 Communications
December 2002

Entity Sensor Management Information Base

Status of this Memo

This document specifies an Internet standards track protocol for the Internet community, and requests discussion and suggestions for improvements. Please refer to the current edition of the "Internet Official Protocol Standards" (STD 1) for the standardization state and status of this protocol. Distribution of this memo is unlimited.

Copyright Notice

Copyright (C) The Internet Society (2002). All Rights Reserved.

Abstract

This memo defines a portion of the Management Information Base (MIB) for use with network management protocols in the Internet community. In particular, it describes managed objects for extending the Entity MIB (RFC 2737) to provide generalized access to information related to physical sensors, which are often found in networking equipment (such as chassis temperature, fan RPM, power supply voltage).

Table of Contents

1	The Internet-Standard Management Framework 2
2	Overview 2
	2.1 Terms 2
	2.2 Relationship to the Entity MIB 2
	2.3 Relationship to General Thresholding Mechanisms 3
3	MIB Structure 3
4	Definitions 4
5	Intellectual Property
6	Acknowledgements
7	Normative References
8	Informative References 14
9	Security Considerations
10	Authors' Addresses 16
11	Full Copyright Statement

Bierman, et. al.

Standards Track

[Page 1]

1. The Internet-Standard Management Framework

For a detailed overview of the documents that describe the current Internet-Standard Management Framework, please refer to section 7 of RFC 3410 [RFC3410].

Managed objects are accessed via a virtual information store, termed the Management Information Base or MIB. MIB objects are generally accessed through the Simple Network Management Protocol (SNMP). Objects in the MIB are defined using the mechanisms defined in the Structure of Management Information (SMI). This memo specifies a MIB module that is compliant to the SMIv2, which is described in STD 58, RFC 2578 [RFC2578], STD 58, RFC 2579 [RFC2579] and STD 58, RFC 2580 [RFC2580].

2. Overview

There is a need for a standardized way of obtaining information related to the physical sensors which are commonly found in networking equipment. Information such as the current value of the sensor, the current operational status, and the data units precision associated with the sensor, should be represented in a consistent manner for any type of sensor.

Physical sensors are represented in the Entity MIB with entPhysicalEntry and an entPhysicalClass value of 'sensor(8)'. The information provided in the ENTITY-SENSOR-MIB module (defined in this document) defines a sparse augmentation of the entPhysicalTable, for entries which represent physical sensors.

2.1. Terms

The key words "MUST", "MUST NOT", "REQUIRED", "SHALL", "SHALL NOT", "SHOULD", "SHOULD NOT", "RECOMMENDED", "MAY", and "OPTIONAL" in this document are to be interpreted as described in BCP 14, RFC 2119. [RFC2119]

2.2. Relationship to the Entity MIB

The MIB objects defined in this document provide a sparse augmentation to the entPhysicalTable in the Entity MIB, for entries in which the associated entPhysicalClass object is equal to 'sensor(8)'. An agent is expected to maintain an entPhySensorEntry with the same entPhysicalIndex value for each entPhysicalEntry representing a physical sensor. Therefore, implementation of the entityPhysicalGroup is required for agents that implement the Entity Sensor MIB.

2.3. Relationship to General Thresholding Mechanisms

There are no specialized sensor value thresholding mechanisms defined in this MIB module. Instead, it is recommended that a generalized thresholding MIB, such as the mechanisms defined by the Alarm and Events groups of the Remote Network Monitoring MIB [RFC2819], be used for this purpose.

3. MIB Structure

The Entity Sensor MIB contains a single group called the entitySensorValueGroup, which allows objects to convey the current value and status of a physical sensor.

The entitySensorValueGroup contains a single table, called the entPhySensorTable, which provides a small number of read-only objects:

entPhySensorType

This object identifies the type of data units associated with the sensor value.

entPhySensorScale

This object identifies the (power of 10) scaling factor associated with the sensor value.

entPhySensorPrecision

This object identifies the number of decimal places of precision associated with the sensor value.

entPhySensorValue

This object identifies the current value of the sensor.

entPhySensorOperStatus

This object identifies the current operational status of the sensor (as it's known to the agent).

entPhySensorUnitsDisplay

This object provides a textual description of the data units represented by the entPhySensorType and entPhySensorScale objects.

entPhySensorValueTimeStamp

The object identifies the value of sysUpTime at the time the agent last updated the information in the entry. This object is only relevant if the agent uses a polling implementation strategy, (i.e., the associated entPhySensorValueUpdateRate object is greater than zero).

entPhySensorValueUpdateRate

This object indicates the nature of the agent implementation of the entPhySensorEntry, and contains the (possibly estimated) number of milliseconds that elapse between polling updates of the information in the associated entry. The value zero indicates that the agent always return current data for the entry (as opposed to the data as it was at the last polling interval).

Definitions 4.

ENTITY-SENSOR-MIB DEFINITIONS ::= BEGIN

IMPORTS

MODULE-IDENTITY, OBJECT-TYPE, Integer32, Unsigned32, mib-2 FROM SNMPv2-SMI MODULE-COMPLIANCE, OBJECT-GROUP FROM SNMPv2-CONF TEXTUAL-CONVENTION, TimeStamp FROM SNMPv2-TC entPhysicalIndex, entityPhysicalGroup FROM ENTITY-MIB

SnmpAdminString FROM SNMP-FRAMEWORK-MIB;

entitySensorMIB MODULE-IDENTITY

"200212160000Z" LAST-UPDATED

"IETF Entity MIB Working Group" ORGANIZATION CONTACT-INFO

Andy Bierman

Cisco Systems, Inc. Tel: +1 408-527-3711 E-mail: abierman@cisco.com Postal: 170 West Tasman Drive

San Jose, CA USA 95134

Dan Romascanu Avaya Inc.

Tel: +972-3-645-8414 Email: dromasca@avaya.com

Postal: Atidim technology Park, Bldg. #3

Tel Aviv, Israel, 61131

K.C. Norseth

L-3 Communications

Tel: +1 801-594-2809

Email: kenyon.c.norseth@L-3com.com

Postal: 640 N. 2200 West.

Salt Lake City, Utah 84116-0850

Send comments to <entmib@ietf.org>
Mailing list subscription info:
 http://www.ietf.org/mailman/listinfo/entmib "

DESCRIPTION

"This module defines Entity MIB extensions for physical sensors.

Copyright (C) The Internet Society (2002). This version of this MIB module is part of RFC 3433; see the RFC itself for full legal notices."

REVISION "200212160000Z"

DESCRIPTION

"Initial version of the Entity Sensor MIB module, published as RFC 3433."

::= { mib-2 99 }

-- entitySensorNotifications OBJECT IDENTIFIER

-- ::= { entitySensorMIB 2 } entitySensorConformance OBJECT IDENTIFIER

::= { entitySensorMIB 3 }

-- Textual Conventions

--

EntitySensorDataType ::= TEXTUAL-CONVENTION

STATUS current

DESCRIPTION

"An object using this data type represents the Entity Sensor measurement data type associated with a physical sensor value. The actual data units are determined by examining an object of this type together with the associated EntitySensorDataScale object.

An object of this type SHOULD be defined together with objects of type EntitySensorDataScale and EntitySensorPrecision. Together, associated objects of these three types are used to identify the semantics of an object of type EntitySensorValue.

Valid values are:

```
other(1):
                                a measure other than those listed below
               unknown(2):
                                unknown measurement, or arbitrary,
                                relative numbers
               voltsAC(3):
                                electric potential
                                electric potential electric current
               voltsDC(4):
               amperes(5):
                                power
              watts(6):
               hertz(7):
                                frequency
               celsius(8):
                               temperature
               percentRH(9):
                                percent relative humidity
                               shaft revolutions per minute
               rpm(10):
              cmm(11),:
              SYNTAX INTEGER {
        other(1),
unknown(2),
        voltsAC(3),
        voltsDC(4),
        amperes(5),
       watts(6),
        hertz(7).
        celsius(8)
        percentRH(9),
        rpm(10),
        cmm(11),
        truthválue(12)
    }
EntitySensorDataScale ::= TEXTUAL-CONVENTION
    STATUS
                 current
    DESCRIPTION
            "An object using this data type represents a data scaling
           factor, represented with an International System of Units
            (SI) prefix. The actual data units are determined by
            examining an object of this type together with the
            associated EntitySensorDataType object.
            An object of this type SHOULD be defined together with
            objects of type EntitySensorDataType and
           EntitySensorPrecision. Together, associated objects of
            these three types are used to identify the semantics of an
            object of type EntitySensorValue."
    REFERENCE
            "The International System of Units (SI),
```

```
National Institute of Standards and Technology,
         Spec. Publ. 330, August 1991."
SYNTAX INTEGER {
    yocto(1),
                  -- 10^-24
    zepto(2),
                  -- 10^-21
                  -- 10^-18
    atto(3),
                 -- 10^-15
    femto(4),
                  -- <del>10</del>^-12
    pico(5),
    nano(6),
                 -- 10^-9
    micro(7),
                 -- 10^-6
               -- 10^{-3}
    milli(8),
    units(9),
                 -- 10^0
    kilo(10),
                 -- 10^3
                 -- 10^6
    mega(11),
                 -- 10^9
    giga(12),
    tera(13), -- 10^12
    exa(14), -- 10<sup>12</sup>
peta(15), -- 10<sup>18</sup>
    zetta(16), -- 10^21
yotta(17) -- 10^24
}
```

DESCRIPTION

"An object using this data type represents a sensor precision range.

An object of this type SHOULD be defined together with objects of type EntitySensorDataType and EntitySensorDataScale. Together, associated objects of these three types are used to identify the semantics of an object of type EntitySensorValue.

If an object of this type contains a value in the range 1 to 9, it represents the number of decimal places in the fractional part of an associated EntitySensorValue fixed-point number.

If an object of this type contains a value in the range -8 to -1, it represents the number of accurate digits in the associated EntitySensorValue fixed-point number.

The value zero indicates the associated EntitySensorValue object is not a fixed-point number.

Agent implementors must choose a value for the associated EntitySensorPrecision object so that the precision and

accuracy of the associated EntitySensorValue object is correctly indicated.

For example, a physical entity representing a temperature sensor that can measure 0 degrees to 100 degrees C in 0.1 degree increments, +/- 0.05 degrees, would have an EntitySensorPrecision value of '1', an EntitySensorDataScale value of 'units(9)', and an EntitySensorValue ranging from '0' to '1000'. The EntitySensorValue would be interpreted as 'degrees C * 10'."

SYNTAX Integer32 (-8..9)

"An object using this data type represents an Entity Sensor value.

An object of this type SHOULD be defined together with objects of type EntitySensorDataType, EntitySensorDataScale and EntitySensorPrecision. Together, associated objects of those three types are used to identify the semantics of an object of this data type.

The semantics of an object using this data type are determined by the value of the associated EntitySensorDataType object.

If the associated EntitySensorDataType object is equal to 'voltsAC(3)', 'voltsDC(4)', 'amperes(5)', 'watts(6), 'hertz(7)', 'celsius(8)', or 'cmm(11)', then an object of this type MUST contain a fixed point number ranging from -999,999,999 to +999,999,999. The value -1000000000 indicates an underflow error. The value +1000000000 indicates an overflow error. The EntitySensorPrecision indicates how many fractional digits are represented in the associated EntitySensorValue object.

If the associated EntitySensorDataType object is equal to 'percentRH(9)', then an object of this type MUST contain a number ranging from 0 to 100.

If the associated EntitySensorDataType object is equal to 'rpm(10)', then an object of this type MUST contain a number ranging from -999,999,999 to +999,999,999.

If the associated EntitySensorDataType object is equal to 'truthvalue(12)', then an object of this type MUST contain either the value 'true(1)' or the value 'false(2)'.

Bierman, et. al.

Standards Track

[Page 8]

```
If the associated EntitySensorDataType object is equal to
             'other(1)' or unknown(2)', then an object of this type MUST contain a number ranging from -1000000000 to 1000000000."
    SYNTAX Integer32 (-1000000000..1000000000)
EntitySensorStatus ::= TEXTUAL-CONVENTION
    STATUS
                   current
    DESCRIPTION
             "An object using this data type represents the operational
             status of a physical sensor.
             The value 'ok(1)' indicates that the agent can obtain the
             sensor value.
             The value 'unavailable(2)' indicates that the agent
             presently cannot obtain the sensor value.
             The value 'nonoperational(3)' indicates that the agent
             believes the sensor is broken. The sensor could have a hard
             failure (disconnected wire), or a soft failure such as out-
of-range, jittery, or wildly fluctuating readings."
    SYNTAX INTEGER {
        ok(1),
         unavailable(2)
         nonoperational(3)
    }
-- Entity Sensor Table
entPhySensorTable OBJECT-TYPE
                   SEQUENCE OF EntPhySensorEntry
    SYNTAX
    MAX-ACCESS
                    not-accessible
    STATUS
                   current
    DESCRIPTION
             "This table contains one row per physical sensor represented
             by an associated row in the entPhysicalTable."
    ::= { entitySensorObjects 1 }
entPhySensorEntry OBJECT-TYPE
    SYNTAX
                    EntPhySensorEntry
    MAX-ACCESS
                    not-accessible
    STATUS
                    current
    DESCRIPTION
             "Information about a particular physical sensor.
```

```
An entry in this table describes the present reading of a sensor, the measurement units and scale, and sensor
             operational status.
             Entries are created in this table by the agent. An entry
             for each physical sensor SHOULD be created at the same time
             as the associated entPhysicalEntry. An entry SHOULD be destroyed if the associated entPhysicalEntry is destroyed."
            { entPhysicalIndex }
                                      -- SPARSE-AUGMENTS
    ::= { entPhySensorTable 1 }
EntPhySensorEntry ::= SEQUENCE {
         entPhySensorType
                                         EntitySensorDataType,
         entPhySensorScale
                                         EntitySensorDataScale,
         entPhySensorPrecision
                                         EntitySensorPrecision,
         entPhySensorValue
                                         EntitySensorValue,
         entPhySensorOperStatus
                                         EntitySensorStatus.
         entPhySensorUnitsDisplay
                                         SnmpAdminString,
         entPhySensorValueTimeStamp TimeStamp, entPhySensorValueUpdateRate Unsigned32
}
entPhySensorType OBJECT-TYPE
    SYNTAX
                   EntitySensorDataType
    MAX-ACCESS
                    read-only
    STATUS
                    current
    DESCRIPTION
             "The type of data returned by the associated
             entPhySensorValue object.
             This object SHOULD be set by the agent during entry
             creation, and the value SHOULD NOT change during operation."
    ::= { entPhySensorEntry 1 }
entPhySensorScale OBJECT-TYPE
    SYNTAX
                    EntitySensorDataScale
    MAX-ACCESS
                    read-only
    STATUS
                    current
    DESCRIPTION
             "The exponent to apply to values returned by the associated
             entPhySensorValue object.
             This object SHOULD be set by the agent during entry
             creation, and the value SHOULD NOT change during operation."
    ::= { entPhySensorEntry 2 }
```

```
entPhySensorPrecision OBJECT-TYPE
                  EntitySensorPrecision
    SYNTAX
    MAX-ACCESS
                  read-only
    STATUS
                  current
    DESCRIPTION
            "The number of decimal places of precision in fixed-point
            sensor values returned by the associated entPhySensorValue
            object.
            This object SHOULD be set to '0' when the associated
            entPhySensorType value is not a fixed-point type: e.g.
            'percentRH(9)', 'rpm(10)', 'cmm(11)', or 'truthvalue(12)'.
            This object SHOULD be set by the agent during entry
            creation, and the value SHOULD NOT change during operation."
    ::= { entPhySensorEntry 3 }
entPhySensorValue OBJECT-TYPE
                  EntitySensorValue
    SYNTAX
    MAX-ACCESS
                  read-only
    STATUS
                  current
    DESCRIPTION
            "The most recent measurement obtained by the agent for this
            sensor.
            To correctly interpret the value of this object, the
            associated entPhySensorType, entPhySensorScale, and
            entPhySensorPrecision objects must also be examined."
    ::= { entPhySensorEntry 4 }
entPhySensorOperStatus OBJECT-TYPE
    SYNTAX
                  EntitySensorStatus
    MAX-ACCESS
                  read-only
    STATUS
                  current
    DESCRIPTION
            "The operational status of the sensor."
    ::= { entPhySensorEntry 5 }
entPhySensorUnitsDisplay OBJECT-TYPE
                SnmpAdminString
    SYNTAX
    MAX-ACCESS read-only
    STATUS
                current
    DESCRIPTION
            "A textual description of the data units that should be used
            in the display of entPhySensorValue."
    ::= { entPhySensorEntry 6 }
```

```
entPhySensorValueTimeStamp OBJECT-TYPE
                  TimeStamp
    SYNTAX
    MAX-ACCESS
                  read-only
    STATUS
                  current
    DESCRIPTION
            "The value of sysUpTime at the time the status and/or value
            of this sensor was last obtained by the agent.
    ::= { entPhySensorEntry 7 }
entPhySensorValueUpdateRate OBJECT-TYPE
    SYNTAX
                  Unsigned32
                  "milliseconds"
    UNITS
    MAX-ACCESS
                  read-only
    STATUS
                  current
    DESCRIPTION
            "An indication of the frequency that the agent updates the
            associated entPhySensorValue object, representing in
            milliseconds.
            The value zero indicates:

    the sensor value is updated on demand (e.g.,

                  when polled by the agent for a get-request),
                - the sensor value is updated when the sensor
                  value changes (event-driven),
                - the agent does not know the update rate.
    ::= { entPhySensorEntry 8 }
-- Conformance Section
entitySensorCompliances OBJECT IDENTIFIER
    ::= { entitySensorConformance 1 }
                        OBJECT IDENTIFIER
entitySensorGroups
    ::= { entitySensorConformance 2 }
entitySensorCompliance MODULE-COMPLIANCE
    STATUS current
    DESCRIPTION
            "Describes the requirements for conformance to the Entity
            Sensor MIB module.
    MODULE -- this module
        MANDATORY-GROUPS { entitySensorValueGroup }
```

```
MODULE ENTITY-MIB
        MANDATORY-GROUPS { entityPhysicalGroup }
    ::= { entitySensorCompliances 1 }
-- Object Groups
entitySensorValueGroup OBJECT-GROUP
    OBJECTS {
             entPhySensorType,
             entPhySensorScale,
             entPhySensorPrecision,
             entPhySensorValue,
             entPhySensorOperStatus,
             entPhySensorUnitsDisplay,
             entPhySensorValueTimeStamp,
             entPhySensorValueUpdateRate
    STATUS current
    DESCRIPTION
            "A collection of objects representing physical entity sensor
            information."
    ::= { entitySensorGroups 1 }
```

END

5. Intellectual Property

The IETF takes no position regarding the validity or scope of any intellectual property or other rights that might be claimed to pertain to the implementation or use of the technology described in this document or the extent to which any license under such rights might or might not be available; neither does it represent that it has made any effort to identify any such rights. Information on the IETF's procedures with respect to rights in standards-track and standards-related documentation can be found in BCP-11. Copies of claims of rights made available for publication and any assurances of licenses to be made available, or the result of an attempt made to obtain a general license or permission for the use of such proprietary rights by implementors or users of this specification can be obtained from the IETF Secretariat.

The IETF invites any interested party to bring to its attention any copyrights, patents or patent applications, or other proprietary rights which may cover technology that may be required to practice this standard. Please address the information to the IETF Executive Director.

6. Acknowledgements

This memo is a product of the Entity MIB working group. It is based on an existing proprietary MIB module written by Cliff Sojourner.

7. Normative References

- [RFC2119] Bradner, S., "Key words for use in RFCs to Indicate Requirement Levels", BCP 14, RFC 2119, March 1997.
- [RFC2578] McCloghrie, K., Perkins, D., Schoenwaelder, J., Case, J.,
 Rose, M. and S. Waldbusser, "Structure of Management
 Information Version 2 (SMIv2)", STD 58, RFC 2578, April
 1999.
- [RFC2579] McCloghrie, K., Perkins, D., Schoenwaelder, J., Case, J.,
 Rose, M., and S. Waldbusser, "Textual Conventions for
 SMIv2", STD 58, RFC 2579, April 1999.
- [RFC2580] McCloghrie, K., Perkins, D., Schoenwaelder, J., Case, J.,
 Rose, M. and S. Waldbusser, "Conformance Statements for
 SMIv2", STD 58, RFC 2580, April 1999.
- [RFC2737] McCloghrie, K. and A. Bierman, "Entity MIB (Version 2)", RFC 2737, December 1999.
- [RFC3414] Blumenthal, U. and B. Wijnen, "User-based Security Model (USM) for version 3 of the Simple Network Management Protocol (SNMPv3)", STD 62, RFC 3414, December 2002.
- [RFC3415] Wijnen, B., Presuhn, R. and K. McCloghrie, "View-based Access Control Model (VACM) for the Simple Network Management Protocol (SNMP)", STD 62, RFC 3415, December 2002.

8. Informative References

- [RFC2819] Waldbusser, S., "Remote network Monitoring Management Information Base", RFC 2819, May 2000.
- [RFC3410] Case, J., Mundy, R., Partain, D. and B. Stewart, "Introduction and Applicability Statements for Internet-Standard Management Framework", RFC 3410, December 2002.

9. Security Considerations

There is one managed object in this MIB that may contain sensitive information. This is:

entPhySensorValue

This object may expose the values of particular physical sensors for a device.

SNMPv1 by itself is not a secure environment. Even if the network itself is secure (for example by using IPSec), there is no control as to who on the secure network is allowed to access and GET/SET (read/change/create/delete) the objects in this MIB.

It is recommended that the implementors consider the security features as provided by the SNMPv3 framework. Specifically, the use of the User-based Security Model STD 62, RFC 3414 [RFC3414] and the View-based Access Control Model STD 62, RFC 3415 [RFC3415] is recommended.

It is then a customer/user responsibility to ensure that the SNMP entity giving access to an instance of this MIB, is properly configured to give access to only the objects, and those principals (users) that have legitimate rights to indeed GET or SET (change/create/delete) them.

10. Authors' Addresses

Andy Bierman Cisco Systems, Inc. 170 West Tasman Drive San Jose, CA USA 95134 Phone: +1 408-527-3711 EMail: abierman@cisco.com

Dan Romascanu Avaya Inc. Atidim Technology Park, Bldg. #3 Tel Aviv, 61131, Israel Phone: +972-3-545-8414 EMail: dromasca@avaya.com

K.C. Norseth L-3 Communications 640 N. 2200 West. Salt Lake City, Utah 84116-0850 Phone: +1 801-594-2809 EMail: kenyon.c.norseth@L-3com.com

11. Full Copyright Statement

Copyright (C) The Internet Society (2002). All Rights Reserved.

This document and translations of it may be copied and furnished to others, and derivative works that comment on or otherwise explain it or assist in its implementation may be prepared, copied, published and distributed, in whole or in part, without restriction of any kind, provided that the above copyright notice and this paragraph are included on all such copies and derivative works. However, this document itself may not be modified in any way, such as by removing the copyright notice or references to the Internet Society or other Internet organizations, except as needed for the purpose of developing Internet standards in which case the procedures for copyrights defined in the Internet Standards process must be followed, or as required to translate it into languages other than English.

The limited permissions granted above are perpetual and will not be revoked by the Internet Society or its successors or assigns.

This document and the information contained herein is provided on an "AS IS" basis and THE INTERNET SOCIETY AND THE INTERNET ENGINEERING TASK FORCE DISCLAIMS ALL WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY WARRANTY THAT THE USE OF THE INFORMATION HEREIN WILL NOT INFRINGE ANY RIGHTS OR ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

Acknowledgement

Funding for the RFC Editor function is currently provided by the Internet Society.