Network Working Group Request for Comments: 1471 F. Kastenholz FTP Software, Inc. June 1993

The Definitions of Managed Objects for the Link Control Protocol of the Point-to-Point Protocol

Status of this Memo

This RFC specifies an IAB standards track protocol for the Internet community, and requests discussion and suggestions for improvements. Please refer to the current edition of the "IAB Official Protocol Standards" for the standardization state and status of this protocol. Distribution of this memo is unlimited.

Abstract

This memo defines a portion of the Management Information Base (MIB) for use with network management protocols in TCP/IP-based internets. In particular, it describes managed objects used for managing the Link Control Protocol and Link Quality Monitoring on subnetwork interfaces that use the family of Point-to-Point Protocols [8, 9, 10, 11, & 12].

Table of Contents

1. The Network Management Framework	2
2. Objects	2
2.1 Format of Definitions	2
3. Overview	2
3.1 Object Selection Criteria	2
3.2 Structure of the PPP	3
3.3 MIB Groups	4
3.4 Relationship to Interface and Interface Extensions	
Groups	5
4. Definitions	6
4.1 PPP Link Group	7
4.2 PPP LQR Group	16
4.3 PPP LQR Extensions Group	21
4.4 PPP Tests	22
4.4.1 PPP Echo Test	22
4.4.2 PPP Discard Test	23
5. Acknowledgements	23
6. Security Considerations	23
7. References	24
8. Author's Address	25

Kastenholz [Page 1]

The Network Management Framework

The Internet-standard Network Management Framework consists of three components. They are:

STD 16/RFC 1155 which defines the SMI, the mechanisms used for describing and naming objects for the purpose of management. STD 16/RFC 1212 defines a more concise description mechanism, which is wholly consistent with the SMI.

STD 17/RFC 1213 which defines MIB-II, the core set of managed objects for the Internet suite of protocols.

STD 15/RFC 1157 which defines the SNMP, the protocol used for network access to managed objects.

The Framework permits new objects to be defined for the purpose of experimentation and evaluation.

2. Objects

Managed objects are accessed via a virtual information store, termed the Management Information Base or MIB. Objects in the MIB are defined using the subset of Abstract Syntax Notation One (ASN.1) [3] defined in the SMI. In particular, each object type is named by an OBJECT IDENTIFIER, an administratively assigned name. The object type together with an object instance serves to uniquely identify a specific instantiation of the object. For human convenience, we often use a textual string, termed the descriptor, to refer to the object type.

2.1. Format of Definitions

Section 4 contains the specification of all object types contained in this MIB module. The object types are defined using the conventions defined in the SMI, as amended by the extensions specified in [5,6].

3. Overview

3.1. Object Selection Criteria

To be consistent with IAB directives and good engineering practice, an explicit attempt was made to keep this MIB as simple as possible. This was accomplished by applying the following criteria to objects proposed for inclusion:

(1) Require objects be essential for either fault or configuration management. In particular, objects for

Kastenholz [Page 2]

which the sole purpose was to debug implementations were explicitly excluded from the MIB.

- (2) Consider evidence of current use and/or utility.
- (3) Limit the total number of objects.
- (4) Exclude objects which are simply derivable from others in this or other MIBs.

3.2. Structure of the PPP

This section describes the basic model of PPP used in developing the PPP MIB. This information should be useful to the implementor in understanding some of the basic design decisions of the MIB.

The PPP is not one single protocol but a large family of protocols. Each of these is, in itself, a fairly complex protocol. The PPP protocols may be divided into three rough categories:

Control Protocols

The Control Protocols are used to control the operation of the PPP. The Control Protocols include the Link Control Protocol (LCP), the Password Authentication Protocol (PAP), the Link Quality Report (LQR), and the Challenge Handshake Authentication Protocol (CHAP).

Network Protocols

The Network Protocols are used to move the network traffic over the PPP interface. A Network Protocol encapsulates the datagrams of a specific higher-layer protocol that is using the PPP as a data link. Note that within the context of PPP, the term "Network Protocol" does not imply an OSI Layer-3 protocol; for instance, there is a Bridging network protocol.

Network Control Protocols (NCPs)

The NCPs are used to control the operation of the Network Protocols. Generally, each Network Protocol has its own Network Control Protocol; thus, the IP Network Protocol has its IP Control Protocol, the Bridging Network Protocol has its Bridging Network Control Protocol and so on.

This document specifies the objects used in managing one of these protocols, namely the Link Control Protocol and Link Quality Monitoring Protocol.

Kastenholz [Page 3]

3.3. MIB Groups

Objects in this MIB are arranged into several MIB groups. Each group is organized as a set of related objects.

These groups are the basic unit of conformance: if the semantics of a group are applicable to an implementation then all objects in the group must be implemented.

The PPP MIB is organized into several MIB Groups, including, but not limited to, the following groups:

- o The PPP Link Group
- o The PPP LQR Group
 o The PPP LQR Extensions Group
 o The PPP IP Group
- o The PPP Bridge Group
- o The PPP Security Group

This document specifies the following groups:

The PPP Link Group

This group represents the lowest "level" of the PPP protocol.

This group contains two tables, one containing status information and the other configuration information. The configuration table is split off of the status so that it may be placed in a separate MIB View for security purposes.

Implementation of this group is mandatory for all PPP implementations.

The PPP LQR Group

This group provides the basic MIB variables that apply to the PPP LQR Protocol. This group provides MIB access to the information required for LQR processing. This group contains two tables, one containing status information and the other configuration information. The configuration table is split off of the status so that it may be placed in a separate MIB View for security purposes.

Implementation of the PPP LQR Group is mandatory for all PPP implementations that implement LQR.

The PPP LQR Extensions Group

The PPP LQR Extensions group contains the most recently received LQR packet, as well as the "save" fields that are "logically appended" [12] to received LQR packets. This is done in order to

Kastenholz [Page 4] facilitate external implementations of the Link Quality Monitoring policies.

It is not practical to examine the relevant MIB objects which are used to generate LQR packets since LQR policies may require synchronization of the values of all data used to determine Link Quality; i.e., the values of the relevant counters must all be taken at the same instant in time. Thus, by recording the last received LQR packet, a synchronized record of the relevant data is available.

As this information may not be efficiently maintained on all PPP implementations, implementation of this group is optional.

3.4. Relationship to Interface and Interface Extensions Groups

The PPP Mib is a medium-specific extension to the standard MIB-2 interface group [2] and to the Interface Extensions MIB [7]. This section discusses certain components of these groups when the interface is a PPP interface.

The PPP interface represents a single interface in the sense used in [2] and thus has a single entry in the ifTable.

Furthermore, the PPP interface may be operating over a lower layer hardware interface (such as an RS-232 port). It is important to capture the relationship between the PPP interface and the lower-layer interface over which it operates. This MIB presumes that the lower-layer interface has an ifEntry associated with it. The lower-layer ifEntry is identified via the pppLinkStatusPhysicalIndex object, which contains the value of ifIndex for the lower-layer ifEntry.

For example, suppose that you run PPP over a RS-232 port. This would use two entries in the ifTable. Let's suppose that entry number 123 is for the PPP "interface" and entry number 987 is for the RS-232 port. So, ifSpecific.123 would contain the ppp OBJECT IDENTIFIER, pppLinkStatusPhysicalIndex.123 would contain 987, and ifSpecific.987 would contain the rs_232 OBJECT IDENTIFIER (or whatever it is).

All PPP packets are defined in [8] as being broadcast packets. Thus, the packets are counted as non-unicast packets in the ifTable (ifInNUcastPkts and ifOutNUCastPkts) and as broadcasts in the ifExtnsTable (ifExtnsBroadcastsReceivedOks and ifExtnsBroadcastsTransmittedOks).

Kastenholz [Page 5]

ifSpecific

Contains the OBJECT IDENTIFIER ppp.

ifAdminStatus

Setting this object to up will inject an administrative open event into the LCP's finite state machine. Setting this object to down will inject an administrative close event into the LCP's finite state machine.

The use of the testing value is beyond the scope of this document.

ifOperStatus

Represents the state of the LCP Finite State Machine. If the Finite State Machine is in the Opened state then the value of ifOperStatus is up, otherwise the value of ifOperStatus is down.

The meaning of the testing value is beyond the scope of this document.

Per the SNMP Protocol Specification [13], the linkUp and linkDown traps apply to the PPP Protocol entity. When the LCP's Finite State Machine attains the Opened state, a linkUp trap should be sent. When the Finite State Machine leaves the Opened state, a linkDown trap should be sent.

Some tests for the link are defined in this document. Execution of these tests does not place the link's ifOperStatus in the testing state as these tests do not prevent normal data transmission from occuring over the link.

4. Definitions

```
PPP-LCP-MIB DEFINITIONS ::= BEGIN

IMPORTS

Counter
FROM RFC1155-SMI
ifIndex, transmission
FROM RFC1213-MIB
OBJECT-TYPE
FROM RFC-1212;

-- PPP MIB

ppp OBJECT IDENTIFIER ::= { transmission 23 }

pppLcp OBJECT IDENTIFIER ::= { ppp 1 }
```

Kastenholz [Page 6]

```
-- The individual groups within the PPP-LCP-MIB
     pppLink
                  OBJECT IDENTIFIER ::= { pppLcp 1 }
                  OBJECT IDENTIFIER ::= { pppLcp 2 }
     pppLqr
                  OBJECT IDENTIFIER ::= { pppLcp 3 }
     pppTests
-- 4.1. PPP Link Group
-- The PPP Link Group. Implementation of this
-- group is mandatory for all PPP entities.
-- The following object reflect the values of the option
-- parameters used in the PPP Link Control Protocol
     pppLinkStatusLocalMRU
     pppLinkStatusRemoteMRU
     pppLinkStatusLocalToPeerACCMap
     pppLinkStatusPeerToLocalACCMap
     pppLinkStatusLocalToRemoteProtocolCompression
     pppLinkStatusRemoteToLocalProtocolCompression
___
--
     pppLinkStatusLocalToRemoteACCompression
     pppLinkStatusRemoteToLocalACCompression
     pppLinkStatusTransmitFcsSize
___
___
     pppLinkStatusReceiveFcsSize
-- These values are not available until after the PPP Option
-- negotiation has completed, which is indicated by the link
-- reaching the open state (i.e., ifOperStatus is set to
-- up).
--
-- Therefore, when ifOperStatus is not up
-- the contents of these objects is undefined. The value
-- returned when accessing the objects is an implementation
-- dependent issue.
SEQUENCE OF PppLinkStatusEntry
     SYNTAX
     ACCESS
               not-accessible
     STATUS
               mandatory
     DESCRIPTION
               "A table containing PPP-link specific variables
               for this PPP implementation.'
     ::= { pppLink 1 }
```

Kastenholz [Page 7]

```
pppLinkStatusEntry
                     OBJECT-TYPE
               PppLinkStatusEntry
     SYNTAX
     ACCESS
               not-accessible
     STATUS
               mandatory
     DESCRIPTION
               "Management information about a particular PPP
               Link.
               { ifIndex }
     INDEX
     ::= { pppLinkStatusTable 1 }
PppLinkStatusEntry ::= SEQUENCE {
     pppLinkStatusPhysicalIndex
          INTEGER,
     pppLinkStatusBadAddresses
          Counter,
     pppLinkStatusBadControls
          Counter,
     pppLinkStatusPacketTooLongs
          Counter,
     pppLinkStatusBadFCSs
          Counter,
     pppLinkStatusLocalMRU
          INTEGER.
     pppLinkStatusRemoteMRU
          INTEGER,
     pppLinkStatusLocalToPeerACCMap
          OCTET STRING,
     pppLinkStatusPeerToLocalACCMap
          OCTET STRING,
     pppLinkStatusLocalToRemoteProtocolCompression
          INTEGER,
     pppLinkStatusRemoteToLocalProtocolCompression
          INTEGER,
     pppLinkStatusLocalToRemoteACCompression
          INTEGER,
     pppLinkStatusRemoteToLocalACCompression
          INTEGER,
     pppLinkStatusTransmitFcsSize
          INTEGER,
     pppLinkStatusReceiveFcsSize
          INTEGER
pppLinkStatusPhysicalIndex
                              OBJECT-TYPE
               INTEGER(0..2147483647)
     SYNTAX
     ACCESS
               read-only
     STATUS
               mandatory
     DESCRIPTION
```

Kastenholz [Page 8]

"The value of ifIndex that identifies the lower-level interface over which this PPP Link is operating. This interface would usually be an HDLC or RS-232 type of interface. If there is no lower-layer interface element, or there is no ifEntry for the element, or the element can not be identified, then the value of this object is 0. For example, suppose that PPP is operating over a serial port. This would use two entries in the ifTable. The PPP could be running over `interface' number 123 and the serial port could be running over `interface' number 987. Therefore, ifSpecific.123 would contain the OBJECT IDENTIFIER ppp pppLinkStatusPhysicalIndex.123 would contain 987, and ifSpecific.987 would contain the OBJECT IDENTIFIER for the serial-port's media-specific MIB."

::= { pppLinkStatusEntry 1 }

SYNTAX Counter
ACCESS read-only
STATUS mandatory

DESCRIPTION

"The number of packets received with an incorrect Address Field. This counter is a component of the ifInErrors variable that is associated with the interface that represents this PPP Link."

REFERENCE

"Section 3.1, Address Field, of RFC1331."
::= { pppLinkStatusEntry 2 }

SYNTAX Counter ACCESS read-only STATUS mandatory DESCRIPTION

"The number of packets received on this link with an incorrect Control Field. This counter is a component of the ifInErrors variable that is associated with the interface that represents this PPP Link."

REFERENCE

"Section 3.1, Control Field, of RFC1331."

Kastenholz [Page 9]

```
::= { pppLinkStatusEntry 3 }
pppLinkStatusPacketTooLongs
                                 OBJECT-TYPE
     SYNTAX
                Counter
     ACCESS
                read-only
     STATUS
                mandatory
     DESCRIPTION
                "The number of received packets that have been discarded because their length exceeded the
                MRU. This counter is a component of the
                ifInErrors variable that is associated with the
                interface that represents this PPP Link. NOTE, packets which are longer than the MRU but which
                are successfully received and processed are NOT
                included in this count."
     ::= { pppLinkStatusEntry 4 }
SYNTAX
                Counter
     ACCESS
                read-only
     STATUS
                mandatory
     DESCRIPTION
                "The number of received packets that have been
                discarded due to having an incorrect FCS. This
                counter is a component of the ifInErrors variable that is associated with the interface
                that represents this PPP Link.'
     ::= { pppLinkStatusEntry 5 }
                          OBJECT-TYPE
pppLinkStatusLocalMRU
                INTEGER(1..2147483648)
     SYNTAX
     ACCESS
                read-only
     STATUS
                mandatory
     DESCRIPTION
                "The current value of the MRU for the local PPP
                Entity. This value is the MRU that the remote
                entity is using when sending packets to the
                local PPP entity. The value of this object is
                meaningful only when the link has reached the
                open state (ifOperStatus is up).'
     ::= { pppLinkStatusEntry 6 }
pppLinkStatusRemoteMRU
                           OBJECT-TYPE
     SYNTAX
                INTEGER(1..2147483648)
```

Kastenholz [Page 10]

```
ACCESS
                  read-only
      STATUS
                  mandatory
      DESCRIPTION
                  "The current value of the MRU for the remote
                  PPP Entity. This value is the MRU that the
                 local entity is using when sending packets to
the remote PPP entity. The value of this object
is meaningful only when the link has reached
                  the open state (ifOperStatus is up).
      ::= { pppLinkStatusEntry 7 }
pppLinkStatusLocalToPeerACCMap
                                       OBJECT-TYPE
                  OCTET STRING (SIZE (4))
      SYNTAX
      ACCESS
                  read-only
      STATUS
                  mandatory
      DESCRIPTION
                  "The current value of the ACC Map used for
                  sending packets from the local PPP entity to
                  the remote PPP entity. The value of this object
                  is meaningful only when the link has reached
                  the open state (ifOperStatus is up).
      ::= { pppLinkStatusEntry 8 }
pppLinkStatusPeerToLocalACCMap
                                       OBJECT-TYPE
                  OCTET STRING (SIZE (4))
      SYNTAX
                  read-only
      ACCESS
      STATUS
                  mandatory
      DESCRIPTION
                 "The ACC Map used by the remote PPP entity when transmitting packets to the local PPP entity. The value of this object is meaningful only
                 when the link has reached the open state
                  (ifOperStatus is up).'
      ::= { pppLinkStatusEntry 9 }
pppLinkStatusLocalToRemoteProtocolCompression
     OBJECT-TYPE
      SYNTAX
                  INTEGER {
                  enabled(1)
                  disabled(2)
      ACCESS
                  read-only
      STATUS
                 mandatory
      DESCRIPTION
                  "Indicates whether the local PPP entity will
```

Kastenholz [Page 11]

```
use Protocol Compression when transmitting
                 packets to the remote PPP entity. The value of
                 this object is meaningful only when the link
                 has reached the open state (ifOperStatus is
                 up)."
      ::= { pppLinkStatusEntry 10 }
pppLinkStatusRemoteToLocalProtocolCompression
     OBJECT-TYPE
     SYNTAX
                 INTEGER {
                 enabled(1)
                 disabled(2)
     ACCESS
                 read-only
     STATUS
                 mandatory
     DESCRIPTION
                 "Indicates whether the remote PPP entity will
                 use Protocol Compression when transmitting
                 packets to the local PPP entity. The value of this object is meaningful only when the link has reached the open state (ifOperStatus is
                 up)."
      ::= { pppLinkStatusEntry 11 }
pppLinkStatusLocalToRemoteACCompression
                                                OBJECT-TYPE
                 INTEGER {
     SYNTAX
                 enabled(1)
                 disabled(2)
     ACCESS
                 read-only
                 mandatory
     STATUS
     DESCRIPTION
                 "Indicates whether the local PPP entity will
                 use Address and Control Compression when
                 transmitting packets to the remote PPP entity. The value of this object is meaningful only
                 when the link has reached the open state
                 (ifOperStatus is up)."
      ::= { pppLinkStatusEntry 12 }
pppLinkStatusRemoteToLocalACCompression
                                                OBJECT-TYPE
     SYNTAX
                 INTEGER {
                 enabled(1)
                 disabled(2)
           }
```

Kastenholz [Page 12]

```
ACCESS
                read-only
     STATUS
                mandatory
     DESCRIPTION
                "Indicates whether the remote PPP entity will
                use Address and Control Compression when
                transmitting packets to the local PPP entity. The value of this object is meaningful only
                when the link has reached the open state
                (ifOperStatus is up)."
     ::= { pppLinkStatusEntry 13
pppLinkStatusTransmitFcsSize
                                  OBJECT-TYPE
                INTEGER (0..128)
     SYNTAX
     ACCESS
                read-only
     STATUS
                mandatory
     DESCRIPTION
                "The size of the Frame Check Sequence (FCS) in
                bits that the local node will generate when
                sending packets to the remote node. The value
                of this object is meaningful only when the link
                has reached the open state (ifOperStatus is
                up).'
     ::= { pppLinkStatusEntry 14 }
INTEGER (0..128)
     SYNTAX
     ACCESS
                read-only
     STATUS
                mandatory
     DESCRIPTION
                "The size of the Frame Check Sequence (FCS) in
                bits that the remote node will generate when
                sending packets to the local node. The value of this object is meaningful only when the link
                has reached the open state (ifOperStatus is
                up).'
     ::= { pppLinkStatusEntry 15 }
pppLinkConfigTable
                       OBJECT-TYPE
                SEQUENCE OF PppLinkConfigEntry
     SYNTAX
     ACCESS
                not-accessible
     STATUS
                mandatory
     DESCRIPTION
                "A table containing the LCP configuration
                parameters for this PPP Link. These variables represent the initial configuration of the PPP
```

Kastenholz [Page 13]

```
Link. The actual values of the parameters may
               be changed when the link is brought up via the
               LCP options negotiation mechanism.'
     ::= { pppLink 2 }
pppLinkConfigEntry OBJECT-TYPE
               PppLinkConfigEntry
     SYNTAX
     ACCESS
               not-accessible
               mandatory
     STATUS
     DESCRIPTION
               "Configuration information about a particular
               PPP Link."
               { ifIndex }
     INDEX
     ::= { pppLinkConfigTable 1 }
PppLinkConfigEntry ::= SEQUENCE {
     pppLinkConfigInitialMRU
          INTEGER,
     pppLinkConfigReceiveACCMap
          OCTET STRING,
     pppLinkConfigTransmitACCMap
          OCTET STRING.
     pppLinkConfigMagicNumber
          INTEGER,
     pppLinkConfigFcsSize
          INTEGER
pppLinkConfigInitialMRU
                          OBJECT-TYPE
               INTEGER(0..2147483647)
     SYNTAX
     ACCESS
               read-write
     STATUS
               mandatorv
     DESCRIPTION
               "The initial Maximum Receive Unit (MRU) that
               the local PPP entity will advertise to the
               remote entity. If the value of this variable is
               O then the local PPP entity will not advertise
               any MRU to the remote entity and the default
               MRÚ will be assumed. Changing this object will
               have effect when the link is next restarted."
     REFERENCE
               "Section 7.2, Maximum Receive Unit of RFC1331."
               { 1500 }
     DEFVAL
     ::= { pppLinkConfigEntry 1 }
```

Kastenholz [Page 14]

```
pppLinkConfigReceiveACCMap
                                 OBJECT-TYPE
                 OCTET STRING (SIZE (4))
     SYNTAX
     ACCESS
                 read-write
     STATUS
                 mandatory
     DESCRIPTION
                 "The Asynchronous-Control-Character-Map (ACC)
                 that the local PPP entity requires for use on its receive side. In effect, this is the ACC
                 Map that is required in order to ensure that
                 the local modem will successfully receive all
                 characters. The actual ACC map used on the
                 receive side of the link will be a combination
                 of the local node's pppLinkConfigReceiveACCMap and the remote node's
                 pppLinkConfigTransmitACCMap. Changing this
                 object will have effect when the link is next
                 restarted.'
     REFERENCE
                 "Section 7.3, page 4, Async-Control-Character-
                 Map of RFC1331."
                   <sup>'</sup>ffffffff'h }
     DEFVAL
      ::= { pppLinkConfigEntry 2 }
pppLinkConfigTransmitACCMap
                                  OBJECT-TYPE
                 OCTET STRING (SIZE (4))
     SYNTAX
     ACCESS
                 read-write
     STATUS
                 mandatory
     DESCRIPTION
                 "The Asynchronous-Control-Character-Map (ACC)
                 that the local PPP entity requires for use on
                 its transmit side. In effect, this is the ACC Map that is required in order to ensure that
                 all characters can be successfully transmitted
                 through the local modem. The actual ACC map used on the transmit side of the link will be a
                 combination of the local node's
                 pppLinkConfigTransmitACCMap and the remote
                 node's pppLinkConfigReceiveACCMap. Changing
                 this object will have effect when the link is
                 next restarted."
     REFERENCE
                 "Section 7.3, page 4, Async-Control-Character-
                 Map of RFC1331.
                    'ffffffffh }
     DEFVAL
     ::= { pppLinkConfigEntry 3 }
```

Kastenholz [Page 15]

```
pppLinkConfigMagicNumber
                           OBJECT-TYPE
                INTEGER {false (1), true (2)}
     SYNTAX
     ACCESS
                read-write
     STATUS
                mandatory
     DESCRIPTION
                "If true(2) then the local node will attempt to
                perform Magic Number negotiation with the remote node. If false(1) then this negotiation
                is not performed. In any event, the local node
                will comply with any magic number negotiations
                attempted by the remote node, per the PPP
                specification. Changing this object will have
                effect when the link is next restarted."
     REFERENCE
                "Section 7.6, Magic Number, of RFC1331."
     DEFVAL
                { false }
     ::= { pppLinkConfigEntry 4 }
pppLinkConfigFcsSize OBJECT-TYPE
                INTEGER (0..128)
     SYNTAX
     ACCESS
                read-write
     STATUS
                mandatory
     DESCRIPTION
                "The size of the FCS, in bits, the local node
                will attempt to negotiate for use with the
                remote node. Regardless of the value of this object, the local node will comply with any FCS
                size negotiations initiated by the remote node,
                per the PPP specification. Changing this object
                will have effect when the link is next
                restarted."
     DEFVAL
                { 16 }
     ::= { pppLinkConfigEntry 5 }
-- 4.2.
         PPP LQR Group
     -- The PPP LQR Group.
     -- Implementation of this group is mandatory for all
     -- PPP implementations that implement LQR.
pppLqrTable
               OBJECT-TYPE
                SEQUENCE OF PppLqrEntry
     SYNTAX
     ACCESS
                not-accessible
```

Kastenholz [Page 16]

```
STATUS
                mandatory
     DESCRIPTION
                "Table containing the LQR parameters and
                statistics for the local PPP entity.'
     ::= { pppLqr 1 }
               OBJECT-TYPE
pppLqrEntry
     SYNTAX
                PppLqrEntry
                not-accessible
     ACCESS
     STATUS
                mandatory
     DESCRIPTION
                "LQR information for a particular PPP link. A
                PPP link will have an entry in this table if
                and only if LQR Quality Monitoring has been
                successfully negotiated for said link.
                { ifIndex }
     INDEX
     ::= { pppLqrTable 1 }
PppLqrEntry ::= SEQUENCE {
     pppLqrQuality
           INTEGER,
     pppLqrInGoodOctets
          Counter,
     pppLqrLocalPeriod
          INTEGER.
     pppLqrRemotePeriod
           INTEGER,
     pppLqr0utLQRs
          Counter,
     pppLqrInLQRs
          Counter
}
pppLqrQuality
                 OBJECT-TYPE
     SYNTAX
                INTEGER {
                good(1),
                bad(2),
                not-determined(3)
     ACCESS
                read-only
     STATUS
                mandatory
     DESCRIPTION
                "The current quality of the link as declared by
                the local PPP entity's Link-Quality Management modules. No effort is made to define good or
                bad, nor the policy used to determine it. The
```

Kastenholz [Page 17]

```
not-determined value indicates that the entity does not actually evaluate the link's quality.
                This value is used to disambiguate the
                 determined to be good' case from the `no
                determination made and presumed to be good'
                case."
     ::= { pppLqrEntry 1 }
                      OBJECT-TYPE
pppLqrInGoodOctets
     SYNTAX
                Counter
     ACCESS
                read-only
     STATUS
                mandatory
     DESCRIPTION
                "The LQR InGoodOctets counter for this link."
     REFERENCE
                "Section 2.2, Counters, of RFC1333."
     ::= { pppLqrEntry 2 }
pppLqrLocalPeriod
                     OBJECT-TYPE
     SYNTAX
                INTEGER(1..2147483648)
     ACCESS
                read-only
     STATUS
                mandatory
     DESCRIPTION
                "The LQR reporting period, in hundredths of a
                second that is in effect for the local PPP
                entity."
     REFERENCE
                "Section 2.5, Configuration Option Format, of
                RFC1333."
     ::= { pppLqrEntry 3 }
pppLqrRemotePeriod
                      OBJECT-TYPE
     SYNTAX
                INTEGER(1..2147483648)
     ACCESS
                read-only
                mandatory
     STATUS
     DESCRIPTION
                "The LQR reporting period, in hundredths of a
                second, that is in effect for the remote PPP entity."
     REFERENCE
                "Section 2.5, Configuration Option Format, of
                RFC1333."
     ::= { pppLqrEntry 4 }
```

Kastenholz [Page 18]

```
pppLqrOutLQRs
                OBJECT-TYPE
               Counter
     SYNTAX
     ACCESS
               read-only
     STATUS
               mandatory
     DESCRIPTION
               "The value of the OutLQRs counter on the local
               node for the link identified by ifIndex.'
     REFERENCE
               "Section 2.2, Counters, of RFC1333."
     ::= { pppLqrEntry 5 }
               OBJECT-TYPE
pppLqrInLQRs
     SYNTAX
               Counter
     ACCESS
               read-only
     STATUS
               mandatory
     DESCRIPTION
               "The value of the InLQRs counter on the local
               node for the link identified by ifIndex."
     REFERENCE
               "Section 2.2, Counters, of RFC1333."
     ::= { pppLqrEntry 6 }
-- The PPP LQR Configuration table.
pppLqrConfigTable
                    OBJECT-TYPE
               SEQUENCE OF PppLqrConfigEntry
     SYNTAX
     ACCESS
               not-accessible
     STATUS
               mandatory
     DESCRIPTION
               "Table containing the LQR Configuration
               parameters for the local PPP entity.'
     ::= { pppLqr 2 }
pppLqrConfigEntry
                    OBJECT-TYPE
     SYNTAX
               PppLqrConfigEntry
     ACCESS
               not-accessible
     STATUS
               mandatory
     DESCRIPTION
               "LQR configuration information for a particular
               PPP link."
     INDEX
               { ifIndex }
     ::= { pppLqrConfigTable 1 }
```

Kastenholz [Page 19]

```
PppLqrConfigEntry ::= SEQUENCE {
     pppLqrConfigPeriod
          INTEGER,
     pppLqrConfigStatus
          INTEGER
}
pppLqrConfigPeriod
                     OBJECT-TYPE
     SYNTAX
               INTEGER(0..2147483647)
     ACCESS
               read-write
     STATUS
               mandatory
     DESCRIPTION
               "The LQR Reporting Period that the local PPP
               entity will attempt to negotiate with the
               remote entity, in units of hundredths of a
               second. Changing this object will have effect
               when the link is next restarted.'
     REFERENCE
               "Section 2.5, Configuration Option Format, of
               RFC1333."
     DEFVAL
               { 0 }
     ::= { pppLqrConfigEntry 1 }
pppLgrConfigStatus
                     OBJECT-TYPE
               INTEGER {disabled (1), enabled (2)}
     SYNTAX
               read-write
     ACCESS
     STATUS
               mandatory
     DESCRIPTION
               "If enabled(2) then the local node will attempt
               to perform LQR negotiation with the remote
               node. If disabled(1) then this negotiation is
               not performed. In any event, the local node
               will comply with any magic number negotiations
               attempted by the remote node, per the PPP
               specification. Changing this object will have
               effect when the link is next restarted.
               Setting this object to the value disabled(1)
               has the effect of invalidating the
               corresponding entry in the pppLqrConfigTable
               object. It is an implementation-specific matter
               as to whether the agent removes an invalidated
               entry from the table. Accordingly, management
               stations must be prepared to receive tabular
               information from agents that corresponds to
               entries not currently in use."
     REFERENCE
               "Section 7.6, Magic Number, of RFC1331."
```

Kastenholz [Page 20]

```
DEFVAL
              { enabled }
     ::= { pppLqrConfigEntry 2 }
-- 4.3. PPP LQR Extensions Group
-- The PPP LQR Extensions Group.
-- Implementation of this group is optional.
-- The intent of this group is to allow external
-- implementation of the policy mechanisms that
-- are used to declare a link to be "bad" or not.
-- It is not practical to examine the MIB objects
-- which are used to generate LQR packets since
-- LQR policies tend to require synchronization of
-- the values of all data used to determine Link
-- Quality; i.e. the values of the relevant counters -- must all be taken at the same instant in time.
pppLqrExtnsTable
                    OBJECT-TYPE
     SYNTAX
                SEQUENCE OF PppLqrExtnsEntry
                not-accessible
     ACCESS
     STATUS
                mandatory
     DESCRIPTION
                "Table containing additional LQR information
                for the local PPP entity.'
     ::= { pppLqr 3 }
pppLqrExtnsEntry
                  OBJECT-TYPE
     SYNTAX
                PppLqrExtnsEntry
     ACCESS
                not-accessible
     STATUS
                mandatory
     DESCRIPTION
                "Extended LQR information for a particular PPP
                link. Assuming that this group has been
                implemented, a PPP link will have an entry in this table if and only if LQR Quality
                Monitoring has been successfully negotiated for
                said link.
     INDEX
                { ifIndex }
     ::= { pppLqrExtnsTable 1 }
PppLqrExtnsEntry ::= SEQUENCE {
```

Kastenholz [Page 21]

```
pppLqrExtnsLastReceivedLqrPacket
           OCTET STRING(SIZE(68))
}
pppLgrExtnsLastReceivedLgrPacket OBJECT-TYPE
     SYNTAX
                OCTET STRING(SIZE(68))
     ACCESS
                read-only
     STATUS
                mandatory
     DESCRIPTION
                 "This object contains the most recently
                received LQR packet. The format of the packet
                is as described in the LQM Protocol
                specificiation. All fields of the packet, including the `save' fields, are stored in this
                object.
                The LQR packet is stored in network byte order.
                The LAP-B and PPP headers are not stored in
                this object; the first four octets of this
                variable contain the Magic-Number field, the
                second four octets contain the LastOutLORs field and so on. The last four octets of this
                object contain the SaveInOctets field of the
                LOR packet."
     REFERENCE
                "Section 2.6, Packet Format, of RFC1333"
     ::= { pppLqrExtnsEntry 1 }
         PPP Tests
-- 4.4.
-- The extensions to the interface table in RFC1229 define a
-- table through which the network manager can instruct the
-- managed object to perform various tests of the interface. This
-- is the ifExtnsTestTable.
-- The PPP MIB defines two such tests.
-- 4.4.1.
            PPP Echo Test
-- The PPP Echo Test is defined as
     pppEchoTest
                      OBJECT IDENTIFIER ::= { pppTests 1 }
-- Invoking this test causes a PPP Echo Packet to be sent on the
-- line. ifExtnsTestResult returns success(2) if the echo
-- response came back properly. It returns failed(7) if the -- response did not properly return. The definition of "proper"
```

Kastenholz [Page 22]

- -- in this context is left to the discretion of the implementor.
- -- 4.4.2. PPP Discard Test
- -- The PPP Discard Test is defined as

```
pppDiscardTest OBJECT IDENTIFIER ::= { pppTests 2 }
```

-- Invoking this test causes a PPP Discard Packet to be sent on -- the line. ifExtnsTestResult returns success(2) if the discard -- packet was successfully transmitted and failed(7) if an error -- was detected on transmission. The definition of "transmission -- error" in this context is left to the discretion of the

-- implementor.

END

5. Acknowledgements

This document was produced by the PPP working group. In addition to the working group, the author wishes to thank the following individuals for their comments and contributions:

Bill Simpson -- Daydreamer Glenn McGregor -- Merit Jesse Walker -- DEC Chris Gunner -- DEC

6. Security Considerations

The PPP MIB affords the network operator the ability to configure and control the PPP links of a particular system. This represents a security risk.

These risks are addressed in the following manners:

- (1) All variables which represent a significant security risk are placed in separate, optional, MIB Groups. As the MIB Group is the quantum of implementation within a MIB, the implementor of the MIB may elect not to implement these groups.
- (2) The implementor may choose to implement the variables which present a security risk so that they may not be written, i.e., the variables are READ-ONLY. This method still presents a security risk, and is not recommended, in that the variables, specifically the PPP Authentication Protocols' variables, may be easily read.

Kastenholz [Page 23]

(3) Using SNMPv2, the operator can place the variables into MIB views which are protected in that the parties which have access to those MIB views use authentication and privacy protocols, or the operator may elect to make these views not accessible to any party. In order to facilitate this placement, all security-related variables are placed in separate MIB Tables. This eases the identification of the necessary MIB View Subtree.

7. References

- [1] Rose M., and K. McCloghrie, "Structure and Identification of Management Information for TCP/IP-based internets", STD 16, RFC 1155, Performance Systems International, Hughes LAN Systems, May 1990.
- [2] McCloghrie K., and M. Rose, Editors, "Management Information Base for Network Management of TCP/IP-based internets", STD 17, RFC 1213, Performance Systems International, March 1991.
- [3] Information processing systems Open Systems Interconnection Specification of Abstract Syntax Notation One (ASN.1), International Organization for Standardization, International Standard 8824, December 1987.
- [4] Information processing systems Open Systems Interconnection Specification of Basic Encoding Rules for Abstract Notation One (ASN.1), International Organization for Standardization, International Standard 8825, December 1987.
- [5] Rose, M., and K. McCloghrie, Editors, "Concise MIB Definitions", STD 16, RFC 1212, Performance Systems International, Hughes LAN Systems, March 1991.
- [6] Rose, M., Editor, "A Convention for Defining Traps for use with the SNMP", RFC 1215, Performance Systems International, March 1991.
- [7] McCloghrie, K., "Extensions to the Generic-Interface MIB", RFC 1229, Hughes LAN Systems, Inc., May 1991.
- [8] Simpson, W., "The Point-to-Point Protocol for the Transmission of Multi-protocol Datagrams over Point-to-Point Links, RFC 1331, Daydreamer, May 1992.
- [9] McGregor, G., "The PPP Internet Protocol Control Protocol", RFC 1332, Merit, May 1992.

Kastenholz [Page 24]

- [10] Baker, F., "Point-to-Point Protocol Extensions for Bridging", RFC 1220, ACC, April 1991.
- [11] Lloyd, B., and W. Simpson, "PPP Authentication Protocols", RFC 1334, L&A, Daydreamer, October 1992.
- [12] Simpson, W., "PPP Link Quality Monitoring", RFC 1333, Daydreamer, May 1992.
- [13] Case, J., Fedor, M., Schoffstall, M., and J. Davin, "Simple Network Management Protocol", STD 15, RFC 1157, SNMP Research, Performance Systems International, Performance Systems International, MIT Laboratory for Computer Science, May 1990.

8. Author's Address

Frank Kastenholz FTP Software, Inc. 2 High Street North Andover, Mass 01845 USA

Phone: (508) 685-4000 EMail: kasten@ftp.com

Kastenholz [Page 25]