Network Working Group Request for Comments: 2239 Category: Standards Track K. de Graaf
3Com Corporation
D. Romascanu
Madge Networks Ltd.
D. McMaster
Cisco Systems Inc.
K. McCloghrie
Cisco Systems Inc.
S. Roberts
Farallon Computing, Inc.
November 1997

Definitions of Managed Objects for IEEE 802.3 Medium Attachment Units (MAUs) using SMIv2

Status of this Memo

This document specifies an Internet standards track protocol for the Internet community, and requests discussion and suggestions for improvements. Please refer to the current edition of the "Internet Official Protocol Standards" (STD 1) for the standardization state and status of this protocol. Distribution of this memo is unlimited.

Copyright Notice

Copyright (C) The Internet Society (1997). All Rights Reserved.

Table of Contents

1 The SNMP	v2 Netwo	ork Ma	anag	emer	nt	Fra	ame	WO	rk	•						 •	•	•	2
1.1 Object	Definit	tions				• •													2
2 Overview	•••••																		3
2.1 Relati	onship 1	to RF	C 15	15 .		• •													3
2.2 MAU Ma	nagement	t				• •													3
2.3 Relati	onship 1	to Otl	her	MIBS	5.														3
2.3.1 Rela	tionship	o to	the	MIB-	-II	' 1	int	er	fac	ces	s'	g	ro	up)				3
2.3.2 Rela																			4
2.4 Manage	ment of	Inte	rnal	MAL	Js	• • •													4
3 Definiti	ons															 •		•	4
4 Acknowle	dgements	5														 •		•	39
5 Referenc	es																		40
6 Security	Conside	eratio	ons															•	41
7 Authors'	Address	ses .												•	•	 •	•	•	41
8 Full Cop	yright S	State	nent			• •									•	 •		•	43

Abstract

This memo defines an portion of the Management Information Base (MIB) for use with network management protocols in the Internet community. In particular, it defines objects for managing 10 and 100 Mb/second Medium Attachment Units (MAUs) based on IEEE Std 802.3 Section 30, "10 & 100 Mb/s Management," October 26, 1995.

1. The SNMPv2 Network Management Framework

The SNMPv2 Network Management Framework presently consists of three major components. They are:

- the SMI, described in RFC 1902 [6] the mechanisms used for describing and naming objects for the purpose of management.
- the MIB-II, STD 17, RFC 1213 [5] the core set of managed objects for the Internet suite of protocols.
- the protocol, STD 15, RFC 1157 [10] and/or RFC 1905 [9] the protocol used for accessing managed information.

Textual conventions are defined in RFC 1903 [7], and conformance statements are defined in RFC 1904 [8].

The Framework permits new objects to be defined for the purpose of experimentation and evaluation.

1.1. Object Definitions

Managed objects are accessed via a virtual information store, termed the Management Information Base or MIB. Objects in the MIB are defined using the subset of Abstract Syntax Notation One (ASN.1) defined in the SMI. In particular, each object type is named by an OBJECT IDENTIFIER, an administratively assigned name. The object type together with an object instance serves to uniquely identify a specific instantiation of the object. For human convenience, we often use a textual string, termed the descriptor, to refer to the object type.

2. Overview

Relationship to RFC 1515 2.1.

This MIB is intended to be a superset of that defined by RFC 1515 [11], which will go to historic status. This MIB includes all of the objects contained in that MIB, plus several new ones which provide additional capabilities. Implementors are encouraged to support all applicable conformance groups in order to make the best use of the new functionality provided by this MIB. The new objects provide management support for: management support for:

- management of 100 Mb/s devices
- 0 auto-negotiation on interface MAUs
- iack management 0

2.2. MAU Management

Instances of these object types represent attributes of an IEEE 802.3 MAU. Several types of MAUs are defined in the IEEE 802.3 CSMA/CD standard [1] and [2]. These MAUs may be connected to IEEE 802.3 repeaters or to 802.3 (Ethernet-like) interfaces. For convenience this document refers to these devices as "repeater MAUs" and "interface MAUs."

The definitions presented here are based on Section 30.5, "Layer Management for 10 & 100 Mb/s Medium Attachment Units (MAUs)", and Annex 30A, "GDMO Specifications for 802.3 managed objects" of IEEE Std 802.3u-1995. That specification includes definitions for both 10Mb/s and 100Mb/s devices, and is essentially a superset of the 10Mb/s definitions given by IEEE 802.3 Section 20. This specification is intended to serve the same purpose: to provide for management of both 10Mb/s and 100Mb/s MAUs.

2.3. Relationship to Other MIBs

It is assumed that an agent implementing this MIB will also implement (at least) the 'system' group defined in MIB-II [5]. The following sections identify other MIBs that such an agent should implement.

2.3.1. Relationship to the MIB-II 'interfaces' group

The sections of this document that define interface MAU-related objects specify an extension to the 'interfaces' group of MIB-II. An agent implementing these interface-MAU related objects must also

de Graaf, et. al.

Standards Track

[Page 3]

implement the 'interfaces' group of MIB-II. The value of the object
ifMauIfIndex is the same as the value of 'ifIndex' used to instantiate the interface to which the given MAU is connected.

It is expected that an agent implementing the interface-MAU related objects in this MIB will also implement the Ethernet-like Interfaces MIB, RFC 1650.

(Note that repeater ports are not represented as interfaces in the sense of MIB-II's 'interfaces' group.)

Relationship to the 802.3 Repeater MIB 2.3.2.

The section of this document that defines repeater MAU-related objects specifies an extension to the 802.3 Repeater MIB defined in [4]. An agent implementing these repeater-MAU related objects must also implement the 802.3 Repeater MIB.

The values of 'rpMauGroupIndex' and 'rpMauPortIndex' used to instantiate a repeater MAU variable shall be the same as the values of 'rptrPortGroupIndex' and 'rptrPortIndex' used to instantiate the port to which the given MAU is connected.

2.4. Management of Internal MAUs

In some situations, a MAU can be "internal" -- i.e., its functionality is implemented entirely within a device. For example, a managed repeater may contain an internal repeater- MAU and/or an internal interface-MAU through which management communications originating on one of the repeater's external ports pass in order to reach the management agent associated with the repeater. internal MAUs may or may not be managed. If they are managed, objects describing their attributes should appear in the appropriate MIB subtree:

dot3RpMauBasicGroup for internal repeater-MAUs and dot3IfMauBasicGroup for internal interface-MAUs.

3. Definitions

MAU-MIB DEFINITIONS ::= BEGIN

IMPORTS

Counter32, Integer32, OBJECT-TYPE, MODULE-IDENTITY, NOTIFICATION-TYPE, OBJECT-IDENTITY, mib-2 FROM SNMPv2-SMI TruthValue, TEXTUAL-CONVENTION

de Graaf, et. al.

Standards Track

[Page 4]

```
FROM SNMPv2-TC
    OBJECT-GROUP, MODULE-COMPLIANCE, NOTIFICATION-GROUP
        FROM SNMPv2-CONF;
mauMod MODULE-IDENTITY
    LAST-UPDATED "9710310000Z"
    ORGANIZATION "IETF HUB MIB Working Group"
    CONTACT-INFO
        "WG E-mail: hubmib@hprnd.rose.hp.com
             Chair: Dan Romascanu
            Postal: Madge Networks (Israel) Ltd.
                    Atidim Technology Park, Bldg. 3
                    Tel Aviv 61131, Ísrael
               Tel: 972-3-6458414, 6458458
Fax: 972-3-6487146
            E-mail: dromasca@madge.com
            Editor: Kathryn de Graaf
            Postal: 3Com Corporation
                    118 Turnpike Rd.
                    Southborough, MA
                                       01772
                    USA
               Tel: (508)229-1627
               Fax: (508)490-5882
            E-mail: kdegraaf@isd.3com.com"
    DESCRIPTION
            "Management information for 802.3 MAUs.
            The following references are used throughout this
            MIB module:
            [IEEE 802.3 Std]
               refers to IEEE 802.3/ISO 8802-3 Information
               processing systems - Local area networks -
               Part 3: Carrier sense multiple access with
               collision detection (CSMA/CD) access method
               and physical layer specifications (1993),
               and to IEEE Std 802.3u-1995, Supplement to
               IEEE Std 802.3, clauses 22 through 29.
            [IEEE 802.3 Mgt]
               refers to IEEE 802.3u-1995, - 10 Mb/s &
               100 Mb/s Management, Section 30 -
               Supplement to IEEE Std 802.3."
    ::= { snmpDot3MauMgt 6 }
```

```
snmpDot3MauMgt OBJECT IDENTIFIER ::= { mib-2 26 }
-- textual conventions
JackType ::= TEXTUAL-CONVENTION
    STATUS
                 current
    DESCRIPTION
             "Common enumeration values for repeater and
             interface MAU jack types.'
    SYNTAX
                 INTEGER {
                     other(1),
                     rj45(2)
                     rj45S(3), -- rj45 shielded
                     db9(4),
                     bnc(5),
                     fAUI(6),
                               -- female aui
                     mAUI(7),
fiberSC(8)
                                 -- male aui
                     fiberMIC(9),
                     fiberST(10),
                     telco(11)
                 }
                               OBJECT IDENTIFIER ::= { snmpDot3MauMgt 1 }
OBJECT IDENTIFIER ::= { snmpDot3MauMgt 2 }
OBJECT IDENTIFIER ::= { snmpDot3MauMgt 3 }
dot3RpMauBasicGroup
dot3IfMauBasicGroup
dot3BroadMauBasicGroup
dot3IfMauAutoNegGroup
                               OBJECT IDENTIFIER ::= { snmpDot3MauMgt 5 }
-- object identities for MAU types
-- (see rpMauType and ifMauType for usage)
dot3MauType
    OBJECT IDENTIFIER ::= { snmpDot3MauMqt 4 }
dot3MauTypeAUI OBJECT-IDENTITY
    STATUS
                current
    DESCRIPTION
             "no internal MAU, view from AUI"
    ::= { dot3MauType 1 }
dot3MauType10Base5 OBJECT-IDENTITY
    STATUS
                 current
    DESCRIPTION
             "thick coax MAU (per 802.3 section 8)"
    ::= { dot3MauType 2 }
```

```
dot3MauTypeFoirl OBJECT-IDENTITY
    STATUS
               current
    DESCRIPTION
            "FOIRL MAU (per 802.3 section 9.9)"
    ::= { dot3MauType 3 }
dot3MauType10Base2 OBJECT-IDENTITY
    STATUS
              current
    DESCRIPTION
            "thin coax MAU (per 802.3 section 10)"
    ::= { dot3MauType 4 }
dot3MauType10BaseT OBJECT-IDENTITY
    STATÚS
              current
    DESCRIPTION
            "UTP MAU (per 802.3 section 14)"
    ::= { dot3MauType 5 }
dot3MauType10BaseFP OBJECT-IDENTITY
    STATUS
               current
    DESCRIPTION
            "passive fiber MAU (per 802.3 section 16)"
    ::= { dot3MauType 6 }
dot3MauTvpe10BaseFB OBJECT-IDENTITY
    STATUS
              current
    DESCRIPTION
            "sync_fiber MAU (per 802.3 section 17)"
    ::= { dot3MauType 7 }
dot3MauType10BaseFL OBJECT-IDENTITY
    STATUS
               current
    DESCRIPTION
            "async fiber MAU (per 802.3 section 18)"
    ::= { dot3MauType 8 }
dot3MauType10Broad36 OBJECT-IDENTITY
    STATUS
               current
    DESCRIPTION
            "broadband DTE MAU (per 802.3 section 11). Note
            that 10BROAD36 MAUs can be attached to interfaces
            but not to repeaters."
    ::= { dot3MauType 9 }
---- new since RFC 1515:
dot3MauType10BaseTHD OBJECT-IDENTITY
    STATÚS
            current
```

```
DESCRIPTION
            "UTP MAU (per 802.3 section 14), half duplex mode"
    ::= { dot3MauType 10 }
dot3MauType10BaseTFD OBJECT-IDENTITY
    STATUS
               current
    DESCRIPTION
            "UTP MAU (per 802.3 section 14), full duplex mode"
    ::= { dot3MauType 11 }
dot3MauType10BaseFLHD OBJECT-IDENTITY
    STATUS
              current
    DESCRIPTION
            "async fiber MAU (per 802.3 section 18), half
            duplex mode"
    ::= { dot3MauType 12 }
dot3MauType10BaseFLFD OBJECT-IDENTITY
    STATUS
               current
    DESCRIPTION
            "async fiber MAU (per 802.3 section 18), full
            duplex mode"
    ::= { dot3MauType 13 }
dot3MauTvpe100BaseT4 OBJECT-IDENTITY
    STATÚS
              current
    DESCRIPTION
            "4 pair categ. 3 UTP (per 802.3 section 23)"
    ::= { dot3MauType 14 }
dot3MauType100BaseTXHD OBJECT-IDENTITY
    STATUS
               current
    DESCRIPTION
            "2 pair categ. 5 UTP (per 802.3 section 25), half
            duplex mode"
    ::= { dot3MauType 15 }
dot3MauType100BaseTXFD OBJECT-IDENTITY
    STATUS
               current
    DESCRIPTION
            "2 pair categ. 5 UTP (per 802.3 section 25), full
            duplex mode"
    ::= { dot3MauType 16 }
dot3MauType100BaseFXHD OBJECT-IDENTITY
    STATUS
               current
    DESCRIPTION
            "X fiber over PMT (per 802.3 section 26), half
```

```
duplex mode"
    ::= { dot3MauType 17 }
dot3MauType100BaseFXFD OBJECT-IDENTITY
    STATUS
               current
    DESCRIPTION
            "X fiber over PMT (per 802.3 section 26), full
            duplex mode"
    ::= { dot3MauType 18 }
dot3MauType100BaseT2HD OBJECT-IDENTITY
    STATUS
              current
    DESCRIPTION
            "2 pair categ. 3 UTP (per 802.3 section 32), half
            duplex mode"
    ::= { dot3MauType 19 }
dot3MauType100BaseT2FD OBJECT-IDENTITY
    STATUS
               current
    DESCRIPTION
            "2 pair categ. 3 UTP (per 802.3 section 32), full
            duplex mode"
    ::= { dot3MauType 20 }
-- The Basic Repeater MAU Table
rpMauTable OBJECT-TYPE
               SEQUENCE OF RpMauEntry
    SYNTAX
    MAX-ACCESS not-accessible
               current
    STATUS
    DESCRIPTION
            "Table of descriptive and status information about
            the MAU(s) attached to the ports of a repeater."
    ::= { dot3RpMauBasicGroup 1 }
rpMauEntry OBJECT-TYPE
    SYNTAX
               RpMauEntry
    MAX-ACCESS not-accessible
    STATUS
               current
    DESCRIPTION
            "An entry in the table, containing information
            about a single MAU."
               { rpMauGroupIndex, rpMauPortIndex, rpMauIndex }
    INDEX
    ::= { rpMauTable 1 }
```

```
RpMauEntry ::=
    SEQUENCE {
         rpMauGroupIndex
             Integer32,
         rpMauPortIndex
             Integer32,
         rpMauIndex
             Integer32,
         rpMauType
             OBJECT IDENTIFIER,
         rpMauStatus
             INTEGER,
         rpMauMediaAvailable
             INTEGER,
         rpMauMediaAvailableStateExits
             Counter32,
         rpMauJabberState
             INTEGER,
         rpMauJabberingStateEnters
         Counter32, rpMauFalseCarriers
             Counter32
    }
rpMauGroupIndex OBJECT-TYPE
                Integer32 (1..2147483647)
    SYNTAX
    MAX-ACCESS read-only
    STATUS
                current
    DESCRIPTION
             "This variable uniquely identifies the group
             containing the port to which the MAU described by
             this entry is connected.
             Note: In practice, a group will generally be a field-replaceable unit (i.e., module, card, or board) that can fit in the physical system
             enclosure, and the group number will correspond to
             a number marked on the physical enclosure.
             The group denoted by a particular value of this
             object is the same as the group denoted by the
             same value of rptrGroupIndex."
    ::= { rpMauEntry 1 }
rpMauPortIndex OBJECT-TYPE
                Integer32 (1..2147483647)
    SYNTAX
    MAX-ACCESS read-only
    STATUS current
```

```
DESCRIPTION
             "This variable uniquely identifies the repeater
             port within group rpMauGroupIndex to which the MAU
             described by this entry is connected."
             "Reference RFC 1516, rptrPortIndex."
    ::= { rpMauEntry 2 }
rpMauIndex OBJECT-TYPE
                Integer32 (1..2147483647)
    SYNTAX
    MAX-ACCESS read-only
    STATUS
                current
    DESCRIPTION
             "This variable uniquely identifies the MAU described by this entry from among other MAUs
             connected to the same port (rpMauPortIndex)."
    REFERENCE
              "[IEEE 802.3 Mgt], 30.5.1.1.1, aMAUID."
    ::= { rpMauEntry 3 }
rpMauType OBJECT-TYPE
                 OBJECT IDENTIFIER
    SYNTAX
    MAX-ACCESS read-only
    STATUS
                current
    DESCRIPTION
             "This object identifies the 10 or 100 Mb/s
             baseband MAU type. An initial set of MAU types
             are defined above. The assignment of OBJECT IDENTIFIERs to new types of MAUs is managed by the
             IANA. If the MAU type is unknown, the object
             identifier
             unknownMauType OBJECT IDENTIFIER ::= { 0 0 }
             is returned. Note that unknownMauType is a
             syntactically valid object identifier, and any conformant implementation of ASN.1 and the BER
             must be able to generate and recognize this
             value."
    REFERENCE
             "[IEEE 802.3 Mgt], 30.5.1.1.2, aMAUType."
    ::= { rpMauEntry 4 }
rpMauStatus OBJECT-TYPE
                 INTEGER {
    SYNTAX
                     other(1),
unknown(2),
                     operationál(3),
```

standby(4) shutdown(5), reset(6)

MAX-ACCESS read-write STATUS current **DESCRIPTION**

"The current state of the MAU. This object may be implemented as a read-only object by those agents and MAUs that do not implement software control of the MAU state. Some agents may not support setting the value of this object to some of the enumerated values.

The value other(1) is returned if the MAU is in a state other than one of the states 2 through 6.

The value unknown(2) is returned when the MAU's true state is unknown; for example, when it is being initialized.

A MAU in the operational(3) state is fully functional, operates, and passes signals to its attached DTE or repeater port in accordance to its specification.

A MAU in standby(4) state forces DI and CI to idle and the media transmitter to idle or fault, if supported. Standby(4) mode only applies to link The state of rpMauMediaAvailable is type MAUs. unaffected.

A MAU in shutdown(5) state assumes the same condition on DI, CI, and the media transmitter as though it were powered down or not connected. The MAU may return other(1) value for the rpMauJabberState and rpMauMediaAvailable objects when it is in this state. For an AUI, this state will remove power from the AUI.

Setting this variable to the value reset(6) resets the MAU in the same manner as a power-off, poweron cycle of at least one-half second would. agent is not required to return the value reset (6).

Setting this variable to the value operational(3), standby(4), or shutdown(5) causes the MAU to

```
assume the respective state except that setting a mixing-type MAU or an AUI to standby(4) will cause
               the MAU to enter the shutdown state.
    REFERENCE
               "[IEEE 802.3 Mgt], 30.5.1.1.7, aMAUAdminState,
              30.5.1.2.2, acMAŪÁdminControl, and 30.5.1.2.1, acRESETMAU."
     ::= { rpMauEntry 5 }
rpMauMediaAvailable OBJECT-TYPE
    SYNTAX
                  INTEGER {
                       other(1)
                        unknown(2)
                       available(3),
notAvailable(4),
                        remoteFault(5)
                        invalidSignal(6),
                        remoteJabber(7).
                        remoteLinkLoss(8),
                       remoteTest(9)
    MAX-ACCESS read-only
    STATUS
                 current
    DESCRIPTION
               "If the MAU is a link or fiber type (FOIRL,
               10BASE-T, 10BASE-F) then this is equivalent to the
              link test fail state/low light function. For an AUI or a coax (including broadband) MAU this indicates whether or not loopback is detected on
               the DI circuit. The value of this attribute
               persists between packets for MAU types AUI,
               10BASE5, 10BASE2, 10BROAD36, and 10BASE-FP.
```

The value other(1) is returned if the mediaAvailable state is not one of 2 through 6.

The value unknown(2) is returned when the MAU's true state is unknown; for example, when it is being initialized. At power-up or following a reset, the value of this attribute will be unknown for AUI, coax, and 10BASE-FP MAUs. For these MAUs loopback will be tested on each transmission during which no collision is detected. If DI is receiving input when DO returns to IDL after a transmission and there has been no collision during the transmission then loopback will be detected. The value of this attribute will only change during non-collided transmissions for AUÍ,

coax, and 10BASE-FP MAUs.

For 100BASE-T4, 100BASE-TX and 100BASE-FX the enumerations match the states within the respective link integrity state diagrams, fig 23-12 and 24-15 of sections 23 and 24 of [2]. Any MAU which implements management of autonegotiation will map remote fault indication to remote fault.

The value available(3) indicates that the link, light, or loopback is normal. The value notAvailable(4) indicates link loss, low light, or no loopback.

The value remoteFault(5) indicates that a fault has been detected at the remote end of the link. This value applies to 10BASE-FB, 100BASE-T4 Far End Fault Indication and non-specified remote faults from a system running auto-negotiation. The values remoteJabber(7), remoteLinkLoss(8), and remoteTest(9) should be used instead of remoteFault(5) where the reason for remote fault is identified in the remote signaling protocol.

The value invalidSignal(6) indicates that an invalid signal has been received from the other end of the link. InvalidSignal(6) applies only to MAUs of type 10BASE-FB.

Where an IEEE Std 802.3u-1995 clause 22 MII is present, a logic one in the remote fault bit (reference section 22.2.4.2.8 of that document) maps to the value remoteFault(5), and a logic zero in the link status bit (reference section 22.2.4.2.10 of that document) maps to the value notAvailable(4). The value notAvailable(4) takes precedence over the value remoteFault(5).

"[IEEE 802.3 Mgt], 30.5.1.1.4, aMediaAvailable." ::= { rpMauEntry 6 }

rpMauMediaAvailableStateExits OBJECT-TYPE Counter32 SYNTAX MAX-ACCESS read-only STATUS current

DESCRIPTION

"A count of the number of times that

```
rpMauMediaAvailable for this MAU instance leaves
the state available(3)."
    REFERENCE
             "[IEEE 802.3 Mgt], 30.5.1.1.5, aLoseMediaCounter."
    ::= { rpMauEntry 7 }
rpMauJabberState OBJECT-TYPE
                 INTEGER {
    SYNTAX
                     other(1),
unknown(2)
                     noJabber(3)
                     jabbering(4)
    MAX-ACCESS read-only
    STATUS
                 current
    DESCRIPTION
             "The value other(1) is returned if the jabber
             state is not 2, 3, or 4. The agent must always return other(1) for MAU type dot3MauTypeAUI.
             The value unknown(2) is returned when the MAU's
             true state is unknown; for example, when it is
             being initialized.
             If the MAU is not jabbering the agent returns
             noJabber(3). This is the 'normal' state.
             If the MAU is in jabber state the agent returns
             the jabbering(4) value.
    REFERENCE
             "[IEEE 802.3 Mgt], 30.5.1.1.6, aJabber.jabberFlag."
    ::= { rpMauEntry 8 }
rpMauJabberingStateEnters OBJECT-TYPE
    SYNTAX
               Counter32
    MAX-ACCESS read-only
    STATUS
                current
    DESCRIPTION
             "A count of the number of times that
             mauJabberState for this MAU instance enters the state jabbering(4). For MAUs of type
             dot3MauTypeAUI, dot3MauType100BaseT4,
             dot3MauType100BaseTX, and dot3MauType100BaseFX,
             this counter will always indicate zero."
    REFERENCE
             "[IEEE 802.3 Mgt], 30.5.1.1.6,
             aJabber.jabberCounter."
```

```
::= { rpMauEntry 9 }
rpMauFalseCarriers OBJECT-TYPE
                Counter32
    SYNTAX
    MAX-ACCESS read-only
    STATUS
                current
    DESCRIPTION
             "A count of the number of false carrier events during IDLE in 100BASE-X links. This counter does
             not increment at the symbol rate. It can
             increment after a valid carrier completion at a
             maximum rate of once per 100 ms until the next
             carrier event.
             This counter increments only for MAUs of type
             dot3MauType100BaseT4, dot3MauType100BaseTX, and
             dot3MauType100BaseFX. For all other MAU types,
             this counter will always indicate zero.
             The approximate minimum time for rollover of this
             counter is 7.4 hours."
    REFERENCE
             "[IEEE 802.3 Mgt], 30.5.1.1.10, aFalseCarriers."
    ::= { rpMauEntry 10 }
-- The rpJackTable applies to MAUs attached to repeaters -- which have one or more external jacks (connectors).
rpJackTable OBJECT-TYPE
                SEQUENCE OF RpJackEntry
    SYNTAX
    MAX-ACCESS not-accessible
    STATUS
                current
    DESCRIPTION
             "Information about the external jacks attached to
             MAUs attached to the ports of a repeater."
    ::= { dot3RpMauBasicGroup 2 }
rpJackEntry OBJECT-TYPE
    SYNTAX
               RpJackEntry
    MAX-ACCESS not-accessible
                current
    STATUS
    DESCRIPTION
             "An entry in the table, containing information about a particular jack."
    INDEX
              { rpMauGroupIndex,
                 rpMauPortIndex,
```

```
rpMauIndex,
                rpJackIndex }
    ::= { rpJackTable 1 }
RpJackEntry ::=
    SEQUENCE {
        rpJackIndex
             Integer32,
        rpJackType
             JackType
    }
rpJackIndex OBJECT-TYPE
               Integer32 (1..2147483647)
    SYNTAX
    MAX-ACCESS not-accessible
    STATUS
                current
    DESCRIPTION
             "This variable uniquely identifies the jack described by this entry from among other jacks
    attached to the same MAU (rpMauIndex)."
::= { rpJackEntry 1 }
rpJackType OBJECT-TYPE
    SYNTAX
                JackType
    MAX-ACCESS read-only
    STATUS
                current
    DESCRIPTION
             "The jack connector type, as it appears on the
             outside of the system.
    ::= { rpJackEntry 2 }
-- The Basic Interface MAU Table
ifMauTable OBJECT-TYPE
                SEOUENCE OF IfMauEntry
    SYNTAX
    MAX-ACCESS not-accessible
               current
    STATUS
    DESCRIPTION
             "Table of descriptive and status information about
             MAU(s) attached to an interface."
    ::= { dot3IfMauBasicGroup 1 }
ifMauEntry OBJECT-TYPE
    SYNTAX
                IfMauEntry
```

```
MAX-ACCESS not-accessible
    STATUS
               current
    DESCRIPTION
            "An entry in the table, containing information
            about a single MAU."
               { ifMauIfIndex, ifMauIndex }
    INDEX
    ::= { ifMauTable 1 }
IfMauEntry ::=
    SEQUENCE {
        ifMauIfIndex
            Integer32,
        ifMauIndex
            Integer32,
        ifMauType
            OBJECT IDENTIFIER,
        ifMauStatus
            INTEGER,
        ifMauMediaAvailable
            INTEGER,
        ifMauMediaAvailableStateExits
            Counter32,
        ifMauJabberState
            INTEGER.
        ifMauJabberingStateEnters
            Counter32,
        ifMauFalseCarriers
            Counter32,
        ifMauTypeList
            Integer32,
        ifMauDefaultType
            OBJECT IDENTIFIER,
        ifMauAutoNegSupported 
            TruthValue
    }
ifMauIfIndex OBJECT-TYPE
             Integer32 (1..2147483647)
    SYNTAX
    MAX-ACCESS read-only
    STATUS
               current
    DESCRIPTION
            "This variable uniquely identifies the interface
            to which the MAU described by this entry is
            connected."
    REFERENCE
    "RFC 1213, ifIndex" ::= { ifMauEntry 1 }
```

```
ifMauIndex OBJECT-TYPE
                  Integer32 (1..2147483647)
    SYNTAX
    MAX-ACCESS read-only
    STATUS
                  current
    DESCRIPTION
               "This variable uniquely identifies the MAU
              described by this entry from among other MAUs connected to the same interface (ifMauIfIndex)."
    REFERENCE
               "[IEEE 802.3 Mgt], 30.5.1.1.1, aMAUID."
     ::= { ifMauEntry 2 }
ifMauType OBJECT-TYPE
                 OBJECT IDENTIFIER
    SYNTAX
    MAX-ACCESS read-only
    STATUS
                  current
    DESCRIPTION
               "This object identifies the 10 or 100 Mb/s
               baseband or broadband MAU type. An initial set of
               MAU types are defined above. The assignment of
              OBJECT IDENTIFIERs to new types of MAUs is managed
               by the IANA. If the MAU type is unknown, the
               object identifier
               unknownMauType OBJECT IDENTIFIER ::= { 0 0 }
               is returned. Note that unknownMauType is a
              syntactically valid object identifier, and any
               conformant implementation of ASN.1 and the BER
               must be able to generate and recognize this value.
               This object represents the operational type of the
              MAU, as determined by either (1) the result of the auto-negotiation function or (2) if auto-negotiation is not enabled or is not implemented for this MAU, by the value of the object if MauDefault Type. In case (2), a set to the object if MauDefault Type will force the MAU into
               object ifMauDefaultType will force the MAU into
               the new operating mode."
    REFERENCE
               "[IEEE 802.3 Mgt], 30.5.1.1.2, aMAUType."
     ::= { ifMauEntry 3 }
ifMauStatus OBJECT-TYPE
    SYNTAX
                  INTEGER {
                       other(1),
unknown(2),
                       operational(3),
```

standby(4) shutdown(5), reset(6)

MAX-ACCESS read-write STATUS current **DESCRIPTION**

"The current state of the MAU. This object may be implemented as a read-only object by those agents and MAUs that do not implement software control of the MAU state. Some agents may not support setting the value of this object to some of the enumerated values.

The value other(1) is returned if the MAU is in a state other than one of the states 2 through 6.

The value unknown(2) is returned when the MAU's true state is unknown; for example, when it is being initialized.

A MAU in the operational(3) state is fully functional, operates, and passes signals to its attached DTE or repeater port in accordance to its specification.

A MAU in standby(4) state forces DI and CI to idle and the media transmitter to idle or fault, if supported. Standby(4) mode only applies to link The state of ifMauMediaAvailable is type MAUs. unaffected.

A MAU in shutdown(5) state assumes the same condition on DI, CI, and the media transmitter as though it were powered down or not connected. The MAU may return other(1) value for the ifMauJabberState and ifMauMediaAvailable objects when it is in this state. For an AUI, this state will remove power from the AUI.

Setting this variable to the value reset(6) resets the MAU in the same manner as a power-off, poweron cycle of at least one-half second would. agent is not required to return the value reset (6).

Setting this variable to the value operational(3), standby(4), or shutdown(5) causes the MAU to

```
assume the respective state except that setting a mixing-type MAU or an AUI to standby(4) will cause
              the MAU to enter the shutdown state.
    REFERENCE
               "[IEEE 802.3 Mgt], 30.5.1.1.7, aMAUAdminState,
              30.5.1.2.2, acMAŪÁdminControl, and 30.5.1.2.1,
              acRESETMAU.
     ::= { ifMauEntry 4 }
ifMauMediaAvailable OBJECT-TYPE
    SYNTAX
                  INTEGER {
                       other(1)
                       unknown(2)
                       available(3),
notAvailable(4),
                       remoteFault(5).
                       invalidSignal(6),
                       remoteJabber(7).
                       remoteLinkLoss(8),
                       remoteTest(9)
    MAX-ACCESS read-only
    STATUS
                 current
    DESCRIPTION
               "If the MAU is a link or fiber type (FOIRL,
              10BASE-T, 10BASE-F) then this is equivalent to the
              link test fail state/low light function. For an AUI or a coax (including broadband) MAU this indicates whether or not loopback is detected on
              the DI circuit. The value of this attribute
              persists between packets for MAU types AUI,
              10BASE5, 10BASE2, 10BROAD36, and 10BASE-FP.
```

The value other(1) is returned if the mediaAvailable state is not one of 2 through 6.

The value unknown(2) is returned when the MAU's true state is unknown; for example, when it is being initialized. At power-up or following a reset, the value of this attribute will be unknown for AUI, coax, and 10BASE-FP MAUs. For these MAUs loopback will be tested on each transmission during which no collision is detected. If DI is receiving input when DO returns to IDL after a transmission and there has been no collision during the transmission then loopback will be detected. The value of this attribute will only change during non-collided transmissions for AUÍ,

coax, and 10BASE-FP MAUs.

For 100BASE-T4, 100BASE-TX and 100BASE-FX the enumerations match the states within the respective link integrity state diagrams, fig 23-12 and 24-15 of sections 23 and 24 of [2]. Any MAU which implements management of autonegotiation will map remote fault indication to remote fault.

The value available(3) indicates that the link, light, or loopback is normal. The value notAvailable(4) indicates link loss, low light, or no loopback.

The value remoteFault(5) indicates that a fault has been detected at the remote end of the link. This value applies to 10BASE-FB, 100BASE-T4 Far End Fault Indication and non-specified remote faults from a system running auto-negotiation. The values remoteJabber(7), remoteLinkLoss(8), and remoteTest(9) should be used instead of remoteFault(5) where the reason for remote fault is identified in the remote signaling protocol.

The value invalidSignal(6) indicates that an invalid signal has been received from the other end of the link. InvalidSignal(6) applies only to MAUs of type 10BASE-FB.

Where an IEEE Std 802.3u-1995 clause 22 MII is present, a logic one in the remote fault bit (reference section 22.2.4.2.8 of that document) maps to the value remoteFault(5), and a logic zero in the link status bit (reference section 22.2.4.2.10 of that document) maps to the value notAvailable(4). The value notAvailable(4) takes precedence over the value remoteFault(5).

"[IEEE 802.3 Mgt], 30.5.1.1.4, aMediaAvailable." ::= { ifMauEntry 5 }

ifMauMediaAvailableStateExits OBJECT-TYPE SYNTAX Counter32

MAX-ACCESS read-only STATUS current

DESCRIPTION

"A count of the number of times that

```
ifMauMediaAvailable for this MAU instance leaves
the state available(3)."
    REFERENCE
              "[IEEE 802.3 Mgt], 30.5.1.1.5, aLoseMediaCounter."
    ::= { ifMauEntry 6 }
ifMauJabberState OBJECT-TYPE
                 INTEGER {
    SYNTAX
                     other(1),
unknown(2)
                     noJabber(3)
                     jabbering(4)
    MAX-ACCESS read-only
    STATUS
                 current
    DESCRIPTION
             "The value other(1) is returned if the jabber
             state is not 2, 3, or 4. The agent must always return other(1) for MAU type dot3MauTypeAUI.
             The value unknown(2) is returned when the MAU's
             true state is unknown; for example, when it is
             being initialized.
             If the MAU is not jabbering the agent returns
             noJabber(3). This is the 'normal' state.
             If the MAU is in jabber state the agent returns
             the jabbering(4) value.
    REFERENCE
             "[IEEE 802.3 Mgt], 30.5.1.1.6, aJabber.jabberFlag."
    ::= { ifMauEntry 7 }
ifMauJabberingStateEnters OBJECT-TYPE
               Counter32
    SYNTAX
    MAX-ACCESS read-only
    STATUS
                current
    DESCRIPTION
             "A count of the number of times that
             mauJabberState for this MAU instance enters the state jabbering(4). For MAUs of type
             dot3MauTypeAUI, dot3MauType100BaseT4,
             dot3MauType100BaseTX, and dot3MauType100BaseFX,
             this counter will always indicate zero."
    REFERENCE
             "[IEEE 802.3 Mgt], 30.5.1.1.6,
             aJabber.jabberCounter."
```

::= { ifMauEntry 8 }

ifMauFalseCarriers OBJECT-TYPE

SYNTAX Counter32 MAX-ACCESS read-only STATUS current

DESCRIPTION

"A count of the number of false carrier events during IDLE in 100BASE-X links. This counter does not increment at the symbol rate. It can increment after a valid carrier completion at a maximum rate of once per 100 ms until the next carrier event.

This counter increments only for MAUs of type dot3MauType100BaseT4, dot3MauType100BaseTX, and dot3MauType100BaseFX. For all other MAU types, this counter will always indicate zero.

The approximate minimum time for rollover of this counter is 7.4 hours."

REFERENCE

"[IEEE 802.3 Mgt], 30.5.1.1.10, aFalseCarriers." ::= { ifMauEntry 9 }

ifMauTypeList OBJECT-TYPE SYNTAX Integer32 MAX-ACCESS read-only

current **STATUS**

DESCRIPTION

"A value that uniquely identifies the set of possible IEEE 802.3 types that the MAU could be. The value is a sum which initially takes the value zero. Then, for each type capability of this MAU, 2 raised to the power noted below is added to the sum. For example, a MAU which has the capability to be only 10BASE-T would have a value of 512 (2**9). In contrast, a MAU which supports both 10Base-T (full duplex) and 100BASE-TX (full duplex) would have a value of ((2**11) + (2**16))or 67584.

The powers of 2 assigned to the capabilities are these:

Power Capability

other or unknown 0

1 AUI

```
2
         10BASE-5
 3
         FOIRL
         10BASE-2
 5
6
         10BASE-T duplex mode unknown
         10BASE-FP
 7
         10BASE-FB
 8
         10BASE-FL duplex mode unknown
 9
         10BROAD36
         10BASE-T
10
                     half duplex mode
                     full duplex mode
11
         10BASE-T
12
         10BASE-FL half duplex mode
13
         10BASE-FL full duplex mode
14
         100BASE-T4
         100BASE-TX half duplex mode
100BASE-TX full duplex mode
100BASE-FX half duplex mode
15
16
17
         100BASE-FX full duplex mode
18
         100BASE-T2 half duplex mode
19
20
         100BASE-T2 full duplex mode
```

If auto-negotiation is present on this MAU, this object will map to ifMauAutoNegCapability."

::= { ifMauEntry 10 }

ifMauDefaultType OBJECT-TYPE
SYNTAX OBJECT IDENTIFIER
MAX-ACCESS read-write
STATUS current
DESCRIPTION

"This object identifies the default administrative 10 or 100 Mb/s baseband MAU type, to be used in conjunction with the operational MAU type denoted by ifMauType.

The set of possible values for this object is the same as the set defined for the ifMauType object.

This object represents the administratively-configured type of the MAU. If auto-negotiation is not enabled or is not implemented for this MAU, the value of this object determines the operational type of the MAU. In this case, a set to this object will force the MAU into the specified operating mode.

If auto-negotiation is implemented and enabled for this MAU, the operational type of the MAU is

determined by auto-negotiation, and the value of this object denotes the type to which the MAU will automatically revert if/when auto-negotiation is later disabled.

NOTE TO IMPLEMENTORS: It may be necessary to provide for underlying hardware implementations which do not follow the exact behavior specified In particular, when ifMauAutoNegAdminStatus transitions from enabled to disabled, the agent implementation must ensure that the operational type of the MAU (as reported by ifMauType) correctly transitions to the value specified by this object, rather than continuing to operate at the value earlier determined by the auto-negotiation function."

REFERENCE

```
"[IEEE 802.3 Mgt], 30.5.1.1.1, aMAUID, and [IEEE
        802.3 Std], 22.2.4.1.4."
::= { ifMauEntry 11 }
```

ifMauAutoNegSupported OBJECT-TYPE

TruthValue SYNTAX MAX-ACCESS read-only STATUS current **DESCRIPTION**

"This object indicates whether or not autonegotiation is supported on this MAU. ::= { ifMauEntry 12 }

-- The ifJackTable applies to MAUs attached to interfaces -- which have one or more external jacks (connectors).

ifJackTable OBJECT-TYPE SEQUENCE OF IfJackEntry SYNTAX MAX-ACCESS not-accessible STATUS current **DESCRIPTION**

"Information about the external jacks attached to MAUs attached to an interface.' ::= { dot3IfMauBasicGroup 2 }

ifJackEntry OBJECT-TYPE IfJackEntry SYNTAX MAX-ACCESS not-accessible STATUS current

```
DESCRIPTION
             "An entry in the table, containing information about a particular jack."
               { ifMauIfIndex,
    INDEX
                 ifMauIndex,
                 ifJackIndex }
    ::= { ifJackTable 1 }
IfJackEntry ::=
    SEQUENCE {
         ifJackIndex
             Integer32,
         ifJackType
             JackType
    }
ifJackIndex OBJECT-TYPE
                 Integer32 (1..2147483647)
    SYNTAX
    MAX-ACCESS not-accessible
    STATUS
                 current
    DESCRIPTION
             "This variable uniquely identifies the jack described by this entry from among other jacks
              attached to the same MAU."
    ::= { ifJackEntry 1 }
ifJackType OBJECT-TYPE
                JackType
    SYNTAX
    MAX-ACCESS read-only
    STATUS
                 current
    DESCRIPTION
              "The jack connector type, as it appears on the
             outside of the system.
    ::= { ifJackEntry 2 }
-- The ifMauAutoNegTable applies to systems in which
-- auto-negotiation is supported on one or more MAUs
-- attached to interfaces. Note that if auto-negotiation
-- is present and enabled, the ifMauType object reflects
-- the result of the auto-negotiation function.
ifMauAutoNegTable OBJECT-TYPE
                SEQUENCE OF IfMauAutoNegEntry
    MAX-ACCESS not-accessible
                current
    STATUS
    DESCRIPTION
```

```
"Configuration and status objects for the auto-
            negotiation function of MAUs attached to
            interfaces."
    ::= { dot3IfMauAutoNegGroup 1 }
ifMauAutoNegEntry OBJECT-TYPE
               IfMauAutoNegEntry
    SYNTAX
   MAX-ACCESS not-accessible
    STATUS
              current
    DESCRIPTION
            "An entry in the table, containing configuration
            and status information for the auto-negotiation
            function of a particular MAU."
                 { ifMauIfIndex, ifMauIndex }
    ::= { ifMauAutoNegTable 1 }
IfMauAutoNegEntry ::=
    SEQUENCE {
        ifMauAutoNegAdminStatus
            INTEGER,
        ifMauAutoNegRemoteSignaling
            INTEGER,
        ifMauAutoNegConfig
            INTEGER.
        ifMauAutoNegCapability
            Integer32,
        ifMauAutoNegCapAdvertised
            Integer32,
        ifMauAutoNegCapReceived
            Integer32,
        ifMauAutoNegRestart
            INTEGER
    }
ifMauAutoNegAdminStatus OBJECT-TYPE
    SYNTAX
               INTEGER {
                   enabled(1)
                   disabled(2)
               }
    MAX-ACCESS read-write
    STATUS
               current
    DESCRIPTION
            "Setting this object to enabled(1) will cause the
            interface which has the auto-negotiation signaling
            ability to be enabled.
```

If the value of this object is disabled(2) then the interface will act as it would if it had no auto-negotiation signaling. Under these conditions, an IEEE 802.3 MAU will immediately be forced to the state indicated by the value of the object ifMauDefaultType.

NOTE TO IMPLEMENTORS: When ifMauAutoNegAdminStatus transitions from enabled to disabled, the agent implementation must ensure that the operational type of the MAU (as reported by ifMauType) correctly transitions to the value specified by the ifMauDefaultType object, rather than continuing to operate at the value earlier determined by the auto-negotiation function.'

```
REFERENCE
```

"[IEEE 802.3 Mgt], 30.6.1.1.2, aAutoNegAdminState and 30.6.1.2.2, acAutoNegAdminControl.
::= { ifMauAutoNegEntry 1 }

```
ifMauAutoNegRemoteSignaling OBJECT-TYPE
               INTEGER {
    SYNTAX
                   detected(1),
                   notdetected(2)
```

} MAX-ACCESS read-only **STATUS** current DESCRIPTION

> "A value indicating whether the remote end of the link is using auto-negotiation signaling. It takes the value detected(1) if and only if, during the previous link negotiation, FLP Bursts were received."

REFERENCE

```
"[IEEE 802.3 Mgt], 30.6.1.1.3,
        aĀutoNegRemoteŠignaling."
::= { ifMauAutoNegEntry 2 }
```

ifMauAutoNegConfig OBJECT-TYPE SYNTAX

INTEGER { other(1), configuring(2), complete(3), disabled(4), parallelDetectFail(5)

MAX-ACCESS read-only STATUS current

```
DESCRIPTION
```

"A value indicating the current status of the auto-negotiation process. The enumeration parallelDetectFail(5) maps to a failure in parallel detection as defined in 28.2.3.1 of [IEEE 802.3 Std]."

REFERENCE

"[IEEE 802.3 Mgt], 30.6.1.1.4, aAutoNegAutoConfig." ::= { ifMauAutoNegEntry 4 }

ifMauAutoNegCapability OBJECT-TYPE

Integer32 SYNTAX MAX-ACCESS read-only **STATUS** current **DESCRIPTION**

"A value that uniquely identifies the set of capabilities of the local auto-negotiation entity. The value is a sum which initially takes the value zero. Then, for each capability of this interface, 2 raised to the power noted below is added to the sum. For example, an interface which has the capability to support only 100Base-TX half duplex would have a value of 32768 (2**15). In contrast, an interface which supports both 100Base-TX half duplex and and 100Base-TX full duplex would have a value of 98304 ((2**15) +(2**16)).

The powers of 2 assigned to the capabilities are these:

```
Power
        Capability
          other or unknown
 (1-9)
          (reserved)
10
          10BASE-T half duplex mode
11
          10BASE-T full duplex mode
12
          (reserved)
13
          (reserved)
14
          100BASE-T4
          100BASE-TX half duplex mode
15
 16
          100BASE-TX full duplex mode
17
          (reserved)
18
          (reserved)
19
         100BASE-T2 half duplex mode
         100BASE-T2 full duplex mode
```

Note that interfaces that support this MIB may

```
have capabilities that extend beyond the scope of
              this MIB.'
    REFERENCE
              "[IEEE 802.3 Mgt], 30.6.1.1.5,
              aAutoNegLocalTechnologyAbility."
     ::= { ifMauAutoNegEntry 5 }
ifMauAutoNegCapAdvertised OBJECT-TYPE
                 Integer32
    SYNTAX
    MAX-ACCESS read-write
    STATUS
                 current
    DESCRIPTION
              "A value that uniquely identifies the set of capabilities advertised by the local autonegotiation entity. Refer to ifMauAutoNegCapability for a description of the
              possible values of this object.
              Capabilities in this object that are not available
              in ifMauAutoNegCapability cannot be enabled."
    REFERENCE
               "[IEEE 802.3 Mgt], 30.6.<u>1</u>.1.6,
              aAutoNegAdvertisedTechnologyAbility."
     ::= { ifMauAutoNegEntry 6 }
ifMauAutoNegCapReceived OBJECT-TYPE
                  Integer32
    SYNTAX
    MAX-ACCESS read-only
                  current
    STATUS
    DESCRIPTION
              "A value that uniquely identifies the set of capabilities received from the remote auto-
              negotiation entity. Refer to ifMauAutoNegCapability for a description of the possible values of this object.
              Note that interfaces that support this MIB may be
              attached to remote auto-negotiation entities which
              have capabilities beyond the scope of this MIB."
    REFERENCE
              "[IEEE 802.3 Mgt], 30.6.1.1.7
              aAutoNegReceivedTechnologyAbility."
     ::= { ifMauAutoNegEntry 7 }
ifMauAutoNegRestart OBJECT-TYPE
                  INTEGER {
    SYNTAX
                       restart(1)
                       norestart(2)
```

```
}
    MAX-ACCESS read-write
    STATUS
                current
    DESCRIPTION
             "If the value of this object is set to restart(1)
             then this will force auto-negotiation to begin link renegotiation. If auto-negotiation signaling
             is disabled, a write to this object has no effect.
             Setting the value of this object to norestart(2)
             has no effect."
    REFERENCE
             "[IEEE 802.3 Mgt], 30.6.1.2.1,
             acAutoNegRestartAutoConfig.'
    ::= { ifMauAutoNegEntry 8 }
-- The Basic Broadband MAU Table
broadMauBasicTable OBJECT-TYPE
    SYNTAX
               SEQUENCE OF BroadMauBasicEntry
    MAX-ACCESS not-accessible
    STATUS
                current
    DESCRIPTION
             "Table of descriptive and status information about the broadband MAUs connected to interfaces."
    ::= { dot3BroadMauBasicGroup 1 }
broadMauBasicEntry OBJECT-TYPE
               BroadMauBasicEntry
    MAX-ACCESS not-accessible
    STATUS
                current
    DESCRIPTION
             "An entry in the table, containing information
             about a single broadband MAU.'
    INDEX
               { broadMauIfIndex, broadMauIndex }
    ::= { broadMauBasicTable 1 }
BroadMauBasicEntry ::=
    SEQUENCE {
        broadMauIfIndex
             Integer32,
         broadMauIndex
             Integer32,
         broadMauXmtRcvSplitType
             INTEGER,
```

```
broadMauXmtCarrierFreq
            Integer32,
        broadMauTranslationFreq
            Integer32
    }
broadMauIfIndex OBJECT-TYPE
               Integer32 (1..2147483647)
    SYNTAX
    MAX-ACCESS read-only
    STATUS
               current
    DESCRIPTION
            "This variable uniquely identifies the interface
            to which the MAU described by this entry is
            connected."
    REFERENCE
            "Reference RFC 1213, ifIndex."
    ::= { broadMauBasicEntry 1 }
broadMauIndex OBJECT-TYPE
    SYNTAX
               Integer32 (1..2147483647)
    SYNTAX Integer32
MAX-ACCESS read-only
    STATUS
               current
    DESCRIPTION
            "This variable uniquely identifies the MAU
            connected to interface broadMauIfIndex that is
            described by this entry."
    REFERENCE
            "Reference IEEE 802.3 MAU Mgt, 20.2.3.2, aMAUID."
    ::= { broadMauBasicEntry 2 }
broadMauXmtRcvSplitType OBJECT-TYPE
               INTEGER {
    SYNTAX
                   other(1)
                   single(2),
                   dual(3)
    MAX-ACCESS read-only
    STATUS
               current
    DESCRIPTION
            "This object indicates the type of frequency
            multiplexing/cabling system used to separate the
            transmit and receive paths for the 10BROAD36 MAU.
            The value other(1) is returned if the split type
            is not either single or dual.
            The value single(2) indicates a single cable
            system. The value dual(3) indicates a dual cable
```

```
system, offset normally zero."
    REFERENCE
             "Reference IEEE 802.3 MAU Mgt, 20.2.3.2,
            aBbMAUXmitRcvSplitType."
    ::= { broadMauBasicEntry 3 }
broadMauXmtCarrierFreq OBJECT-TYPE
    SYNTAX
                Integer32
    MAX-ACCESS read-only
    STATUS
               current
    DESCRIPTION
             "This variable indicates the transmit carrier
            frequency of the 10BR0AD36 MAU in MHz/4; that is, in units of 250 kHz."
    REFERENCE
             "Reference IEEE 802.3 MAU Mgt, 20.2.3.2,
            aBroadbandFrequencies.xmitCarrierFrequency."
    ::= { broadMauBasicEntry 4 }
broadMauTranslationFreq OBJECT-TYPE
    SYNTAX Integer32
MAX-ACCESS read-only
    STATUS
            current
    DESCRIPTION
             "This variable indicates the translation offset
            frequency of the 10BROAD36 MAU in MHz/4; that is, in units of 250 kHz."
    REFERENCE
             "Reference IEEE 802.3 MAU Mgt, 20.2.3.2,
            aBroadbandFrequencies.translationFrequency."
    ::= { broadMauBasicEntry 5 }
-- Notifications for use by 802.3 MAUs
rpMauJabberTrap NOTIFICATION-TYPE
    OBJECTS
                 { rpMauJabberState }
    STATUS
                 current
    DESCRIPTION
             "This trap is sent whenever a managed repeater MAU
            enters the jabber state.
            The agent must throttle the generation of
            consecutive rpMauJabberTraps so that there is at
            least a five-second gap between them."
    REFERENCE
             "[IEEE 802.3 Mgt], 30.5.1.3.1, nJabber
```

```
notification."
    ifMauJabberTrap NOTIFICATION-TYPE
    OBJECTS
                { ifMauJabberState }
    STATUS
                current
    DESCRIPTION
            "This trap is sent whenever a managed interface
            MAU enters the jabber state.
            The agent must throttle the generation of
            consecutive ifMauJabberTraps so that there is at
            least a five-second gap between them."
    REFERENCE
            "[IEEE 802.3 Mgt], 30.5.1.3.1, nJabber
            notification."
    -- Conformance information
mauModConf
        OBJECT IDENTIFIER ::= { mauMod 1 }
  mauModCompls
        OBJECT IDENTIFIER ::= { mauModConf 1 }
  mauModObjGrps
        OBJECT IDENTIFIER ::= { mauModConf 2 }
  mauModNotGrps
        OBJECT IDENTIFIER ::= { mauModConf 3 }
-- Object groups
mauRpGrpBasic OBJECT-GROUP
                { rpMauGroupIndex,
    OBJECTS
                  rpMauPortIndex,
                  rpMauIndex,
                  rpMauType,
                  rpMauStatus,
                  rpMauMediaAvailable,
                  rpMauMediaAvailableStateExits,
                  rpMauJabberState,
                  rpMauJabberingStateEnters }
    STATUS
                current
    DESCRIPTION
        "Basic conformance group for MAUs attached to
        repeater ports. This group is also the conformance specification for RFC 1515
```

```
implementations."
    ::= { mauModObjGrps 1 }
mauRpGrp100Mbs OBJECT-GROUP
    OBJECTS
              { rpMauFalseCarriers }
    STATUS
                 current
    DESCRIPTION
         "Conformance group for MAUs attached to
        repeater ports with 100 Mb/s capability."
    ::= { mauModObjGrps 2 }
mauRpGrpJack OBJECT-GROUP
                { rpJackType }
    OBJECTS
    STATUS
                 current
    DESCRIPTION
         "Conformance group for MAUs attached to
    repeater ports with managed jacks."
::= { mauModObjGrps 3 }
mauIfGrpBasic OBJECT-GROUP
                 { ifMauIfIndex.
    OBJECTS
                   ifMauIndex,
                   ifMauType,
                   ifMauStatus,
                   ifMauMediaAvailable.
                   ifMauMediaAvailableStateExits,
                   ifMauJabberState,
                   ifMauJabberingStateEnters }
    STATUS
                 current
    DESCRIPTION
         "Basic conformance group for MAUs attached to
        interfaces. This group also provides a
        conformance specification for RFC 1515
        implementations."
    ::= { mauModObjGrps 4 }
mauIfGrp100Mbs OBJECT-GROUP
                 { ifMauFalseCarriers.
    OBJECTS
                   ifMauTypeList,
                   ifMauDefaultType,
                   ifMauAutoNegSupported }
    STATUS
                 current
    DESCRIPTION
        "Conformance group for MAUs attached to interfaces with 100 Mb/s capability."
    ::= { mauModObjGrps 5 }
mauIfGrpJack OBJECT-GROUP
```

```
OBJECTS
                { ifJackType }
    STATUS
                current
    DESCRIPTION
        "Conformance group for MAUs attached
        to interfaces with managed jacks."
    ::= { mauModObjGrps 6 }
mauIfGrpAutoNeg OBJECT-GROUP
                { ifMauAutoNegAdminStatus,
    OBJECTS
                  ifMauAutoNegRemoteSignaling,
                  ifMauAutoNegConfig,
                  ifMauAutoNegCapability,
                  ifMauAutoNegCapAdvertised,
                  ifMauAutoNegCapReceived,
                  ifMauAutoNegRestart }
    STATUS
                current
    DESCRIPTION
        "Conformance group for MAUs attached to
        interfaces with managed auto-negotiation."
    ::= { mauModObjGrps 7 }
mauBroadBasic OBJECT-GROUP
                { broadMauIfIndex.
    OBJECTS
                  broadMauIndex,
                  broadMauXmtRcvSplitTvpe.
                  broadMauXmtCarrierFreq,
                  broadMauTranslationFreq }
    STATUS
                current
    DESCRIPTION
        "Conformance group for broadband MAUs
        attached to interfaces. This group
        provides a conformance specification
        for RFC 1515 implementations."
    ::= { mauModObiGrps 8 }
-- Notification groups
rpMauNotifications NOTIFICATION-GROUP
    NOTIFICATIONS { rpMauJabberTrap }
                current
    STATUS
    DESCRIPTION
        "Notifications for repeater MAUs."
    ::= { mauModNotGrps 1 }
ifMauNotifications NOTIFICATION-GROUP
    NOTIFICATIONS { ifMauJabberTrap }
    STATUS
                current
    DESCRIPTION
```

```
"Notifications for interface MAUs."
    ::= { mauModNotGrps 2 }
-- Compliances
mauModRpCompl MODULE-COMPLIANCE
    STATUS
                current
    DESCRIPTION
        "Compliance for MAUs attached to repeater ports."
    MODULE -- this module
        MANDATORY-GROUPS { mauRpGrpBasic }
        GROUP mauRpGrp100Mbs
        DESCRIPTION
            "Implementation of this optional group is
            recommended for MAUs which have 100Mb/s
            capability."
        GROUP mauRpGrpJack
        DESCRIPTION
            "Implementation of this optional group is
            recommended for MAUs which have one or more
            external jacks."
        GROUP rpMauNotifications
        DESCRIPTION
            "Implementation of this group is
            recommended for MAUs attached to repeater
            ports."
    ::= { mauModCompls 1 }
mauModIfCompl MODULE-COMPLIANCE
    STATUS
                current
    DESCRIPTION
        "Compliance for MAUs attached to interfaces."
    MODULE -- this module
        MANDATORY-GROUPS { mauIfGrpBasic }
        GROUP mauIfGrp100Mbs
        DESCRIPTION
            "Implementation of this optional group is
            recommended for MAUs which have 100Mb/s capability."
```

```
GROUP mauIfGrpJack
    DESCRIPTION
         "Implementation of this optional group is
         recommended for MAUs which have one or more
        external jacks."
    GROUP mauIfGrpAutoNeg
    DESCRIPTION
         "Implementation of this group is
        mandatory for MAUs which support
        managed auto-negotiation."
    GROUP mauBroadBasic
    DESCRIPTION
        "Implementation of this group is mandatory for broadband MAUs."
    GROUP ifMauNotifications
    DESCRIPTION
         "Implementation of this group is
        recommended for MAUs attached to interfaces."
::= { mauModCompls 2 }
```

END

4. Acknowledgements

This document was produced by the IETF Hub MIB Working Group, whose efforts were greatly advanced by the contributions of the following people:

Chuck Black
John Flick
Jeff Johnson
Leon Leong
Mike Lui
Dave Perkins
Geoff Thompson
Maurice Turcotte
Paul Woodruff

Special thanks as well to Dave Perkins for his excellent work on the SMICng compiler, which made it easy to take advantage of the latest SNMPv2 constructs in this MIB.

5. References

- IEEE 802.3/ISO 8802-3 Information processing systems -Local area networks - Part 3: Carrier sense multiple access with collision detection (CSMA/CD) access method and physical layer specifications, 1993.
- IEEE 802.3u-1995, "MAC Parameters, Physical Layer, Medium Attachment Units and Repeater for 100 Mb/s Operation, Type 100BASE-T," Sections 21 through 29, Supplement to IEEE Std 802.3, October 26, 1995. Γ21
- IEEE 802.3u-1995, "10 & 100 Mb/s Management," Section 30,
 Supplement to IEEE Std 802.3, October 26, 1995. Γ31
- de Graaf, K., D. Romascanu, D. McMaster and K. McCloghrie, "Definitions of Managed Objects for IEEE Γ4] 802.3 Repeater Devices using SMIv2", RFC 2108, February 1997.
- McCloghrie, K. and M. Rose, Editors, "Management Information Base for Network Management of TCP/IP-based [5] internets: MIB-II", STD 17, RFC 1213, March 1991.
- Case, J., McCloghrie, K., Rose, M. and S. Waldbusser, "Structure of Management Information for version 2 of the Γ61 Simple Network Management Protocol (SNMPv2)", RFC 1902, January 1996.
- Case, J., McCloghrie, K., Rose, M. and S. Waldbusser, "Textual Conventions for version 2 of the Simple Network Management Γ7] Protocol (SNMPv2)", RFC 1903, January 1996.
- Case, J., McCloghrie, K., Rose, M. and S. Waldbusser, "Conformance Statements for version 2 of the Simple Network Management Protocol (SNMPv2)", RFC 1904, January 1996. Г87
- Case, J., McCloghrie, K., Rose, M. and S. Waldbusser, "Protocol Г91 Operations for version 2 of the Simple Network Management Protocol (SNMPv2)", RFC 1905, January 1996.
- [10] Case, J., M. Fedor, M. Schoffstall and J. Davin, "Simple Network Management Protocol", STD 15, RFC 1157, May 1990.
- [11] McMaster, D., K. McCloghrie and S. Roberts, "Definitions of Managed Objects for IEEE 802.3 Medium Attachment Units (MAUS)", RFC 1515, September 1993.

6. Security Considerations

Certain management information defined in this MIB may be considered sensitive in some network environments. Therefore, authentication of received SNMP requests and controlled access to management information should be employed in such environments. The method for this authentication is a function of the SNMP Administrative Framework, and has not been expanded by this MIB.

Several objects in this MIB allow write access. Setting these objects can have a serious effect on the operation of the network, including enabling or disabling a MAU, changing a MAU's default type, enabling, disabling or restarting autonegotiation, or modifying the capabilities that a MAU advertizes during autonegotiation. It is recommended that implementers seriously consider whether set operations should be allowed without providing, at a minimum, authentication of request origin.

7. Authors' Addresses

Kathryn de Graaf 3Com Corporation 118 Turnpike Rd. Southborough, MA 01772 USA

Phone: (508)229-1627 (508)490-5882 Fax:

EMail: kdegraaf@isd.3com.com

Dan Romascanu Madge Networks (Israel) Ltd. Atidim Technology Park, Bldg. 3 Tel Aviv 61131, Israel

Phone: 972-3-6458414, 6458458

972-3-6487146 EMail: dromasca@madge.com

Donna McMaster Cisco Systems Inc. 170 West Tasman Drive San Jose, CA 95134

Phone:: (408) 526-5260 EMail: mcmaster@cisco.com

Keith McCloghrie Cisco Systems Inc. 170 West Tasman Drive San Jose, CA 95134

Phone: (408) 526-5260 EMail: kzm@cisco.com

Sam Roberts Farallon Computing, Inc. 2470 Mariner Square Loop Alameda, CA 94501-1010

Phone:: (510) 814-5215

EMail: sroberts@farallon.com

8. Full Copyright Statement

Copyright (C) The Internet Society (1997). All Rights Reserved.

This document and translations of it may be copied and furnished to others, and derivative works that comment on or otherwise explain it or assist in its implementation may be prepared, copied, published and distributed, in whole or in part, without restriction of any kind, provided that the above copyright notice and this paragraph are included on all such copies and derivative works. However, this document itself may not be modified in any way, such as by removing the copyright notice or references to the Internet Society or other Internet organizations, except as needed for the purpose of developing Internet standards in which case the procedures for copyrights defined in the Internet Standards process must be followed, or as required to translate it into languages other than English.

The limited permissions granted above are perpetual and will not be revoked by the Internet Society or its successors or assigns.

This document and the information contained herein is provided on an "AS IS" basis and THE INTERNET SOCIETY AND THE INTERNET ENGINEERING TASK FORCE DISCLAIMS ALL WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY WARRANTY THAT THE USE OF THE INFORMATION HEREIN WILL NOT INFRINGE ANY RIGHTS OR ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.