Network Working Group Request for Comments: 1232 F. Baker
Advanced Computer Communications, Inc.
C. Kolb
Performance Systems International, Inc.
Editors
May 1991

Definitions of Managed Objects for the DS1 Interface Type

Status of this Memo

This memo defines objects for managing DS1 Interface objects for use with the SNMP protocol. This memo is a product of the Transmission MIB Working Group of the Internet Engineering Task Force (IETF). This RFC specifies an IAB standards track protocol for the Internet community, and requests discussion and suggestions for improvements. Please refer to the current edition of the "IAB Official Protocol Standards" for the standardization state and status of this protocol. Distribution of this memo is unlimited.

Table of Contents

1. Abstract	. 1
2. The Network Management Framework	. 2
3. Objects	. 2
3.1 Format of Definitions	3
4. Overview	. 3
4.1 Binding between Interfaces and CSUs	3
4.2 Objectives of this MIB Module	4
4.3 DS1 Terminology	4
5. Definitions	. 6
5.1 The DS1 Configuration Group	6
5.2 The DS1 Interval Group	13
5.3 The DS1 Current Group	16
5.4 The DS1 Total Group	19
5.5 The DS1 Fractional Group	22
6. Acknowledgements	. 25
7. References	. 26
8. Security Considerations	. 27
9. Authors' Addresses	. 28

1. Abstract

This memo defines an experimental portion of the Management Information Base (MIB) for use with network management protocols in TCP/IP-based internets. In particular, this memo defines MIB objects

for representing DS1 physical interfaces. Implementors should consult in addition to this memo the companion document that describes that DS3 managed objects.

2. The Network Management Framework

The Internet-standard Network Management Framework consists of three components. They are:

RFC 1155 which defines the SMI, the mechanisms used for describing and naming objects for the purpose of management. RFC 1212 defines a more concise description mechanism, which is wholly consistent with the SMI.

RFC 1156 which defines MIB-I, the core set of managed objects for the Internet suite of protocols. RFC 1213, defines MIB-II, an evolution of MIB-I based on implementation experience and new operational requirements.

RFC 1157 which defines the SNMP, the protocol used for network access to managed objects.

The Framework permits new objects to be defined for the purpose of experimentation and evaluation.

3. Objects

Managed objects are accessed via a virtual information store, termed the Management Information Base or MIB. Objects in the MIB are defined using the subset of Abstract Syntax Notation One (ASN.1) [7] defined in the SMI. In particular, each object has a name, a syntax, and an encoding. The name is an object identifier, an administratively assigned name, which specifies an object type. The object type together with an object instance serves to uniquely identify a specific instantiation of the object. For human convenience, we often use a textual string, termed the OBJECT DESCRIPTOR, to also refer to the object type.

The syntax of an object type defines the abstract data structure corresponding to that object type. The ASN.1 language is used for this purpose. However, the SMI [3] purposely restricts the ASN.1 constructs which may be used. These restrictions are explicitly made for simplicity.

The encoding of an object type is simply how that object type is represented using the object type's syntax. Implicitly tied to the notion of an object type's syntax and encoding is how the object type is represented when being transmitted on the network.

The SMI specifies the use of the basic encoding rules of ASN.1 [8], subject to the additional requirements imposed by the SNMP.

3.1. Format of Definitions

Section 5 contains contains the specification of all object types contained in this MIB module. The object types are defined using the conventions defined in the SMI, as amended by the extensions specified in [13].

4. Overview

These objects are used when the particular media being used to realize an interface is a DS1 physical interface. At present, this applies to these values of the ifType variable in the Internetstandard MIB:

The definitions contained herein are based on the AT&T T-1 specifications and Extended Superframe (ESF) format [9, 10], the latter of which conforms to proposed ANSI specifications [14, 15]. The various T1 and E1 line disciplines are similar enough that separate MIBs are unwarranted, although there are some differences. For example, Loss of Frame is defined more rigorously in the ESF specification than in the D4 specification, but it is defined in both.

4.1. Binding between Interfaces and CSUs

It should be noted that it is possible to multiplex multiple bit streams onto a single DS1 physical interface (CSU), realizing multiple interfaces from the perspective of the Internet-standard MIB. It is also possible to concatenate physical interfaces to provide a single logical interface. As such, it is important to be able to distinguish between the indices used to identify the CSUs attached to a node and the indices used to identify an interface (in the MIB sense) attached to a node.

Each agent which resides on a host which uses DS1 physical interfaces is required to assign a small, positive integer uniquely to each CSU. This is known as the "CSUIndex", and is used to distinguish between different CSUs attached to a node. The CSUIndex is also used as the "key" when accessing tabular information about DS1 physical interfaces.

The potentially many-to-one binding between CSU indices and the

ifIndex value assigned to each MIB interface are defined in the ds1ConfigTable table defined in the next section.

4.2. Objectives of this MIB Module

There are numerous things that could be included in a MIB for DS1 Interfaces: the management of multiplexors, CSUs, DSUs, and the like. The intent of this document is to facilitate the common management of CSUs, both in-chassis and external via proxy. As such, a design decision was made up front to very closely align the MIB with the set of objects that can generally be read from CSUs that are currently deployed, which is to say ESF CSUs conforming to AT&T specifications. However, by simple generalization of these objects, the MIB is also made applicable to D4 and G.704 devices.

To meet a requirement not easily satisfied in other places, there is one additional group present, the Fractional DS1 group. This is intended to facilitate the use of fractional DS1 devices (i.e., devices which utilize a subset of the 8 bit channels available in the frame) over the managed CSUs.

4.3. DS1 Terminology

The terminology used in this document to describe error conditions on a T1 or E1 circuit monitored by a CSU are from references [10], [11], [14], and [15].

- Out of Frame event

 An Out of Frame event is declared when the receiver detects two or more framing-bit errors within a 3 millisecond period, or two or more errors out of five or less consecutive framing-bits. At this time, the framer enters the Out of Frame State and starts searching for
 - less consecutive framing-bits. At this time, the framer enters the Out of Frame State, and starts searching for a correct framing pattern. The Out of Frame state ends when reframe occurs.
- Loss of Signal
 This event is declared upon observing 175 +/- 75
 contiguous pulse positions with no pulses of either
 positive or negative polarity (also called keep alive).
- Code Violation Error Event
 A Code Violation Error Event is the occurrence of a received Cyclic Redundancy Check code that is not identical to the corresponding locally-calculated code.
- Bipolar Violation A Bipolar Violation, for B8ZS-coded signals, is the

occurrence of a received bipolar violation that is not part of a zero-substitution code. It also includes other error patterns such as: eight or more consecutive zeros and incorrect parity.

Errored Seconds

An Errored Second is a second with one or more Code Violation Error Events OR one or more Out of Frame events. In D4 and G.704 section 2.1.3.2 (eg, G.704 which does not implement the CRC), the presence of Bipolar Violations also triggers an Errored Second.

Severely Errored Seconds

A Severely Errored Second is a second with 320 or more Code Violation Error Events OR one or more Out of Frame events.

Severely Errored Framing Second

An Severely Errored Framing Second is a second with one or more Out of Frame events.

Unavailable Signal State

This state is declared at the onset of 10 consecutive Severely Errored Seconds. It is cleared at the onset of 10 consecutive seconds with no Severely Errored Second.

Unavailable Seconds

Unavailable Seconds are calculated by counting the number of seconds that the CSU is in the Unavailable Signal State, including the initial 10 seconds to enter the state but not including the 10 seconds to exit the state.

Note that any second that may be counted as an Unavailable Second may not be counted as an Errored Second, a Severely Errored Second. Since the 10 Severely Errored Seconds that comprise the transition from the available to Unavailable Signal State may also be counted as Errored Seconds, and Severely Errored Seconds previous to entering the state, these three counters are adjusted so that any second counted during this transition is then subtracted. The 10 seconds in the transition from unavailable to available may be counted as Errored Seconds.

A special case exists when the 10 or more second period crosses the 900 second statistics window boundary, as the foregoing description implies that the Severely Errored Second and Unavailable Second counters must be adjusted

when the Unavailable Signal State is entered. Clearly, successive GETs of the affected ds1IntervalSES and ds1IntervalUAS objects will return differing values if the first GET occurs during the first few seconds of the window. This is viewed as an unavoidable side-effect of selecting the presently deployed AT&T objects as a basis for this memo.

Yellow Alarm

A Yellow Alarm is declared because of an incoming Yellow Signal from the far-end. In effect, the circuit is declared to be a one way link.

Red Alarm

A Red Alarm is declared because of an incoming Loss of Signal, Loss of Framing, Alarm Indication Signal. After a Red Alarm is declared, the device sends a Yellow Signal to the far-end. The far-end, when receives the Yellow Signal, declares a Yellow Alarm.

Circuit Identifier

This is a character string specified by the circuit vendor, and is useful when communicating with the vendor during the troubleshooting process.

5. Definitions

RFC1232-MIB DEFINITIONS ::= BEGIN

IMPORTS

experimental, Counter
FROM RFC1155-SMI
DisplayString
FROM RFC1158-MIB
OBJECT-TYPE
FROM RFC-1212;

- -- This MIB module uses the extended OBJECT-TYPE macro as defined in [13].
- -- this is the MIB module for ds1 objects

ds1 OBJECT IDENTIFIER ::= { experimental 2 }

-- the DS1 Configuration group

```
-- Although the objects in this group are read-only, at the
-- agent's discretion they may be made read-write so that the
-- management station, when appropriately authorized, may
-- change the behavior of the CSU, e.g., to place the device -- into a loopback state or emit a QRSS BER test.
-- Implementation of this group is mandatory for all systems
-- that attach to a ds1.
ds1ConfigTable OBJECT-TYPE
            SEQUENCE OF DS1ConfigEntry
    SYNTAX
            not-accessible
    ACCESS
    STATUS
            mandatory
    DESCRIPTION
             "The DS1 Configuration table."
    ::= { ds1 1 }
ds1ConfigEntry OBJECT-TYPE
            DS1ConfigEntry
    SYNTAX
    ACCESS
             not-accessible
    STATUS mandatory
    DESCRIPTION
             "An entry in the DS1 Configuration table."
            { ds1CSUIndex }
    ::= { ds1ConfigTable 1 }
DS1ConfigEntry ::=
    SEQUENCE {
        ds1CSUIndex
             INTEGER,
        ds1Index
             INTEGER,
        ds1TimeElapsed
             INTEGER (1..900),
        ds1ValidIntervals
             INTEGER (0..96),
        ds1LineType
             INTEGER,
        ds1ZeroCoding
             INTEGER,
        ds1Loopback
             INTEGER,
        ds1SendCode
             INTEGER,
        ds1YellowAlarm
             INTEGER,
        ds1RedAlarm
             INTEGER,
```

```
ds1CircuitIdentifier
             DisplayString (SIZE (0..255))
}
ds1CSUIndex OBJECT-TYPE
    SYNTAX
             INTEGER
             read-only
    ACCESS
    STATUS
             mandatory
    DESCRIPTION
             "The index value which uniquely identifies the CSU
             to which this entry is applicable."
    ::= { ds1ConfigEntry 1 }
ds1Index OBJECT-TYPE
    SYNTAX
            INTEGER
    ACCESS
             read-only
    STATUS
             mandatory
    DESCRIPTION
             "An index value that uniquely identifies an
             interface to a ds1. The interface identified by a particular value of this index is the same interface as identified by the same value an
             ifIndex object instance.'
    ::= { ds1ConfigEntry 2 }
ds1TimeElapsed OBJECT-TYPE
             INTEGER (1..900)
    SYNTAX
             read-only
    ACCESS
    STATUS
             mandatory
    DESCRIPTION
             "The number of seconds that have elapsed since the
             beginning of the current error-measurement period.
             Any fraction is rounded up."
    ::= { ds1ConfigEntry 3 }
ds1ValidIntervals OBJECT-TYPE
    SYNTAX INTEGER (0..96)
    ACCESS
             read-only
    STATUS
             mandatory
    DESCRIPTION
             "The number of previous intervals for which valid
             data was collected. The value will be 96 unless
             the CSU device was brought online within the last
             24 hours, in which case the value will be the
             number of complete 15 minute intervals the CSU has
             been online."
    ::= { ds1ConfigEntry 4 }
```

```
ds1LineType OBJECT-TYPE
    SYNTAX INTEGER {
                  other(1)
                  ds1ESF(2),
                  ds1D4(3),
                  ds1ANŠI-ÉSF(4),
                  ds1G704(5)
                  ds1G704-CRC(6)
    ACCESS
             read-only
    STATUS
             mandatory
    DESCRIPTION
             "This variable indicates the variety of DS1 Line
             implementing this circuit. The type of circuit
             affects the number of bits per second that the
             circuit can reasonably carry, as well as the
             interpretation of the usage and error statistics.
             The values, in sequence, describe:
                            SPECIFICATION:
             TITLE:
                             AT&T Extended SuperFrame DS1 [10]
AT&T D4 format DS1 [16], [17]
ANSI Extended SuperFrame format [14]
             ds1ESF
             ds1D4
             ds1ANSI-ESF
                             CCITT Recommendation G.704 [12]
             ds1G704
                               (section 2.1.3.2)
             ds1G704-CRC
                             CCITT Recommendation G.704 [12]
                               (section 2.1.3.1)
    ::= { ds1ConfigEntry 5 }
ds1ZeroCoding OBJECT-TYPE
    SYNTAX INTEGER {
                  ds1JammedBit(1),
                  ds1B8ZS(2),
                  ds1InvertedHDLC(3).
                  ds1HDB3(4),
                 ds1ZBTSI(5)
             }
    ACCESS
             read-only
    STATUS
             mandatory
    DESCRIPTION
             "This variable describes the variety of Zero Code Suppression used on the link, which in turn
             affects a number of its characteristics.
             ds1JammedBit refers the Jammed bit Zero Encoding,
             in which the AT&T specification of at least one
             pulse every 8 bit periods is literally implemented
```

by forcing a pulse in bit 8 of each channel. Thus, only seven bits per channel, or 1.344 Mbps, is available for data.

ds1B8ZS refers to the use of a specified pattern of normal bits and bipolar violations which are used to replace a sequence of eight zero bits (see [14]). In this context, all eight bits in a channel are technically available for data, but care must be taken with D4 encoded data to avoid having HDLC Flag streams imitate spurious Yellow Alarm conditions. Typically, one bit per frame is ignored to force flag streams to rotate, thereby avoiding this error type. CCITT Recommendation G.703 [11] may be referred to for further definition of these.

ds1InvertedHDLC refers to the practice, common on HDLC encoded DS1 data links, of inverting the data between the serial interface chip and the CSU. Since HDLC guarantees one zero every 6 bits in the worst case, while the standards call for (in effect) at least one pulse every eight, inverted HDLC enjoys 4/24 one's density on the line, which may improve the effective clock stability of a DS1 line. As with B8ZS, all eight bits in a channel are technically available for data, but care must be taken with D4 encoded data to avoid having HDLC Flag streams imitate spurious Yellow Alarm conditions. Typically, one bit per frame is ignored to force flag streams to rotate, thereby avoiding this error type.

ANSI Clear Channels may use ds1ZBTSI, or Zero Byte Time Slot Interchange (see [14]).

```
ACCESS read-only
STATUS mandatory
DESCRIPTION
```

"This variable represents the loopback state of the CSU. Devices supporting read/write access should return badValue in response to a requested loopback state that the CSU does not support. The values mean:

ds1NoLoop

Not in the loopback state. A device that is not capable of performing a loopback on either interface shall always return this as it's value.

ds1LocalLoopbackLocalSide

Signal received from the local side of the device is looped back at the local connector (eg, without involving the CSU).

ds1LocalLoopbackRemoteSide

Signal received from the local side of the device is looped back at the remote connector (eg, through the CSU).

ds1RemoteLoopbackLocalSide

Signal received from the remote side of the device is looped back at the local connector (eg, through the CSU).

ds1RemoteLoopbackRemoteSide

```
Signal received from the remote side of the device is looped back at the remote connector (eg, without involving the CSU)."
::= { ds1ConfigEntry 7 }
```

```
ds1SendCode OBJECT-TYPE
SYNTAX INTEGER {
```

ds10therTest(1),
ds1SendNoCode(2),
ds1SendSetCode(3),
ds1SendResetCode(4),
ds1SendQRSS(5)

```
}
    ACCESS
            read-only
    STATUS
            mandatory
    DESCRIPTION
       "This variable indicates what type of code is
       being sent across the DS1 circuit by the CSU.
                                                        The
       values mean:
                         sending looped or normal data
       ds1SendNoCode
                         sending a loopback request
       ds1SendSetCode
       ds1SendResetCode sending a loopback termination request
                         sending the BERT pattern described in ANSI T1.403-1989 section 5.6
       ds1SendQRSS
                         sending a different BERT/BLERT pattern,
       ds10therTest
                         such as all zeroes, all ones, etc.
    ::= { ds1ConfigEntry 8 }
ds1YellowAlarm OBJECT-TYPE
    SYNTAX INTEGER {
                ds1NoYellowAlarm (1),
                ds1YellowAlarm (2)
    ACCESS
            read-only
    STATUS
            mandatory
    DESCRIPTION
            "This variable indicates if a Yellow Alarm
            condition exists.
            Note that G.704 interfaces do not support Yellow
            Alarms. Accordingly, such agents should return
            the value ds1NoYellowAlarm."
    ::= { ds1ConfigEntry 9 }
ds1RedAlarm OBJECT-TYPE
    SYNTAX INTEGER {
                ds1NoRedAlarm (1),
                ds1RedAlarm (2)
    ACCESS
            read-only
    STATUS
            mandatory
    DESCRIPTION
            "This variable indicates if a Red Alarm condition
            exists.
            Note that G.704 interfaces do not support Red
            Alarms. Accordingly, such agents should return
            the value ds1NoRedAlarm."
    ::= { ds1ConfigEntry 10 }
```

```
ds1CircuitIdentifier OBJECT-TYPE
    SYNTAX
            DisplayString (SIZE (0..255))
    ACCESS
            read-only
    STATUS
            mandatory
    DESCRIPTION
            "This variable contains the transmission vendor's
    circuit identifier, for the purpose of facilitating troubleshooting."
::= { ds1ConfigEntry 11 }
-- the DS1 Interval group
-- Implementation of this group is mandatory for all systems
-- that attach to a ds1.
-- It is recognized that some currently deployed CSUs do not
-- record the entire set of statistics specified in this
-- group. Accordingly, some agents queried for these objects
-- may treat these objects as having an ACCESS clause value
-- of not-accessible.
-- The DS1 Interval Table contains various statistics
-- collected by each CSU over the previous 24 hours of
-- operation. The past 24 hours are broken into 96 completed
-- 15 minute intervals.
ds1IntervalTable OBJECT-TYPE
    SYNTAX SEQUENCE OF DS1IntervalEntry
    ACCESS
            not-accessible
    STATUS mandatory
    DESCRIPTION
            "The DS1 Interval table."
    ::= { ds1 2 }
ds1IntervalEntry OBJECT-TYPE
    SYNTAX DS1IntervalEntry
    ACCESS
            not-accessible
    STATUS
            mandatory
    DESCRIPTION
            "An entry in the DS1 Interval table."
            { ds1IntervalIndex, ds1IntervalNumber }
    ::= { dsiIntervalTable 1 }
DS1IntervalEntry ::=
    SEQUENCE {
        ds1IntervalIndex
            INTEGER,
```

```
ds1IntervalNumber
             INTEGER (1..96),
         ds1IntervalESs
             Counter,
         ds1IntervalŚESs
         Counter, ds1IntervalSEFSs
         Counter, ds1IntervalUASs
             Counter,
         ds1IntervalCSSs
             Counter,
         ds1IntervalBPVs
         Counter,
ds1IntervalCVs
             Counter
    }
ds1IntervalIndex OBJECT-TYPE
    SYNTAX
             INTEGER
             read-only
    ACCESS
    STATUS
             mandatory
    DESCRIPTION
             "The index value which uniquely identifies the CSU
             to which this entry is applicable. The interface
             identified by a particular value of this index is
             the same interface as identified by the same value an ds1CSUIndex object instance."
    ::= { ds1IntervalEntry 1 }
ds1IntervalNumber OBJECT-TYPE
    SYNTAX
             INTEGER (1..96)
    ACCESS
             read-only
    STATUS
             mandatorv
    DESCRIPTION
             "A number between 1 and 96, where 1 is the most
             recently completed 15 minute interval and 96 is
             the least recently completed 15 minute interval (assuming that all 96 intervals are valid)."
    ::= { ds1IntervalEntry 2 }
ds1IntervalESs OBJECT-TYPE
    SYNTAX Counter
    ACCESS
             read-only
    STATUS
             mandatory
    DESCRIPTION
              "The counter associated with the number of Errored
             Seconds, as defined by ANSI Draft Standard
```

```
T1M1.3/90 - 027R2[15], encountered by a DS1 CSU
             during one of the previous 96 fifteen minute
             intervals."
    ::= { ds1IntervalEntry 3 }
ds1IntervalSESs OBJECT-TYPE
    SYNTAX
             Counter
    ACCESS
             read-only
    STATUS
             mandatory
    DESCRIPTION
             "The counter associated with the number of
             Severely Errored Seconds, as defined by ANSI Draft
             Standard T1M1.3/90 - 027Ŕ2[15], encountered by a
             DS1 CSU during one of the previous 96 fifteen
             minute intervals.'
    ::= { ds1IntervalEntry 4 }
ds1IntervalSEFSs OBJECT-TYPE
    SYNTAX Counter
    ACCESS
             read-only
    STATUS
             mandatory
    DESCRIPTION
             "The counter associated with the number of
             Severely Errored Framing Seconds, as defined by ANSI Draft Standard T1M1.3/90 - 027R2[15],
             encountered by a DS1 CSU during one of the
             previous 96 fifteen minute intervals."
    ::= { ds1IntervalEntry 5 }
ds1IntervalUASs OBJECT-TYPE
    SYNTAX
             Counter
    ACCESS
             read-only
    STATUS
             mandatory
    DESCRIPTION
             "The counter associated with the number of Unavailable Seconds, as defined by ANSI Draft
             Standard T1M1.3/90 - 027R2[15], encountered by a
             DS1 CSU during one of the previous 96 fifteen
             minute intervals."
    ::= { ds1IntervalEntry 6 }
ds1IntervalCSSs OBJECT-TYPE
    SYNTAX Counter
    ACCESS
             read-only
    STATUS
             mandatory
    DESCRIPTION
             "The counter associated with the number of
             Controlled Slip Seconds, as defined by ANSI Draft
```

```
Standard T1M1.3/90 - 027R2[15], encountered by a
             DS1 CSU during one of the previous 96 fifteen
             minute intervals."
    ::= { ds1IntervalEntry 7 }
ds1IntervalBPVs OBJECT-TYPE
    SYNTAX
             Counter
    ACCESS
             read-only
    STATUS
             mandatory
    DESCRIPTION
             "The counter associated with the number of Bipolar
             Violations, as defined by ANSI Draft Standard
             T1M1.3/90 - 027R2[15], encountered by a DS1 CSU
             during one of the previous 96 fifteen minute intervals."
    ::= { ds1IntervalEntry 8 }
ds1IntervalCVs OBJECT-TYPE
    SYNTAX Counter
    ACCESS
             read-only
    STATUS
             mandatory
    DESCRIPTION
             "The counter associated with the number of Code
             Violation Error Events, as defined by ANSI Draft Standard T1M1.3/90 - 027R2[15], encountered by a
             DS1 CSU during one of the previous 96 fifteen
             minute intervals.
             Note that D4 and G.704 (section 2.1.3.2)
             interfaces do not support Code Violation Error
             Events. Accordingly, such agents may treat this object as having an ACCESS clause value of not-
             accessible."
    ::= { ds1IntervalEntry 9 }
-- the DS1 Current group
-- Implementation of this group is mandatory for all systems
-- that attach to a ds1.
-- It is recognized that some currently deployed CSUs do not
-- record the entire set of statistics specified in this
-- group. Accordingly, some agents queried for these objects
-- may treat these objects as having an ACCESS clause value
-- of not-accessible.
```

-- The DS1 current table contains various statistics being

```
-- collected for the current 15 minute interval.
ds1CurrentTable OBJECT-TYPE
    SYNTAX
            SEQUENCE OF DS1CurrentEntry
    ACCESS
             not-accessible
    STATUS mandatory
    DESCRIPTION
              "The DS1 Current table."
    ::= { ds1 3 }
ds1CurrentEntry OBJECT-TYPE
    SYNTAX DS1CurrentEntry
             not-accessible
    ACCESS
    STATUS
             mandatory
    DESCRIPTION
              "An entry in the DS1 Current table."
              { ds1CurrentIndex }
    ::= { ds1CurrentTable 1 }
DS1CurrentEntry ::=
    SEQUENCE {
         ds1CurrentIndex
              INTEGER,
         ds1CurrentESs
              Counter.
         ds1CurrentSESs
              Counter
         ds1CurrentSÉFSs
              Counter,
         ds1CurrentUÁSs
              Counter,
         ds1CurrentCŚSs
              Counter,
         ds1CurrentBPVs
         Counter, ds1CurrentCVs
              Counter
    }
ds1CurrentIndex OBJECT-TYPE
    SYNTAX INTEGER
    ACCESS
              read-only
    STATUS
             mandatory
    DESCRIPTION
              "The index value which uniquely identifies the CSU
              to which this entry is applicable. The interface identified by a particular value of this index is the same interface as identified by the same value
```

```
an ds1CSUIndex object instance."
    ::= { ds1CurrentEntry 1 }
ds1CurrentESs OBJECT-TYPE
    SYNTAX
             Counter
    ACCESS
             read-only
    STATUS
             mandatory
    DESCRIPTION
             "The counter associated with the number of Errored
             Seconds, as defined by ANSI Draft Standard
             T1M1.3/90 - 027R2[15], encountered by a DS1 CSU in
             the current 15 minute interval."
    ::= { ds1CurrentEntry 2 }
ds1CurrentSESs OBJECT-TYPE
    SYNTAX
            Counter
    ACCESS
             read-only
    STATUS
             mandatory
    DESCRIPTION
             "The counter associated with the number of
             Severely Errored Seconds, as defined by ANSI Draft Standard T1M1.3/90 - 027R2[15], encountered by a
             DS1 CSU in the current 15 minute interval.'
    ::= { ds1CurrentEntry 3 }
ds1CurrentSEFSs OBJECT-TYPE
    SYNTAX
             Counter
    ACCESS
             read-only
    STATUS
             mandatory
    DESCRIPTION
             "The counter associated with the number of
             Severely Errored Framing Seconds, as defined by ANSI Draft Standard T1M1.3/90 - 027R2[15],
             encountered by a DS1 CSU in the current 15 minute
             interval.
    ::= { ds1CurrentEntry 4 }
ds1CurrentUASs OBJECT-TYPE
    SYNTAX Counter
    ACCESS
             read-only
    STATUS
             mandatory
    DESCRIPTION
             "The counter associated with the number of
             Unavailable Seconds, as defined by ANSI Draft
             Standard T1M1.3/90 - 027R2[15], encountered by a
             DS1 CSU in the current 15 minute interval."
    ::= { ds1CurrentEntry 5 }
```

```
ds1CurrentCSSs OBJECT-TYPE
    SYNTAX
             Counter
    ACCESS
              read-only
    STATUS
             mandatory
    DESCRIPTION
              "The counter associated with the number of
             Controlled Slip Seconds, as defined by ANSI Draft Standard T1M1.3/90 - 027R2[15], encountered by a
              DS1 CSU in the current 15 minute interval.'
    ::= { ds1CurrentEntry 6 }
ds1CurrentBPVs OBJECT-TYPE
    SYNTAX Counter
    ACCESS
              read-only
    STATUS
             mandatory
    DESCRIPTION
              "The counter associated with the number of Bipolar
              Violations, as defined by ANSI Draft Standard
             T1M1.3/90 - 027R2[15], encountered by a DS1 CSU in the current 15 minute interval."
    ::= { ds1CurrentEntry 7 }
ds1CurrentCVs OBJECT-TYPE
    SYNTAX Counter
    ACCESS
              read-only
    STATUS
             mandatory
    DESCRIPTION
              "The counter associated with the number of Code
             Violation Error Events, as defined by ANSI Draft Standard T1M1.3/90 - 027R2[15], encountered by a
              DS1 CSU in the current 15 minute interval.
             Note that D4 and G.704 (section 2.1.3.2)
              interfaces do not support Code Violation Error
             Events. Accordingly, such agents may treat this object as having an ACCESS clause value of not-
              accessible."
    ::= { ds1CurrentEntry 8 }
-- the DS1 Total group
-- Implementation of this group is mandatory for all systems
-- that attach to a ds1.
-- It is recognized that some currently deployed CSUs do not
-- record the entire set of statistics specified in this
-- group. Accordingly, some agents queried for these objects
```

```
-- may treat these objects as having an ACCESS clause value
-- of not-accessible.
-- The DS1 Total Table contains the cumulative sum of the
-- various statistics for the 24 hour interval preceding the
-- first valid interval in the ds1CurrentTable.
ds1TotalTable OBJECT-TYPE
    SYNTAX SEQUENCE OF DS1TotalEntry
    ACCESS
            not-accessible
    STATUS mandatory
    DESCRIPTION
            "The DS1 Total table. 24 hour interval."
    ::= { ds1 4 }
ds1TotalEntry OBJECT-TYPE
    SYNTAX DS1TotalEntry
            not-accessible
    ACCESS
    STATUS
            mandatory
    DESCRIPTION
            "An entry in the DS1 Total table."
    INDEX
            { ds1TotalIndex }
    ::= { ds1TotalTable 1 }
DS1TotalEntry ::=
    SEQUENCE {
        ds1TotalIndex
            INTEGER,
        ds1TotalESs
            Counter,
        ds1TotalSESs
            Counter,
        ds1TotalSEFŚs
            Counter,
        ds1TotalUASs
            Counter,
        ds1TotalCSSs
            Counter,
        ds1TotalBPVs
            Counter,
        ds1TotalCVs
            Counter
    }
ds1TotalIndex OBJECT-TYPE
    SYNTAX
           INTEGER
    ACCESS
            read-only
    STATUS mandatory
```

```
DESCRIPTION
             "The index value which uniquely identifies the CSU
             to which this entry is applicable. The interface
             identified by a particular value of this index is
             the same interface as identified by the same value
             an ds1CSUIndex object instance."
    ::= { ds1TotalEntry 1 }
ds1TotalESs OBJECT-TYPE
    SYNTAX Counter
    ACCESS
             read-only
    STATUS
            mandatory
    DESCRIPTION
             "The counter associated with the number of Errored
            Seconds, as defined by ANSI Draft Standard
            T1M1.3/90 - 027R2[15], encountered by a DS1 CSU in the previous 24 hour interval"
    ::= { ds1TotalEntry 2 }
ds1TotalSESs OBJECT-TYPE
    SYNTAX Counter
    ACCESS
             read-only
    STATUS
            mandatory
    DESCRIPTION
             "The counter associated with the number of
             Severely Errored Seconds, as defined by ANSI Draft
            Standard T1M1.3/90 - 027R2[15], encountered by a
            DS1 CSU in the previous 24 hour interval.
    ::= { ds1TotalEntry 3 }
ds1TotalSEFSs OBJECT-TYPE
    SYNTAX Counter
    ACCESS
             read-only
    STATUS
            mandatorv
    DESCRIPTION
             "The counter associated with the number of
            Severely Errored Framing Seconds, as defined by ANSI Draft Standard T1M1.3/90 - 027R2[15],
            encountered by a DS1 CSU in the previous 24 hour
             interval."
    ::= { ds1TotalEntry 4 }
ds1TotalUASs OBJECT-TYPE
    SYNTAX
            Counter
    ACCESS
             read-only
    STATUS
            mandatory
    DESCRIPTION
             "The counter associated with the number of
```

```
Unavailable Seconds, as defined by ANSI Draft
             Standard T1M1.3/90 - 027R2[15], encountered by a
             DS1 CSU in the previous 24 hour interval.'
    ::= { ds1TotalEntry 5 }
ds1TotalCSSs OBJECT-TYPE
    SYNTAX
            Counter
    ACCESS
             read-only
    STATUS
             mandatory
    DESCRIPTION
             "The counter associated with the number of
             Controlled Slip Seconds, as defined by ANSI Draft
             Standard T1M1.3/90 - 027R2[15], encountered by a
             DS1 CSU in the previous 24 hour interval.
    ::= { ds1TotalEntry 6 }
ds1TotalBPVs OBJECT-TYPE
    SYNTAX
             Counter
             read-only
    ACCESS
    STATUS
            mandatory
    DESCRIPTION
             "The counter associated with the number of Bipolar
             Violations, as defined by ANSI Draft Standard
             T1M1.3/90 - 027R2[15], encountered by a DS1 CSU in
             the previous 24 hour interval."
    ::= { ds1TotalEntry 7 }
ds1TotalCVs OBJECT-TYPE
    SYNTAX
             Counter
    ACCESS
             read-only
    STATUS
             mandatory
    DESCRIPTION
             "The counter associated with the number of Code
             Violation Error Events, as defined by ANSI Draft Standard T1M1.3/90 - 027R2[15], encountered by a
             DS1 CSU in the previous 24 hour interval.
             Note that D4 and G.704 (section 2.1.3.2)
             interfaces do not support Code Violation Error
             Events. Accordingly, such agents may treat this object as having an ACCESS clause value of not-
             accessible.'
    ::= { ds1TotalEntry 8 }
-- the DS1 Fractional group
-- Implementation of this group is mandatory for those
```

-- systems utilizing a fractional DS1 capability

-- The DS1 fractional table contains identifies which DS1 -- channels associated with a CSU are being used to support a -- logical interface, i.e., an entry in the interfaces table
-- from the Internet-standard MIB. For Clear Channel
-- implementations, exactly one ifTable entry corresponds to
-- the CSU being managed. In this very typical case, the -- variable ds1Index indicates the value of ifIndex which -- corresponds to the interface being supported by a -- particular CSU. -- However, for fractional DS1 implementations, the -- correspondent value of ds1Index is 0, and for each DS1 -- channel supporting a logical interface, there is an entry -- in the DS1 fractional table which names a value for -- ifIndex. For ds1ESF, ds1D4, and ds1ANSI-ESF, there are 24 legal channels, numbered 1 through 24. For G.704, there are 32 legal channels, numbered 1 ___ through 32. ds1G704 can carry user data in channels 2 -through 32, channel 1 being an overhead channel. ds1G704-CRC can carry user data in channels 2 through ___ 16 and 18 through 32, channels 1 and 17 being overhead channels. ds1FracTable OBJECT-TYPE SEQUENCE OF DS1FracEntry SYNTAX ACCESS not-accessible STATUS mandatory **DESCRIPTION** "The DS1 Fractional table." ::= { ds1 5 } ds1FracEntry OBJECT-TYPE SYNTAX DS1FracEntry ACCESS not-accessible STATUS mandatory **DESCRIPTION** "An entry in the DS1 Fractional table." INDEX { ds1FracIndex, ds1FracNumber } ::= { ds1FracTable 1 } DS1FracEntry ::= SEQUENCE {

```
ds1FracIndex
             INTEGER,
        ds1FracNumber
             INTEGER (1..32),
        ds1FracIfIndex
             INTEGER
ds1FracIndex OBJECT-TYPE
    SYNTAX INTEGER
    ACCESS
             read-only
    STATUS
             mandatory
    DESCRIPTION
             "The index value which uniquely identifies the CSU
             to which this entry is applicable. The interface
             identified by a particular value of this index is
             the same interface as identified by the same value an ds1CSUIndex object instance."
    ::= { ds1FracEntry 1 }
ds1FracNumber OBJECT-TYPE
    SYNTAX INTEGER (1..32)
    ACCESS
             read-only
    STATUS
             mandatory
    DESCRIPTION
             "The channel number for this entry."
    ::= { ds1FracEntry 2 }
ds1FracIfIndex OBJECT-TYPE
    SYNTAX INTEGER
    ACCESS
             read-only
    STATUS
             mandatory
    DESCRIPTION
             "An index value that uniquely identifies an
             interface to a ds1. The interface identified by a particular value of this index is the same
             interface as identified by the same value an
             ifIndex object instance.'
    ::= { ds1FracEntry 3 }
```

END

6. Acknowledgements

This document was produced by the SNMP and the Transmission MIB Working Groups:

Anne Ambler, Spider Karl Auerbach, Sun Fred Baker, ACC Ken Brinkerhoff Ron Broersma, NOSC Jack Brown, US Army Theodore Brunner, Bellcore Jeffrey Buffum, HP Jeffrey D. Case, UTK Chris Chiptasso, Spartacus Paul Ciarfella, DEC **Bob Collet** Tracy Cox, Bellcore
James R. Davin, MIT-LCS
Kurt Dobbins, Cabletron
Nadya El-Afandi, Network Systems Gary Ellis, HP Fred Engle Mike Erlinger Richard Fox, Synoptics Karen Frisa, CMU Chris Gunner, DEC Ken Hibbard, Xylogics Ole Jacobsen, Interop **Ken Jones** Satish Joshi, Synoptics Frank Kastenholz, Racal-Interlan Shimshon Kaufman, Spartacus Jim Kinder, Fibercom Alex Koifman, BBN Christopher Kolb, PSI Cheryl Krupczak, NCR Peter Lin, Vitalink John Lunny, TWG Carl Malamud Keith McCloghrie, HLS Donna McMaster, David Systems Lynn Monsanto, Sun Dave Perkins, 3COM Jim Reinstedler, Ungerman Bass Anil Rijsinghani, DEC Kary Robertson Marshall T. Rose, PSI (chair)

L. Michael Sabo, NCSC Jon Saperia, DEC John Seligson Fei Shu, NEC Sam Sjogren, TGV Mark Sleeper, Sparta Lance Sprung Mike St.Johns **Bob Stewart, Xyplex Emil Sturniold** Kaj Tesink, Bellcore Dean Throop, Data General Bill Townsend, Xylogics Maurice Turcotte Kannan Varadhou Sudhanshu Verma, HP Warren Vik, Interactive Systems David Waitzman, BBN Steve Waldbusser, CMU Dan Wintringhan David Wood Jeff Young, Cray Research

7. References

- [1] Cerf, V., "IAB Recommendations for the Development of Internet Network Management Standards", RFC 1052, NRI, April 1988.
- [2] Cerf, V., "Report of the Second Ad Hoc Network Management Review Group", RFC 1109, NRI, August 1989.
- [3] Rose M., and K. McCloghrie, "Structure and Identification of Management Information for TCP/IP-based internets", RFC 1155, Performance Systems International, Hughes LAN Systems, May 1990.
- [4] McCloghrie K., and M. Rose, "Management Information Base for Network Management of TCP/IP-based internets", RFC 1156, Hughes LAN Systems, Performance Systems International, May 1990.
- [5] Case, J., Fedor, M., Schoffstall, M., and J. Davin, "Simple Network Management Protocol", RFC 1157, SNMP Research, Performance Systems International, Performance Systems International, MIT Laboratory for Computer Science, May 1990.
- [6] McCloghrie K., and M. Rose, Editors, "Management Information Base for Network Management of TCP/IP-based internets", RFC 1213, Performance Systems International, March 1991.

- [7] Information processing systems Open Systems Interconnection Specification of Abstract Syntax Notation One (ASN.1), International Organization for Standardization, International Standard 8824, December 1987.
- [8] Information processing systems Open Systems Interconnection Specification of Basic Encoding Rules for Abstract Notation One (ASN.1), International Organization for Standardization, International Standard 8825, December 1987.
- [9] AT&T Information Systems, AT&T ESF DS1 Channel Service Unit User's Manual, 999-100-305, February 1988.
- [10] AT&T Technical Reference, Requirements for Interfacing Digital Terminal Equipment to Services Employing the Extended Superframe Format, Publication 54016, May 1988.
- [11] CCITT Specifications Volume III, Recommendation G.703, Physical/Electrical Characteristics of Hierarchical Digital Interfaces, July 1988.
- [12] CCITT Specifications Volume III, Recommendation G.704, Synchronous frame structures used at primary and secondary hierarchical levels, July 1988.
- [13] Rose, M., and K. McCloghrie, Editors, "Concise MIB Definitions", RFC 1212, Performance Systems International, Hughes LAN Systems, March 1991.
- [14] ANSI T1.403-1989 American National Standard for Telecommunications -- Carrier-to-Customer Installation -- DS1 Metallic Interface.
- [15] ANSI T1M1.3/90 027R2 Draft Proposed Standard -- Description of Installation and Maintenance Parameters for Digital Circuits, Facilities, and Networks.
- [16] Bell System Techical Reference, Publication 62411, High Capacity Digital Service Channel Interface Specification, September 1983.
- [17] Bell System Technical Reference, Publication 43801, "Digital Channel Bank Requirements and Objectives", November 1982.
- 8. Security Considerations

Security issues are not discussed in this memo.

9. Authors' Addresses

Fred Baker Advanced Computer Communications, Inc. 720 Santa Barbara Street Santa Barbara, California 93101

Phone: (805) 963 9431

EMail: fbaker@acc.com

Christopher P. Kolb Performance Systems International, Inc. Reston International Center 11800 Sunrise Valley Drive Suite 1100 Reston, VA 22091

Phone: (703) 620-6651

EMail: kolb@psi.com