How the Cost Data Is Built: An Overview

Unit Prices*

All cost data have been divided into 50 divisions according to the MasterFormat® system of classification and numbering.

Assemblies*

The cost data in this section have been organized in an "Assemblies" format. These assemblies are the functional elements of a building and are arranged according to the 7 elements of the UNIFORMAT II classification system. For a complete explanation of a typical "Assembly", see "RSMeans data: Assemblies—How They Work."

Residential Models*

Model buildings for four classes of construction—economy, average, custom, and luxury—are developed and shown with complete costs per square foot.

Commercial/Industrial/ Institutional Models*

This section contains complete costs for 77 typical model buildings expressed as costs per square foot.


Green Commercial/Industrial/ Institutional Models*

This section contains complete costs for 25 green model buildings expressed as costs per square foot

References*

This section includes information on Equipment Rental Costs, Crew Listings, Historical Cost Indexes, City Cost Indexes, Location Factors, Reference Tables, and Change Orders, as well as a listing of abbreviations.

- Equipment Rental Costs: Included are the average costs to rent and operate hundreds of pieces of construction equipment.
- Crew Listings: This section lists all the crews referenced in the cost data. A crew is composed of more than one trade classification and/or the addition of power equipment to any trade classification. Power equipment is included in the cost of the crew. Costs are shown both with bare labor rates and with the installing contractor's overhead and profit added. For each, the total crew cost per eight-hour day and the composite cost per labor-hour are listed.



Square Foot Models

- Historical Cost Indexes: These indexes provide you with data to adjust construction costs over time.
- City Cost Indexes: All costs in this data set are U.S. national averages. Costs vary by region. You can adjust for this by CSI Division to over 730 cities in 900+ 3-digit zip codes throughout the U.S. and Canada by using this data.
- Location Factors: You can adjust total project costs to over 730 cities in 900+ 3-digit zip codes throughout the U.S. and Canada by using the weighted number, which applies across all divisions.
- Reference Tables: At the beginning of selected major classifications in the Unit Prices are reference numbers indicators.
 These numbers refer you to related information in the Reference Section. In this section, you'll find reference tables, explanations, and estimating information that support how we develop the unit price data, technical data, and estimating procedures.
- Change Orders: This section includes information on the factors that influence the pricing of change orders.

 Abbreviations: A listing of abbreviations used throughout this information, along with the terms they represent, is included.

Index (printed versions only)

A comprehensive listing of all terms and subjects will help you quickly find what you need when you are not sure where it occurs in MasterFormat®.

Conclusion

This information is designed to be as comprehensive and easy to use as possible.

The Construction Specifications Institute (CSI) and Construction Specifications Canada (CSC) have produced the 2018 edition of MasterFormat®, a system of titles and numbers used extensively to organize construction information.

All unit prices in the RSMeans cost data are now arranged in the 50-division MasterFormat® 2018 system.

Not all information is available in all data sets

Note: The material prices in RSMeans cost data are "contractor's prices." They are the prices that contractors can expect to pay at the lumberyards, suppliers'/distributors' warehouses, etc. Small orders of specialty items would be higher than the costs shown, while very large orders, such as truckload lots, would be less. The variation would depend on the size, timing, and negotiating power of the contractor. The labor costs are primarily for new construction or major renovation rather than repairs or minor alterations. With reasonable exercise of judgment, the figures can be used for any building work.

Estimating with RSMeans data: Unit Prices

Following these steps will allow you to complete an accurate estimate using RSMeans data: Unit Prices.

1. Scope Out the Project

- Think through the project and identify the CSI divisions needed in your estimate.
- Identify the individual work tasks that will need to be covered in your estimate.
- The Unit Price data have been divided into 50 divisions according to CSI MasterFormat® 2018.
- In printed versions, the Unit Price Section Table of Contents on page 1 may also be helpful when scoping out your project.
- Experienced estimators find it helpful to begin with Division 2 and continue through completion. Division 1 can be estimated after the full project scope is known.

2. Quantify

- Determine the number of units required for each work task that you identified.
- Experienced estimators include an allowance for waste in their quantities. (Waste is not included in our Unit Price line items unless otherwise stated.)

3. Price the Quantities

- Use the search tools available to locate individual Unit Price line items for your estimate.
- Reference Numbers indicated within a Unit Price section refer to additional information that you may find useful.
- The crew indicates who is performing the work for that task. Crew codes are expanded in the Crew Listings in the Reference Section to include all trades and equipment that comprise the crew.
- The Daily Output is the amount of work the crew is expected to complete in one day.
- The Labor-Hours value is the amount of time it will take for the crew to install one unit of work.
- The abbreviated Unit designation indicates the unit of measure upon which the crew, productivity, and prices are based.
- Bare Costs are shown for materials, labor, and equipment needed to complete the Unit Price

- line item. Bare costs do not include waste, project overhead, payroll insurance, payroll taxes, main office overhead, or profit.
- The Total Incl O&P cost is the billing rate or invoice amount of the installing contractor or subcontractor who performs the work for the Unit Price line item.

4. Multiply

- Multiply the total number of units needed for your project by the Total Incl O&P cost for each Unit Price line item.
- Be careful that your take off unit of measure matches the unit of measure in the Unit column.
- The price you calculate is an estimate for a completed item of work.
- Keep scoping individual tasks, determining the number of units required for those tasks, matching each task with individual Unit Price line items, and multiplying quantities by Total Incl O&P costs.
- An estimate completed in this manner is priced as if a subcontractor, or set of subcontractors, is performing the work.
 The estimate does not yet include Project Overhead or Estimate Summary components such as general contractor markups on subcontracted work, general contractor office overhead and profit, contingency, and location factors.

5. Project Overhead

- Include project overhead items from Division 1-General Requirements.
- These items are needed to make the job run. They are typically, but not always, provided by the general contractor. Items include, but are not limited to, field personnel, insurance, performance bond, permits, testing, temporary utilities, field office and storage facilities, temporary scaffolding and platforms, equipment mobilization and demobilization, temporary roads and sidewalks, winter protection, temporary barricades and fencing, temporary security, temporary signs, field engineering and layout, final cleaning, and commissioning.
- Each item should be quantified and matched to individual Unit Price line items in Division
 1, then priced and added to your estimate.

- An alternate method of estimating project overhead costs is to apply a percentage of the total project cost—usually 5% to 15% with an average of 10% (see General Conditions).
- Include other project related expenses in your estimate such as:
 - Rented equipment not itemized in the Crew Listings
 - Rubbish handling throughout the project (see section 02 41 19.19)

6. Estimate Summary

- Include sales tax as required by laws of your state or county.
- Include the general contractor's markup on self-performed work, usually 5% to 15% with an average of 10%.
- Include the general contractor's markup on subcontracted work, usually 5% to 15% with an average of 10%.
- Include the general contractor's main office overhead and profit:
 - RSMeans data provides general guidelines on the general contractor's main office overhead (see section 01 31 13.60 and Reference Number R013113-50).
 - Markups will depend on the size of the general contractor's operations, projected annual revenue, the level of risk, and the level of competition in the local area and for this project in particular.
- Include a contingency, usually 3% to 5%, if appropriate.
- Adjust your estimate to the project's location by using the City Cost Indexes or the Location Factors in the Reference Section:
 - Look at the rules in "How to Use the City Cost Indexes" to see how to apply the Indexes for your location.
 - When the proper Index or Factor has been identified for the project's location, convert it to a multiplier by dividing it by 100, then multiply that multiplier by your estimated total cost. The original estimated total cost will now be adjusted up or down from the national average to a total that is appropriate for your location.