Estimating Tips 04 05 00 Common Work Results for Masonry

- The terms mortar and grout are often used interchangeably—and incorrectly. Mortar is used to bed masonry units, seal the entry of air and moisture, provide architectural appearance, and allow for size variations in the units. Grout is used primarily in reinforced masonry construction and to bond the masonry to the reinforcing steel. Common mortar types are M (2500 psi), S (1800 psi), N (750 psi), and O (350 psi), and they conform to ASTM C270. Grout is either fine or coarse and conforms to ASTM C476, and in-place strengths generally exceed 2500 psi. Mortar and grout are different components of masonry construction and are placed by entirely different methods. An estimator should be aware of their unique uses and costs.
- Mortar is included in all assembled masonry line items. The mortar cost, part of the assembled masonry material cost, includes all ingredients, all labor, and all equipment required. Please see reference number RO40513-10.
- Waste, specifically the loss/droppings of mortar and the breakage of brick and block, is included in all unit cost lines that include mortar and masonry units in this division. A factor of 25% is added for mortar and 3% for brick and concrete masonry units.

Scaffolding or staging is not included in any of the Division 4 costs. Refer to Subdivision 01 54 23 for scaffolding and staging costs.

04 20 00 Unit Masonry

- The most common types of unit masonry are brick and concrete masonry. The major classifications of brick are building brick (ASTM C62), facing brick (ASTM C216), glazed brick, fire brick, and pavers. Many varieties of texture and appearance can exist within these classifications, and the estimator would be wise to check local custom and availability within the project area. For repair and remodeling jobs, matching the existing brick may be the most important criteria.
- Brick and concrete block are priced by the piece and then converted into a price per square foot of wall. Openings less than two square feet are generally ignored by the estimator because any savings in units used are offset by the cutting and trimming required.
- It is often difficult and expensive to find and purchase small lots of historic brick. Costs can vary widely. Many design issues affect costs, selection of mortar mix, and repairs or replacement of masonry materials. Cleaning techniques must be reflected in the estimate.
- All masonry walls, whether interior or exterior, require bracing. The cost of bracing walls during construction

should be included by the estimator, and this bracing must remain in place until permanent bracing is complete. Permanent bracing of masonry walls is accomplished by masonry itself, in the form of pilasters or abutting wall corners, or by anchoring the walls to the structural frame. Accessories in the form of anchors, anchor slots, and ties are used, but their supply and installation can be by different trades. For instance, anchor slots on spandrel beams and columns are supplied and welded in place by the steel fabricator, but the ties from the slots into the masonry are installed by the bricklayer. Regardless of the installation method, the estimator must be certain that these accessories are accounted for in

Reference Numbers

Reference numbers are shown at the beginning of some major classifications. These numbers refer to related items in the Reference Section. The reference information may be an estimating procedure, an alternate pricing method, or technical information.

Note: Not all subdivisions listed here necessarily appear.

Same Data. Simplified.

Enjoy the convenience and efficiency of accessing your costs anywhere:

- Skip the multiplier by setting your location
- Quickly search, edit, favorite and share costs
- Stay on top of price changes with automatic updates

Discover more at rsmeans.com/online

