
Doc USER

Main screeen



Simulation Events

-Appearance of simulation errors

Simulation Status

-Status of simulation

Simulation Options

Button Automatic Simulation:

-Button to launch automatic simulation


Button Manual Simulation:

-Button to open Manual screeen

Button Stop Simulation:

-Button to stop automatic simulation

Manual simulation screen



Selected Errors

-Display list of plane errors selected

Select plane errors input

-Input to select plane errors

Select plane input

-Input to select plane

Selected Plane

-Display selected plane

Button Remove

-Button to remove errors selected

Button Done

-Button to launch simulation