Dirección ROM	Etiqueta	Instrucción	Datos	
0x00	INICIO	LD k	K1	
0x01		MOVWF aa	A0	
0x02	CICLO	LD k	K2	
0x03		MOVWF aa	A1	
0x04		INPUTW		
0x05		MOVWF aa	A2	
0x06		SUB k	К0	
0x07		CALLZ aa	CAMBIO	
0x08		LD aa	A0	
0x09		OUTPUTW		
0x0A		LD aa	A1	
0x0B		OUTPUTW		
0x0C		JUMP	CICLO	
0x0D	CAMBIO	LD aa	A2	
0x0E		MOVWF aa	A1	
0x0F		RETURN		
0x10				
0x11				
0x12				
0x13				
0x14				

Grupo	K0	K1	K2	A0	A1	A2

1	1d	1010b	1111b	0x00	0x01	0x02
2	2d	1111b	1100b	0x03	0x04	0x05
3	3d	1100b	1001b	0x06	0x07	0x08
4	4d	1001b	1010b	0x09	0x0A	0x0B
5	5d	1010b	1100b	0x0C	0x0D	0x0E
6	6d	1111b	1001b	0x0F	0x10	0x11