Bambu 3D Printer Stand & Storage Workbench (V3 - L-Shaped Legs)

Top Surface: Existing Walnut Desktop (48” × 24” × 1”)
Finished Bench Height: 31.5” (Top surface at chest height for printer bed & AMS)
Footprint: Base Frame 45.0” Wide × 21.0” Deep (1.5” perimeter top reveal)

---

1. Dimensional Lumber (100% SPF 2×4 — Home Depot Canada In-Stock)

All framing is built from standard **2-inch x 4-inch x 8-ft. SPF Premium Stud Lumber** (SKU `1000112108` / Model `112108`, ~$6.50 CAD). **No 4×4 posts and no planer needed!**

Corner L-Legs (4 Legs = 8 pcs of 2×4)

Part Name	Qty	Size (T × W × L)	Notes
Front/Rear Leg Flanges	4 pcs	1.5” × 3.5” × 30.00”	Front face of corner column
Side Return Leg Flanges	4 pcs	1.5” × 3.5” × 30.00”	Side return joined at 90° with pocket screws + glue
Corner Foot Blocks	4 pcs	1.5” × 2.0” × 2.0”	Glued in bottom inside corner of each L-leg to mount leveling feet

Framing Rails & Stretchers (2×4 Lumber)

Part Name	Qty	Size (T × W × L)	Notes
Front & Rear Upper Aprons	2 pcs	1.5” × 3.5” × 38.00”	Upper perimeter long rails
Side Upper Aprons	2 pcs	1.5” × 3.5” × 11.00”	Upper short side rails
Upper Center Cross-Tie	1 pc	1.5” × 3.5” × 18.00”	Desktop mid support & divider anchor
Front & Rear Lower Stretchers	2 pcs	1.5” × 3.5” × 38.00”	Lower stretchers 1.5” off floor
Side Lower Stretchers	2 pcs	1.5” × 3.5” × 11.00”	Lower side stretchers
Lower Center Cross-Tie	1 pc	1.5” × 3.5” × 18.00”	Bottom shelf & divider support

Total 2×4 Lumber Needed: **7 standard 8-foot (96”) 2×4 studs** (~$45.50 CAD total for the entire solid timber base!).

---

2. Hardwood Plywood Project Panels (Columbia Forest Products PureBond)

Item	Qty	Product Title on Home Depot Canada	Store SKU	Model #	Purpose
3/4” Walnut	1	CFP 3/4 in. x 2 ft. x 4 ft. PureBond Walnut Plywood ($54)	Online	—	All 3 drawer fronts (matches desktop)
3/4” Birch	1	CFP 3/4 in. x 2 ft. x 4 ft. PureBond Birch	1001513690	4391	Center divider & CR-6 printer shelf

Item	Qty	Product Title on Home Depot Canada	Store SKU	Model #	Purpose
		Plywood ($41)			
1/2” Birch	1	CFP 1/2 in. x 2 ft. x 4 ft. PureBond Birch Plywood ($36)	1001513691	4384	Rear anti-racking shear wall panel
1/2” Birch	2	CFP 1/2 in. x 2 ft. x 4 ft. PureBond Birch Plywood (~$36 ea)	1001513691	4384	Drawer box front, back, and side walls
1/4” Birch	1	CFP 1/4 in. x 2 ft. x 4 ft. PureBond Birch Plywood (~$28)	1001513692	4377	Drawer box bottom panels (grooved)

3. How the “L-Shaped” 2×4 Leg Joint is Built

```
TOP-DOWN VIEW OF FRONT-LEFT CORNER LEG:

            X = 1.5"              X = 5.0"
             ┌──────────────────────┐  ◄── Piece A (Front Flange:
1.5" x 3.5" x 30")
             │   1.5" x 3.5" 2x4    │
  Y = 3.0"   ├──────────┐           ┘
             │          │  ◄── Pocket screws drilled on inside face
of Piece B into Piece A
             │ Piece B  │      with Titebond II wood glue along the
seam!
```



1. **Cut:** Use your miter saw with a stop block to cut eight identical 30.0” pieces of 2×4.
2. **Pocket Holes:** Set your Kreg Jig to the **1-1/2” setting**. Drill 3 pocket holes along the inside face of Piece B facing into the edge of Piece A.
3. **Glue & Assemble:** Apply a bead of Titebond II wood glue along the seam, clamp Piece A and Piece B at 90° using a square, and drive **2-1/2” coarse pocket hole screws**.
4. **Foot Block:** Glue a 2” × 2” scrap 2×4 block in the bottom inside corner of the “L” to hold the 3/8” threaded leveling foot insert.
5. **No Planer Needed:** The factory-flat edge of Piece B butts against the factory-flat face of Piece A. The factory eased edges create a subtle, decorative V-groove reveal along the corner.

---

4. Hardware Checklist

- [ ] **Drawer Slides:** 18” Full-Extension Ball-Bearing Slides, 100 lb (Amazon 6-pack for $72)
- [ ] **Drawer Pulls:** 3 pcs modern 5” bar pulls
- [ ] **Leveling Feet:** 4 pcs heavy-duty 3/8”-16 threaded rubber swivel glides + pronged tee-nuts / threaded inserts
- [ ] **Pocket Screws:** 1 box 2-1/2” coarse pocket hole screws (for 2×4 frame & L-legs)
- [ ] **Drawer Screws:** 1 box 1” pocket screws (for 1/2” drawer boxes)
- [ ] **Tabletop Fasteners:** 8 pcs Figure-8 desktop fasteners (use 5/8” or 3/4” Forstner bit)
- [ ] **Wood Glue:** 1 bottle Titebond II