



xD-Tools

MiniDisc & CD Studio - User Manual

Designing labels, recording MiniDiscs, burning CD-Rs, and titling both

Version 0.2.0

Artur "Screemer" Jakubowicz

August 2026

Contents

1. What this is	3
2. Getting started	5
3. The main window	7
4. Templates	9
5. Metadata and cover art	11
6. Automatic layout	13
7. Printing and cutting	15
8. The MDRem adapter	18
9. The software remote	20
10. Writing titles onto the disc	22
11. Recording an album from foobar2000	24
12. Recording a CD	27
13. Burning an audio CD	30
14. Recording a folder of files	33
15. Erasing a disc	35
16. Experimental: downloading from a Telegram bot	36
17. Troubleshooting	40
18. Appendix: the MDRem command set	41


1. What this is

xD-Tools is a desktop workbench for MiniDisc and CD-R. (The x stands in for M or C - which began as a joke and turned out to be the description.) It started as a label designer and grew into a handful of tools that share one project file:

- **Design** the labels: a MiniDisc's sticker and J-card, or a CD's ring label and slim-case insert - and export them ready to print and cut.
- **Record** a whole album from foobar2000 onto a MiniDisc, with a proper track mark at every song.
- **Burn** an audio CD-R from a folder or from foobar2000's playlist, with CD-Text titles.
- **Title** a MiniDisc: write the album name and every track name onto the disc itself, so the deck's own display shows them.
- **Drive the deck** from a software remote - transport, track numbers, play modes.

Which medium a project is for is chosen once, when you create it, and everything follows from that: which templates you are offered, what the second page is called, and which entries the Recording menu shows. A MiniDisc project is never offered CD burning, and a CD project is never offered the deck's remote.

The first of those needs nothing but the computer. The other three need **MDRem**: a small RP2040 board that pretends to be a Sony RM-D10P infrared remote and plugs into USB. Everything MDRem-related is optional and switched off until you turn it on.



1. What talks to what: commands over USB, keys over infrared, audio over S/PDIF.

Three separate links, and it is worth being clear about which carries what. The USB cable carries commands and nothing else - no audio ever travels over it. The infrared beam carries keypresses, exactly as a handheld remote would. The audio takes the third path entirely, over S/PDIF, and is needed only when recording.

What you need

For	You need
Designing and printing	xD-Tools, a printer, and - for cutting - a Cricut machine or a steady hand with scissors.
Titling a disc	An MDRem adapter on a USB port, and a Sony MiniDisc deck it can be aimed at.
Recording an album	The above, plus foobar2000 with the Beefweb component, and a digital (S/

	PDIF) cable from the computer to the deck - or an analogue one, at a real cost in quality.
--	--

Everything in this manual was worked out against a Sony MDS-JE480 . Other Sony decks that accept the RM-D10P keyboard protocol should behave the same way, but the timings in particular were measured on that one.
--

One thing to understand up front

The deck cannot answer. Infrared only travels one way, and this model's Control A1 bus is not connected inside. So xD-Tools can send a command, but it can never find out whether the deck did it.

That shapes the whole MDRem half of the program: it shows you exactly what it is about to do before it does it, it errs on the side of doing too much rather than too little (clearing an old title with more keypresses than can possibly be needed), and when it reports success it means "everything was sent", never "the disc now says this". Check the deck's display yourself.

2. Getting started

Installing

If you have the packaged build, run `xD-Tools.exe`. From source:


- `python -m venv .venv`
- `.venv\Scripts\pip install -e ".[dev]"`
- `.venv\Scripts\python -m mdtools.main`

Choosing a language

Help > Language offers English, Polski and Japanese. The change needs a restart, and the dialog offers to do it for you.

The startup screen

xD-Tools opens on a short list of what you might want to do: reopen one of the last few projects, browse for another one, or start a new one.




2. The startup screen. *Remote...* only appears once the adapter is enabled.

- **Open Selected** / double-click - reopen a recent project.
- **Open Other Project...** - browse for a `.mdproj` file anywhere.
- **New Project...** - pick a template for each of the two pages.
- **Multiprint...** - put artwork from several different projects on one sheet of paper. This one does not open a project at all; it is a standalone job.
- **Remote...** - the software remote. Also standalone, and only shown when MDRem is enabled.

A project is two pages plus metadata

Every project holds exactly one **Disc Label** design and one **Cover / J-Card** design, switched with the dropdown at the top left of the main window. Alongside them it holds the album title, artist, year and track list - which the label designs, the titling and the automatic layout all draw on.



3. File > New asks for one template of each kind.

File > Save (Ctrl+S) writes all of that - both designs, the metadata, and any images you placed - into a single `.mdproj` file. Images are embedded, not linked, so moving the project or deleting the original picture cannot break it.

Closing a project

File > Close Project (Ctrl+W) brings the startup screen back rather than quitting, so moving on to another disc is not a trip through relaunching the program. The window's own close button does the same thing. If there are unsaved changes you are asked about them first.


To leave xD-Tools altogether, use **File > Exit**, or cancel the startup screen when it reappears.

Where your projects are saved

The first time you save, xD-Tools proposes **Documents\MiniDiscProjects** and a file name built from the album itself - `Skillet - Unleashed (2016).mdproj`. That is the same line the deck is told to display, so the file on your computer and the title on the disc agree with each other.

Other file dialogs start somewhere sensible too: **Add Image...** and cover art open in your Pictures folder, and the SVG, PNG and PDF exports open **next to the project they came from**, so the design and the files that cut and print it stay together.

3. The main window



4. The disc label page, laid out automatically from an album.

The canvas

The middle of the window is the page you are editing, drawn at its real physical size. The red and blue lines are the template's cut and fold lines - they are always drawn on top of your artwork so you can see where the edges are, and they never appear in an exported PNG. The hatched area outside them is the part that gets cut away.

- **Zoom In / Zoom Out / 100% / Fit** on the toolbar, or Ctrl with the mouse wheel, or Ctrl+= and Ctrl+-.
- **Grayscale** previews the page the way a black-and-white print will look, with brightness and contrast sliders that appear next to it. It is view-only - the canvas goes read-only while it is on - and what you dial in here is what Export Print PNG (Grayscale) will use.

The three panels

Tools (left) adds things to the page: text, a filled rectangle, an image from a file, an image from the built-in gallery, or text taken straight from the project's metadata. **Metadata...** - the album's own details - lives here too, beside the layers it feeds. Below the separator are the four page-wide operations - Clip Layers, Bake Layers, Save as Template and Auto-Layout. Every button is icon-only; hover for its name.

Properties (top right) edits whatever is selected, and shows only the fields that apply to it: text gets its content, size, font and colour; a rectangle gets a colour; an image gets neither. **Probe...** picks a colour off the canvas itself, which is how you match text to a colour in the cover art.

Layers (bottom right) lists everything on the page, front to back. Select, rename, reorder with Move Up / Move Down, or delete. The template outline is not a layer and cannot be touched here.

All three panels can be closed and reopened from the **View** menu, and dragged out into floating windows.

Moving, scaling and rotating

- Drag an item's **body** to move it.
- Drag a **corner handle** (blue square) to resize. By default width and height change independently; hold **Ctrl** to keep the proportions.
- Drag the **circle above it** to rotate. Hold **Ctrl** to snap to 10-degree steps, which is how you get an exact quarter turn.
- Delete or Backspace removes the selection.


Everything goes through undo (Ctrl+Z), including the automatic layouts.

4. Templates

A template is the physical shape of the thing you are printing: its size, its corners, and where it folds. xD-Tools ships with six.

Template	What it is
MiniDisc Disc Label	The classic 37 x 52 mm sticker for the front of the disc, with a 3 mm chamfer on the top-left corner and rounded corners elsewhere.
MiniDisc Disc Label (with Slider)	The same, plus a separate small sticker for the cartridge's sliding shutter.
Full disc label	A label covering the whole 71 x 68 mm face of the cartridge, inset by a 0.8 mm margin, with the shutter cut out of it.
Full disc label (with Slider)	The full face plus the shutter sticker, nested into the cutout it sits in. This is what the automatic layout uses.
MiniDisc Cover (J-Card)	The three-panel insert for the case: front, spine, back.
MiniDisc Cover (J-Card + Window)	The same with a cut-out window.

The **shutter** is the sliding panel on the cartridge that keeps dust off the disc - the deck pushes it aside to reach the surface. It is not the write-protect tab, which is a separate small catch on the cartridge's edge and never gets a label. Because the shutter has to keep sliding, the full-face templates cut a channel for its whole travel rather than just its resting position: a label over that channel would jam it shut.



5. Templates > Manage Templates.

Verified and unverified

A template is marked **Verified** once its dimensions have been checked against a real part. When you are looking at a page whose template is not verified, the status bar says so - measure your own case, correct the numbers here, and tick the box before cutting anything for real.

Making your own

Built-in templates can be edited but not deleted, so File > New always has something to offer. Ones you add yourself can be deleted freely.

Tools > Save as Template... captures the current page's shape *and everything on it* as a new template, so a layout you like can be the starting point for the next disc.


Changing a template later

Templates > Change Template for This Page... switches the page you are on to a different one.

This **clears the page**: every layer on it is removed and the undo history is reset. It asks first. The other page and the metadata are untouched.

5. Metadata and cover art

Metadata... in the Tools panel holds the album title, artist, year and track list. It is worth filling in even if you are only designing a label: the track list can be dropped onto the artwork as text, and the automatic layout and the disc titling both read from here.



Album title: Night Ferry

Artist: Aurora Test Signal

Lookup Track List...

Load from foobar2000

Year of release: 2026

Tracks:

	Title	only on a compi	ie (mm:ss, optional)
1	Harbour Lights		4:12
2	Slow Tide		3:48
3	Night Ferry		5:21
4	Cold Deck		4:03
5	Signal Drift		6:15

Add Track Remove Selected Move Up Move Down

Upload Tracklist

OK Cancel

6. The Metadata dialog, with cover art fetched and a track list loaded.

Three ways to fill it in

1. **By hand.** Add Track, type, and reorder with Move Up / Move Down. Times are optional and written as mm:ss.
2. **Lookup Track List...** searches the iTunes catalogue for the album and artist you typed, and fills in the track list, the year and the cover art. If more than one release matches you are asked which.
3. **Load from foobar2000** takes everything from whatever is loaded in foobar's current playlist, then looks up cover art for it.

Load from foobar2000 is usually the better source. Those are the actual files you are about to record, with their actual tags, in the actual order - a search can return a different edition with a different track order.

Cover art

A fetched cover is saved in two places: with the project, so it is still there next time you open it, and in the per-user gallery, so **Tools > Insert Asset...** can drop it onto a page like any other image.

If the cover that comes back is wrong, click it. The preview is a button: it opens a file picker so you can point at the right sleeve yourself. Both automatic sources guess, and for a reissue, a compilation or a band with a common name they regularly guess wrong - a search has no way of knowing which pressing you are holding.

When there is nothing good to be found

xD-Tools would rather show no cover than the wrong one. A result has to match the album title **and** the artist before it is accepted: a title on its own is not enough, because a cover version of the title track by somebody else matches that perfectly. When nothing clears the bar, the preview stays empty - which is the honest answer, and one click away from being put right.

There is one more place to look first, though. FLAC files often carry the sleeve inside them, and most rips of your own CDs do. When a search comes back with nothing usable, that picture is used instead. It is certainly the right sleeve for that release; it comes second only because it is often a smaller scan than the 600-pixel artwork a search returns. MP3 files are not read this way.

Putting metadata onto the page

The metadata button in the Tools panel inserts any single field - album, artist, year - or the whole numbered track list, as a text layer. It can also insert the track list as **two side-by-side columns**, which is what a long list needs to fit on a J-card back panel.

6. Automatic layout

The **magic wand** in the Tools panel builds both pages from the album's own artwork and track list. It is the fastest route from "I have a disc" to "I have something to print".


Fill in album and artist in **Metadata...** first - that is what it searches by. If there is no cover art yet it looks one up before starting.

It **replaces both pages** and resets the undo history, so it asks for confirmation first. The metadata itself is left alone.

What it builds

The disc label: the full-face template, the cover art stretched across it and then cropped to the cut outline, and the MiniDisc logo on the shutter sticker. The insertion-orientation triangle and its label stay on top of the artwork rather than being buried under it.

That mark also **changes colour to suit the cover**: black or white, whichever stays readable against the top of that particular sleeve. Left at its default black it was still there over a dark full-bleed cover, just invisible, which looks exactly like having lost it.



7. The J-card, with every colour taken from the cover itself.

The J-card, in three panels:

- **Front** - the cover art, turned a quarter turn so its top edge runs down the left side of the card, filling the panel, with a small MiniDisc logo in the corner.
- **Spine** - a band in an accent colour picked out of the cover, carrying the year, album and artist turned to read down it.
- **Back** - the cover's most common colour, with the numbered track list, split into two columns once the list gets long, and the running time at the foot.

The front and back are turned in *opposite* directions on purpose: the card wraps around the case, so the back ends up the other way up.

Everything it produces is ordinary layers. Move them, restyle them, delete them - it is a first draft, not a finished design.

Clip Layers and Bake Layers

Clip Layers trims everything to the printable area: layers entirely outside it are removed, images that hang over the edge are cut back to it. The automatic disc layout uses this to trim the deliberately oversized cover down to the cut outline.

Bake Layers flattens the whole page into a single image, exactly as the PNG export would render it. Useful for locking a finished design; note that a baked layer's resolution is fixed for good, which is why it renders at a higher DPI than a normal export.

7. Printing and cutting

The two exports

The design leaves xD-Tools as two files that describe the same object in two ways.

Export	Contains	For
Export Print PNG...	Your artwork, at 300 DPI by default, clipped to the template outline - transparent outside it, including the chamfered and rounded-away corners.	Printing.
Export Cut SVG...	Only the cut and fold lines of the current page, in real physical units. No artwork.	The cutting machine.
Export Print PNG (Grayscale)...	The same artwork converted to grey, with a brightness/contrast dialog and a live preview first.	Mono printers.

The Cricut route


1. Export the PNG and print it on your sticker or card stock.
2. Import the SVG into Cricut Design Space.
3. Use **Print Then Cut**: the machine finds the printed sheet's registration and cuts the SVG's outline exactly onto it.

The SVG carries real millimetres, so nothing needs scaling by hand at the other end.

Orientation, and one label per sheet

The Print window has a **Page Size** and an **Orientation**. Landscape is not decoration: a CD's folded slim-case insert is 242mm wide, and no portrait sheet takes it upright - on a portrait A4 it can only be printed turned a quarter turn.


Each label on its own sheet does what it says, and for a CD project it is switched on for you. The reason is arithmetic rather than taste: a CD label (118mm) beside that insert (242mm) needs 363mm of a sheet that offers 287mm, so the two cannot share one however they are turned. With the option on, the preview shows one sheet at a time - the **Showing** box picks which - and printing, Export PDF and Export PNG all walk both. A PNG holds one page, so exporting two sheets writes two files, numbered.



8. A CD project's print layout: the disc label on its own sheet, the folded insert on another.

Printing directly

File > Print... skips the export step: it lays several copies of both pages onto one sheet of A4 or Letter, auto-arranged into a grid you can then drag around by hand. Right-clicking a copy turns it 90 degrees, which is often what makes one more fit.





9. File > Print. The preview is the physical sheet.

From here you can send it to a real printer, or save exactly what is shown as a PDF or a PNG.

Multiprint..., on the startup screen, does the same thing across *different* projects - add artwork from several saved `.mdproj` files onto one sheet, so a stack of discs is one print run instead of six.


8. The MDRem adapter

MDRem is a Waveshare RP2040-Zero board with an infrared LED on it, running firmware that emulates a **Sony RM-D10P** - the keyboard remote Sony sold in the mid-nineties for typing titles onto MiniDiscs. It appears on the computer as an ordinary serial port.

The hardware

Pin	Role
GPIO12	Infrared output, into the transistor's base resistor.
GPIO13	Input, used only by the firmware's <code>SELFTEST</code> self-check.
GPIO16	The board's own RGB status LED.

The LED is driven by an NPN transistor as a low-side switch, because tens of milliamps cannot be pulled through a GPIO pin directly. Power comes from VBUS, not the 3.3 V regulator.



10. The output stage: S9014, $R_b = 470\text{ ohm}$, $R_d = 47\text{ ohm}$ (about 72 mA).

If the range is poor, look at R_d first. At 100 ohm (about 34 mA) the deck had to be within a centimetre or two and aimed precisely; at 47 ohm it works from a comfortable 20-30 cm. Do not go below about 33 ohm - 100 mA is the S9014's limit.


The status LED

Colour	Meaning
White	Starting up.
Green	Ready; the last command succeeded.
Blue	Transmitting infrared.

Red	The last command failed. Stays lit until something succeeds.
Purple	Hardware initialisation failed - the adapter is not working.

Turning it on in xD-Tools

Window > Settings..., tick **Enable MDRem IR remote adapter**, and choose the serial port.



11. Window > Settings. The foobar2000 address is separate from the adapter.


Detect asks every serial port on the machine whether an MDRem answers on it. It has to work that way: the board reports the USB ID `2E8A:0003`, which is also its own bootloader's and other WAVeshare boards', so the only reliable identification is the device replying to a `PING`.


Three things appear once the checkbox is ticked: **Upload Tracklist** in the Metadata dialog, **Remote...** on the startup screen, and the whole **Recording** menu - all three ways of recording a disc, Remote Control... and Erase MiniDisc...

The foobar2000 address on the same page is deliberately *not* tied to the checkbox - reading a playlist needs foobar2000, not the infrared adapter.

9. The software remote

The software remote is a stand-in for the deck's own remote control, laid out the way a physical one is. It opens from either **Remote...** on the startup screen or **Recording > Remote Control...** - the second exists because reaching for the remote should not mean closing the project you are working on.





12. The remote window. The status line reports what was sent, not what happened.

Group	Keys
Transport	Previous, Play, Next, scan back, Pause, scan forward, Stop, Power, Eject.
Tracks	1 to 10, selected directly. Higher numbers exist in the firmware but have no button here - use >25 on the deck.
Play Mode	Continuous, Shuffle, Program, Repeat, A-B, >25.
Display	Display, Scroll.
Titling	Name, Enter, Delete, Cancel.
Recording	Record, Music Sync, T.Rec, D.Rec, A.Space, M.Scan.


The Recording group is kept well away from the transport keys on purpose: on a real remote Record is a deliberate reach, and a mouse makes an accidental press far easier than a thumb does.

The status line says **Sent**, never **Done**. The deck cannot report back. If nothing happens, the most likely causes are aim and distance - see the troubleshooting chapter.

Record pressed while the deck is already recording adds a track mark. That is how the automatic recording splits a gapless album, and you can use it by hand the same way.

10. Writing titles onto the disc

Metadata... > Upload Tracklist writes the disc title and every track name onto the MiniDisc itself. The disc title is assembled as `Artist - Album (Year)`, skipping whatever is not filled in.



13. Everything is shown before anything is written.

Before it starts

The list is exactly what will be written, already converted. Read it: this is the only chance to notice a title that came out wrong, because afterwards nothing can tell you what actually landed on the disc.

It is slow, and that is the deck

The deck accepts about three and a half keypresses per second, and every character is its own infrared frame. A full album takes three to four minutes. The original Sony remote was no faster - contemporary reviews complained about it. The point is that you type on a real keyboard and walk away.

Job	Roughly
One track title, on a disc with old titles to clear	about 25 s
One track title, on a freshly recorded disc	about 12 s
A whole album, clearing first	3 to 4 minutes

Erase existing titles first

Clearing the old title is the single slowest part of writing a new one and roughly doubles the total time. It is on by default because leaving it off over an existing title leaves the old text behind, with the new text running into it.

Turn it off on a disc you just recorded. There is nothing there to erase, and it very nearly halves the wait. The recording flow turns it off for you.

Because the old title cannot be read back, clearing deliberately overshoots: it sends more delete presses than the new title could possibly need. Extra deletes on an empty field cost nothing.

Titles are converted to plain ASCII

MiniDisc decks only display characters 0x20 to 0x7E. Accented letters lose their marks - Zazolc gesla jazn - and anything with no Latin equivalent at all is dropped. The dialog lists the dropped characters before writing anything.

Japanese titles do not work, even though MiniDisc is a Japanese format. The deck's own katakana is reachable only through its native entry method - the CHAR key plus the jog dial - which is a different input path entirely and takes ten seconds a character. Transliterate instead.

Eject when it finishes

A deck holds edited titles in volatile memory until the disc is ejected. Pull the power first and everything you just wrote is gone. The dialog offers to eject for you when it is done - say yes.

Tracks past 25

The firmware's key table stops at track 25, so there is no way to select a higher track on the deck at all. Those titles are listed as skipped rather than silently dropped.

11. Recording an album from foobar2000

Recording > Record to MiniDisc from foobar2000... does the whole job in one go: it arms the deck, plays the album out of foobar2000, watches it to the end, writes the titles, and lays out both labels from the album's own artwork.

This needs the MDRem adapter, and the menu entry only appears once it is enabled in Window > Settings... The adapter is what puts the deck into record and what marks the tracks. Without one, recording means pressing record on the deck yourself and letting its own LEVEL-SYNC decide where the tracks begin - xD-Tools has no part in that.

Setting up

1. Install the **Beefweb Remote Control** component (`foo_beefweb`) in foobar2000. That is how xD-Tools reads the playlist and follows what is playing. Its default address, `http://localhost:8880`, is what xD-Tools expects; change it in Window > Settings... if you moved it.
2. Connect the computer's **S/PDIF** output - optical or coaxial - to the deck's digital input. This carries the audio; the USB link carries only commands.
3. Set foobar2000's output to **44.1 kHz, 16-bit, stereo** - see below.
4. Load the album into foobar2000's current playlist, in the order you want it on the disc.
5. Put a blank or erasable disc in the deck, tab closed, and set the recording mode (SP or LP2) **on the deck** - xD-Tools cannot read or change it.
6. Turn **LEVEL-SYNC off** on the deck. See below.
7. Aim the adapter at the deck's remote sensor and leave it there.

The format going into the deck

A MiniDisc is 44.1 kHz, 16-bit stereo, and the deck's digital input expects to be fed that. Hand it a 96 kHz or 24-bit stream - which is what a modern player happily outputs if the files are high-resolution and nothing is told to convert them - and the deck may simply refuse it, or drop out partway. It cannot tell xD-Tools that it has, either.

So convert on the computer, where it is free to get right: install foobar2000's **Resampler (SoX)** component, add it to the DSP chain and set it to **44100 Hz**, and set the output device to **16-bit stereo**. Files already at 44.1/16 pass through untouched, so this costs nothing on an ordinary CD rip and saves the awkward case.

Analogue instead, if you have to

The deck's **analogue** line inputs work too, and xD-Tools drives the recording exactly the same way - it presses the deck's keys, which does not depend on how the audio arrives. **The quality is considerably worse**, though, and unavoidably so: the sound leaves the sound card as analogue and is digitised again by the deck, so it picks up two extra conversions and whatever noise the card's output stage adds, before ATRAC has even started. Use S/PDIF whenever the deck has it.

Going analogue also means setting the deck's input selector to analogue and its recording level by hand - a digital input has neither to worry about.

Playlist "Aurora Test Signal - Night Ferry" -- 11 tracks, 51:36 total.
It will be recorded to the disc in this order, then titled from these names.

Artist

Album

Year



#	Title	Artist	Length
1	Harbour Lights		4:12
2	Slow Tide		3:48
3	Night Ferry		5:21
4	Cold Deck		4:03
5	Signal Drift		6:15
6	Salt and Static		3:37
7	Lantern		4:44
8	Undertow		5:02
9	Blue Hour		3:59
10	Far Shore		4:28
11	Morning Dock		6:07

Everything above and in the Title column can be edited, and is what gets written onto the disc.
Fill the Artist column in only on a compilation, where each track has its own.

☐ Mark tracks through the adapter

14. The playlist as it will be recorded, in that order.

What the window shows

The album, artist and year the disc will be titled with, the cover art it will be labelled with, and the track list - all of it editable. **This is the last place to correct any of it:** once the recording has run, those titles are already on the disc. The cover is looked up as the window opens rather than when the album ends, for the same reason. Everything freezes the moment recording starts.

Fill in the **Artist** column only when the tracks are by different performers. On an ordinary album it stays empty; on a compilation it is what tells xD-Tools the disc is one.

What happens

1. xD-Tools shows the playlist and its total time, and warns if it will not fit on an 80-minute disc in SP.
2. It sets foobar to play straight through once - no shuffle, no repeat - so the disc cannot end up in a different order than the titles, and sets foobar's own volume to -5 dB to leave the deck some headroom.
3. It tells the deck to start recording, then **asks you to confirm the deck really is in record-pause**. It cannot check, and getting this wrong means playing a whole album into a deck that is not recording and finding out forty minutes later.
4. It releases the pause, and a moment later starts playback - in that order, so the deck is already running when the first note arrives.
5. Recording runs. You can watch which track is going down and how much is left. Stop stops both ends.
5. When the album ends it offers to write the titles, taken from the playlist itself.
7. Finally the album, artist, year and track list become the project's metadata, cover art is looked up, and **both pages lay themselves out**.

That last step **replaces whatever was on both pages**. After a recording it does not ask - you have just sat through several prompts and watched an album go down in real time, and one more would be noise.

Track marks: the important part

A CD player tells the deck where the tracks are, in the S/PDIF subcode. **A computer does not.** Left to itself the deck falls back on LEVEL-SYNC: it starts a new track whenever the sound drops to silence and comes back.

That fails on any album where one song runs into the next. Two songs with no gap between them are recorded as one long track, and no amount of editing afterwards makes that pleasant.

So xD-Tools sends a track mark itself, at the exact moment foobar changes track - that is the **Mark tracks through the adapter** checkbox, and it should stay ticked.

Turn LEVEL-SYNC off on the deck when you use it. Running both marks the same boundary twice, a fraction of a second apart, and leaves a sliver of a track stranded between them. They fight; they do not co-operate.

Recording mode and length

An MD holds 80 minutes in SP. xD-Tools warns when the playlist is longer than that, but it can only warn - LP2 and LP4 have to be set on the deck itself, and there is no way to read back which mode it is in.

12. Recording a CD

Recording > Record CD to MiniDisc... copies an audio CD onto a MiniDisc. It reads the disc, works out what album it is, extracts every track to a file, loads those files into foobar2000 in the right order, and then hands over to the recording you already know - the same arming, the same track marks, the same titling.

This needs the MDRem adapter too, and the menu entry only appears once it is enabled. Reading a CD does not need it, but this entry does not stop at reading one: it goes straight on to record what it read.

Why it copies the disc first

foobar2000 can play a CD directly, and letting it do so would be simpler. But then the disc is being read in real time, during the recording, with nothing to fall back on - a drive stumbling over a scratch at minute 31 puts that stumble on the MiniDisc, and a MiniDisc recording is not something you can patch afterwards.

Copying first moves every read error to a point where it costs a re-read and nothing else. xD-Tools uses **cdparanoia** for this, built precisely to keep working at a damaged disc until it gets the audio right, and **flac** to store the result. Both ship with xD-Tools; there is nothing to install.



15. The disc read, identified, and ready to copy.

Step by step

1. Put the CD in the drive and choose the drive from the list. **Refresh** looks again if you plugged one in after opening the window.
2. Press **Read Disc**. xD-Tools reads the table of contents and looks the disc up on MusicBrainz, which identifies it from the lengths of its tracks - a CD carries no text of its own.
3. Check what came back. If several pressings match, pick the right one from **Release**; the track titles and the cover art change with it.
4. Correct anything wrong. The titles are editable, and they are what gets written into the files and later onto the MiniDisc.
5. Press **Rip and Record**. When the copy finishes, the recording window opens by itself.

A disc that is not in MusicBrainz - anything home-burned, and plenty of obscure releases - simply comes back with numbered placeholder titles for you to type over. Nothing else about the process changes.

How long it takes

Expect roughly **fifteen minutes for a full album**, about three times faster than playing it. That is

cdparanoia being careful, and it is the price of the error correction that made copying worth doing in the first place. The recording itself then takes as long as the album does, because it happens in real time.

When the disc is a compilation

A mixtape is not an album, and treating it like one goes wrong in visible ways: the disc gets named after whichever track happened to be first, the J-card credits one performer for twelve, and a cover art search returns some unrelated record's sleeve.

So xD-Tools checks. If most of the tracks cannot be attributed to a single artist, it credits the disc to **Various Artists**, names it `Mixtape` unless the release has a name of its own, prints each performer beside their track on the J-card, and **draws a cover from the track list** instead of looking one up.

Fill in the **Artist** column yourself when you know a disc is a compilation and MusicBrainz did not say so - that column is what the check reads.

An album with a guest feature on one track is **not** a compilation, and is not treated as one. The test is whether most tracks belong to the same artist, not whether the credits vary at all.

The same applies when recording from foobar2000: a playlist of unrelated tracks is recognised the same way, with the same result.

Where the copied files go

Into your temporary folder by default, under `xD-Tools CD Rip`, one folder per album. It is created if it is not there, so a folder you have only typed into Settings and never made is not a problem. They are raw material for a recording rather than a music collection - one album is a few hundred megabytes - and Window > Settings... can point that somewhere else.

They are **not** deleted when the recording finishes, because foobar2000 still has them in its playlist and you may want to play them again. The previous copy is cleared out when you start the next one.

Loading the copied tracks into foobar2000 **empties its current playlist**. Anything you had queued up there is gone, so move it elsewhere first if you want to keep it.

13. Burning an audio CD

Recording > **Burn Audio CD from Folder...** or **from foobar2000...** writes a real Red Book audio CD-R - the kind any CD player will play - from files you already have. No infrared adapter is involved: this is the drive's job, so these two entries stay available even with MDRem switched off.

	Title	Artist	Length	Status
1	Harbour Lights	Aurora Test Signal	-	could not be read
2	Slow Tide	Aurora Test Signal	-	could not be read
3	Night Ferry	Aurora Test Signal	-	could not be read
4	Cold Deck	Aurora Test Signal	-	could not be read
5	Signal Drift	Aurora Test Signal	-	could not be read
6	Salt and Static	Aurora Test Signal	-	could not be read
7	Lantern	Aurora Test Signal	-	could not be read

16. The burn window: what will be written, and what it will be called.

What the window shows

The album's name, artist and year, an editable title and artist per track, and a cover you can click to replace - the same window the recording flow uses, and the same rule: **what is on screen when you press Burn is what gets written**, both onto the disc as CD-Text and into the project you design the label from.

The line under the track list gives the album's length against what the disc holds. The **Status** column is the part worth reading before you press anything.

Why a track can refuse to be burned

A CD holds 44.1 kHz, 16-bit, stereo audio and nothing else. Two Red Book rules can stop a burn outright, and the window says so per track rather than letting you find out on playback:

- a track shorter than **four seconds**, which some players will not play;
- more than **99 tracks**, or an album longer than the disc.

A file that is merely at the wrong rate is not a refusal. A 48 kHz / 24-bit download - which is what

most of them are - says "will be converted to 44100 Hz / 16-bit" and is resampled on the way to the disc by the bundled SoX. The conversion happens in a scratch folder; your own files are never touched.

Titles on the disc: CD-Text

The album and track names are written onto the CD as CD-Text, which players that support it will show. It carries plain ASCII, so accented letters lose their marks the same way MiniDisc titles do - and anything with no equivalent at all is listed in the window **before** you burn, rather than quietly dropped.


Simulate first, if you like

Simulate only runs the whole sequence with the laser off. It takes as long as a real burn and proves the drive, the speed and the files, without spending a disc. Worth doing once on a new drive.


A CD-R cannot be rewritten. Once writing starts, the disc is either finished or wasted - which is why the window asks before starting, and asks again if you press Stop while the laser is on. Stopping during the earlier "Preparing audio" stage costs nothing at all.

The label, afterwards

When the burn finishes, the album's details are offered to the open project if it is a CD one. Say yes and the Tools panel's automatic layout has everything it needs: the cover, the artist, the year and the track list.



17. The disc label: the cover lightened across the ring, with the hub cut out and the Digital Audio mark at the foot.



18. The folded slim-case insert: cover on the right panel, track list on the left. Folded down the middle, the left half shows through the back of the case.

What you need

- A CD writer. It is found by asking cdrecord, not by guessing - if the **Burner** box is empty, check the drive is connected and press **Refresh**.
- A blank CD-R. A disc that already holds something cannot take a fresh burn.
- Nothing else: cdrecord and SoX are bundled on Windows.

14. Recording a folder of files

Recording > Record Folder to MiniDisc... records an album you already have on disk. Point it at the folder it is in, and xD-Tools loads those files into foobar2000 in the right order and hands over to the recording you already know - the same arming, the same track marks, the same titling.

This needs the MDRem adapter too, and the entry only appears once it is enabled. Loading a folder does not need one; going on to record what was loaded does.

#	Title	Artist	Length
1	Harbour Lights		4:12
2	Slow Tide		3:48
3	Night Ferry		5:21
4	Cold Deck		4:03
5	Signal Drift		6:15
6	Salt and Static		3:37
7	Lantern		4:44
8	Undertow		5:02
9	Blue Hour		3:59
10	Far Shore		4:28
11	Morning Dock		6:07

The tracks are recorded in the order shown, which comes from the filenames. Titles come from the files' own tags; a file with no title tag is recorded under its filename.

Loaded into foobar2000. Check the album below, then record.

19. The folder read, and what foobar2000 made of its tags.

Step by step

1. Press **Browse...** and choose the folder the album is in. It is loaded into foobar2000 straight away - choosing it is the decision, so there is nothing further to confirm. FLAC, MP3 and everything else foobar2000 plays are recognised; anything that is not audio - artwork, a cue sheet, a log - is ignored.
2. Check the order. It comes from the filenames, compared so that **10** follows **9** rather than **1**. If it is wrong, the filenames are what to fix.
3. Check the album and artist. They are guessed from the folder's own name to start with, and whatever the files are tagged with replaces that guess as soon as the tracks are loaded. Type over either if both are wrong.

4. Look at what came back: the titles foobar read out of the files, and the cover art - searched for first, and taken from inside the FLAC files themselves if the search found nothing good.
5. Press **Record**. It only becomes available once foobar has actually taken the tracks.

Where the titles come from

From the files - read by foobar2000 rather than by xD-Tools, which is the better tag reader of the two and has to read them anyway in order to play them. A file with no title tag is recorded under its filename: the honest answer, and usually a usable one.

The album and artist shown in this window are what gets written onto the disc and onto the label, so a correction is worth making before you press the button. Nothing is ever written back into your files.

A subfolder per disc

A folder with tracks in it *is* the album, and its subfolders are left alone - a scans or bonus directory does not join the running order. Only when the folder itself holds no audio at all does xD-Tools look inside, which is what makes a two-disc album kept as `CD1` and `CD2` come out in disc order.

Loading a folder **empties foobar2000's current playlist**, exactly as recording a CD does. Move anything you had queued up there elsewhere first.

15. Erasing a disc


Recording > Erase MiniDisc... clears the disc in the deck. It works on whatever is physically loaded, so it does not care which project is open, or whether one is.

There is no undo, and xD-Tools cannot see the result. Make sure the disc in the deck is the one you mean, and that its write-protect tab is closed.

Why it asks what you can see

This is the one operation where xD-Tools does not know what its own command does. The **Erase** key is recognised by the deck as a write command - that much was confirmed - but which editing menu it opens was never established, because the write keys could only be tested safely on a protected disc, where the deck answers every one of them with the same complaint.

Rather than guess with your recording, xD-Tools sends Erase and then asks what the deck's display says. If it is showing something like **All Erase?**, press **Send Enter** and watch the display - the window stays open, so you can press it again. Some decks want it more than once, and there is no way for xD-Tools to find that out: the deck never answers back. Press **Done** when the disc is blank, or **Nothing Happened** to back the deck out of whatever menu it is sitting in.



20. It sends the command, then asks what the deck is showing.

As with titling, an erase lives in the deck's memory until the disc is ejected. xD-Tools offers to eject afterwards - take it, or the disc keeps its old contents should the deck lose power.

16. Experimental: downloading from a Telegram bot


Everything in this chapter is **experimental** and hidden until you ask for it. It works, but it is newer and less exercised than the rest of the program, and the way it is presented may still change.

xD-Tools can hold a conversation with a Telegram bot **you run yourself**, download the files it sends, and hand the result to Record Folder to MiniDisc - so a download becomes a recorded, titled disc without leaving the program.

This is for a bot you control. Downloading albums from a public bot that redistributes music without the rights holder's permission is not what this is for, and owning the CD does not make it legal - that covers copying your own disc, not taking a copy from a stranger.

Turning it on

Window > Settings has a **Show experimental features** checkbox. Tick it and an **Experimental** menu appears in the menu bar; untick it and the menu disappears again. Nothing behind it runs while it is off.



21. *Experimental > Experimental Settings. Experimental features keep their own settings window.*

Experimental > Experimental Settings... is where the bot lives. Two fields matter:


- **Bot username** - the bot you want to talk to, @something.
- **Download folder** - where files land. It defaults to a folder under your system temporary directory, on the grounds that a download is raw material for a recording rather than a music library. Point it

anywhere you like.

There is no API ID or API Hash to fill in. xD-Tools carries its own, so signing in is the only step. If a build ever ships without them it says so plainly instead of failing to connect.

Signing in

xD-Tools signs in as **your own Telegram account**, not as a bot. That is not a design preference: Telegram's Bot API forbids one bot from messaging another, so the only way to talk to your bot the way a person would is to be a person.

A screenshot of a dark-themed Telegram sign-in interface. At the top, text reads: "MDTools needs to sign in as your own Telegram account to talk to your bot -- Telegram does not let one bot message another directly." Below this is a text input field labeled "Phone number" containing the value "+1 555 0100". At the bottom right are two buttons: "Send Code" and "Cancel".


22. Sign in to Telegram. Phone number, then the code Telegram sends you, then a password if you use two-step verification.

Sign in to Telegram... asks for your phone number, then the code Telegram sends to your other devices, then - if you have two-step verification on - your password. It is the same sequence the Telegram app itself uses.

The sign-in is saved locally, in `telegram.session` next to xD-Tools' own settings. That file is equivalent to being logged in to your account: it is not encrypted, and it is not something to copy onto another machine or send to anyone.

The conversation

Experimental > Download Album from Telegram Bot... opens a plain chat. It appears only once a sign-in has been saved.



23. The chat, with the download queue on the right.

Deliberately a plain chat rather than a search box: your bot's commands are yours, and xD-Tools cannot know them. So it shows whatever the bot sends and lets you drive it - text, its inline buttons, and any file it attaches. **Quick commands** sends `/start` or `/help` with one click, since almost every bot understands those.

Two conveniences worth knowing. Whatever the bot writes is **translated underneath the original**, into whichever language xD-Tools is set to - the original stays, because a translation can be wrong and an exact command or filename is better read as sent. And a bot that edits its own message to build a menu, rather than sending a new one each time, is followed correctly: the message changes in place, as it does on your phone.

The download queue

Files never appear in the conversation - they go to the **queue on the right**, which is the only place a file's name, size, progress and speed are shown. A whole album arriving as twenty attachments would otherwise bury the conversation under twenty near-identical rows.

Downloading starts by itself, and at most three files download at once. A failed one gets a **Retry** button rather than disappearing.

From download to disc

Files from every session pile up in the one download folder, so several albums end up side by side. **Sort into Album Folders** separates them: one subfolder per album, named from the tags, with anything untagged grouped by when it arrived.

Sorting only ever moves audio files. A cover image the bot sent alongside the tracks, or anything else already in that folder, is left exactly where it is.

Record Downloaded Albums... then goes to the recording flow. It sorts first, so you cannot accidentally record two albums onto one disc, and asks which album if there is more than one. From there it is the

ordinary Record Folder to MiniDisc window described two chapters ago - which is also why this needs the MDRem adapter, even though downloading does not.

Open Download Folder opens it in your file manager, for a look before recording.

Both operations are also on the menu without opening the chat at all, for files downloaded earlier: **Sort Telegram Downloads into Album Folders...** and **Record from Telegram Downloads...**

Both buttons go quiet while anything is still downloading - sorting or recording half-written files would be worse than waiting.

17. Troubleshooting

The deck ignores everything

1. **Check the adapter is alive.** Its status LED should be green. Purple means the firmware could not start the hardware at all.
2. **Check it is transmitting.** Point the adapter's LED at a phone camera - infrared shows up as a violet-white dot. The firmware's `BEAM` command lights it steadily for two seconds, which is long enough to see; a single command is 45 ms and invisible.
3. **Check the aim and the distance.** The working range is roughly 20-30 cm, straight at the deck's remote sensor. If you need to be closer than that, the LED current is too low - see the Rd note in the MDRem chapter.
4. **Check the port.** Window > Settings... > Detect. If nothing answers, the adapter is not enumerating - try a different cable.

"Not connected" in the remote window

Something else already has the serial port open. Only one program can hold it at a time - close the other xD-Tools window, dialog, or terminal that is using it.

The new title has the old one stuck on the end

Erase existing titles first was unticked, or the old title was longer than the clearing allowed for. Run the upload again with it ticked.

Two songs ended up as one track

They run into each other with no silence between them, and LEVEL-SYNC had nothing to hear. Record again with **Mark tracks through the adapter** ticked and LEVEL-SYNC off on the deck.

Every track got the same title

This was a real bug and is fixed, but the underlying deck behaviour is worth knowing: the deck is a state machine with no way to ask it anything, and a track number sent while it is paused does not take. That is why the titling sequence sends **Stop** first - it puts the deck in a known state instead of assuming one.

Nothing was saved to the disc

Titles live in the deck's memory until the disc is ejected. Eject it.

foobar2000 cannot be reached

- foobar2000 is running.
- The **Beefweb Remote Control** component is installed *and enabled*.
- The address in Window > Settings... matches Beefweb's port.

The printed label is the wrong size

Check the printer is not scaling to fit - it must print at 100%. If the canvas itself looks the wrong physical size on screen, that is **Screen DPI** in Window > Settings..., which affects the display only, not the export.

18. Appendix: the MDRem command set

The adapter speaks plain text over its virtual serial port at 115200 baud. Every command answers with a single line - OK, PONG, or ERR <reason> - so a program can parse the reply without knowing the command. Lines beginning with ; are diagnostics.

xD-Tools drives all of this for you. It is documented here for anyone wanting to talk to the adapter directly, from a terminal or their own script.

Command	Does
PING	Answers PONG. This is how the adapter is identified.
HELP	Lists the commands.
KEY <name>	Reports a key's code and bit count. Sends nothing.
SEND <name>	Sends a named key, or a single character.
RAW <hex> [bits]	Sends an arbitrary code. bits defaults to 20.
DUMP <hex> [bits]	Prints the mark/space timings. Sends nothing.
TITLEDISC <text>	Writes the disc title.
TITLETRACK <n> <text>	Writes track n's title.
TIMING ...	Adjusts the timings - including TIMING COUNT, the number of delete presses used to clear a title.
SELFTEST	Checks the carrier. Needs a jumper from GPIO12 to GPIO13.
GPIONTEST	Continuity test for that jumper alone.
BEAM [ms]	Steady carrier, 2000 ms by default - visible in a phone camera.
BLINK [cycles]	The same, blinking, which is easier to spot.

SEND A and SEND a are **different codes**. Single characters are case-sensitive on purpose; key names are not.

How the protocol works

Sony SIRC: a 40 kHz carrier at roughly one-third duty, bits sent least-significant first, a 2400 microsecond start mark, and frames repeating every 45 ms. A '1' is a 1200 microsecond mark, a '0' is 600. Like a real remote, each keypress is sent three times.

The character codes are 20-bit, 0x61D00 with the ASCII value in the low byte - the RM-D10P's own keyboard protocol. The deck's own function keys (Play, Stop, Record, Enter) are **12-bit** codes from a different block. Sending those as 20-bit produces a completely different frame and the deck ignores it.

Things that were tried and do not work

- **Katakana**. The obvious theory - that the character codes are 0x61D00 plus a JIS X 0201 byte, which would put half-width katakana in the unused upper half - was tested against a real deck and refuted. A control 'A' appeared; none of the katakana codes did anything.

- **Delete outside name-edit mode.** On a paused track it does nothing at all. Titles can only be cleared after Name.
- **Holding a key down to clear faster.** The deck's auto-repeat clears four characters in 1.09 s - 272 ms each - against 285 ms for individual presses. About three and a half edit operations per second is a hard ceiling.