

# *Fluoroscopic Radiation Safety*



## Patient and Occupational Safety

Michael J. Bohan, YNHH Radiation Safety Officer  
(203) 688-2950 or mike.bohan@yale.edu

## ***ACCREDITATION & DISCLOSURE***

**The Yale School of Medicine designates this Enduring Material for a maximum of 1 *AMA PRA Category 1 Credit*™. Physicians should claim only the credit commensurate with the extent of their participation in the activity.**

**Acknowledgement is made on behalf of the Department that:**

**There is no commercial support for this activity.**

**Confirmation is also made that disclosure has been peer reviewed and there are no conflicts of interest.**

# *Basic Radiation Safety Techniques*

Time - As exposure time increases, dose accumulates

- Keep fluoro times as short as possible.

A bell or buzzer will go off after 5 minutes of beam time, keep track of fluoro time, report fluoro times in excess of 60 minutes to the Radiation Safety Office (203) 688-2950

Distance - As distance from the radiation source increases, the radiation intensity decreases rapidly by the inverse square law.

- Keep patient anatomy and staff as far away from the x-ray tube port as possible

Shielding - Diagnostic x-rays are easily shielded with thin sheets of lead.


- Wear lead aprons, thyroid shields, leaded glasses and use overhead leaded shields and table skirts whenever possible

Keep fluoro times as short as possible

*Time*

Dose Rate = 10 rad/min

Accumulated  
Dose (rad)




Stay as far away from the x-ray tube port as possible

*Distance*

$1/(0.5 \text{ ft})^2 = 4$  times dose rate @ 1 foot!


Percent  
of  
exposure  
rate at  
1 foot

Inverse Square Law



# *Half-value Layer*

Lead aprons are very effective at diagnostic x-ray energies and shield at least 95% of the radiation



# *Federal Regulatory Occupational Dose Limits*

Total Effective Dose Limit (TEDE)	5,000 millirem/yr
Individual Organ Limit	50,000 millirem/yr
Len of the Eye (LDE)	15,000 millirem/yr
Skin, Hands & Single Organs	50,000 millirem/yr
TEDE - Summation of external and weighted internal doses	

# *Federal Regulatory Internal Dose Weighting Factors*

The organ weighting factors take into consideration the radiation sensitivity of the tissues.

<u>Organ or tissue</u>	<u>Weighting Factor</u>
Gonads	0.25
Breast	0.15
Red bone marrow	0.12
Lung	0.12
Thyroid	0.03
Bone surfaces	0.03
Remaining organs	0.30
Total body	1.00

# *Federal Regulatory General Public Dose Limits*


Total dose (all sources)	500 millirem/yr
Individual source limit	100 millirem/yr
Declared pregnant worker	500 mrem/9 months (<50 mrem/month)

# *Occupational Exposures at Yale-New Haven Hospital*

ALARA Radiation Dose Summary 2003

Dose (mR/Yr)	Series----->		All Sources																				Cumul. Percent	Dose (mR/Yr)						
	AB	ACT	ADI	AER	ARN	ASP	AST	C	CCC	ENT	G	GK	I	K	M	MC	MD1	MD2	MD3	MDR	N	O	R	W	X	YPB	Totals	Percent		
5001 - 7500																									0	0.0%	100.0%	5001 - 7500		
4001 - 5000																									0	0.0%	100.0%	4001 - 5000		
3001 - 4000																									2	0.3%	100.0%	3001 - 4000		
2001 - 3000	1																								2	0.4%	99.7%	2001 - 3000		
1001 - 2000	2																								8	1.1%	99.3%	1001 - 2000		
501 - 1000	1																								11	1.5%	98.2%	501 - 1000		
401 - 500	1																								4	0.5%	96.7%	401 - 500		
301 - 400																									3	0.4%	96.2%	301 - 400		
201 - 300	1																								13	1.8%	95.8%	201 - 300		
101 - 200		1	1	2	2	4				1	6			6	4			4	2	1	1	1	2		38	5.2%	94.0%	101 - 200		
51 - 100		2	2	7	2		1	1						12	4	1			1	5	4	3	1		46	6.3%	88.8%	51 - 100		
11 - 50	1	8	4	6	8	6	1	3			3			14	3	1	2	3	1	12	8	1	3	1		89	12.2%	82.5%	11 - 50	
1 - 10			1	5	8	4	2	9			3	6		7	3			1	2	7	4	1		2	65	8.9%	70.3%	1 - 10		
Minimal	11	24	5	29	11	15	29	55	11	4	34	5	7	10	30	6	3	2	10	32	31	51	5	6	1	21	448	61.4%	61.4%	Minimal
Totals:	18	33	13	44	38	38	32	68	13	4	52	11	7	10	71	23	5	15	18	43	57	68	7	15	4	23	730	100.0%		

Dose (mR/Yr)	NRC Byproduct Materials											Cumul. Percent	Dose (mR/Yr)	Series Codes	
	C	ENT	GK	I	K	M	MC	N	O	W	Totals				
5001 - 7500											0	0.0%	100.0%	5001 - 7500	
4001 - 5000											0	0.0%	100.0%	4001 - 5000	
3001 - 4000											0	0.0%	100.0%	3001 - 4000	
2001 - 3000											0	0.0%	100.0%	2001 - 3000	
1001 - 2000											0	0.0%	100.0%	1001 - 2000	
501 - 1000											0	0.0%	100.0%	501 - 1000	
401 - 500						1					1	0.3%	100.0%	401 - 500	
301 - 400					1						1	0.3%	99.7%	301 - 400	
201 - 300					1	2	1				4	1.2%	99.4%	201 - 300	
101 - 200					6	4	1	1	2		14	4.2%	98.2%	101 - 200	
51 - 100	1				12	4	5	4	3		29	8.7%	94.0%	51 - 100	
11 - 50	3				14	3	12	8	3		43	12.9%	85.3%	11 - 50	
1 - 10	9	6			7	3	7	4	1		37	11.1%	72.5%	1 - 10	
Minimal	55	4	5	7	10	30	6	31	51	6	205	61.4%	61.4%	Minimal	
Totals:	68	4	11	7	10	71	23	57	68	15	334	100.0%			



# *Occupational Exposures at Yale-New Haven Hospital*

Ninety-seven percent of all monitored individuals at YNHH receive less than 10% of the annual exposure limit (500 mrem/yr).

The 3% who receive greater than 500 millirem/yr are the interventional radiologists and cardiologists.

Personnel who routinely receive greater than 10% of the limits are issued two film badges (collar & waist)

If you are issued only one badge, wear it at the collar outside of any protective aprons. Waist badges should be worn under protective aprons

# *Multiple Badge Fluoroscopic Dosimetry*

Effective dose equivalent is calculated for multiple badge wearers using the ANSI formula as required by CT State DEP regulatory guidance.

Effective Dose Equivalent =  $(0.11 \times \text{collar badge}) + (0.89 \times \text{waist badge})$

*HPS N13.41-1997*

*An American National Standard (ANSI)*

*Criteria for Performing Multiple Dosimetry*

# *Multiple Badge Fluoroscopic Dosimetry*

For example, if a fluoroscopist received 2,500 millirem to their collar badge and 250 millirem to their waist badge for the year, their effective dose equivalent (EDE) would be:

$$(0.11 * 2,500 \text{ mrem/yr}) + (0.89 * 250 \text{ mrem/yr}) = \text{ANSI EDE}$$

$$275 \text{ mrem/yr} + 223 \text{ mrem/yr} = 498 \text{ mrem/yr}$$


# *Patient Safety Issues*

- Fluoroscopic techniques are being used by an increasing number of clinicians not adequately trained in radiation safety or radiobiology
- Patients are suffering radiation-induced skin injuries due to unnecessarily high radiation doses. Younger patients may face an increased risk of future cancer.
- Many fluoroscopic users are not aware of the potential for injury from procedures, their occurrence or the simple methods for decreasing their incidence utilizing dose control strategies.

# *Patient Safety Issues*

- Many patients are not being adequately counseled about radiation risks before consent for difficult and challenging procedures, nor followed up for the onset of injury, when radiological procedures result in high doses.
- Untrained and inexperienced fluoroscopists have injured patients and exposed staff to high doses.
- Occupational doses can be reduced by limiting unnecessary patient dose, through the correct use and procurement of equipment (including the use of shielding devices).


## X-RAY TUBE DIAGRAM



# *The X-ray Imaging Process*


Absorption and transmission of x-rays contribute to the imaging process and patient dose.

Scattered or partially absorbed x-rays contribute to occupational exposure, but are less than 1% of the primary beam intensity.



# *X-Ray Beam Spectrum - 100 kVp*


- A. - Hypothetical x-ray spectrum
- B. - Spectrum from tungsten target without filtration
- C. - Spectrum with filtration equivalent to 2.4 mm Al (inherent + added)
- The mean x-ray energy (keV) is approximately 1/3 the peak energy (kVp)
- Unfiltered x-ray beams cause excessive dose to skin because low energy photons cannot penetrate through the patient
- keV - kilovolt
- kVp - kiloVolt peak




# *The X-ray Imaging Process*

Collimation of the x-ray beam reduces dose to the patient, to the staff and improves image quality due to reduction in x-ray scatter.

Always collimate down once you get to the area of interest.



# *The X-ray Imaging Process*




The Good,  
The Bad,  
and the  
Ugly


Entrance  
Dose Rates

**Good Geometry**  
2 rad/min

**Bad Geometry**  
32 rad/min!




# *The X-ray Imaging Process*




Fluoscopes are routinely operated in automatic exposure mode.

As the patient becomes thicker x-ray output goes higher to maintain image quality



# *A Typical Fluoroscopic Lab*



Overhead shields need to be positioned down next to the patient and adjacent to the image intensifier to seal scatter off from below.

Table skirts shield the highest backscatter levels from the x-ray tube.

# *Case Reports*

- Patient skin doses in some interventional procedures approach those experienced in some cancer radiotherapy fractions
- Skin injuries are occurring in patients as a result of very high radiation doses during interventional procedures, as a result of the use of inappropriate equipment and more often poor operational technique.
- Injuries to physicians and staff performing interventional procedures have been observed recently, due to the use of inappropriate equipment, poor operational technique and less than optimal radiation safety practices.

# *Doses in interventional procedures*

Effect	Threshold dose (rad)	Minutes fluoro at 2 rad/min	Minutes fluoro at 20 rad/min
Transient erythema	<b>200</b>	<b>100</b>	<b>10</b>
Permanent epilation	<b>700</b>	<b>350</b>	<b>35</b>
Dry desquamation	<b>1,400</b>	<b>700</b>	<b>70</b>
Dermal necrosis	<b>1,800</b>	<b>900</b>	<b>90</b>
Telangiectasia	<b>1,000</b>	<b>500</b>	<b>50</b>
Cataract	<b>&gt;500</b>	<b>&gt;250 to eye</b>	<b>&gt;25 to eye</b>
Skin cancer	<b>Not known</b>	<b>Not known</b>	<b>Not known</b>

- FIG.1
  - Radiation wound 22 months after angioplasty procedure.
  - Injury resulted in dermal necrosis
  - Dose  $> 1,800$  rad
  - $> 360$  minutes fluoro time

During long procedures,  
move beam entry point to  
spread cumulative dose

Typical fluoro skin entrance  
dose rate  $\approx 2 - 5$  rad/min

## *Case Study*



# *Case Study*

- FIG.2

- Patient arm exposed to lateral c-arm radiation.
  - Elbow was located right next to x-ray tube port

1. Keep arm out of lateral fields



2. Keep x-ray tube port as far from the skin as possible

3. Patient should be closest to the image intensifier

# *Controlling Patient Dose*

- Practical Actions: To control dose to the patient & staff
  - Keep beam-on time to an absolute minimum ---  
The Golden Rule
  - Reduce fluoroscopy pulses/sec to as low as possible/suitable (30/sec, 15/sec, 7/sec, 3/sec)
  - Reduce cine frame rates (4, 2 or 1/sec)
  - Remember that dose rates will be greater and dose will accumulate faster in larger patients.

# *Controlling Patient Dose*

- Keep the tube current as low as possible by keeping the kVp as high as possible to achieve the appropriate compromise between image quality and low patient dose.
- Keep the x-ray tube at maximal distance from the patient.

# *Controlling Patient Dose*

- Keep the image intensifier as close to the patient as possible.
- Don't "over use" geometric magnification.
  - Smaller I.I. view increases dose rate
- Consider removing the grid during procedures on small patients (pediatric cases) or when the image intensifier cannot be placed close to the patient.


# *Controlling Patient Dose*

- Always collimate closely to the area of interest.
- Use the last image hold feature whenever possible, don't use live fluoro to confirm static information
- When the procedure is unexpectedly prolonged, consider options for positioning the patient or altering the field so that the same area of skin is not continuously in the direct x-ray field.

# *Controlling Staff Dose*

- To control dose to the staff:
  - Personnel must wear protective aprons, use shielding, monitor their doses, and know how to position themselves and the machines for minimum dose.
    - Overhead glass & table apron shields
  - If the beam is horizontal, or near horizontal, the operator should stand on the image intensifier side [to reduce dose].

# Plan view of an interventional operating x-ray unit with isodose curves



Dose rates are 4 times higher on the x-ray tube side

# *Controlling Staff Dose*

- If the beam is vertical, or near vertical, keep the tube under the patient. Use table “skirt” shields whenever available.
- The one exception to this rule is for mini C-arms. When used for extremities, the dose rates are low enough that for practical reasons it is better to have the x-ray tube above the stage.
- Wear your film badge monitors properly and return them promptly.
  - Collar Badges - Outside protective aprons
  - Waist Badges - Under protective aprons

# *Mini C-arms*

- Mini C-arms emit about 1/10th the dose rate as compared to a regular C-arm.
- However, good radiation safety practices must still be followed to keep staff and patient exposure As Low as Reasonably Achievable (ALARA).
- Leaded aprons should be worn by all personnel located within 6 feet (2 meters) of the Mini C-arm during operation.
- Mini C-arms should be limited to extremity use only. They are not designed to examine thick structures.
- Since Mini C-arms are commonly used for pediatric purposes, limiting exposure time is still important in minimizing long term radiation risk to this population.

## *Additional Resources and References*

For additional training contact the YNHH Radiation Safety Office at  
(203) 688-2950 or [mike.bohan@yale.edu](mailto:mike.bohan@yale.edu)

Online References:

[http://www.e-radiography.net/radsafety/rad\\_physics.htm](http://www.e-radiography.net/radsafety/rad_physics.htm)

<http://www.fda.gov/Radiation-EmittingProducts/RadiationEmittingProductsandProcedures/MedicalImaging/MedicalX-Rays/ucm116672.htm>

[http://www.icrp.org/downloadDoc.asp?document=docs/ICRP\\_85\\_Interventional\\_s.pps](http://www.icrp.org/downloadDoc.asp?document=docs/ICRP_85_Interventional_s.pps)