ELL101: Introduction to Electrical Engineering

Madhusudan Singh, Manan Suri, Saif K. Mohammad, Shubhendu Bhasin and A. P. Prathosh


IIT Delhi

Winter 2021


Lecture 13: Rudimentary semiconductor physics and pn junctions

- Step response. Definition of a unit step function. Step response for an RC circuit
- The case of non-monotonic forcing stimuli. Square wave response.
 Minimum period of square wave for capacitor voltage to approach the forcing voltage levels.
- Motivation for the vital importance of semiconductor materials and devices.
 Courses at IIT Delhi that address this topic in greater detail. Audience and users for devices.
- Basics of semiconductor materials periodic table, lattice types, forms, etc.
 Different types of conductivity. Deposition processes and device fabrication unit processes. Characterization. Packaging.
- Carriers in semiconductors in two different energy regimes. Bandstructure.
 Types of bandgaps.
- Doping. Intrinsic carrier concentration. Identities of donors and acceptors. Electrons and holes. Law of mass action.
- pn junction formation. Introduction to diffusion and drift. Effect of bias.


Materials used here are bound by Fair Use for educational purpose.



 Bandstructure tells you about energies that a carrier will take for given momenta.




- Bandstructure tells you about energies that a carrier will take for given momenta.
- Number of carriers (carrier density $\sim cm^{-3}$) arises from several different considerations:




$$g_{3D}(\mathcal{E}) = \frac{m^*}{\pi^2 \hbar^2} \sqrt{\frac{2m^*\mathcal{E}}{\hbar^2}}$$

- Bandstructure tells you about energies that a carrier will take for given momenta.
- Number of carriers (carrier density $\sim cm^{-3}$) arises from several different considerations:
 - Number of states available as a function of energy (density of states $\sim cm^{-3}eV^{-1}$).



- Bandstructure tells you about energies that a carrier will take for given momenta.
- Number of carriers (carrier density ~ cm⁻³) arises from several different considerations:
 - Number of states available as a function of energy (density of states $\sim cm^{-3}eV^{-1}$).
 - Probability of occupying a state (Fermi statistics, dimensionless) as a function of energy.

$$g_{3D}(\mathcal{E}) = \frac{m^*}{\pi^2 \hbar^2} \sqrt{\frac{2m^* \mathcal{E}}{\hbar^2}}$$
$$f(\mathcal{E}, T) = \frac{1}{1 + e^{\frac{\mathcal{E} - \mathcal{E}_F}{k_B T}}}$$




- Bandstructure tells you about energies that a carrier will take for given momenta.
- Number of carriers (carrier density ~ cm⁻³) arises from several different considerations:
 - Number of states available as a function of energy (density of states $\sim cm^{-3}eV^{-1}$).
 - Probability of occupying a state (Fermi statistics, dimensionless) as a function of energy.

$$g_{3D}(\mathcal{E}) = \frac{m^*}{\pi^2 \hbar^2} \sqrt{\frac{2m^* \mathcal{E}}{\hbar^2}}$$

$$f(\mathcal{E}, T) = \frac{1}{1 + e^{\frac{\mathcal{E} - \mathcal{E}_F}{k_B T}}}$$

$$n = \int_{\mathcal{E}_C}^{\infty} g_{3D,C}(\mathcal{E}) f(\mathcal{E}, T) d\mathcal{E}$$

Materials used here are bound by Fair Use for educational purpose.



- Bandstructure tells you about energies that a carrier will take for given momenta.
- Number of carriers (carrier density $\sim cm^{-3}$) arises from several different considerations:
 - Number of states available as a function of energy (density of states $\sim cm^{-3}eV^{-1}$).
 - Probability of occupying a state (Fermi statistics, dimensionless) as a function of energy.

$$g_{3D}(\mathcal{E}) = \frac{m^*}{\pi^2 \hbar^2} \sqrt{\frac{2m^* \mathcal{E}}{\hbar^2}}$$


$$f(\mathcal{E}, T) = \frac{1}{1 + e^{\frac{\mathcal{E} - \mathcal{E}_F}{k_B T}}}$$

$$n = \int_{\mathcal{E}_C}^{\infty} g_{3D,C}(\mathcal{E}) f(\mathcal{E}, T) d\mathcal{E}$$

$$p = \int_{-\infty}^{\mathcal{E}_V} g_{3D,V}(\mathcal{E}) (1 - f(\mathcal{E}, T)) d\mathcal{E}$$

This analysis includes doping through the position of the Fermi level.

Materials used here are bound by Fair Use for educational purpose.



- Bandstructure tells you about energies that a carrier will take for given momenta.
- Number of carriers (carrier density) $\sim cm^{-3}$) arises from several different considerations:
 - Number of states available as a function of energy (density of states $\sim cm^{-3}eV^{-1}$).
 - Probability of occupying a state (Fermi statistics, dimensionless) as Definition of Fermi level. a function of energy.

$$g_{3D}(\mathcal{E}) = \frac{m^*}{\pi^2 \hbar^2} \sqrt{\frac{2m^* \mathcal{E}}{\hbar^2}}$$


$$f(\mathcal{E}, T) = \frac{1}{1 + e^{\frac{\mathcal{E} - \mathcal{E}_F}{k_B T}}}$$

$$n = \int_{\mathcal{E}_C}^{\infty} g_{3D,C}(\mathcal{E}) f(\mathcal{E}, T) d\mathcal{E}$$

$$p = \int_{-\infty}^{\mathcal{E}_V} g_{3D,V}(\mathcal{E}) (1 - f(\mathcal{E}, T)) d\mathcal{E}$$

This analysis includes doping through the position of the Fermi level

Materials used here are bound by Fair Use for educational purpose.



- Bandstructure tells you about energies that a carrier will take for given momenta.
- Number of carriers (carrier density ~ cm⁻³) arises from several different considerations:
 - Number of states available as a function of energy (density of states $\sim cm^{-3}eV^{-1}$).
 - Probability of occupying a state (Fermi statistics, dimensionless) as a function of energy.

$$g_{3D}(\mathcal{E}) = \frac{m^*}{\pi^2 \hbar^2} \sqrt{\frac{2m^* \mathcal{E}}{\hbar^2}}$$

$$f(\mathcal{E}, T) = \frac{1}{1 + e^{\frac{\mathcal{E} - \mathcal{E}_F}{k_B T}}}$$

$$n = \int_{\mathcal{E}_C}^{\infty} \underbrace{g_{3D,C}(\mathcal{E}) f(\mathcal{E}, T) d\mathcal{E}}_{dn'}$$

$$p = \int_{-\infty}^{\mathcal{E}_V} g_{3D,V}(\mathcal{E}) (1 - f(\mathcal{E}, T)) d\mathcal{E}$$

This analysis includes doping through the position of the Fermi level.

S Definition of Fermi level.

Definition of effective mass.

Materials used here are bound by Fair Use for educational purpose.

Intrinsic carrier concentration.
 Approximation for cases where
 Fermi level is at least 3k_BT away from the band edges.

$$n_i = \frac{1}{\sqrt{2}} \left(\frac{\sqrt{m_n^* m_p^* k_B T}}{\pi \hbar^2} \right)^{3/2} e^{-\frac{\mathcal{E}_g}{2k_B T}}$$

Materials used here are bound by Fair Use for educational purpose.

- Intrinsic carrier concentration.
 Approximation for cases where
 Fermi level is at least 3k_BT away from the band edges.
- Intrinsic level lies nearly midway.
 For an undoped semiconductor, the Fermi level is coincident with the intrinsic level

$$n_{i} = \frac{1}{\sqrt{2}} \left(\frac{\sqrt{m_{n}^{*} m_{p}^{*}} k_{B} T}{\pi \hbar^{2}} \right)^{3/2} e^{-\frac{\mathcal{E}_{g}}{2k_{B} T}}$$

$$\mathcal{E}_{C} + \mathcal{E}_{V} = 3 \qquad (m^{*})$$

$$\mathcal{E}_{i} = \frac{\mathcal{E}_{C} + \mathcal{E}_{V}}{2} - \frac{3}{4}k_{B}T\log\left(\frac{m_{n}^{*}}{m_{p}^{*}}\right)$$

Materials used here are bound by Fair Use for educational purpose.

- Intrinsic carrier concentration.
 Approximation for cases where
 Fermi level is at least 3k_BT away from the band edges.
- Intrinsic level lies nearly midway.
 For an undoped semiconductor, the Fermi level is coincident with the intrinsic level.
- Expressions for carrier concentrations are not easy to use.

$$\begin{aligned} n_i &= \frac{1}{\sqrt{2}} \left(\frac{\sqrt{m_n^* m_p^*} k_B T}{\pi \hbar^2} \right)^{3/2} e^{-\frac{\mathcal{E}_g}{2k_B T}} \\ \mathcal{E}_i &= \frac{\mathcal{E}_C + \mathcal{E}_V}{2} - \frac{3}{4} k_B T \log \left(\frac{m_n^*}{m_p^*} \right) \\ n_0 &= n_i e^{\frac{\mathcal{E}_E - \mathcal{E}_i}{k_B T}} \\ p_0 &= n_i e^{\frac{\mathcal{E}_i - \mathcal{E}_F}{k_B T}} \end{aligned}$$

Materials used here are bound by Fair Use for educational purpose.

- Intrinsic carrier concentration.
 Approximation for cases where
 Fermi level is at least 3k_BT away from the band edges.
- Intrinsic level lies nearly midway.
 For an undoped semiconductor, the Fermi level is coincident with the intrinsic level.
- Expressions for carrier concentrations are not easy to use.
- Doping adds to individual carrier concentration. Law of mass action applies if we have equilibrium.

$$n_{i} = \frac{1}{\sqrt{2}} \left(\frac{\sqrt{m_{n}^{*} m_{p}^{*}} k_{B} T}{\pi \hbar^{2}} \right)^{3/2} e^{-\frac{\mathcal{E}_{g}}{2k_{B} T}}$$

$$\mathcal{E}_{i} = \frac{\mathcal{E}_{C} + \mathcal{E}_{V}}{2} - \frac{3}{4}k_{B}T\log\left(\frac{m_{n}^{*}}{m_{p}^{*}}\right)$$

$$\mathcal{E}_{r} - \mathcal{E}_{i}$$

$$n_0 = n_i e^{-\kappa_B T}$$

 $\varepsilon_i - \varepsilon_F$

$$p_0 = n_i e^{\frac{\mathcal{E}_i - \mathcal{E}_F}{k_B T}}$$

Materials used here are bound by Fair Use for educational purpose.

 Mobility is a measure of how easy it is for an electron or hole to move in response to an external electric field.

$$v_{n,p} = \mu_{n,p} E$$

- Mobility is a measure of how easy it is for an electron or hole to move in response to an external electric field.
- Different scattering mechanisms play a role. Mobility can depend on carrier concentration.

$$v_{n,p} = \mu_{n,p} E$$

- Mobility is a measure of how easy it is for an electron or hole to move in response to an external electric field.
- Different scattering mechanisms play a role. Mobility can depend on carrier concentration.
- Current density additionally depends on how many carriers participate in transport.

$$v_{n,p} = \mu_{n,p}E$$

$$J = \underbrace{q(n\mu_n + p\mu_p)}_{\sigma}E$$

- Mobility is a measure of how easy it is for an electron or hole to move in response to an external electric field.
- Different scattering mechanisms play a role. Mobility can depend on carrier concentration.
- Current density additionally depends on how many carriers participate in transport.
- Resistivity can be measured using a lot of different methods - Hall effect, Haynes-Shockley, time of flight, CELIV, etc.

$$v_{n,p} = \mu_{n,p}E$$

$$J = \underbrace{q(n\mu_n + p\mu_p)}_{\sigma}E$$

$$\rho \equiv \frac{1}{\sigma} = \frac{1}{q(n\mu_n + p\mu_p)}$$

Semiconductor properties

Materials used here are bound by Fair Use for educational purpose.


| | | E _g (eV) | μ _n (cm ² /V-s) | μ _{:p} (cm²/V-s) | m* _n /m _o (m _i ,m _i) | m [*] _p /m _o (m _{lh} ,m _{hh}) | a (Å) | €, | Density (g/cm³) | Melting point (°C) |
|---------|----------|------------------------|--|------------------------------|--|--|-------|------|--------------------|--------------------------|
| Si | (i/D) | 1.11 | 1350 | 480 | 0.98, 0.19 | 0.16, 0.49 | 5.43 | 11.8 | 2.33 | 1415 |
| Ge | (i/D) | 0.67 | 3900 | 1900 | 1.64, 0.082 | 0.04, 0.28 | 5.65 | 16 | 5.32 | 936 |
| SiC (a) | (i/M) | 2.86 | 500 | - | 0.6 | 1.0 | 3.08 | 10.2 | 3.21 | 2830 |
| AIP | (i/Z) | 2.45 | 80 | - | - | 0.2, 0.63 | 5.46 | 9.8 | 2.40 | 2000 |
| AlAs | (i/Z) | 2.16 | 1200 | 420 | 2.0 | 0.15, 0.76 | 5.66 | 10.9 | 3.60 | 1740 |
| AISb | (i/Z) | 1.6 | 200 | 300 | 0.12 | 0.98 | 6.14 | 11 | 4.26 | 1080 |
| GaP | (i/Z) | 2.26 | 300 | 150 | 1.12, 0.22 | 0.14, 0.79 | 5.45 | 11.1 | 4.13 | 1467 |
| GaAs | (d/Z) | 1.43 | 8500 | 400 | 0.067 | 0.074, 0.50 | 5.65 | 13.2 | 5.31 | 1238 |
| GaN | (d/Z, W) | 3.4 | 380 | _ | 0.19 | 0.60 | 4.5 | 12.2 | 6.1 | 2530 |
| GaSb | (d/Z) | 0.7 | 5000 | 1000 | 0.042 | 0.06, 0.23 | 6.09 | 15.7 | 5.61 | 712 |
| inP | (d/Z) | 1.35 | 4000 | 100 | 0.077 | 0.089, 0.85 | 5.87 | 12.4 | 4.79 | 1070 |
| InAs | (d/Z) | 0.36 | 22600 | 200 | 0.023 | 0.025, 0.41 | 6.06 | 14.6 | 5.67 | 943 |
| InSb | (d/Z) | 0.18 | 105 | 1700 | 0.014 | 0.015, 0.40 | 6.48 | 17.7 | 5.78 | 525 |
| ZnS | (d/Z, W) | 3.6 | 180 | 10 | 0.28 | - | 5.409 | 8.9 | 4.09 | 1650 |
| ZnSe | (d/Z) | 2.7 | 600 | 28 | 0.14 | 0.60 | 5.671 | 9.2 | 5.65 | 1100 |
| ZnTe | (d/Z)' | 2.25 | 530 | 100 | 0.18 | 0.65 | 6.101 | 10.4 | 5.51 | 1238 |
| CdS | (d/W, Z) | 2.42 | 250 | 15 | 0.21 | 0.80 | 4.137 | 8.9 | 4.82 | 1475 |
| CdSe | (d/W) | 1.73 | 800 | - | 0.13 | 0.45 | 4.30 | 10.2 | 5.81 | 1258 |
| CdTe | (d/Z) | 1.58 | 1050 | 100 | 0.10 | 0.37 | 6.482 | 10.2 | 6.20 | 1098 |
| PbS | (i/H) | 0.37 | 575 | 200 | 0.22 | 0.29 | 5.936 | 17.0 | 7.6 | 1119 |
| PbSe | (i/H) | 0.27 | 1500 | 1500 | _ | _ | 6.147 | 23.6 | 8.73 | 1081 |
| PbTe | (i/H) | 0.29 | 6000 | 4000 | 0.17 | 0.20 | 6.452 | 30 | 8.16 | 925 |

All values at 300 K.


*Vaporizes

Source: Streetman

 Electrons and holes are generated from heat. Thermal generation. Intrinsic.




- Electrons and holes are generated from heat. Thermal generation.
 Intrinsic.
- Thermal generation is a band to band process. Electron-hole pair is formed



$$n_{i} = \frac{1}{\sqrt{2}} \left(\frac{\sqrt{m_{n}^{*} m_{p}^{*}} k_{B} T}{\pi \hbar^{2}} \right)^{3/2} e^{-\frac{\mathcal{E}_{g}}{2k_{B} T}}$$
$$G(T) = \alpha_{r} n_{i}^{2}$$


- Electrons and holes are generated from heat. Thermal generation. Intrinsic.
- Thermal generation is a band to band process. Electron-hole pair is formed.
- Optical generation involves absorption of a photon to produce an electron hole pair.



$$G(T) + G_{op} = \alpha_r np$$

$$\equiv \alpha_r (n_0 + \Delta n) (p_0 + \Delta p)$$

- Electrons and holes are generated from heat. Thermal generation. Intrinsic.
- Thermal generation is a band to band process. Electron-hole pair is formed
- Optical generation involves absorption of a photon to produce an electron hole pair.
- If no trapping is present, at steady state, and for low levels of light.




$$G(T) + G_{op} = \alpha_r np$$

$$\equiv \alpha_r (n_0 + \Delta n) (p_0 + \Delta p)$$

$$G_{op} = \underbrace{\alpha_r (n_0 + p_0)}_{\frac{1}{\tau_n}} \Delta n$$

- Electrons and holes are generated from heat. Thermal generation.
 Intrinsic.
- Thermal generation is a band to band process. Electron-hole pair is formed
- Optical generation involves absorption of a photon to produce an electron hole pair.
- If no trapping is present, at steady state, and for low levels of light.



$$G(T) + G_{op} = \alpha_r np$$

$$\equiv \alpha_r (n_0 + \Delta n) (p_0 + \Delta p)$$


$$G_{op} = \underbrace{\alpha_r (n_0 + p_0)}_{\frac{1}{\tau_n}} \Delta n$$

- Equilibrium number of carriers are dictated by doping and the law of mass action.
- Thermal generation produces excess carriers as a function of temperature.
 This is the intrinsic carrier concentration.
- However, when light is incident, and then switched off, excess carriers generated will recombine.


$$\Delta n = (\Delta n)_0 e^{-t/\tau_n}$$

- It can be shown that the excess carrier population recombines as an exponential for low number of carriers. This process can produce photons.
- Electroluminescence: Excess carriers are injected electrically and emit light. This is a light emitting diode (LED). Only direct bandgap semiconductors can be used for this purpose.


• Diffusion causes majority carriers (doping level = N_A on p-side and N_D on n-side) to cross-migrate.




- Diffusion causes majority carriers (doping level = N_A on p-side and N_D on n-side) to cross-migrate.
 - Carriers leave behind ionized atoms. A depletion region straddling the junction, devoid of carriers, is formed.
 - Bands bend, creating a barrier to majority carrier (diffusion dominated) flow. Tunable with application of external voltage.



- Diffusion causes majority carriers (doping level = N_A on p-side and N_D on n-side) to cross-migrate.
 - Carriers leave behind ionized atoms. A depletion region straddling the junction, devoid of carriers, is formed.
 - Bands bend, creating a barrier to majority carrier (diffusion dominated) flow. Tunable with application of external voltage.
 - Minority carriers accelerate down the electric field slope (drift current). Total current = diffusion + drift currents.



- Diffusion causes majority carriers (doping level = N_A on p-side and N_D on n-side) to cross-migrate.
 - Carriers leave behind ionized atoms. A depletion region straddling the junction, devoid of carriers, is formed.
 - Bands bend, creating a barrier to majority carrier (diffusion dominated) flow. Tunable with application of external voltage.
 - Minority carriers accelerate down the electric field slope (drift current). Total current = diffusion + drift currents.
- Diode equation. Significant for several classes of devices.



$$J = \underbrace{q\left(\frac{D_p}{L_n}p_n + \frac{D_n}{L_n}n_p\right)}_{J_0}\left[e^{\frac{qV_{app}}{k_BT}} - 1\right]$$

Materials used here are bound by Fair Use for educational purpose.

Forward bias reduces the barrier
 ~ V_{bi} - V_{app} to majority carrier
 injection.




Materials used here are bound by Fair Use for educational purpose.

• Forward bias reduces the barrier $\sim V_{bi} - V_{app}$ to majority carrier injection.




Exponential increase in majority carrier current (diffusion dominated).


- Forward bias reduces the barrier
 ~ V_{bi} V_{app} to majority carrier
 injection.
- Exponential increase in majority carrier current (diffusion dominated).
- Reverse bias increases the barrier $\sim V_{bi} + V_{app}$ to majority carrier injection.




- Forward bias reduces the barrier
 ~ V_{bi} V_{app} to majority carrier
 injection.
- Exponential increase in majority carrier current (diffusion dominated).
- Reverse bias increases the barrier $\sim V_{bi} + V_{app}$ to majority carrier injection.
- Current is dominated by minority carrier drift.




- Forward bias reduces the barrier $\sim V_{bi} V_{app}$ to majority carrier injection.
- Exponential increase in majority carrier current (diffusion dominated).
- Reverse bias increases the barrier $\sim V_{bi} + V_{app}$ to majority carrier injection.
- Current is dominated by minority carrier drift.
- Shape of diode response. Regimes of operation.



- Forward bias reduces the barrier
 ~ V_{bi} V_{app} to majority carrier
 injection.
- Exponential increase in majority carrier current (diffusion dominated).
- Reverse bias increases the barrier $\sim V_{bi} + V_{app}$ to majority carrier injection.
- Current is dominated by minority carrier drift.
- Shape of diode response. Regimes of operation.
- Effect of light incidence.



- Forward bias reduces the barrier
 ~ V_{bi} V_{app} to majority carrier
 injection.
- Exponential increase in majority carrier current (diffusion dominated).
- Reverse bias increases the barrier $\sim V_{bi} + V_{app}$ to majority carrier injection.
- Current is dominated by minority carrier drift.
- Shape of diode response. Regimes of operation.
- Effect of light incidence.
- Different types of diode operation.
 Take ELL739/ELL743 for more details.



Materials used here are bound by Fair Use for educational purpose.

Never too early to get involved with professional bodies in your area.
 Benefits:

Materials used here are bound by Fair Use for educational purpose.

- Never too early to get involved with professional bodies in your area.
 Benefits:
 - Career guidance, mentorship and networking.

Materials used here are bound by Fair Use for educational purpose.

- Never too early to get involved with professional bodies in your area.
 Benefits:
 - Career guidance, mentorship and networking.
 - Exposure to areas with significant growth.

Materials used here are bound by Fair Use for educational purpose.

- Never too early to get involved with professional bodies in your area.
 Benefits:
 - Career guidance, mentorship and networking.
 - Exposure to areas with significant growth.
 - Discounts for professional activities, conferences, publications, etc.

Materials used here are bound by Fair Use for educational purpose.

- Never too early to get involved with professional bodies in your area.
 Benefits:
 - Career guidance, mentorship and networking.
 - Exposure to areas with significant growth.
 - Discounts for professional activities, conferences, publications, etc.
- Two important societies:

Materials used here are bound by Fair Use for educational purpose.

- Never too early to get involved with professional bodies in your area.
 Benefits:
 - Career guidance, mentorship and networking.
 - Exposure to areas with significant growth.
 - Discounts for professional activities, conferences, publications, etc.
- Two important societies:

devices and materials

 IEEE (Institute of Electrical and Electronics Engineers): You can write to me via email for a referral to get an invitation. IEEE has several societies. For students interested in devices, please select the Electron Devices Society as the additional membership.

 $\label{thm:materials} \mbox{Materials used here are bound by Fair Use for educational purpose.}$

- Never too early to get involved with professional bodies in your area.
 Benefits:
 - Career guidance, mentorship and networking.
 - Exposure to areas with significant growth.
 - Discounts for professional activities, conferences, publications, etc.
- Two important societies:
 - IEEE (Institute of Electrical and Electronics Engineers): You can write to me via email for a referral to get an invitation. IEEE has several societies. For students interested in devices, please select the *Electron Devices Society* as the additional membership.
 - MRS (Materials Research Society): Become a student member today. There is an active student chapter on campus. Send email to the IIT Delhi MRS University Chapter to join. They hold very interesting webinars a few times every semester. Potential fiscal support for special projects. Annual lottery for partial travel support for the MRS Fall Meeting in Boston (as Chapter representative: restricted to presenters who are student members).