03.122 WRS Maintenance Procedure

(03. ECLSS)

OBJECTIVE:

To maintain the Water Recovery System (WRS) by replacing filters

EQUIPMENT:

Flat blade screwdriver


PPE safety glasses

PPE Kobalt work gloves

PPE Static wrist tether

ECLSS KIT: Rechargeable trap filter (will be gathered during the procedure)

Microbial filter (will be gathered during the procedure)



L2C 1. REMOVE RECHARGEABLE TRAP FILTER

- 1.1 Don PPE safety glasses
- 1.2 Don PPE gloves
- 1.3 Don Static Wrist Tether and attach to any unpainted metallic surface
- 1.4 Turn Distillation Gas Vent Valve clockwise to closed position (see Figure 1)

21 DEC 18 Page 1 of 6

(03. ECLSS)




Figure 1: Distillation Gas Vent Valve

1.5 Pull Rechargeable Trap Lever down (see Figure 2)



Figure 2: Rechargeable Trap Lever

21 DEC 18 Page 2 of 6

03.122 WRS Maintenance Procedure

(03. ECLSS)

1.6 Remove Rechargeable Trap Filter Cover by sliding left and temp stow (see Figure 3)



Figure 3: Rechargeable Trap Filter Cover

1.7 Disconnect hose from Filter Housing

21 DEC 18 Page **3** of **6**

1.8 Remove and temp stow rubber gasket (see Figure 4)



Figure 4: Rubber Gasket



Figure 5: Filter Screen



Figure 6: Filter Sleeve and Rechargeable Trap Filter

21 DEC 18 Page 4 of 6

03.122 WRS Maintenance Procedure

(03. ECLSS)

- 1.8 Remove and temp stow Filter Screen from Filter Housing
- 1.9 Remove used Rechargeable Trap Filter and Filter Sleeve from Filter Housing
- 1.10 Remove used Rechargeable Trap Filter from Filter Sleeve
- 1.11 Temp stow Filter Sleeve
- 1.12 Place used Rechargeable Trap Filter in a Ziploc bag labeled "Used Trap Filter" and stow in ECLSS kit

L2C 2. <u>INSTALL NEW RECHARGEABLE TRAP FILTER</u>

- 2.1 Retrieve clean Rechargeable Trap Filter from bag of spares in the ECLSS kit and insert into Filter Sleeve
- 2.2 Insert Filter Sleeve into Filter Housing
- 2.3 Insert Filter Screen into Filter Housing with screen facing out
- 2.4 Place rubber gasket on Filter Housing and mate hose

- 2.5 Secure the Rechargeable Trap Filter Cover using clamp.
- 2.6 Confirm adjustable clamp on the lever is positioned within the base of the cover. Pull lever up to lock

NOTE

Hand-tighten clamp then point the lever towards the outer wall of the cabin

L2C 3 REMOVE MICROBIAL FILTER

3.1 Grasp Microbial filter and turn clockwise to remove

21 DEC 18 Page **5** of **6**

(03. ECLSS)



Figure 7: Microbial Filter

- 3.2 Stow used microbial filter in ECLSS kit in Ziploc bag labeled "Used Microbial Filter"
- 3.3 Call MCC and report serial number of removed microbial filter

L2C 4 INSTALL NEW MICROBIAL FILTER

- 4.1 Remove new Microbial filter from ECLSS kit
- 4.2 Insert new Microbial filter into filter housing and turn counter clockwise until you feel a click.
- 4.3 Call MCC and report serial number of new microbial filter
- 4.4 Turn Distillation Gas Vent Valve counter-clockwise to open position.
- 4.5 Doff PPE gloves and safety glasses
- 4.6 Stow PPE and ECLSS kit in Airlock stowage locations.

21 DEC 18 Page 6 of 6