03.101 CCAA Main Cabin Fan Activation

(03. HSS)

OBJECTIVE:

To activate the main cabin fans to provide air circulation for the ECLSS systems.

1. <u>ACTIVATE MAIN CABIN FANS</u>

1.1 On HSS CDRA display, touch Main Cabin Fan 1 icon to activate fan (see Figure 1).

Verify fan has audibly turned on.

1.2 On HSS CDRA display, touch Main cabin Fan 2 icon to activate fan (see Figure 1).

Verify fan has audibly turned on.




Figure 1. Main Cabin Fan Power

12-Aug-2020 Page 1 of 1