03.106 HSS Emergency O2 Deactivation

(03. HSS)

OBJECTIVE:

To deactivate the Emergency O2 Generation System.

EQUIPMENT:

None

L₁D

NOTE

In the event of an Oxygen Generation System failure, liquid O2 tanks are onboard and can be used on an emergency basis.

1. DEACTIVATE EMERGENCY O2 GENERATION SYSTEM



Figure 1: Emergency O2 Generation System

- 1.1 Flip power switch of Emergency O2 Generation System to "OFF" (see Figure 1).
 - 1.1.1 Confirm Emergency O2 Generation System is off by verifying red light is no longer illuminated.
 - 1.1.2 Confirm Emergency O2 Generation System is off by verifying no audible fan sound.

1 Sept. 2020 Page 1 of 1