03.101 CCAA Main Cabin Fan Activation

(03. ECLSS)

OBJECTIVE:

To activate the main cabin fans to provide air circulation for the ECLSS systems.

L1F Subf 1. ACTIVATE MAIN CABIN FANS

1.1 Remove floor panel 1F and temp stow.



Figure 1. Cabin Fan Power Switches

1.2 On Main Cabin Fan, pull switch out and push toward "ON" to activate fan (see Figure 1).

Verify fan has audibly turned on.

1.3 On Secondary Cabin Fan, pull switch out and push toward "ON" to activate fan (see Figure 1).

Verify fan has audibly turned on.

1.4 Replace floor panel 1F and safely latch.

29-Jan-2019 Page 1 of 1