03.114 Fuel Cell Activation

(03. ECLSS)

OBJECTIVE:

To place one or both of the fuel cells in Operate mode to return to nominal activities.

EQUIPMENT:

PPE safety glasses Orange caution cone 1x

L1C Subf 1. ACTIVATE FUEL CELLS

- 1.1 Remove floor panel 1C and temp stow. Place orange caution cone to side of opening.
- 1.2 Don PPE safety glasses.




Figure 1: Fuel Cell Control Panel

1.3 Check 15 amp circuit breaker is not tripped by verifying there is no white ring visible on the circuit breaker (see Figure 1).

If tripped, contact MCC.

10 Jan 2019 Page **1** of **3**

(03. ECLSS)

1.4 Check fuel cell 1 and 2 yellow standby lights are illuminated and green operate lights are off (see Figure 2).



Figure 2: Fuel Cell Standby Light

NOTE

Fuel cell power switch has three positions:

Down = Operate Mode

Neutral (Center) = Power Removed

Up = Standby Mode

1.5 Lift switch guards and flip power switches for fuel cell 1 and 2 power to Operate Mode.



Figure 3: Fuel Cell Operate Light

- 1.6 Check fuel cell 1 and 2 green operate lights are illuminated (see Figure 3).
- 1.7 Close switch guards for fuel cells 1 and 2.
- 1.8 Doff PPE safety glasses.
- 1.9 Retrieve and reinstall floor panel 1C.

10 Jan 2019 Page 2 of 3

03.114 Fuel Cell Activation

(03. ECLSS)

1.10 Stow all equipment.

10 Jan 2019 Page **3** of **3**