## **03.118 TCCS Auxiliary Fan Activation**

(03. ECLSS)

## **OBJECTIVE:**

To activate the auxiliary cabin fans on the Trace Contaminant Control Subassembly (TCCS) panel.

## NOTE

The TCCS auxiliary (aux) fans do not have variable speeds. They are used to increase air flow throughout the Environmental Control and Life Support System (ECLSS) during offnominal operations.

## GMWS 1. ACTIVATE TCCS AUX FAN 1 AND FAN 2




Figure 1. Trace Contaminant Control Subassembly (TCCS) Panel

- 1.1 On the TCCS Panel, flip the power switch of Aux Cabin Fan 1 to "ON" (see Figure 1).
- 1.2 On the TCCS Panel, flip the power switch of Aux Cabin Fan 2 to "ON" (see Figure 1).

10 Jan 2019 Page 1 of 1