

RTL Design Sherpa

Lattice Micro-Architecture Specification 1.2

October 13, 2026

Table of Contents

Lattice Mas Index....11

Lattice Micro-Architecture Specification Index....12

Document Organization....13

Main Documentation....13

Chapter 1: Architecture....14

Chapter 2: Address Decode and Arbitration....15

Chapter 3: RTL Generator....16

Quick Navigation....17

For New Users....17

For Integration....17

Common Questions....17

Visual Assets....18

Architecture Diagrams....18

Timing Diagrams....18

Component Overview....19

Key Features....19

Pre-Generated Variants....19

Design Philosophy....19

Related Documentation....20

Companion Specifications....20

Project-Level....20

Test Infrastructure....20

RTL 20
Version History 21
Lattice Visual Documentation 22
Overview 23
Documentation Structure 24
Main Documentation Files 24
Supporting Documentation 24
Visual Assets 25
Architecture Diagrams 25
Timing Diagrams 25
Quick Start 26
For New Users 26
For Existing Users 26
Directory Structure 27
Key Concepts 28
1. Architecture 28
2. Address Decode 28
3. Arbitration 28
4. RTL Generation 28
Common Questions 30
Q: Which pre-generated variant should I use? 30
Q: How do I change the base address? 30
Q: Can I change per-slave address sizes? 30
Q: How does arbitration work with 3+ masters? 30

Q: What's the throughput?..... 31
Regenerating Diagrams..... 32
Graphviz Diagrams (Architecture, Address Decode)..... 32
WaveJSON Diagrams (Timing)..... 32
Version History..... 33
Maintainers..... 34
Lattice Architecture..... 35
Overview..... 36
Architecture Diagram..... 37
Figure 1.1: Lattice Top-Level Architecture..... 37
Functional Blocks..... 38
1. Master-Side Protocol Conversion..... 38
2. Internal Crossbar Logic..... 38
3. Slave-Side Protocol Conversion..... 38
Signal Flow Example..... 40
Parameter Configuration..... 41
APB5 Parity Across the Fabric..... 42
APB5 PWAKEUP Across the Fabric..... 43
Pre-Generated Variants..... 44
Design Philosophy..... 45
Next Steps..... 46
Address Decode and Arbitration..... 47
Overview..... 48
Address Decode..... 49

Address Map Structure....49
Decode Algorithm....49
Out-of-Range Addresses....49
Address Decode Flow Diagram....50
Figure 2.1: Address Decode Flow....50
Decode Example Walkthrough....51
Multiple Address Maps....51
Arbitration....52
Per-Slave Round-Robin....52
Round-Robin Timing Diagram....52
Arbitration Example Walkthrough....52
Multi-Slave Parallelism....53
Grant Persistence....54
Arbitration Latency....54
Integration Examples....55
Example 1: CPU to 4 Peripherals (No Contention)....55
Example 2: CPU + DMA to 4 Peripherals (Potential Contention)....55
Performance Characteristics....56
Throughput....56
Latency....56
Design Notes....57
Why 64KB Per Slave?....57
Why Round-Robin?....57
Troubleshooting....58

Issue: Wrong Slave Selected....58
Issue: Master Starved....58
Issue: Back-to-Back Transactions Stalling....58
Next Steps....59
Lattice RTL Generator....60
Overview....61
Generator Architecture....62
Two-Level Structure....62
Quick Start....63
Generate Standard Variants (1:1, 2:1, 1:4, 2:4)....63
Generate Custom Variant....63
Generate with Custom Base Address....63
Command-Line Interface....65
Full Options....65
Examples....66
Generated Code Structure....67
Template Components....67
Generator Algorithm....71
Step-by-Step Process....71
Code Generation Patterns....73
Loop-Based Generation....73
String Formatting....73
Customization Examples....74
Example 1: Large SoC with 10 Peripherals....74

Example 2: Multi-CPU System....74
Example 3: Memory-Mapped I/O Region....74
Using Generated Modules....76
Integration Example....76
Parameter Override....77
Generator Limitations and Future Work....78
Current Limitations....78
Future Enhancements....78
Testing Generated Code....80
Verification Flow....80
Recommended Test Cases....80
Advanced Usage....81
Using as Python Library....81
Batch Generation....81
Troubleshooting....82
Issue: “ModuleNotFoundError: No module named ‘amba.apbx_xbar_generator’”....82
Issue: Generated Code Won’t Lint....82
Issue: Generated Code Too Large....82
References....83
Verification Wrappers....84

List of Figures

Figure 1.1: Lattice Top-Level Architecture..... 37
Figure 2.1: Address Decode Flow..... 50

List of Tables

Table 1: Pre-Generated Variants....19
Table 2: Main Documentation Files....24
Table 3: Supporting Documentation....24
Table 4: Architecture Diagram Assets....25
Table 5: Timing Diagram Assets....25
Table 6: Generated-Variant Parameters....41
Table 7: Pre-Generated Crossbar Variants....44
Table 8: Command Line Options....64
Table 9: Python API Arguments....64
Table 10: Verification Wrapper Parameters....83

List of Waveforms

Waveform 2.1: Round-Robin Arbitration Timing.....52

Lattice Mas Index

Generated: 2026-10-20

RTL Design Sherpa · Learning Hardware Design Through Practice GitHub · Documentation Index · MIT License

---

Lattice Micro-Architecture Specification Index

Component: Lattice (MxN Interconnect) **Version:** 1.4 **Date:** 2026-10-20 **Purpose:** Detailed micro-architecture specification for Lattice component

---

Document Organization

This specification covers the Lattice: a parametric MxN interconnect that routes multiple APB masters to multiple APB slaves with automatic address-based routing and round-robin arbitration.

Main Documentation

README.md

Chapter 1: Architecture

chapters/01_architecture.md

Chapter 2: Address Decode and Arbitration

chapters/02_address_and_arbitration.md

Chapter 3: RTL Generator

chapters/03_rtl_generator.md

Quick Navigation

For New Users

1. Start with README.md for overview and quick start
2. Read 01_architecture.md to understand the design
3. Study 02_address_and_arbitration.md for operational details
4. Reference 03_rtl_generator.md if you need a custom configuration

For Integration

- **Pre-generated variants:** See 01_architecture.md Section “Pre-Generated Variants”
- **Custom generation:** See 03_rtl_generator.md Section “Quick Start”
- **Address mapping:** See 02_address_and_arbitration.md Section “Address Decode”
- **Arbitration behavior:** See 02_address_and_arbitration.md Section “Arbitration”

Common Questions

All answered in README.md, section “Common Questions”.

Visual Assets

Every diagram in this specification is checked in as both source and rendered output:

- **Source Files:**
  - `assets/graphviz/*.dot` - Graphviz source diagrams
  - `assets/wavedrom/*.json` - WaveJSON timing diagrams
- **Rendered Files:**
  - `assets/graphviz/*.png` - PNG format (for document generation)

Architecture Diagrams

1. **Lattice Architecture (2x4 Example)**
   - Source: assets/graphviz/apbx_xbar_architecture.dot
   - Rendered: assets/graphviz/apbx_xbar_architecture.png
2. **Address Decode Flow**
   - Source: assets/graphviz/address_decode_flow.dot
   - Rendered: assets/graphviz/address_decode_flow.png

Timing Diagrams

1. **Round-Robin Arbitration**
   - Source: assets/wavedrom/arbitration_round_robin.json
   - Rendered: assets/wavedrom/arbitration_round_robin.png

Component Overview

Key Features

- **Parametric MxN Configuration:** Any combination of M masters and N slaves (up to 16x16)
- **Automatic Address Decode:** 64KB per slave, simple offset-based routing
- **Round-Robin Arbitration:** Per-slave fair arbitration, no master starvation
- **Back-to-Back Transactions:** Accepted without master-side idle cycles, though they do not overlap inside the fabric (10 pclk cycles each for M = 1, 11 for arbitrated variants; one more than that variant's single-transfer latency — see HAS 5.2)
- **Grant Persistence:** Grant held through transaction completion
- **RTL Generation:** Python-based generator for custom configurations

Pre-Generated Variants

Pre-Generated Variants

Module	M×N	Use Case
apbx_xbar_1to1	1×1	Passthrough, protocol conversion
apbx_xbar_2to1	2×1	Multi-master arbitration
apbx_xbar_1to4	1×4	Simple SoC peripheral bus
apbx_xbar_2to4	2×4	Typical SoC with CPU+DMA
apbx_xbar_2to2_mixed	2×2	Mixed APB4/APB5 (m0=APB4, m1=APB5; s0=APB5, s1=APB4)

Design Philosophy

Proven Building Blocks: - Built from production-tested `apb4_slave` and `apb4_master` modules - No new protocol logic - pure composition - Each component independently verified

Parametric Generation: - Generator creates any MxN configuration - Pre-generated common variants for fast integration - Custom variants generated on-demand

Clean Separation: - Master-side: APB slaves convert protocol → cmd/rsp - Internal: Arbitration + address decoding - Slave-side: APB masters convert cmd/rsp → protocol

---

Related Documentation

Companion Specifications

- **Lattice HAS** - Hardware Architecture Specification (high-level)

Project-Level

- **PRD.md:** ../../PRD.md - Complete product requirements document
- **CLAUDE.md:** ../../CLAUDE.md - AI assistant integration guide
- **README.md:** ../../README.md - Quick start guide

Test Infrastructure

- **Test Directory:** `../../dv/tests/` - CocoTB + pytest test suite
- **Test Results:** 100% passing (9/9) — all pre-generated variants plus the dedicated timing test; `apbx_xbar_2to2_mixed` additionally has a formal harness

RTL

- **Core Modules:** `../../rtl/apbx_xbar_*.sv` - Pre-generated crossbars
- **Wrappers:** `../../rtl/wrappers/` - testbench scaffolds (pclk/presetn only), not integration wrappers
- **Generator:** `../../bin/generate_xbars.py` - Python generator script

Version History

Version 1.0 (2025-10-25): - Initial specification release - Complete visual documentation (3 diagrams) - Generator documentation - All pre-generated variants verified (100% passing)

Version 1.1 (2026-10-12): - Refreshed against current RTL, generator, and DV - Updated verification status (9/9 tests passing, mixed-variant formal harness) - Added `--slave-size` CLI option to generator table - Updated line-of-code counts (single source of truth remains HAS ch05_performance/03_resources.md)

Last Updated: 2026-10-12 **Maintained By:** RTL Design Sherpa Project

RTL Design Sherpa · Learning Hardware Design Through Practice GitHub · Documentation Index · MIT License

---

Lattice Visual Documentation

Component: Lattice (MxN Interconnect) **Version:** 1.2 **Status:** Production Ready **Last Updated:** 2026-10-12

Overview

This directory holds the Lattice's documentation set: the architecture chapters, their diagrams and timing waveforms, and the generator guide.

Component Purpose: Parametric MxN APB interconnect connecting multiple masters to multiple slaves with automatic address-based routing and round-robin arbitration.

Documentation Structure

Main Documentation Files

Main Documentation Files

Document	Description	Contents
01_architecture.md	Architecture Overview	Top-level block diagram, functional blocks, signal flow, parameters
02_address_and_arbitration.md	Address Decode & Arbitration	Address map structure, decode algorithm, round-robin timing
03_rtl_generator.md	RTL Generator Guide	Generator architecture, usage, customization, advanced topics

Supporting Documentation

Supporting Documentation

Document	Location	Description
PRD.md	../../PRD.md	Complete product requirements document
CLAUDE.md	../../CLAUDE.md	AI assistant integration guide
README.md	../../README.md	Quick start guide

Visual Assets

Architecture Diagrams

Architecture Diagram Assets

Diagram	Format	Description
apbx_xbar_architecture	Graphviz	2x4 crossbar showing master-side slaves, arbitration, slave-side masters
address_decode_flow	Graphviz	Step-by-step address decode example (0x10023456 to Slave 2)

Rendered Format: PNG beside each source in `assets/graphviz/` (what the chapters embed).

Timing Diagrams

Timing Diagram Assets

Diagram	Format	Description
arbitration_round_robin	WaveJSON	2 masters competing for Slave 0 with round-robin arbitration

Rendered Format: - PNG: `assets/wavedrom/arbitration_round_robin.png`

Quick Start

For New Users

1. **Understand the Architecture**
   - Read 01_architecture.md
   - Study the architecture diagram
   - Understand master-side/slave-side protocol conversion
2. **Learn Address Decode & Arbitration**
   - Read 02_address_and_arbitration.md
   - Study address decode flow diagram
   - Study arbitration timing diagram
3. **Generate Custom Crossbar (if needed)**
   - Read 03_rtl_generator.md
   - Use pre-generated variants (1to1, 2to1, 1to4, 2to4, 2to2_mixed) if possible
   - Run generator for custom MxN configurations
4. **Integrate Into Your Design**
   - See integration examples in CLAUDE.md
   - Reference complete specification in PRD.md

For Existing Users

Need a Crossbar? - 1 master, N slaves → Use `apbx_xbar_1toN` or generate - 2 masters, N slaves → Use `apbx_xbar_2toN` or generate - M masters, N slaves → Generate with `generate_xbars.py`

Understanding Behavior? - Address decode issues → See 02_address_and_arbitration.md - Arbitration questions → See 02_address_and_arbitration.md

Modifying/Generating? - Generator usage → See 03_rtl_generator.md

---

Directory Structure

```
docs/lattice_mas/
├── README.md                                ← This file
├── lattice_mas_index.md                    ← Book index (PDF build)
├── chapters/
│   ├── 01_architecture.md                   ← Architecture overview
│   ├── 02_address_and_arbitration.md        ← Decode & arbitration
details
│   └── 03_rtl_generator.md                  ← Generator documentation
└── assets/
    ├── graphviz/                            ← Diagram sources +
rendered PNGs
    │   ├── apbx_xbar_architecture.dot / .png
    │   ├── address_decode_flow.dot / .png
    │   └── regenerate_all_graphviz.sh
    └── wavedrom/                            ← Source timing diagrams
        └── arbitration_round_robin.json
```

Key Concepts

1. Architecture

Three-Stage Design: 1. **Master-Side:** APB slaves convert protocol → cmd/rsp 2. **Internal Logic:** Address decode + arbitration + response routing 3. **Slave-Side:** APB masters convert cmd/rsp → protocol

Why This Design? - Reuses proven `apb4_slave` and `apb4_master` components - Clean separation of concerns - Scalable to any MxN configuration

2. Address Decode

Fixed 64KB Per Slave:

```
Slave 0: BASE_ADDR + 0x00000 - 0x0FFFF
Slave 1: BASE_ADDR + 0x10000 - 0x1FFFF
Slave 2: BASE_ADDR + 0x20000 - 0x2FFFF
...
```

Decode Formula:

```
offset = PADDR - BASE_ADDR
slave_index = offset[16 +: $clog2(S)]  // [17:16] for S=4, [16] for
S=2
```

See: 02_address_and_arbitration.md

3. Arbitration

Per-Slave Round-Robin: - Each slave has independent arbiter - Priority rotates after each grant - Grant persists through transaction completion - No master starvation

See: 02_address_and_arbitration.md

4. RTL Generation

All Generator Code in Component Area: - **Convenience Wrapper:** `bin/generate_xbars.py` (top-level script) - **Core Generator:** `bin/apbx_xbar_generator.py` (library implementation)

Usage:

```
# Generate standard variants
python generate_xbars.py

# Generate custom 3x6 crossbar
python generate_xbars.py --masters 3 --slaves 6
```

See: 03_rtl_generator.md

Common Questions

Q: Which pre-generated variant should I use?

Decision Tree:

```
1 master, 1 slave  → apbx_xbar_1to1 (passthrough)
1 master, 4 slaves → apbx_xbar_1to4 (address decode only)
2 masters, 1 slave → apbx_xbar_2to1 (arbitration only)
2 masters, 4 slaves → apbx_xbar_2to4 (full crossbar)
2 masters, 2 slaves (mixed APB4/APB5) → apbx_xbar_2to2_mixed
Other MxN          → Generate with generate_xbars.py
```

Q: How do I change the base address?

At Instantiation:

```
apbx_xbar_1to4 #(
    .BASE_ADDR(32'h8000_0000)  // Override default 0x10000000
) u_xbar (...);
```

Or Generate with Custom Base:

```
python generate_xbars.py --masters 2 --slaves 4 --base-addr 0x80000000
```

Q: Can I change per-slave address sizes?

No: each slave is fixed at a 64KB window. Only the map's origin is settable, via the `BASE_ADDR` parameter.

Workarounds: 1. Use multiple crossbars with different BASE_ADDR 2. Modify generator's decode logic (advanced) 3. Address translation in slaves

See: 03_rtl_generator.md#limitations

Q: How does arbitration work with 3+ masters?

Round-Robin Example (4 Masters, Same Slave):

```
Initial priority: M0
Transaction 1: M0 requests → M0 granted → Priority rotates to M1
Transaction 2: M0, M1, M2 request → M1 granted → Priority rotates to
M2
Transaction 3: M0, M3 request → M2 skipped (not requesting) → M3
granted → Priority rotates to M0
Transaction 4: M0, M1 request → M0 granted → Priority rotates to M1
```

Key: Priority rotates after each grant, ensuring fairness.

See: 02_address_and_arbitration.md#arbitration

Q: What's the throughput?

Single Master: - Back-to-back transactions without master-side gaps (no overlap inside the fabric; 10 pclk cycles each for M = 1, 11 when arbitrated) - Limited only by slave PREADY response time

Multiple Masters (Same Slave): - Fair sharing: Each master gets ~1/M bandwidth - Example: 2 masters = 50% each, 4 masters = 25% each

Multiple Masters (Different Slaves): - Full parallelism: Each master gets 100% of its target slave - Total system bandwidth = (number of slaves) × slave_bandwidth

See: 02_address_and_arbitration.md#performance

Regenerating Diagrams

Graphviz Diagrams (Architecture, Address Decode)

```
# Renders every .dot beside itself as PNG (150 dpi, alpha flattened,
PNG8)
assets/graphviz/regenerate_all_graphviz.sh
```

WaveJSON Diagrams (Timing)

```
cd assets/wavedrom/

# Generate SVG, then PNG
wavedrom-cli -i arbitration_round_robin.json -s
arbitration_round_robin.svg
wavedrom-cli -i arbitration_round_robin.json -p
arbitration_round_robin.png
```

Version History

Version 1.0 (2025-10-25): - Initial visual documentation release - 3 main documentation files - 2 Graphviz architecture diagrams - 1 WaveJSON timing diagram - RTL generator documentation

Version 1.1 (2026-10-12): - Refreshed against current RTL, generator, and DV - Added mixed-variant and timing-test guidance

---

Maintainers

RTL Design Sherpa Project

Questions or Issues: 1. Check this documentation first 2. Review PRD.md for complete specification 3. Review CLAUDE.md for integration guidance 4. Open a GitHub issue if the problem persists

---

Last Updated: 2026-10-12 **Version:** 1.2 **Status:** Production Ready

RTL Design Sherpa · Learning Hardware Design Through Practice GitHub · Documentation Index · MIT License

---

Lattice Architecture

Component: Lattice (MxN Interconnect) **Version:** 1.2 **Status:** Production Ready

Overview

The Lattice is a parametric interconnect that connects M APB masters to N APB slaves with automatic address-based routing and per-slave round-robin arbitration. It is a pure composition of the proven `apb4_slave` and `apb4_master` components — there is no new protocol logic in the crossbar itself.


Key Features: - Arbitrary MxN configuration (up to 16x16) - Automatic address decode (64KB per slave) - Round-robin arbitration per slave - Back-to-back transactions (no overlap; 10 pclk cycles each for M = 1, 11 when arbitrated) - Grant persistence through transaction completion

---

Architecture Diagram

The 2x4 configuration below connects 2 masters (CPU and DMA) to 4 slaves (UART, GPIO, Timer, SPI):

Figure 1.1: Lattice Top-Level Architecture



Lattice Architecture (2x4 Example)

Both masters are drawn, for one slave `s`. Each master's cmd is decoded into a request bit for the slave it addresses; the slave's `arbiter_round_robin` (the trapezium) grants one master and holds the grant until the response handshake (`WAIT_GNT_ACK = 1`); the command mux and `apb4_master` carry the granted cmd to the slave. The response climbs the right column, steered back by the slave index registered at cmd accept, or replaced by a local PSLVERR on a decode miss.

Functional Blocks

1. Master-Side Protocol Conversion

Component: `apb4_slave[M]` instances (one per master)

Purpose: Convert incoming APB protocol transactions to internal cmd/rsp bus format

Features: - Full APB protocol handling (PSEL, PENABLE, PREADY) - Transaction buffering - Error response generation - Back-to-back transaction support

Dataflow:

```
APB Master → apb4_slave → cmd/rsp bus → Internal Crossbar Logic
```

---

2. Internal Crossbar Logic

Components: - **Address Decode** - Parallel decode to determine target slave - **Per-Slave Arbiters** - Round-robin arbitration for each slave - **Response Routing** - Registered paths back to requesting masters

Key Operations:

Address Decode:

```
offset = PADDR - BASE_ADDR
slave_index = offset[16 +: $clog2(S)]  // [17:16] for S=4, [16] for
S=2
```

Arbitration: - Independent arbiter per slave - Round-robin priority rotation - Grant persistence through response - No starvation guarantee

Response Routing: - Track which master initiated each transaction - Route PRDATA/PSLVERR back to originating master - Maintain transaction ordering per master

---

3. Slave-Side Protocol Conversion

Component: `apb4_master[N]` instances (one per slave)

Purpose: Convert internal cmd/rsp bus format back to APB protocol for slaves

Features: - APB protocol generation (PSEL, PENABLE timing) - Response collection (PRDATA, PSLVERR, PREADY) - Wait state handling - Error propagation

Dataflow:

```
Internal Crossbar Logic → cmd/rsp bus → apb4_master → APB Slave
```

Signal Flow Example

Transaction: Master 0 (CPU) writes to Slave 2 (Timer) at address 0x10023456

Step-by-step:

1. **Master 0 → apb4_slave[0]:**
   - CPU asserts PSEL, PADDR=0x10023456, PWRITE=1
   - apb4_slave[0] converts to cmd/rsp format
2. **Address Decode:**
   - offset = 0x10023456 - 0x10000000 = 0x00023456
   - slave_index = 0x00023456 >> 16 = 0x2
   - Target: Slave 2
3. **Arbiter[2]:**
   - Check if Slave 2 is available
   - Grant to Master 0 (if no conflict)
   - Route cmd to apb4_master[2]
4. **apb4_master[2] → Slave 2:**
   - Generate APB write transaction
   - Assert PSEL[2], PENABLE, PADDR, PWDATA
   - Wait for PREADY
5. **Response Path:**
   - Slave 2 responds with PREADY, PSLVERR
   - apb4_master[2] captures response
   - Response routed back to apb4_slave[0]
   - apb4_slave[0] returns PREADY to CPU

Total Latency: 9 cycles SETUP-to-PREADY uncontended on a single-master variant, 10 when arbitrated; sustained back-to-back cadence is 10 and 11 respectively (measured; see 2.x — the fabric's boundary IP and registered skid buffers dominate, not APB's 2-cycle protocol minimum)

Parameter Configuration

Every variant has its M×N **baked in** by the generator, so there is no port-count parameter to override at elaboration — a different shape means regenerating, not re-elaborating. What remains parameterizable:

Generated-Variant Parameters

Parameter	Range	Default	Description
ADDR_WIDTH	18-64 (decoding variants); 1-64 (1to1/2to1)	32	Address bus width
DATA_WIDTH	8-64	32	Data bus width
STRB_WIDTH	derived	DATA_WIDTH/8	Write strobe width
BASE_ADDR	any except the top S x 64KB (where BASE+span wraps 32-bit)	0x10000000	Base of the slave address map

Port counts, per-slave window size and APB version per port are generator inputs, not parameters — see chapter 3.

Derived: - Slave address range: 64KB (0x10000) per slave, as the shipped variants are generated (the generator's own default window is 4KB) - Total address space: S × 64KB

APB5 Parity Across the Fabric

Parity is carried only between two APB5 ports. A **mixed pairing ignores parity entirely**, gated by the same `MST_APB5`/`SLV_APB5` masks as the rest of the APB5 sideband — there is no separate policy knob.

The parity pins are the AMBA APB (IHI 0024E) chapter 5 `*CHK` signals: `PADDRCHK`, `PCTRLCHK`, `PSELCHK`, `PENABLECHK`, `PWDATACHK`, `PSTRBCHK`, `PAUSERCHK`, `PWUSERCHK`, `PWAKEUPCHK`, `PRDATACHK`, `PREADYCHK`, `PSLVERRCHK`, `PRUSERCHK` and `PBUSERCHK`. Parity is odd, with one check bit per 8 bits of the covered signal (Table 5-1).

On an APB5→APB5 path the fabric **checks and regenerates**, and its architecture leaves no alternative. The boundary IP deconstructs each transfer into cmd/rsp, and the parity bits do not cross that interface: `apb5_slave` checks on the way in, `apb5_master` regenerates on the way out. The cmd/rsp fabric between them is therefore **outside the protected domain** — corruption *inside* that span is invisible, because the regenerated bit is correct by construction and masks it. That span is documented rather than hidden, and because of it each APB5 port brings its `parity_error_*` flag out individually: a check whose result goes nowhere is not protection.

The error flags are deliberately **not** folded into `PSLVERR`, which would make a fabric fault indistinguishable from the slave's own error response.

None of this is present in the SHIPPED variants. All of the above describes a variant generated with `enable_parity=True`. Every crossbar in `rtl/` is generated with parity OFF: `apbx_xbar_2to2_mixed` declares no parity ports at all on its module boundary, ties the boundary IP's parity inputs to `'0` and leaves its `parity_error_*` outputs unconnected. So there is nothing to connect and nothing to monitor unless you generate your own variant with the flag set — and a mixed APB4/APB5 pairing carries no parity in any case.

Formal coverage: `formal/apbx_xbar/apbx_xbar_2to2_mixed/` proves the mixed configuration as of 2026-08-29, replacing the proof lost with the thin core on 2026-08-27. Note it proves the SIDEBAND gate, not a parity gate — a mixed pairing carries no parity at all here, so there is no parity property left to state. The generated variants are instantiated with `ENABLE_PARITY=0`, and the APB4-port never-sees-parity question the thin core answered does not arise when the port has no parity pins. Parity itself is covered in simulation by `test_apbx_xbar_parity.py`, which generates an all-APB5 2x2 variant with `enable_parity=True`.

APB5 PWAKEUP Across the Fabric

PWAKEUP is a Requester output (IHI 0024E section 3.7.2, Table 3-7). It is an input on an APB5 master port. On an APB5 slave port, where the fabric is the Requester, it is an output driven by:

```
s<j>_apb_PWAKEUP = <apb5_master boundary IP's registered wake>
                 | m<i>_apb_PWAKEUP  (every APB5 master)
```

The boundary term is high while a command for that slave is pending or a transfer is in flight. It covers APB4 masters, which have no PWAKEUP, and it satisfies the 3.7.2 rule that PWAKEUP stays high until PREADY once it is high with PSEL. The master terms forward a requester's wake ahead of its PSEL. That forwarding is not routed by decode, because every master can reach every slave and the address is not known before PSEL. The OR is unregistered, and 3.7.2 names a glitch-free OR tree as a valid construction. The slave's side carries no wake back to any master. `formal/apbx_xbar/apbx_xbar_2to2_mixed/` proves the forwarding (`ap_pwakeup_forwarded`), the wake under every PSEL (`ap_pwakeup_covers_psel`) and the quiet reset state (`ap_pwakeup_not_fabricated`).

Pre-Generated Variants

Pre-Generated Crossbar Variants

Module	M×N	Use Case
`apbx_xbar_1to1`	1×1	Passthrough, protocol conversion
`apbx_xbar_2to1`	2×1	Multi-master arbitration
`apbx_xbar_1to4`	1×4	Simple SoC peripheral bus
`apbx_xbar_2to4`	2×4	Typical SoC with CPU+DMA
`apbx_xbar_2to2_mixed`	2×2	Mixed APB4/APB5 (m0=APB4, m1=APB5; s0=APB5, s1=APB4), per-port version gating

LOC per variant is in HAS ch05_performance/03_resources.md, which is the single source of truth for it. The column that used to sit here went stale within two days of being reconciled.

Custom Variants: Generated on-demand via Python script

Design Philosophy

Proven Components: - Built from production-tested `apb4_slave.sv` and `apb4_master.sv` - No new protocol logic - pure composition - Each component independently verified

Scalability: - Parametric generation for any MxN configuration - Resource usage scales linearly with M×N - No centralized bottlenecks

Predictability: - Round-robin arbitration provides deterministic behavior - Fixed address map simplifies software integration - Deterministic transfer cost: 9 pclk cycles SETUP-to-PREADY (10 back-to- back) with one master, 10 (11 back-to-back) when arbitrated

---

Next Steps

- See Address Decode and Arbitration for detailed operation examples
- See PRD.md for complete specification
- See CLAUDE.md for integration guidance
- See README.md for quick start guide

Version: 1.2 **Last Updated:** 2026-10-12 **Maintained By:** RTL Design Sherpa Project

RTL Design Sherpa · Learning Hardware Design Through Practice GitHub · Documentation Index · MIT License

---

Address Decode and Arbitration

Component: Lattice (MxN Interconnect) **Version:** 1.2 **Status:** Production Ready

Overview

Two mechanisms do the crossbar's work: 1. **Address Decode** - How incoming addresses map to specific slaves 2. **Arbitration** - How multiple masters share access to the same slave

---

Address Decode

Address Map Structure

The shipped variants use a 64KB (0x10000 bytes) region per slave, fixed for a given generated module and chosen at generation via `--slave-size`:

```
BASE_ADDR + 0x0000_0000 → 0x0000_FFFF : Slave 0 (64KB)
BASE_ADDR + 0x0001_0000 → 0x0001_FFFF : Slave 1 (64KB)
BASE_ADDR + 0x0002_0000 → 0x0002_FFFF : Slave 2 (64KB)
BASE_ADDR + 0x0003_0000 → 0x0003_FFFF : Slave 3 (64KB)
...
BASE_ADDR + 0x000F_0000 → 0x000F_FFFF : Slave 15 (64KB)
```

Default BASE_ADDR: 0x10000000

Total Address Space: (number of slaves) × 64KB

Decode Algorithm

The crossbar extracts the slave index from the upper bits of the address offset:

```
offset = PADDR - BASE_ADDR
slave_index = offset[16 +: $clog2(S)]   // ceil(log2(S)) bits above
the 64KB window
```

Out-of-Range Addresses

This applies to the variants that DECODE — `1to4`, `2to4`, `2to2_mixed`. In `1to1` and `2to1` there is a single slave, no address decode, and `BASE_ADDR` is unused: every access is forwarded to that slave whatever its address, and the slave's own response is returned.

For the decoding variants, an access outside `[BASE_ADDR, BASE_ADDR + S x 64KB)` is a **decode miss**. The crossbar accepts it and answers locally with **PSLVERR**; no slave sees the transfer, and the arbiters are not involved. The master's transaction completes normally (PREADY asserts) with the error flagged, so a bad pointer surfaces as an APB error response rather than a hang.


Earlier RTL left `cmd_ready` low on a miss, which wedged the master in ACCESS with PREADY low and no error signature (projects/components/fabric-gen-ip/lattice-apbx-xbar TASK-002, was APBX-002). Regression: the decode-miss scenarios in `test_apbx_xbar_1to4.py`, `test_apbx_xbar_2to4.py`, and `test_apbx_xbar_2to2_mixed.py`.

Why bit 16 upward? - 64KB = 0x10000 = 2^16 bytes - Lower 16 bits (offset[15:0]) are byte address within slave - `ceil(log2(S))` bits starting at bit 16 select the slave: [17:16] for a 4-slave variant, [16] for 2 slaves. The shipped variants wire exactly those bits — `m0_slave_sel` is 2 bits wide on 1to4/2to4, 1 bit on 2to2_mixed, NOT a 4-bit index - The generator supports up to 16 slaves; bits above the index field do not select a slave, they fail the range check and become a decode miss

Address Decode Flow Diagram

The diagram walks one concrete address — 0x10023456 — through the decode to Slave 2:

Figure 2.1: Address Decode Flow



Address Decode Flow

Decode Example Walkthrough

Scenario: Master accesses address 0x10023456 with BASE_ADDR = 0x10000000

Step 1: Calculate Offset

```
offset = PADDR - BASE_ADDR
       = 0x10023456 - 0x10000000
       = 0x00023456
```

Step 2: Extract Slave Index

```
slave_index = offset[17:16]        // S=4 -> 2 bits
            = 0x00023456 >> 16
            = 0x2
```

Step 3: Parallel Decode

The crossbar checks all slave ranges in parallel: - Slave 0: 0x00000 - 0x0FFFF → NO MATCH - Slave 1: 0x10000 - 0x1FFFF → NO MATCH - **Slave 2: 0x20000 - 0x2FFFF → MATCH** - Slave 3: 0x30000 - 0x3FFFF → NO MATCH

Step 4: Route to Arbiter

Transaction request forwarded to Arbiter[2] (Slave 2's arbiter)

Step 5: Forward to Slave

After arbitration grant, transaction forwarded via apb4_master[2] to physical Slave 2

Final Address Sent to Slave: 0x10023456 (full address preserved)

Multiple Address Maps

Different BASE_ADDR values create distinct address maps:

Example: Two Crossbars

```
// Peripheral Bus: 0x1000_0000 - 0x1003_FFFF
apbx_xbar_1to4 #(
    .BASE_ADDR(32'h1000_0000)
) u_periph_xbar (...);
// Slaves at: 0x1000_0000, 0x1001_0000, 0x1002_0000, 0x1003_0000

// Memory-Mapped I/O: 0x8000_0000 - 0x8003_FFFF
apbx_xbar_1to4 #(
    .BASE_ADDR(32'h8000_0000)
) u_mmio_xbar (...);
// Slaves at: 0x8000_0000, 0x8001_0000, 0x8002_0000, 0x8003_0000
```

Arbitration

Per-Slave Round-Robin


Each slave has an **independent arbiter** that implements round-robin scheduling:

Key Properties: - **Fair:** No master can starve another - **Independent:** Each slave arbitrates separately - **Predictable:** Priority rotates after each grant - **Persistent:** Grant held from command through response

Round-Robin Timing Diagram

Two masters (M0, M1) competing for access to Slave 0:

Waveform 2.1: Round-Robin Arbitration Timing



Round-Robin Arbitration Timing

Arbitration Example Walkthrough

Scenario: Master 0 and Master 1 both want to access Slave 0

Initial State: - Priority: M0 (M0 has priority initially) - Slave 0: IDLE

This walkthrough shows the ORDER of arbitration events, not their timing. It is deliberately not cycle-numbered: a numbered version here showed a three-cycle transaction, which contradicted this chapter's own measured 9-cycle SETUP-to-PREADY figure. `S0_PSEL` cannot assert in the grant cycle — after the REGISTERED grant the command still crosses the `apb4_master` cmd skid, the FSM's IDLE launch and its SETUP state before the downstream PSEL appears. For real numbers see "Transaction Latency" below and `dv/tests/test_apbx_xbar_timing.py`.

Note also that M0_PENABLE is driven by the external master during its own ACCESS phase; the arbiter does not assert it, and it is high before any grant exists.

Transaction 1: M0 requests Slave 0

```
  M0 asserts PSEL with PADDR=0x1000_0000
  Arbiter[0] grants M0 (only requester)
  ... command traverses the fabric ...
  Slave 0 responds; transaction completes
  Priority rotates: M1 now has priority
```

Transaction 2: M0 and M1 both request Slave 0

```
  M0 asserts PSEL with PADDR=0x1000_0010
  M1 asserts PSEL with PADDR=0x1000_0000   -- CONFLICT
  Arbiter[0] grants M1 (has priority); M0 waits
  ... command traverses the fabric ...
  Slave 0 responds; M1's transaction completes
  Priority rotates: M0 now has priority
```

Transaction 3: M0 again, after rotation

```
  M0 is still asserting (it was blocked)
  Arbiter[0] grants M0 (now has priority)
  ... command traverses the fabric ...
  Slave 0 responds; transaction completes
  Priority rotates: M1 now has priority
```

Result: Fair access — each master is served in turn when both request. The grant is held from command acceptance to the response handshake (WAIT_GNT_ACK(1)), so a blocked master waits one full transaction, not one cycle.

Multi-Slave Parallelism

Key Feature: Different slaves can be accessed simultaneously by different masters

Example: Parallel Transactions

```
Time T0:
- Master 0 accesses Slave 0 (UART) - GRANTED
- Master 1 accesses Slave 2 (Timer) - GRANTED
Both transactions proceed in parallel (no conflict)

Time T1:
- Master 0 accesses Slave 0 (UART) - GRANTED
- Master 1 accesses Slave 0 (UART) - BLOCKED (arbitration)
Master 1 waits for Master 0 to complete

Time T2:
- Master 0 completes, releases Slave 0
```

```
- Master 1 accesses Slave 0 (UART) - GRANTED
Priority rotated for Slave 0's arbiter
```

Benefit: Maximum throughput when masters access different slaves

Grant Persistence

Critical Property: Once granted, a master holds the slave until response completes

Why This Matters:

```
WITHOUT Grant Persistence:
- Master 0 granted Slave 0
- Master 0 asserts PENABLE
- *Grant could change here* ← BREAKS PROTOCOL!
- Slave 0 responds to wrong master

WITH Grant Persistence:
- Master 0 granted Slave 0
- Master 0 asserts PENABLE
- Grant held until PREADY asserted ← SAFE
- Slave 0 responds to correct master
- Grant released for next transaction
```

Implementation: Grant signal registered and held from PSEL assertion through PREADY response

Arbitration Latency

Best Case (No Contention): - 1 cycle: the grant is REGISTERED (`grant <= w_next_grant;` in `arbiter_round_robin`), so request → grant is never same-cycle - Fabric overhead is the dominant term, not APB's 2-cycle minimum: a full transfer measures **10** cycles SETUP-to-PREADY on an arbitrated variant (see "Transaction Latency" below). Everything in this chapter is an M > 1 figure — there is no arbiter at all when M = 1, and those variants are a cycle faster.

Worst Case (Maximum Contention): - Wait for the masters ahead in the round-robin to complete FULL transactions — the grant is held until the response handshake (`WAIT_GNT_ACK(1)`), so each is a full transaction, not 1 cycle. The right figure for a QUEUED transaction is the back-to-back period of **11** cycles, not the 10-cycle single-transfer latency — a waiting master inherits the same mandatory SETUP cycle that separates any two consecutive transfers - Example: 2 masters, worst case ~= one full transaction (11 cycles) of wait - Example: 4 masters, worst case = 3 full transactions ~= 33 cycles

Average Case (Random Access Pattern): - (M-1)/2 full transactions of average wait (~11 cycles each) - Statistical fairness over time

---

Integration Examples

Example 1: CPU to 4 Peripherals (No Contention)

```
apbx_xbar_1to4 #(
    .BASE_ADDR(32'h1000_0000)
) u_periph_xbar (
    // Single master (CPU)
    // .m0_apb_PSEL(cpu_apb_PSEL), .m0_apb_PENABLE(...), ...  (elided)

    // 4 slaves (UART, GPIO, Timer, SPI)
    .s0_apb_* (uart_*),   // 0x1000_0000
    .s1_apb_* (gpio_*),   // 0x1001_0000
    .s2_apb_* (timer_*),  // 0x1002_0000
    .s3_apb_* (spi_*)     // 0x1003_0000
);
```

Behavior: - No arbitration needed (single master) - Pure address decode functionality - Zero arbitration overhead

Example 2: CPU + DMA to 4 Peripherals (Potential Contention)

```
apbx_xbar_2to4 #(
    .BASE_ADDR(32'h4000_0000)
) u_soc_xbar (
    // Two masters
    // .m0_apb_PSEL(cpu_apb_PSEL), .m0_apb_PENABLE(...), ...  (elided)
    // .m1_apb_PSEL(dma_apb_PSEL), ...                        (elided)

    // 4 slaves
    .s0_apb_* (mem_ctrl_*),  // 0x4000_0000
    .s1_apb_* (uart_*),      // 0x4001_0000
    .s2_apb_* (i2c_*),       // 0x4002_0000
    .s3_apb_* (adc_*)        // 0x4003_0000
);
```

Behavior: - Each slave has independent arbiter - CPU and DMA can access different slaves simultaneously - If both access same slave, round-robin arbitration - Fair access guaranteed

---

Performance Characteristics

Throughput

Single Master: - Back-to-back transactions supported, but NOT overlapped: `apb4_slave` is a one-command-at-a-time FSM, so the next command is captured only after the previous transaction completes - Measured sustained cadence: 1 transfer per **11** pclk cycles (PREADY-to-PREADY) at an always-ready slave, on an arbitrated variant. That is one MORE than its 10-cycle SETUP-to-PREADY single-transfer latency: nothing overlaps, and the next transfer's mandatory SETUP cycle cannot share a cycle with the previous transfer's ACCESS. (An earlier "zero bubble" claim described a pipeline this RTL does not have; a later "cadence equals latency" claim dropped the SETUP cycle.)

Multiple Masters (Same Slave): - Round-robin introduces fair sharing - Each master gets ~1/M of bandwidth - Example: 2 masters = 50% bandwidth each

Multiple Masters (Different Slaves): - Full parallelism - Each master gets 100% of its target slave - Total system bandwidth = (number of slaves) × slave_bandwidth

Latency

Components:

1. **Address Decode:** 0 cycles (combinational, parallel)
2. **Arbitration Decision:** 1 cycle (grant is registered)
3. **Master APB phases:** 2 cycles (PSEL, then PENABLE)
4. **Boundary IP + skid buffers:** ~6 cycles — `apb4_slave` capture, registered cmd skid, `apb4_master` IDLE→SETUP→ACCESS, registered rsp skid, `apb4_slave` BUSY→PREADY
5. **Slave Response:** Variable (adds to the above)

Total Minimum Latency: 10 cycles SETUP-to-PREADY (9 of them ACCESS->PREADY) on an arbitrated variant, uncontended with a zero-wait slave — measured on `apbx_xbar_2to1`, and the same on `2to4` and `2to2_mixed`. A single-master variant has no arbiter and measures 9 (8 fabric). APB's 2-cycle minimum applies to a directly-attached slave; it does not apply through this fabric, which converts APB→cmd/rsp→APB across registered buffers in both directions.

Sustained cadence is 11 cycles, PREADY-to-PREADY, not 10 — see "Single Master" above and HAS 5.2 for why the two differ and for the M = 1 column.

With Contention: add one full transaction (~11 cycles) per master ahead in the round-robin

---

Design Notes

Why 64KB Per Slave?

Rationale: - Sufficient for most APB peripherals (typically 256B - 4KB register space) - Simple decode logic (single shift operation) - Allows up to 16 slaves with clean byte alignment - Software-friendly (each peripheral has “round” base address)

Alternatives: - Smaller regions (4KB, 16KB) → more slaves, more complex decode - Larger regions (256KB, 1MB) → fewer slaves, wasted address space

Why Round-Robin?

Advantages: - Fair: Prevents starvation - Simple: Minimal logic (counter + comparator) - Predictable: Software can reason about worst-case latency - No configuration: Works out-of-box

Alternatives: - Fixed priority → Can starve low-priority masters - Weighted fair queuing → More complex, requires configuration - Lottery scheduling → Unpredictable, harder to verify

---

Troubleshooting

Issue: Wrong Slave Selected

Check: 1. BASE_ADDR parameter correct? 2. Address within expected range? 3. Calculated slave_index matches expectation?

Debug:

```
offset = PADDR - BASE_ADDR
slave_index = offset >> 16
expected_slave = slave_index  // Should match actual PSEL
```

Issue: Master Starved

Check: 1. Other masters continuously accessing same slave? 2. Round-robin priority rotating correctly? (grant is released at the RESPONSE handshake — `grant_ack = grant && rsp_valid && rsp_ready` with `WAIT_GNT_ACK(1)` — so a master that never completes a transaction holds its grant) 3. Is the starved master's address actually decoding in range? An out-of-range access completes locally with PSLVERR and never reaches an arbiter.

There is no timeout or monitoring knob to enable: `arbiter_round_robin` has no timeout logic, parameter, or port. An earlier revision of this checklist referenced one.

Expected Behavior: - Each master should get grant within M transactions - No master should wait indefinitely

Issue: Back-to-Back Transactions Stalling

Check: 1. Grant persistence working? 2. Slave asserting PREADY correctly? 3. No unintended pipeline bubbles?

Expected Behavior: - Consecutive transactions from same master should flow without gaps - Only arbitration conflicts should introduce wait states

---

Next Steps

- See Architecture for top-level design overview
- See PRD.md for complete specification
- See CLAUDE.md for integration guidance
- See README.md for quick start guide

Version: 1.2 **Last Updated:** 2026-10-12 **Maintained By:** RTL Design Sherpa Project

RTL Design Sherpa · Learning Hardware Design Through Practice GitHub · Documentation Index · MIT License

---

Lattice RTL Generator

Component: Lattice (MxN Interconnect) **Version:** 1.2 **Status:** Production Ready

Overview

Five pre-generated variants (1to1, 2to1, 1to4, 2to4, 2to2_mixed) cover the common configurations. For anything else, the Python-based generator produces any arbitrary MxN crossbar up to 16x16.

Philosophy: - Pre-generated variants for common use cases (fast integration) - Python generator for custom configurations (flexibility) - Template-based code generation (consistency) - Built from proven components (quality)

Generator Architecture

Two-Level Structure

```
projects/components/fabric-gen-ip/lattice-apbx-xbar/
├── bin/
│   └── generate_xbars.py              ← Convenience wrapper script
│
└── projects/components/fabric-gen-ip/lattice-apbx-xbar/bin/
    └── apbx_xbar_generator.py          ← Core generator engine
```

Why Two Files? 1. **Core Generator** (`apbx_xbar_generator.py`): Reusable library function - Can be imported by other scripts - Contains `generate_apbx_xbar()` function - Located in the component's own `bin/` directory: `projects/components/fabric-gen-ip/lattice-apbx-xbar/bin/apbx_xbar_generator.py`. It is NOT under `bin/rtl_generators/` — that path was claimed here until 2026-08-29 and contradicted this chapter's own tree, its troubleshooting section, the README and the PRD. `bin/rtl_generators/amba/` contains only an `__init__.py`.

2. **Convenience Wrapper** (`generate_xbars.py`): Project-specific script
   - Easy command-line interface
   - Pre-configured for standard variants
   - Located in project `bin/` directory

Quick Start

Generate Standard Variants (1:1, 2:1, 1:4, 2:4)

```
cd projects/components/fabric-gen-ip/lattice-apbx-xbar/bin/
python generate_xbars.py
```

Output:

```
Generating 1-to-1 crossbar...
  apbx_xbar_1to1.sv
Generating 2-to-1 crossbar...
  apbx_xbar_2to1.sv
Generating 1-to-4 crossbar...
  apbx_xbar_1to4.sv
Generating 2-to-4 crossbar...
  apbx_xbar_2to4.sv
Generating 2-to-2_mixed crossbar...
  apbx_xbar_2to2_mixed.sv

Generated 5 crossbar variants
```

Generate Custom Variant

```
cd projects/components/fabric-gen-ip/lattice-apbx-xbar/bin/
python generate_xbars.py --masters 3 --slaves 6
```

Output:

```
Generating 3-to-6 crossbar...
Generated apbx_xbar_3to6.sv
```

Generate with Custom Base Address

```
cd projects/components/fabric-gen-ip/lattice-apbx-xbar/bin/
python generate_xbars.py --masters 4 --slaves 8 --base-addr 0x80000000
```

Output:

```
Generating 4-to-8 crossbar...
Generated apbx_xbar_4to8.sv

Address Map:
  Slave 0: [0x80000000, 0x8000FFFF]
  Slave 1: [0x80010000, 0x8001FFFF]
  Slave 2: [0x80020000, 0x8002FFFF]
  ...
  Slave 7: [0x80070000, 0x8007FFFF]
```

Command-Line Interface

Full Options

```
python generate_xbars.py [OPTIONS]
```

Options:

Command Line Options

Option	Short	Type	Default	Description
`--masters`	`-m`	int	None	Number of master interfaces (1-16)
`--slaves`	`-s`	int	None	Number of slave interfaces (1-16)
`--base-addr`	`-b`	hex	0x10000000	Base address for slave address map
`--slave-size`	-	hex	0x10000	Address space per slave: 0x1000=4KB, 0x10000=64KB (matches shipped variants)
`--help`	`-h`	-	-	Show help message

The CLI covers the common cases. Per-port APB version and parity are reachable only through the Python API (`generate_apbx_xbar`), since they take per-port lists rather than scalars:

Python API Arguments

Argument	Type	Default	Description
`slave_size`	int	0x1000	Address window per slave. `generate_xbars.py` passes 0x10000 for the shipped variants
`master_versions`	list	None	Per-master APB version (4/5); None ⇒ all APB4
`slave_versions`	list	None	Per-slave APB version (4/5); None ⇒ all APB4
`name_suffix`	str	`""`	Appended to the generated module name

Argument	Type	Default	Description
`enable_parity`	bool	False	Carry APB5 parity (IHI 0024E ch. 5 `*CHK` signals, odd) on APB5 ports

`enable_parity` checks and regenerates; it does not pass through. A generated variant **checks** parity at the ingress boundary and **regenerates** it on the far side, because the parity bits do not cross the cmd/rsp interface the boundary IP deconstructs each transfer into. The cmd/rsp fabric between the two is outside the protected domain, so with `enable_parity=True` each **APB5** port exposes its own `parity_error_*` outputs (`m0_parity_error_wdata`, `s0_parity_error_rdata`, …) — a check whose result goes nowhere is not protection. APB4 ports get none, and the shipped `apbx_xbar_2to2_mixed` is generated with parity off, so there the boundary IP's flags are tied off internally. A mixed APB4/APB5 pairing carries no parity at all.

(The retired `apbx_xbar_thin` passed parity through end to end instead, which is why this distinction used to be drawn against it. It was deleted on 2026-08-27; there is no other family to contrast with now.)

Rules: - If neither `--masters` nor `--slaves` specified → Generate all standard variants - If only one specified → Error (must specify both) - If both specified → Generate custom variant

Examples

Example 1: Generate All Standard Variants

```
python generate_xbars.py
```

Example 2: Generate 3x6 Crossbar

```
python generate_xbars.py --masters 3 --slaves 6
```

Example 3: Generate 5x10 Crossbar with Custom Base

```
python generate_xbars.py -m 5 -s 10 -b 0xA0000000
```

Example 4: Show Help

```
python generate_xbars.py --help
```

Generated Code Structure

Template Components

The generator creates a complete SystemVerilog module with:

1. **Header with Address Map**

```
// 2-to-4 APB crossbar with address decoding and arbitration
// 2 masters to 4 slaves using apb4_slave and apb4_master modules
//
// (This walkthrough shows the SHIPPED apbx_xbar_2to4 so every
constant
//  below is real (2to4). For a 3-to-6 the shapes scale: 3-bit
slave_sel,
//  a 0x00060000 range bound, and CLIENTS(3) arbiters.)
//
// Address Map (same for all masters):
//   Slave 0: [0x10000000, 0x1000FFFF]
//   Slave 1: [0x10010000, 0x1001FFFF]
//   Slave 2: [0x10020000, 0x1002FFFF]
//   Slave 3: [0x10030000, 0x1003FFFF]
```

2. **Module Declaration with Parameters**

```
module apbx_xbar_2to4 #(
    parameter int ADDR_WIDTH = 32,
    parameter int DATA_WIDTH = 32,
    parameter int STRB_WIDTH = DATA_WIDTH / 8,
    parameter logic [ADDR_WIDTH-1:0] BASE_ADDR = 32'h10000000
) (
    // Clock and Reset
    input  logic                  pclk,
    input  logic                  presetn,

    // Master 0-1 APB interfaces
    // Slave 0-3 APB interfaces
);
```

3. **Internal Signal Declarations**

```
    // Command/Response interfaces for master 0-1 apb4_slave
    logic m0_cmd_valid, m0_cmd_ready, m0_cmd_pwrite;
    logic [ADDR_WIDTH-1:0] m0_cmd_paddr;
    // ... (full cmd/rsp bus for each master)

    // Command/Response interfaces for slave 0-3 apb4_master
    logic s0_cmd_valid, s0_cmd_ready, s0_cmd_pwrite;
    logic [ADDR_WIDTH-1:0] s0_cmd_paddr;
    // ... (full cmd/rsp bus for each slave)
```

4. **Master-Side apb4_slave Instantiations**

```
    // Master 0 apb4_slave
    apb4_slave #(
        .ADDR_WIDTH(ADDR_WIDTH),
        .DATA_WIDTH(DATA_WIDTH)
    ) u_apb4_slave_m0 (
        .pclk(pclk),
        .presetn(presetn),
        // APB interface
        .s_apb_PSEL(m0_apb_PSEL),
        .s_apb_PENABLE(m0_apb_PENABLE),
        // ... (full APB connections)
        // cmd/rsp interface
        .cmd_valid(m0_cmd_valid),
        .cmd_ready(m0_cmd_ready),
        // ... (full cmd/rsp connections)
    );

    // Master 1 apb4_slave instance...
```

5. **Address Decode Logic**

```
    // Per-master offset decode (verbatim shape of the real output --
    // there is no request-matrix signal; per-slave cmd_valid terms
are
    // built directly from the decoded index)
    logic [ADDR_WIDTH-1:0] m0_cmd_offset;
    logic [1:0] m0_slave_sel;
    logic m0_addr_in_range;

    always_comb begin
        m0_cmd_offset    = m0_cmd_paddr - BASE_ADDR;
        m0_addr_in_range = (m0_cmd_paddr >= BASE_ADDR) &&
                           (m0_cmd_paddr < (BASE_ADDR +
32'h00040000));
        m0_slave_sel     = m0_cmd_offset[17:16];   // ceil(log2(S))
bits
    end

    assign s0_cmd_valid = m0_cmd_valid && m0_addr_in_range &&
(m0_slave_sel == 2'd0);
    assign s1_cmd_valid = m0_cmd_valid && m0_addr_in_range &&
(m0_slave_sel == 2'd1);
    // ... one per slave. For M>1 these terms are NOT repeated per
    // master onto the same signal -- the per-slave arbiter grant
    // selects which master drives it:
    //   case (1'b1)
    //     s0_arb_grant[0]: s0_cmd_valid = m0_cmd_valid &&
```

```
m0_addr_in_range && (m0_slave_sel == 2'd0);
    //     s0_arb_grant[1]: s0_cmd_valid = m1_cmd_valid &&
m1_addr_in_range && (m1_slave_sel == 2'd0);
    //   endcase
```

6. **Per-Slave Arbitration Logic**

```
    // One arbiter instance per slave (no hand-rolled priority
    // counters in the output -- the generator instantiates the
    // library arbiter):
    arbiter_round_robin #(
        .CLIENTS(2),          // = M (3 for a 3-to-6)
        .WAIT_GNT_ACK(1)      // hold grant until the response
handshake
    ) u_s0_arbiter (
        .clk(pclk), .rst_n(presetn), .block_arb(1'b0),
        .request(s0_arb_request), .grant_ack(s0_arb_grant_ack),
        .grant(s0_arb_grant),
        .grant_valid(), .grant_id(), .last_grant()
    );
```

7. **Response Routing Logic**

```
    // Route responses back to requesting masters
    always_comb begin
        // Track which master initiated each transaction
        // Route PRDATA/PSLVERR back to correct master
    end
```

8. **Slave-Side apb4_master Instantiations**

```
    // Slave 0 apb4_master
    apb4_master #(
        .ADDR_WIDTH(ADDR_WIDTH),
        .DATA_WIDTH(DATA_WIDTH)
    ) u_s0_master (
        .pclk(pclk),
        .presetn(presetn),
        // cmd/rsp interface
        .cmd_valid(s0_cmd_valid),
        .cmd_ready(s0_cmd_ready),
        // ... (full cmd/rsp connections)
        // APB interface -- apb4_master's ports are m_apb_*, so the
        // slave-side port sN_apb_* connects to m_apb_* on the
instance
        .m_apb_PSEL     (s0_apb_PSEL),
        .m_apb_PENABLE  (s0_apb_PENABLE),
        // ... (full APB connections)
    );

    // Slave 1-3 apb4_master instances...
```

9. Module End

```
endmodule : apbx_xbar_2to4
```

Generator Algorithm

Step-by-Step Process

1. Validate Parameters

```
if M < 1 or M > 16:
    raise ValueError(f"Number of masters must be 1-16, got {M}")
if N < 1 or N > 16:
    raise ValueError(f"Number of slaves must be 1-16, got {N}")
```

2. Calculate Derived Parameters

```
slave_addr_bits = max(1, math.ceil(math.log2(N)))  # Bits for slave
index
strb_width = data_width // 8                        # Byte strobe
width
module_name = f"apbx_xbar_{M}to{N}"                 # Module name
```

3. Generate Address Map Documentation

```
for s in range(N):
    addr_offset = s * 0x10000  # 64KB per slave
    addr_start = base_addr + addr_offset
    addr_end = addr_start + 0xFFFF
    # Generate comment: Slave S: [START, END]
```

4. Generate Module Declaration - Parameters: ADDR_WIDTH, DATA_WIDTH, STRB_WIDTH, BASE_ADDR - Ports: Clock, reset - Master interfaces: M × full APB interface - Slave interfaces: N × full APB interface

5. Generate Internal Signals - Master cmd/rsp buses: M sets - Slave cmd/rsp buses: N sets - Request matrix: [M][N] - Grant matrix: [N][M]

(No priority counters are emitted. Rotation state lives inside the `arbiter_round_robin` instances the generator wires up, which is what the code sample further down says.)

6. Instantiate Master-Side Components

```
for m in range(M):
    # Generate apb4_slave instance
    # Connect APB interface to external master m
    # Connect cmd/rsp to internal buses
```

7. Generate Address Decode Logic

```
for m in range(M):
    # For each master, decode address to slave index
    # offset = paddr - BASE_ADDR
    # slave_idx = offset[16 +: ceil(log2(S))]  # S-sized index above
```

```
64KB
    # Set m_to_s_req[m][slave_idx] = 1
```

8. Generate Arbitration Logic

```
for s in range(N):
    # For each slave, arbitrate among M masters
    # Round-robin: priority rotates after each grant
    # Grant persistence: hold until transaction completes
```

9. Generate Response Routing

```
# Track transaction source (which master)
# Route responses back to originating master
```

10. Instantiate Slave-Side Components

```
for s in range(N):
    # Generate apb4_master instance
    # Connect cmd/rsp from internal buses
    # Connect APB interface to external slave s
```

11. Write Generated Code

```
with open(output_file, 'w') as f:
    f.write(generated_code)
```

Code Generation Patterns

Loop-Based Generation

Master Interfaces:

```
for m in range(M):
    code += f"    // Master {m} APB interface\n"
    code += f"    input  logic m{m}_apb_PSEL,\n"
    code += f"    input  logic m{m}_apb_PENABLE,\n"
    # ... (all APB signals for master m)
```

Slave Interfaces:

```
for s in range(N):
    code += f"    // Slave {s} APB interface\n"
    code += f"    output logic s{s}_apb_PSEL,\n"
    code += f"    output logic s{s}_apb_PENABLE,\n"
    # ... (all APB signals for slave s)
```

String Formatting

Hex Values:

```
code += f"    parameter logic [ADDR_WIDTH-1:0] BASE_ADDR =
{addr_width}'h{base_addr:08X}\n"
# Example: 32'h10000000
```

Address Map Comments:

```
addr_start = base_addr + (s * 0x10000)
code += f"//   Slave {s}: [0x{addr_start:08X}, 0x{addr_start +
0xFFFF:08X}]\n"
# Example: Slave 2: [0x10020000, 0x1002FFFF]
```

Customization Examples

Example 1: Large SoC with 10 Peripherals

Scenario: CPU + DMA need to access 10 peripherals

Command:

```
python generate_xbars.py --masters 2 --slaves 10
```

Generated File: `apbx_xbar_2to10.sv`

Address Map:

```
Slave 0:  0x10000000 - 0x1000FFFF (UART0)
Slave 1:  0x10010000 - 0x1001FFFF (UART1)
Slave 2:  0x10020000 - 0x1002FFFF (GPIO)
Slave 3:  0x10030000 - 0x1003FFFF (I2C)
Slave 4:  0x10040000 - 0x1004FFFF (SPI)
Slave 5:  0x10050000 - 0x1005FFFF (Timer0)
Slave 6:  0x10060000 - 0x1006FFFF (Timer1)
Slave 7:  0x10070000 - 0x1007FFFF (PWM)
Slave 8:  0x10080000 - 0x1008FFFF (ADC)
Slave 9:  0x10090000 - 0x1009FFFF (Watchdog)
```

LOC: ~2500 lines (extrapolated, not generated and counted — the measured anchors are in HAS ch05_performance/03_resources.md)

Example 2: Multi-CPU System

Scenario: 4 CPUs accessing shared peripheral bus with 4 slaves

Command:

```
python generate_xbars.py --masters 4 --slaves 4
```

Generated File: `apbx_xbar_4to4.sv`

Benefits: - Fair arbitration among 4 CPUs - Each slave independently arbitrated - Maximum throughput when CPUs access different slaves

LOC: ~1600 lines (extrapolated, see above)

Example 3: Memory-Mapped I/O Region

Scenario: Single master accessing I/O region at 0xA0000000

Command:

```
python generate_xbars.py --masters 1 --slaves 8 --base-addr 0xA0000000
```

Generated File: `apbx_xbar_1to8.sv`

Address Map:

```
Slave 0:  0xA0000000 - 0xA000FFFF
Slave 1:  0xA0010000 - 0xA001FFFF
...
Slave 7:  0xA0070000 - 0xA007FFFF
```

Using Generated Modules

Integration Example

```
// Generated file: apbx_xbar_3to6.sv

module my_soc (
    input  logic clk,
    input  logic rst_n,
    // ... other interfaces
);

    // Instantiate 3x6 crossbar
    apbx_xbar_3to6 #(
        .ADDR_WIDTH(32),
        .DATA_WIDTH(32),
        .BASE_ADDR(32'h10000000)  // Can override at instantiation
    ) u_periph_xbar (
        .pclk(clk),
        .presetn(rst_n),

        // Connect 3 masters (CPU, DMA, Debug)
        .m0_apb_PSEL(cpu_apb_psel),
        .m0_apb_PENABLE(cpu_apb_penable),
        // ... (full CPU APB interface)

        .m1_apb_PSEL(dma_apb_psel),
        .m1_apb_PENABLE(dma_apb_penable),
        // ... (full DMA APB interface)

        .m2_apb_PSEL(debug_apb_psel),
        .m2_apb_PENABLE(debug_apb_penable),
        // ... (full Debug APB interface)

        // Connect 6 slaves (UART, GPIO, Timer, SPI, I2C, ADC)
        .s0_apb_PSEL(uart_psel),
        .s0_apb_PENABLE(uart_penable),
        // ... (full UART APB interface)

        .s1_apb_PSEL(gpio_psel),
        // ... (remaining slaves)
    );

endmodule : my_soc
```

Parameter Override

```
// Use different base address at instantiation
apbx_xbar_3to6 #(
    .BASE_ADDR(32'h80000000)  // Override default 0x10000000
) u_mmio_xbar (
    // ... connections
);
// Slaves now at: 0x80000000, 0x80010000, 0x80020000, ...
```

Generator Limitations and Future Work

Current Limitations

1. **Fixed 64KB Per Slave**
   - Cannot customize individual slave region sizes
   - Workaround: Use multiple crossbars with different BASE_ADDR
2. **Max 16x16 Configuration**
   - Practical limit due to arbitration complexity
   - Workaround: Hierarchical crossbars
3. **Single Address Map**
   - All masters see same slave address map
   - Workaround: Address translation before crossbar
4. **No Priority Levels**
   - Round-robin only, no fixed priority or weighted arbitration
   - Workaround: External priority arbitration before crossbar

Future Enhancements

1. Variable Slave Sizes

```
# Potential future API
generate_apbx_xbar(
    num_masters=2,
    slave_sizes=[4096, 65536, 1024, 16384],  # Custom sizes per slave
    base_addr=0x10000000
)
```

2. Arbitration Policies

```
# Potential future API
generate_apbx_xbar(
    num_masters=4,
    num_slaves=4,
    arbitration="weighted",  # "round-robin", "fixed-priority",
"weighted"
    weights=[4, 2, 1, 1]     # Master 0 gets 4x priority
)
```

3. Address Translation

```
# Potential future API
generate_apbx_xbar(
    num_masters=2,
    num_slaves=4,
```

```
    master_views=[
        {"base": 0x00000000, "remap": True},   # Master 0 sees 0x0
        {"base": 0x10000000, "remap": False}   # Master 1 sees
0x1000_0000
    ]
)
```

Testing Generated Code

Verification Flow

1. Generate Crossbar

```
python generate_xbars.py --masters 2 --slaves 4
```

2. Lint Generated RTL

```
cd ../../rtl/
verilator --lint-only apbx_xbar_2to4.sv
```

3. Run Functional Tests

```
cd ../../dv/tests/
make run-apbx_xbar_2to4-gate
```

4. View Waveforms (If Test Fails)

```
make run-apbx_xbar_2to4-gate-waves
# create_view_cmd() writes the gtkwave command beside the log
```

Recommended Test Cases

1. **Single Master Access** - Verify basic routing
2. **Multi-Master Contention** - Verify arbitration
3. **Back-to-Back Transactions** - Verify consecutive transfers complete at the expected 10/11-cycle cadence
4. **Address Decode Boundary** - Verify slave selection at boundaries
5. **Error Response Propagation** - Verify PSLVERR routing
6. **APB5 Sideband Gating** - Verify `apbx_xbar_2to2_mixed` sideband behavior
7. **Timing Compliance** - Verify published latency/cadence with `test_apbx_xbar_timing`

Advanced Usage

Using as Python Library

```python
# Import generator function
# generator lives in the component's bin/, so put it on the path first
import sys; sys.path.insert(0,
'projects/components/fabric-gen-ip/lattice-apbx-xbar/bin')
from apbx_xbar_generator import generate_apbx_xbar

# Generate crossbar programmatically
code = generate_apbx_xbar(
    num_masters=3,
    num_slaves=8,
    base_addr=0xA0000000,
    addr_width=32,
    data_width=32,
    output_file="my_custom_xbar.sv"
)

# Generated code is returned as string
print(f"Generated {len(code)} bytes of SystemVerilog code")

# Can also write to file manually
with open("custom_output.sv", "w") as f:
    f.write(code)
```

Batch Generation

```python
# Generate multiple variants in one script
variants = [
    (1, 4, 0x10000000),
    (2, 4, 0x20000000),
    (3, 6, 0x30000000),
    (4, 8, 0x40000000),
]

for masters, slaves, base_addr in variants:
    code = generate_apbx_xbar(
        num_masters=masters,
        num_slaves=slaves,
        base_addr=base_addr,
        output_file=f"xbar_{masters}to{slaves}_0x{base_addr:08X}.sv"
    )
    print(f"Generated xbar_{masters}to{slaves}_0x{base_addr:08X}.sv")
```

Troubleshooting

Issue: "ModuleNotFoundError: No module named 'amba.apbx_xbar_generator'"

Cause: Python can't find the core generator module

Solution:

```
# Verify generator exists
ls -la
projects/components/fabric-gen-ip/lattice-apbx-xbar/bin/apbx_xbar_gene
rator.py

# Run from bin directory
cd projects/components/fabric-gen-ip/lattice-apbx-xbar/bin/
python generate_xbars.py
```

Issue: Generated Code Won't Lint

Cause: Generator bug or unsupported configuration

Solution: 1. Check parameter ranges (1-16 for M and N) 2. No span alignment is required — the slave index comes from the OFFSET. The one illegal region is the top S x 64KB of the address space, where `BASE_ADDR + S*64KB` wraps 32-bit and every access becomes a decode miss 3. Report bug with command that caused issue

Issue: Generated Code Too Large

Cause: Very large MxN configuration (e.g., 16x16)

Expected Behavior: - 1x1: 167 LOC (measured) - 2x4: 792 LOC (measured) - 16x16: ~25,000 LOC (extrapolated; the practical limit)

Solution: - Consider hierarchical approach (multiple smaller crossbars) - Or use different interconnect topology (bus, tree, etc.)

References

- Architecture Overview
- Address Decode and Arbitration
- PRD.md - Complete specification
- CLAUDE.md - Integration guidance
- README.md - Quick start guide

Version: 1.2 **Last Updated:** 2026-10-12 **Maintained By:** RTL Design Sherpa Project

Verification Wrappers

`rtl/wrappers/*_wrap.sv` holds four modules — `apbx_xbar_1to1_wrap`, `apbx_xbar_1to4_wrap`, `apbx_xbar_2to1_wrap`, `apbx_xbar_2to4_wrap`.

The generator does not emit them. They are hand-written testbench scaffolding, and a variant gets one only when a test needs it. The clearest evidence is `apbx_xbar_2to2_mixed`: it is generator output like every other variant, and it has no wrapper at all, because its test drives the DUT directly. Regenerating the family produces no wrappers; generating a new custom MxN produces none either.

They are also not design entities and must not be instantiated in a system. Each declares only `pclk` and `presetn` as ports, holds every master- and slave-side APB signal as an internal net, and instantiates the crossbar against those nets. The cocotb testbenches use the wrapper as `toplevel` and drive the bus by hierarchical name.

Keeping the bus off the port list is deliberate: the AXI/APB factory helpers match signals by name pattern, and a wrapper that re-exported `m0_apb_*` and `s0_apb_*` at its own boundary would give those patterns two matches per signal. The internal-net form leaves exactly one.

Verification Wrapper Parameters

Parameter	Default	On which wrappers	Description
`ADDR_WIDTH`	32	all four	Forwarded to the wrapped crossbar
`DATA_WIDTH`	32	all four	Forwarded to the wrapped crossbar
`BASE_ADDR`	`32'h1000_0000`	`1to4`, `2to4` only	Forwarded to the crossbar's decode base. Absent on `1to1`/`2to1`, matching those variants, where `BASE_ADDR` is inert because there is nothing to decode