



MEC/KMEC Drum End Enclosure-Adjustable Wall Louver Details

PANEL OPENING

KLA4842

PANEL OPENING

PANEL OPENING

KLA1824

STEP#1

PANEL RIB AT LOUVER OPENING AS

REQUIRED.

24" OR 32"

24" PANEL

PANEL OPENING

FIELD CUT PANEL RIB AS REQUIRED

K1237-5 #12 FASTENER

FULL HEIGHT RIB

(IF APPLICABLE)

PANEL

STEP#2

HEAD PANEL AS SHOWN. CAULK PANEL RIB AS

W/ K1237-5 #12 FASTENER AT 16" c/c.

SHOWN ABOVE AND INSTALL NEXT WALL PANEL.
FASTEN PANEL CONNECTOR TO HEAD PANEL RIBS

CAULK SILL, JAMB AND TOP OF LOUVER, PLACE LOUVER IN WALL. POSITION PANEL CONNECTOR AND THEN INSTALL HEAD PANELS. SWEEP CAULK EACH

STIFFENER

AT 2'-0" c/c

(SEE NOTE BELOW)

RIB STIFFENER

WALL PANEL

LOUVER .

(TYPICAL BOTH SIDES)

CAULK WELL WITH K1115P

INSTALLING CLIP.

K1115P CAULKING