

INSTALLATION INSTRUCTIONS FOR 3G CTS & IPS OD FITTINGS

1. Cut Pipe Square

Cut the pipe square. There is no need to prepare the pipe end. Chamfering or lubrication is not required.

2. Ready to Use Position

The fitting is pre-assembled and ready to use, however always ensure the nut is fully relaxed and 2 threads are showing before inserting the pipe.

3. Pipe Insertion

Insert the pipe until the first point of resistance is felt.

4. Nut Tightening

The nut should be tightened by hand and then firmly with a wrench. Tighten the nut to the flange on the body of the fitting so that the marks on the nut line up with the matching marks on the body. No more, no less.