

INSTALLATION INSTRUCTIONS FOR KITEC XPA 3G FITTINGS



1. Cut Pipe Square



2. Re-round Pipe

To ensure that the pipe sits easily in the internal seal, re-round the pipe using the tool supplied. This must be done on the inside and the outside of the pipe.



3. Pipe Insertion

Insert the pipe until the first point of resistance is felt.



4. Nut Tightening

The nut should be tightened by hand and then firmly with a wrench. Tighten the nut all the way to the flange on the body of the fitting.



5. Fully Installed

Fitting is now fully installed and ready to use.



6. Disassembly

To dis-assemble the fitting simply loosen the nut using a wrench until 2 threads are showing. Pipe will be released and can simply be pulled out of the fitting.

Note: Philmac recommends the use of PTFE tape on NPT threads to ensure a positive seal.