


ILLUSTRATION BOOKLET


Part of 595-2014




PICTORIAL 6-1

Operation
Model H8


Copyright © 1977
Heath Company
All Rights Reserved
Printed in the United States of America



PICTORIAL 6-2



PICTORIAL 6-3




CPU BLOCK DIAGRAM


CIRCUIT BOARD X-RAY VIEWS

NOTE: To find the PART NUMBER of a component for the purpose of ordering a replacement part:


- A. Find the circuit component number (R5, C3, etc.) on the X-Ray View.
- B. Locate this same number in the "Circuit Component Number" column of the "Parts List."
- C. Adjacent to the circuit component number, you will find the PART NUMBER and DESCRIPTION which must be supplied when you order a replacement part.



POWER SUPPLY AND MOTHER CIRCUIT BOARD X-RAY VIEW
(Viewed From Component Side)



CONTROL CIRCUIT BOARD X-RAY VIEW
(Viewed From Component Side)



CPU CIRCUIT BOARD X-RAY VIEW
(Viewed From Component Side)