

How do I identify the nozzle size?

SeeMeCNC nozzles have one or more "dots" on the face of the nozzle that identifies the diameter of the nozzle. Here's how those work:

1 dot = 0.4 mm

2 dots = 0.5 mm

3 dots = 0.7 mm

4 dots = 1 mm