

# SenNet NTC-16CH RS485

# Módulo temperatura para 16 canales NTC-10k (RS485-Modbus RTU)

## Contenido

SenNet NTC-16CH RS485 es un equipo para realizar múltiples medidas de temperatura a través de sondas NTC 10k, posee hasta 16 canales para este tipo de sonda, pudiendo realizar mediciones simultaneas.

Para acceder a los datos capturados se utiliza el protocolo Modbus RTU a través de un puerto serie RS485 industrial.

#### Conexionado

La alimentación del dispositivo se realiza con una fuente de 12-24Vdc (consumo medio de 50mA con todas las sondas conectadas).



## Pasos para la instalación:

- 1. Alimentar la sonda (12-24Vdc)
- 2. Configurar un ID Modbus (por defecto ID\_modbus=1)
- Acceder a los datos de la temperatura para los distintos canales NTC con el protocolo Modbus RTU a través del puerto RS485.



## Detalles de la medida

Tipo sensor	Rango medida	Precision sonda	
NTC - 10k	-20 °C+125°C	1%	
Conector XH2.54-2P para sondas NTC-10K			

# Tabla – Modbus RTU para lectura valores de temperatura / resistencia (función 03 - lectura )

• Modbus RTU: 9600 baud – 8N1

• Formato: signed int

2 bytesBase 0

0x0000Valor Temperatura Canal 1signed int0.1°C0x0001Valor Temperatura Canal 2signed int0.1°C0x0002Valor Temperatura Canal 3signed int0.1°C0x0003Valor Temperatura Canal 4signed int0.1°C0x0004Valor Temperatura Canal 5signed int0.1°C0x0005Valor Temperatura Canal 6signed int0.1°C0x0006Valor Temperatura Canal 7signed int0.1°C0x0007Valor Temperatura Canal 8signed int0.1°C0x0008Valor Temperatura Canal 9signed int0.1°C0x0009Valor Temperatura Canal 10signed int0.1°C0x0000Valor Temperatura Canal 11signed int0.1°C0x0000Valor Temperatura Canal 12signed int0.1°C0x0000Valor Temperatura Canal 13signed int0.1°C0x0000Valor Temperatura Canal 14signed int0.1°C0x0000Valor Temperatura Canal 15signed int0.1°C0x0000Valor Temperatura Canal 15signed int0.1°C0x0000Valor Temperatura Canal 16signed int0.1°C0x0000Valor Resistencia Canal 1signed int0.1°C0x0000Valor Resistencia Canal 1signed int0.01Ω0x0021Valor Resistencia Canal 3signed int0.01Ω0x0022Valor	Registro	Descripción	Formato	Factor	Unidades
0x0002Valor Temperatura Canal 3signed int0.1°C0x0003Valor Temperatura Canal 4signed int0.1°C0x0004Valor Temperatura Canal 5signed int0.1°C0x0005Valor Temperatura Canal 6signed int0.1°C0x0006Valor Temperatura Canal 7signed int0.1°C0x0007Valor Temperatura Canal 8signed int0.1°C0x0008Valor Temperatura Canal 9signed int0.1°C0x0009Valor Temperatura Canal 10signed int0.1°C0x0009Valor Temperatura Canal 11signed int0.1°C0x0000Valor Temperatura Canal 12signed int0.1°C0x0000Valor Temperatura Canal 13signed int0.1°C0x0000Valor Temperatura Canal 14signed int0.1°C0x0000Valor Temperatura Canal 15signed int0.1°C0x0000Valor Temperatura Canal 15signed int0.1°C0x0000Valor Resistencia Canal 1signed int0.1°C0x0020Valor Resistencia Canal 2signed int0.1°C0x0021Valor Resistencia Canal 3signed int0.01Ω0x0022Valor Resistencia Canal 3signed int0.01Ω0x0023Valor Resistencia Canal 4signed int0.01Ω0x0024Valor Resistencia Canal 5signed int0.01Ω0x0025Valor R	0x0000	Valor Temperatura Canal 1	signed int	0.1	°C
0x0003Valor Temperatura Canal 4signed int0.1°C0x0004Valor Temperatura Canal 5signed int0.1°C0x0005Valor Temperatura Canal 6signed int0.1°C0x0006Valor Temperatura Canal 7signed int0.1°C0x0007Valor Temperatura Canal 8signed int0.1°C0x0008Valor Temperatura Canal 9signed int0.1°C0x0009Valor Temperatura Canal 10signed int0.1°C0x0000Valor Temperatura Canal 11signed int0.1°C0x0000Valor Temperatura Canal 12signed int0.1°C0x0000Valor Temperatura Canal 13signed int0.1°C0x0000Valor Temperatura Canal 14signed int0.1°C0x0000Valor Temperatura Canal 15signed int0.1°C0x0000Valor Temperatura Canal 15signed int0.1°C0x0000Valor Temperatura Canal 15signed int0.1°C0x0000Valor Resistencia Canal 1signed int0.1°C0x0020Valor Resistencia Canal 2signed int0.01Ω0x0021Valor Resistencia Canal 3signed int0.01Ω0x0022Valor Resistencia Canal 4signed int0.01Ω0x0023Valor Resistencia Canal 5signed int0.01Ω0x0024Valor Resistencia Canal 6signed int0.01Ω0x0025Valor	0x0001	Valor Temperatura Canal 2	signed int	0.1	°C
0x0004Valor Temperatura Canal 5signed int0.1°C0x0005Valor Temperatura Canal 6signed int0.1°C0x0006Valor Temperatura Canal 7signed int0.1°C0x0007Valor Temperatura Canal 8signed int0.1°C0x0008Valor Temperatura Canal 9signed int0.1°C0x0009Valor Temperatura Canal 10signed int0.1°C0x000AValor Temperatura Canal 11signed int0.1°C0x000BValor Temperatura Canal 12signed int0.1°C0x000CValor Temperatura Canal 13signed int0.1°C0x000DValor Temperatura Canal 14signed int0.1°C0x000DValor Temperatura Canal 15signed int0.1°C0x000FValor Temperatura Canal 15signed int0.1°C0x002DValor Resistencia Canal 1signed int0.1°C0x0021Valor Resistencia Canal 2signed int0.01Ω0x0022Valor Resistencia Canal 3signed int0.01Ω0x0023Valor Resistencia Canal 4signed int0.01Ω0x0024Valor Resistencia Canal 5signed int0.01Ω0x0025Valor Resistencia Canal 6signed int0.01Ω0x0020Valor Resistencia Canal 8signed int0.01Ω0x0020Valor Resistencia Canal 10signed int0.01Ω0x0020Valor	0x0002	Valor Temperatura Canal 3	signed int	0.1	°C
0x0005Valor Temperatura Canal 6signed int0.1°C0x0006Valor Temperatura Canal 7signed int0.1°C0x0007Valor Temperatura Canal 8signed int0.1°C0x0008Valor Temperatura Canal 9signed int0.1°C0x0009Valor Temperatura Canal 10signed int0.1°C0x000AValor Temperatura Canal 11signed int0.1°C0x000BValor Temperatura Canal 12signed int0.1°C0x000CValor Temperatura Canal 13signed int0.1°C0x000DValor Temperatura Canal 14signed int0.1°C0x000EValor Temperatura Canal 15signed int0.1°C0x000FValor Temperatura Canal 16signed int0.1°C0x0020Valor Resistencia Canal 1signed int0.01Ω0x0021Valor Resistencia Canal 2signed int0.01Ω0x0022Valor Resistencia Canal 3signed int0.01Ω0x0023Valor Resistencia Canal 4signed int0.01Ω0x0024Valor Resistencia Canal 5signed int0.01Ω0x0025Valor Resistencia Canal 6signed int0.01Ω0x0026Valor Resistencia Canal 7signed int0.01Ω0x0027Valor Resistencia Canal 8signed int0.01Ω0x0028Valor Resistencia Canal 10signed int0.01Ω0x0029Valor	0x0003	Valor Temperatura Canal 4	signed int	0.1	°C
0x0006Valor Temperatura Canal 7signed int0.1°C0x0007Valor Temperatura Canal 8signed int0.1°C0x0008Valor Temperatura Canal 9signed int0.1°C0x0009Valor Temperatura Canal 10signed int0.1°C0x000AValor Temperatura Canal 11signed int0.1°C0x000BValor Temperatura Canal 12signed int0.1°C0x000CValor Temperatura Canal 13signed int0.1°C0x000DValor Temperatura Canal 14signed int0.1°C0x000EValor Temperatura Canal 15signed int0.1°C0x000FValor Temperatura Canal 16signed int0.1°C0x0020Valor Resistencia Canal 1signed int0.01Ω0x0021Valor Resistencia Canal 2signed int0.01Ω0x0022Valor Resistencia Canal 3signed int0.01Ω0x0023Valor Resistencia Canal 4signed int0.01Ω0x0024Valor Resistencia Canal 5signed int0.01Ω0x0025Valor Resistencia Canal 6signed int0.01Ω0x0026Valor Resistencia Canal 8signed int0.01Ω0x0027Valor Resistencia Canal 9signed int0.01Ω0x0028Valor Resistencia Canal 10signed int0.01Ω0x0029Valor Resistencia Canal 11signed int0.01Ω0x002DValor	0x0004	Valor Temperatura Canal 5	signed int	0.1	
0x0007Valor Temperatura Canal 8signed int0.1°C0x0008Valor Temperatura Canal 9signed int0.1°C0x0009Valor Temperatura Canal 10signed int0.1°C0x000AValor Temperatura Canal 11signed int0.1°C0x000BValor Temperatura Canal 12signed int0.1°C0x000CValor Temperatura Canal 13signed int0.1°C0x000DValor Temperatura Canal 14signed int0.1°C0x000EValor Temperatura Canal 15signed int0.1°C0x000FValor Temperatura Canal 16signed int0.1°C0x0020Valor Resistencia Canal 1signed int0.01Ω0x0021Valor Resistencia Canal 2signed int0.01Ω0x0022Valor Resistencia Canal 3signed int0.01Ω0x0023Valor Resistencia Canal 4signed int0.01Ω0x0024Valor Resistencia Canal 5signed int0.01Ω0x0025Valor Resistencia Canal 6signed int0.01Ω0x0026Valor Resistencia Canal 7signed int0.01Ω0x0027Valor Resistencia Canal 8signed int0.01Ω0x0028Valor Resistencia Canal 10signed int0.01Ω0x0029Valor Resistencia Canal 11signed int0.01Ω0x002DValor Resistencia Canal 13signed int0.01Ω0x002DValo	0x0005	Valor Temperatura Canal 6	signed int	0.1	°C
0x0008Valor Temperatura Canal 9signed int0.1°C0x0009Valor Temperatura Canal 10signed int0.1°C0x000AValor Temperatura Canal 11signed int0.1°C0x000BValor Temperatura Canal 12signed int0.1°C0x000CValor Temperatura Canal 13signed int0.1°C0x000DValor Temperatura Canal 14signed int0.1°C0x000EValor Temperatura Canal 15signed int0.1°C0x000FValor Temperatura Canal 16signed int0.1°C0x0020Valor Resistencia Canal 1signed int0.01Ω0x0021Valor Resistencia Canal 2signed int0.01Ω0x0022Valor Resistencia Canal 3signed int0.01Ω0x0023Valor Resistencia Canal 4signed int0.01Ω0x0024Valor Resistencia Canal 5signed int0.01Ω0x0025Valor Resistencia Canal 6signed int0.01Ω0x0026Valor Resistencia Canal 7signed int0.01Ω0x0027Valor Resistencia Canal 8signed int0.01Ω0x0028Valor Resistencia Canal 9signed int0.01Ω0x0029Valor Resistencia Canal 10signed int0.01Ω0x002AValor Resistencia Canal 11signed int0.01Ω0x002BValor Resistencia Canal 12signed int0.01Ω0x002CValo	0x0006	Valor Temperatura Canal 7	signed int	0.1	_
0x0009Valor Temperatura Canal 10signed int0.1°C0x000AValor Temperatura Canal 11signed int0.1°C0x000BValor Temperatura Canal 12signed int0.1°C0x000CValor Temperatura Canal 13signed int0.1°C0x000DValor Temperatura Canal 14signed int0.1°C0x000EValor Temperatura Canal 15signed int0.1°C0x000FValor Temperatura Canal 16signed int0.1°C0x0020Valor Resistencia Canal 1signed int0.01 $\Omega$ 0x0021Valor Resistencia Canal 2signed int0.01 $\Omega$ 0x0022Valor Resistencia Canal 3signed int0.01 $\Omega$ 0x0023Valor Resistencia Canal 4signed int0.01 $\Omega$ 0x0024Valor Resistencia Canal 5signed int0.01 $\Omega$ 0x0025Valor Resistencia Canal 6signed int0.01 $\Omega$ 0x0026Valor Resistencia Canal 7signed int0.01 $\Omega$ 0x0027Valor Resistencia Canal 8signed int0.01 $\Omega$ 0x0028Valor Resistencia Canal 9signed int0.01 $\Omega$ 0x0029Valor Resistencia Canal 10signed int0.01 $\Omega$ 0x002AValor Resistencia Canal 12signed int0.01 $\Omega$ 0x002BValor Resistencia Canal 13signed int0.01 $\Omega$ 0x002CValor Resistencia Canal 14signed int0.01 $\Omega$ <td>0x0007</td> <td>Valor Temperatura Canal 8</td> <td>signed int</td> <td>0.1</td> <td>°C</td>	0x0007	Valor Temperatura Canal 8	signed int	0.1	°C
0x000AValor Temperatura Canal 11signed int0.1°C0x000BValor Temperatura Canal 12signed int0.1°C0x000CValor Temperatura Canal 13signed int0.1°C0x000DValor Temperatura Canal 14signed int0.1°C0x000EValor Temperatura Canal 15signed int0.1°C0x000FValor Temperatura Canal 16signed int0.1°C0x0020Valor Resistencia Canal 1signed int0.01 $\Omega$ 0x0021Valor Resistencia Canal 2signed int0.01 $\Omega$ 0x0022Valor Resistencia Canal 3signed int0.01 $\Omega$ 0x0023Valor Resistencia Canal 4signed int0.01 $\Omega$ 0x0024Valor Resistencia Canal 5signed int0.01 $\Omega$ 0x0025Valor Resistencia Canal 6signed int0.01 $\Omega$ 0x0026Valor Resistencia Canal 7signed int0.01 $\Omega$ 0x0027Valor Resistencia Canal 8signed int0.01 $\Omega$ 0x0028Valor Resistencia Canal 9signed int0.01 $\Omega$ 0x0029Valor Resistencia Canal 10signed int0.01 $\Omega$ 0x002AValor Resistencia Canal 11signed int0.01 $\Omega$ 0x002BValor Resistencia Canal 13signed int0.01 $\Omega$ 0x002CValor Resistencia Canal 13signed int0.01 $\Omega$ 0x002DValor Resistencia Canal 14signed int0.01 $\Omega$ </td <td>0x0008</td> <td>Valor Temperatura Canal 9</td> <td>signed int</td> <td>0.1</td> <td>°C</td>	0x0008	Valor Temperatura Canal 9	signed int	0.1	°C
Ox000B         Valor Temperatura Canal 12         signed int         0.1         °C           0x000C         Valor Temperatura Canal 13         signed int         0.1         °C           0x000D         Valor Temperatura Canal 14         signed int         0.1         °C           0x000E         Valor Temperatura Canal 15         signed int         0.1         °C           0x000F         Valor Temperatura Canal 16         signed int         0.1         °C           0x0020         Valor Resistencia Canal 1         signed int         0.01         Ω           0x0021         Valor Resistencia Canal 2         signed int         0.01         Ω           0x0022         Valor Resistencia Canal 3         signed int         0.01         Ω           0x0023         Valor Resistencia Canal 4         signed int         0.01         Ω           0x0024         Valor Resistencia Canal 5         signed int         0.01         Ω           0x0025         Valor Resistencia Canal 6         signed int         0.01         Ω           0x0026         Valor Resistencia Canal 7         signed int         0.01         Ω           0x0027         Valor Resistencia Canal 8         signed int         0.01         Ω           0	0x0009	Valor Temperatura Canal 10	signed int	0.1	°C
0x000CValor Temperatura Canal 13signed int0.1°C0x000DValor Temperatura Canal 14signed int0.1°C0x000EValor Temperatura Canal 15signed int0.1°C0x000FValor Temperatura Canal 16signed int0.1°C0x0020Valor Resistencia Canal 1signed int0.01 $\Omega$ 0x0021Valor Resistencia Canal 2signed int0.01 $\Omega$ 0x0022Valor Resistencia Canal 3signed int0.01 $\Omega$ 0x0023Valor Resistencia Canal 4signed int0.01 $\Omega$ 0x0024Valor Resistencia Canal 5signed int0.01 $\Omega$ 0x0025Valor Resistencia Canal 6signed int0.01 $\Omega$ 0x0026Valor Resistencia Canal 7signed int0.01 $\Omega$ 0x0027Valor Resistencia Canal 8signed int0.01 $\Omega$ 0x0028Valor Resistencia Canal 9signed int0.01 $\Omega$ 0x0029Valor Resistencia Canal 10signed int0.01 $\Omega$ 0x002AValor Resistencia Canal 11signed int0.01 $\Omega$ 0x002BValor Resistencia Canal 12signed int0.01 $\Omega$ 0x002CValor Resistencia Canal 13signed int0.01 $\Omega$ 0x002DValor Resistencia Canal 14signed int0.01 $\Omega$ 0x002EValor Resistencia Canal 15signed int0.01 $\Omega$	0x000A	Valor Temperatura Canal 11	signed int	0.1	°C
Ox000D         Valor Temperatura Canal 14         signed int         0.1         °C           0x000E         Valor Temperatura Canal 15         signed int         0.1         °C           0x000F         Valor Temperatura Canal 16         signed int         0.1         °C           0x0020         Valor Resistencia Canal 1         signed int         0.01         Ω           0x0021         Valor Resistencia Canal 2         signed int         0.01         Ω           0x0022         Valor Resistencia Canal 3         signed int         0.01         Ω           0x0023         Valor Resistencia Canal 4         signed int         0.01         Ω           0x0024         Valor Resistencia Canal 5         signed int         0.01         Ω           0x0025         Valor Resistencia Canal 6         signed int         0.01         Ω           0x0026         Valor Resistencia Canal 7         signed int         0.01         Ω           0x0027         Valor Resistencia Canal 8         signed int         0.01         Ω           0x0028         Valor Resistencia Canal 9         signed int         0.01         Ω           0x0029         Valor Resistencia Canal 10         signed int         0.01         Ω           0x	0x000B	Valor Temperatura Canal 12	signed int	0.1	°C
Ox000E         Valor Temperatura Canal 15         signed int         0.1         °C           0x000F         Valor Temperatura Canal 16         signed int         0.1         °C           0x0020         Valor Resistencia Canal 1         signed int         0.01 $\Omega$ 0x0021         Valor Resistencia Canal 2         signed int         0.01 $\Omega$ 0x0022         Valor Resistencia Canal 3         signed int         0.01 $\Omega$ 0x0023         Valor Resistencia Canal 4         signed int         0.01 $\Omega$ 0x0024         Valor Resistencia Canal 5         signed int         0.01 $\Omega$ 0x0025         Valor Resistencia Canal 6         signed int         0.01 $\Omega$ 0x0026         Valor Resistencia Canal 7         signed int         0.01 $\Omega$ 0x0027         Valor Resistencia Canal 8         signed int         0.01 $\Omega$ 0x0028         Valor Resistencia Canal 9         signed int         0.01 $\Omega$ 0x0029         Valor Resistencia Canal 10         signed int         0.01 $\Omega$ 0x002A         Valor Resistencia Canal 11         signed int         0.01 $\Omega$	0x000C	Valor Temperatura Canal 13	signed int	0.1	°C
Ox000F         Valor Temperatura Canal 16         signed int         0.1         °C           0x0020         Valor Resistencia Canal 1         signed int         0.01         Ω           0x0021         Valor Resistencia Canal 2         signed int         0.01         Ω           0x0022         Valor Resistencia Canal 3         signed int         0.01         Ω           0x0023         Valor Resistencia Canal 4         signed int         0.01         Ω           0x0024         Valor Resistencia Canal 5         signed int         0.01         Ω           0x0025         Valor Resistencia Canal 6         signed int         0.01         Ω           0x0026         Valor Resistencia Canal 7         signed int         0.01         Ω           0x0027         Valor Resistencia Canal 8         signed int         0.01         Ω           0x0028         Valor Resistencia Canal 9         signed int         0.01         Ω           0x0029         Valor Resistencia Canal 10         signed int         0.01         Ω           0x002A         Valor Resistencia Canal 11         signed int         0.01         Ω           0x002B         Valor Resistencia Canal 12         signed int         0.01         Ω           0x	0x000D	Valor Temperatura Canal 14	signed int	0.1	°C
0x0020         Valor Resistencia Canal 1         signed int         0.01         Ω           0x0021         Valor Resistencia Canal 2         signed int         0.01         Ω           0x0022         Valor Resistencia Canal 3         signed int         0.01         Ω           0x0023         Valor Resistencia Canal 4         signed int         0.01         Ω           0x0024         Valor Resistencia Canal 5         signed int         0.01         Ω           0x0025         Valor Resistencia Canal 6         signed int         0.01         Ω           0x0026         Valor Resistencia Canal 7         signed int         0.01         Ω           0x0027         Valor Resistencia Canal 8         signed int         0.01         Ω           0x0028         Valor Resistencia Canal 9         signed int         0.01         Ω           0x0029         Valor Resistencia Canal 10         signed int         0.01         Ω           0x002A         Valor Resistencia Canal 11         signed int         0.01         Ω           0x002B         Valor Resistencia Canal 12         signed int         0.01         Ω           0x002C         Valor Resistencia Canal 13         signed int         0.01         Ω           0x	0x000E	Valor Temperatura Canal 15	signed int	0.1	
$0x0021$ Valor Resistencia Canal 2       signed int $0.01$ $\Omega$ $0x0022$ Valor Resistencia Canal 3       signed int $0.01$ $\Omega$ $0x0023$ Valor Resistencia Canal 4       signed int $0.01$ $\Omega$ $0x0024$ Valor Resistencia Canal 5       signed int $0.01$ $\Omega$ $0x0025$ Valor Resistencia Canal 6       signed int $0.01$ $\Omega$ $0x0026$ Valor Resistencia Canal 7       signed int $0.01$ $\Omega$ $0x0027$ Valor Resistencia Canal 8       signed int $0.01$ $\Omega$ $0x0028$ Valor Resistencia Canal 9       signed int $0.01$ $\Omega$ $0x0029$ Valor Resistencia Canal 10       signed int $0.01$ $\Omega$ $0x002A$ Valor Resistencia Canal 11       signed int $0.01$ $\Omega$ $0x002B$ Valor Resistencia Canal 13       signed int $0.01$ $\Omega$ $0x002C$ Valor Resistencia Canal 14       signed int $0.01$ $\Omega$ $0x002D$ Valor Resistencia Canal 14       signed int $0.01$ $\Omega$ $0x002E$ Valor Resistencia Can	0x000F	Valor Temperatura Canal 16	signed int	0.1	°C
$0x0022$ Valor Resistencia Canal 3       signed int $0.01$ $\Omega$ $0x0023$ Valor Resistencia Canal 4       signed int $0.01$ $\Omega$ $0x0024$ Valor Resistencia Canal 5       signed int $0.01$ $\Omega$ $0x0025$ Valor Resistencia Canal 6       signed int $0.01$ $\Omega$ $0x0026$ Valor Resistencia Canal 7       signed int $0.01$ $\Omega$ $0x0027$ Valor Resistencia Canal 8       signed int $0.01$ $\Omega$ $0x0028$ Valor Resistencia Canal 9       signed int $0.01$ $\Omega$ $0x0029$ Valor Resistencia Canal 10       signed int $0.01$ $\Omega$ $0x002A$ Valor Resistencia Canal 11       signed int $0.01$ $\Omega$ $0x002B$ Valor Resistencia Canal 13       signed int $0.01$ $\Omega$ $0x002C$ Valor Resistencia Canal 14       signed int $0.01$ $\Omega$ $0x002E$ Valor Resistencia Canal 15       signed int $0.01$ $\Omega$	0x0020	Valor Resistencia Canal 1	signed int	0.01	Ω
0x0023       Valor Resistencia Canal 4       signed int       0.01 $\Omega$ 0x0024       Valor Resistencia Canal 5       signed int       0.01 $\Omega$ 0x0025       Valor Resistencia Canal 6       signed int       0.01 $\Omega$ 0x0026       Valor Resistencia Canal 7       signed int       0.01 $\Omega$ 0x0027       Valor Resistencia Canal 8       signed int       0.01 $\Omega$ 0x0028       Valor Resistencia Canal 9       signed int       0.01 $\Omega$ 0x0029       Valor Resistencia Canal 10       signed int       0.01 $\Omega$ 0x002A       Valor Resistencia Canal 11       signed int       0.01 $\Omega$ 0x002B       Valor Resistencia Canal 12       signed int       0.01 $\Omega$ 0x002C       Valor Resistencia Canal 13       signed int       0.01 $\Omega$ 0x002D       Valor Resistencia Canal 14       signed int       0.01 $\Omega$ 0x002E       Valor Resistencia Canal 15       signed int       0.01 $\Omega$	0x0021	Valor Resistencia Canal 2	signed int	0.01	Ω
0x0024       Valor Resistencia Canal 5       signed int       0.01       Ω         0x0025       Valor Resistencia Canal 6       signed int       0.01       Ω         0x0026       Valor Resistencia Canal 7       signed int       0.01       Ω         0x0027       Valor Resistencia Canal 8       signed int       0.01       Ω         0x0028       Valor Resistencia Canal 9       signed int       0.01       Ω         0x0029       Valor Resistencia Canal 10       signed int       0.01       Ω         0x002A       Valor Resistencia Canal 11       signed int       0.01       Ω         0x002B       Valor Resistencia Canal 12       signed int       0.01       Ω         0x002C       Valor Resistencia Canal 13       signed int       0.01       Ω         0x002D       Valor Resistencia Canal 14       signed int       0.01       Ω         0x002E       Valor Resistencia Canal 15       signed int       0.01       Ω	0x0022	Valor Resistencia Canal 3	signed int	0.01	Ω
0x0025       Valor Resistencia Canal 6       signed int       0.01       Ω         0x0026       Valor Resistencia Canal 7       signed int       0.01       Ω         0x0027       Valor Resistencia Canal 8       signed int       0.01       Ω         0x0028       Valor Resistencia Canal 9       signed int       0.01       Ω         0x0029       Valor Resistencia Canal 10       signed int       0.01       Ω         0x002A       Valor Resistencia Canal 11       signed int       0.01       Ω         0x002B       Valor Resistencia Canal 12       signed int       0.01       Ω         0x002C       Valor Resistencia Canal 13       signed int       0.01       Ω         0x002D       Valor Resistencia Canal 14       signed int       0.01       Ω         0x002E       Valor Resistencia Canal 15       signed int       0.01       Ω	0x0023	Valor Resistencia Canal 4	signed int	0.01	Ω
$\begin{array}{c ccccccccccccccccccccccccccccccccccc$	0x0024	Valor Resistencia Canal 5	signed int	0.01	Ω
$\begin{array}{c ccccccccccccccccccccccccccccccccccc$	0x0025	Valor Resistencia Canal 6	signed int	0.01	Ω
$\begin{array}{c ccccccccccccccccccccccccccccccccccc$	0x0026	Valor Resistencia Canal 7	signed int	0.01	Ω
$\begin{array}{c ccccccccccccccccccccccccccccccccccc$	0x0027	Valor Resistencia Canal 8	signed int	0.01	Ω
$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$	0x0028	Valor Resistencia Canal 9	signed int	0.01	Ω
$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$	0x0029	Valor Resistencia Canal 10	signed int	0.01	Ω
$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$	0x002A	Valor Resistencia Canal 11	signed int	0.01	Ω
0x002D     Valor Resistencia Canal 14     signed int     0.01 $\Omega$ 0x002E     Valor Resistencia Canal 15     signed int     0.01 $\Omega$	0x002B	Valor Resistencia Canal 12	signed int	0.01	Ω
Ox002E Valor Resistencia Canal 15 signed int 0.01 $\Omega$	0x002C	Valor Resistencia Canal 13	signed int	0.01	Ω
	0x002D	Valor Resistencia Canal 14	signed int	0.01	Ω
Ox002F Valor Resistencia Canal 16 signed int 0.01 Ω	0x002E	Valor Resistencia Canal 15	signed int	0.01	Ω
	0x002F	Valor Resistencia Canal 16	signed int	0.01	Ω

# Tabla – Modbus RTU para configuración de los parámetros ajustables de la sonda. (función 03 – lectura / función 06 – escritura)

Modbus RTU: 9600 baud – 8N1Formato: signed int / unsigned


2 bytesBase 0

Registrto	Descripción	Formato	Factor	Unidad
[0x00400x004F]	Valor de corrección de temperatura para los 16 canales. Este registro solo se puede escribir. Datos leídos: OXFFFF	signed int	0.1	°C
Valor positivo de corrección de resistencia NTC para los  [0x00600x006F] 16 canales.  Este registro sólo se puede escribir datos leídos: 0XFFFF		signed int	0.1	Ω
0x00F8	Envío periódico de dato de temperatura/resistencia. (Por defecto: 0)	unsigned	ı	Segundo
0x00F9	Selección tipo de dato a enviar en automático temperatura (0) / resistencia(1). (Por defecto: 0)	unsigned	ı	Segundo
0x00FB	Reseteo a valore por defecto (0x00)	unsigned	-	-
0x00FD	Dirección Modbus 1-254	unsigned	-	
0x00FE	Baudrate  0: 1200;  1: 2400; 2: 4800;  3: 9600; 4: 19200;  5: 38400; 6: 57600;  7: 115200  8: Factory reset	unsigned	-	-
0x00FF	Paridad  0 None Parity  1 Even Parity  2 Odd Parity	unsigned	-	-



#### Envolvente

Características ambientales	
Temperatura trabajo	-20ºC+70ºC
Temperatura de almacenamiento	-20ºC+75ºC
Carcasa	
Dimensiones	123 x 100 x 43 mm
Grado de protección	IP50
Montaje	A pared / Rail DIN
Material	Aluminio AL6063
Normativas	
C€	



## Garantía

Satel Spain garantiza sus productos contra todo defecto de fabricación por un periodo de 1 año.

No se aceptará ninguna devolución de material ni se reparará ningún equipo si no viene acompañado de un informe (RMA) indicando el defecto observado o los motivos de la devolución.

La garantía quedará sin efecto si el equipo ha sufrido "mal uso" o no se han seguido las instrucciones de almacenaje, instalación o mantenimiento de este manual. Se define "mal uso" como cualquier situación de empleo o almacenaje contraria al Código Eléctrico Nacional o que supere los límites indicados en este manual.



Satel Spain declina toda responsabilidad por los posibles daños, en el equipo o en otras partes de las instalaciones y no cubrirá las posibles penalizaciones derivadas de una posible avería, mala instalación o "mal uso" del equipo. En consecuencia, la garantía no es aplicable a las averías producidas en los siguientes casos.

- Por sobretensiones y/o perturbaciones eléctricas en el suministro.
- Por agua, si el producto no tiene la clasificación IP apropiada.
- Por exponer al equipo a temperaturas extremas, que superen el límite de temperatura de funcionamiento o almacenaje.
- Por una modificación del producto por parte del cliente sin previo aviso a Satel Spain.

Frente a posibles erratas de la presente hoja técnica, manténgala actualizada.