


Lesson 4 Start xArm 1S

1. Getting Ready

1.1 Vacuum Pad Installation

- 1) Take out the suction cup and buckle into the four holes of the base one by one, as shown in the figure below:



- 2) Then tighten the nut.

1.2 Adapter Connector

Plug the power pair wiring directly into the DC power interface of the controller.
Turn on the switch after connecting the power.

Note: There is a low-voltage (less than 6.4V) alarm protection for the servo controller. If the power supply for the USB interface is 5V, it will make the sound of “beep” alarm. Please use the provided adapter for power supply.

2. Start Robotic Arm

Servo indicator will flash in colors to represent the normal working state after switching on the robotic arm. The LED1 of power and LED2 of signal on the controller will remain on.