COCKPIT PREPARATION	
FLIGHT TRACKER/ACARS	START
A/C ACCEPTANCE	COMPLETED
FUEL QUANTITY	KGS, BALANCED
SEATBELTS	ON
ADIRS	NAV
BARO REF	QNH

BEFORE START	
PARKING BRAKE	ON
T.O DATA	CONFIRMED
WINDOWS	CLOSED
PED	FLIGHT MODE >
DOORS	CLOSED & ARMED
BEACON	ON

AFTER START	
ANTI-ICE	AS RQRD
ECAM STATUS	CHECKED
PITCH TRIM	%
RUDDER TRIM	NEUTRAL

TAXI	
FLIGHT CONTROL	CHECKED
FLAPS SETTING	CONF
FMA	READ, CHECKED
RADAR & PRED W/S	ON
ECAM MEMO  - AUTO BRIK MAX  - SIGNS ON  - CABIN READY  - SPLRS ARM  - FLAPS TO  - TO CONFIG NORM	T.O NO BLUE
EFB	AS RQRD

LINE-UP	
CABIN	SECURED FOR T.O
T.O RWY	
TCAS	TA/RA
PACKS	AS RQRD

APPROACH	
BARO REF	QNH
SEAT BELTS	ON
MINIMUM	
AUTOBRAKE	AS RQRD
EFB	AS RQRD

LANDING	
CABIN	SECURED FOR LDG
GO AROUND ALT	FT SET
ECAM MEMO  - LDG GEAR DN  - SIGNS ON  - SPLRS ARM  - FLAPS SET	LDG NO BLUE

PARKING	
RADAR & PRED W/S	OFF
PARKING BRAKE	ON
ENGINES	OFF
EXT LIGHTS	OFF
FUEL PUMPS	OFF
Y ELEC PUMP	OFF
PED	AS RQRD

SECURING THE AIRCRAFT	
ADIRS	OFF
OXYGEN	OFF
EMER EXIT LT	OFF
EFB	AS RQRD
BATTERIES	OFF

DEPARTURE CHANGE	
RWY & SID	
FLAPS SETTING	CONF
T.O DATA	CONFIRMED
FCU ALT	FT