06 Secure the board with four screws

ADD THESE PARTS




4 ×
M3 × 6



4 ×
M3 washer

Washer goes under each screw head, on top of the PCB. Tighten gently by hand in opposite corners.



CHECK

No bowing or screw bottoming.