02 Fit the side power switch.

PARTS / TOOLS

1 SW3 switch. Two insulated quick-connect leads.

Snap into the left opening. Check terminal 1–1A continuity in the I position. Fit insulated 4.75 × 0.8 mm connectors with the correct crimp tool.



CHECK / Switch retained; terminals insulated; space for connector boots and wire bends.