06 Install the light guides and lens.

PARTS / TOOLS

2 clear Ø3 × 24.6 rods. 1 masked lens + perimeter adhesive.

Insert rods through the top pocket onto their ledges. Align the screen and LED windows in the reverse mask. Bond the lens perimeter after the optical trial.



CHECK / Rods stay clear of LEDs. Viewing windows remain clear; adhesive stays off the optics.