Operation Guide 5611

CASIO

F-1

E-5

ENGLISH


Congratulations upon your selection of this CASIO watch.

To ensure that this watch provides you with the years of service for which it is designed, carefully read and follow the instructions in this manual, especially the information under "Operating Precautions" and "User Maintenance".

About This Manual









F

Things to check before using the watch

1. Check the Home City and the daylight saving time (DST) setting.

Use the procedure under "To configure Home City settings" (page E-16) to configure your Home City and daylight saving time settings.

Important!

 Proper World Time Mode data depends on correct Home City, time, and date settings in the Timekeeping Mode. Make sure you configure these settings correctly.

2. Set the current time.

• See "Adjusting the Digital Time and Date Settings" (page E-19).

The watch is now ready for use.

E-2

Contents

About This Manual	E-1
Things to check before using the watch	E-2
Mode Reference Guide	E-8
Timekeeping	E-15
Configuring Home City Settings To configure Home City settings To change the Daylight Saving Time (summer time) setting	E-16
Adjusting the Digital Time and Date Settings	

E-3

Checking the Current Time in a Different Time Zone	23
To enter the World Time Mode	24
To view the time in another time zone	24
To specify standard time or daylight saving time (DST) for a cityE-2	25
Using the Stopwatch	26
To enter the Stopwatch Mode	26
To perform an elapsed time operation	27
To pause at a split time	27
To measure two finishes	27
Countdown Timer E-	30
To enter the Countdown Timer Mode	30
To configure the countdown timer	31
To perform a countdown timer operation	32
To stop the alarm	32

Jsing the Alarm
To enter the Alarm Mode
To set an alarm time
To test the alarm
To turn an alarm and the Hourly Time Signal on and off
To stop the alarm
IluminationE-3
To turn on illumination
To change the illumination duration
Adjusting Hand PositionsE-3
Button Operation ToneE-4
To turn the button operation tone on and off

 Troubleshooting.
 E-43

 Main Indicators
 E-45

 Specifications.
 E-46

 Operating Precautions
 E-49

 User Maintenance
 E-60

E-6 E-

Mode Reference Guide

The mode you should select depends on what you want to do.

To do this:

• View the current date in the Home City
• Configure Home City and daylight saving time (DST) settings
• Configure time and date settings
• View the World Time city and time
• Change the display illumination duration setting
• Enable/disable the button operation tone

View the current time in one of 48 cities (31 time zones) around the globe

E-23

To do this:	Enter this mode:	See:
Use the stopwatch to measure elapsed time	Stopwatch Mode	E-26
Use the countdown timer	Countdown Timer Mode	E-30
Set an alarm time	Alarm Mode	E-33

E-8 E-9