## Capacity – Info Theo 2

Petros Elia EURECOM Fall 2024 November 26, 2024 0 Outline |1

- 1 Wireless Channels (AWGN and LTI)
- Pading channels (epsilon, CSIT, freqSelec)
- 3 Multi-user Capacity



1 Outline |2

Wireless Channels (AWGN and LTI) Capacity of wireless channels Capacity of LTI Gaussian channels

- Pading channels (epsilon, CSIT, freqSelec)
- Multi-user Capacity



- Fundamental limits: best performance.
- ► Tool: information theory.
- ightharpoonup Capacity: max rate s.t.  $P_{err} 
  ightarrow 0$
- First AWGN, then fading channels (calculate capacity)
- Derive diversity results
- ightharpoonup Will give insight: allocate W and  $\bar{P}$
- Inventor of IT: Shannon (1948).
  - >  $\exists R > 0$  s.t.  $P_{err} \rightarrow 0$  for long T
  - >  $C = \max R$ :  $P_{err}(R) \rightarrow 0$  as  $T \rightarrow \infty$
  - > and  $P_{\it err} 
    ightarrow 1 \; orall R > C$



Consider AWGN (Additive White Gaussian Noise)

$$y[m] = x[m] + w[m]$$

- > gives sense to  $P_{err} \rightarrow 0$
- > explain capacity
- ▶ 1) T=1
  - > Since  $x[m] = \pm \sqrt{P}$ , means

$$P_e = Q(\frac{\textit{half} - \textit{distance}}{\sigma_w}) = Q(\frac{\sqrt{P}}{\sigma_w})$$

> Not reliable:  $P_e$  fails to go 0



▶ 2) T large: Consider Repetition Coding:

$$\mathbf{x}_{A} = \sqrt{P}[1, 1, ..., 1], \quad \mathbf{x}_{B} = -\sqrt{P}[1, 1, ..., 1]$$

> Let  $\mathbf{x} = \mathbf{x}_A$ 

$$\Rightarrow P_e = Q(\sqrt{\frac{||\mathbf{x}_A - \mathbf{x}_B||^2}{4\sigma^2}})$$

$$= Q(\sqrt{\frac{||\sqrt{P}(2, 2, 2, ..., 2)||^2}{4\sigma^2}})$$

$$= Q(\sqrt{\frac{||4\sqrt{P}(1, 1, 1, ..., 1)||^2}{4\sigma^2}}) = Q(\sqrt{\frac{P}{\sigma^2} \sum_{i=1}^{N} 1}) = Q(\sqrt{\frac{NP}{\sigma^2}})$$

$$\approx e^{-\frac{NP}{\sigma^2}} \xrightarrow{N \to \infty} 0$$

> but

$$R(rate) = \frac{1}{N}$$



► M-PAM

$$\mathbf{x} = \sqrt{P}[q, q, ..., q], \quad q \in \{-(M-1), ..., -1, 1, 3, ..., M-3, M-1\}$$

> example: M=6

$$q \in \{-5, -3, -1, 1, 3, 5\}$$

Say

$$\begin{split} ||\mathbf{x}|| &\leq P N, \ \forall \mathbf{x} \\ &\Rightarrow ||\sqrt{P}\theta[5,5,..,5]||^2 \leq N P \\ &||\theta[5,5,...,5]||^2 \leq N \Rightarrow \theta = \frac{1}{M-1} \\ &\text{half distance between } \sqrt{P}\theta[1,1,1,...,1] \rightarrow \sqrt{P}\theta[-1,-1,...,-1] \end{split}$$

 $||\sqrt{P}\frac{1}{M-1}[1,1,1,...,1]||^2 = \frac{PN}{(M-1)^2}$ 



► Probability of error

$$\Rightarrow P_e = Q(\frac{\textit{half} - \textit{dist}}{\sigma_w}) = Q(\sqrt{\frac{\textit{PN}}{(\textit{M} - 1)^2}})$$

Reliable communications if

$$\Rightarrow (M-1)^2 < N \Rightarrow M < \sqrt{N}$$


Bound on rate

$$\Rightarrow R = \frac{\log M}{N} = \frac{\log \sqrt{N}}{N} \to 0$$



#### 1 Problem with repetition code:

- Repetition code packed every codeword onto single dimension
- ightharpoonup N-dimensional sphere. (N=2 here, but generally very large)



- ▶ But we have *N* dimensions
  - > Codewords must not be close because noise → error.
  - > Must decide on a distance between codewords
- Try to pack as many such spheres as possible
- ► A sphere packing problem in *N*-dim space



- ightharpoonup Packing sphere ightharpoonup to reach capacity.
- Sphere packing problem: pack max number of codewords in sphere of certain radius
- recall:

$$\mathbf{y} = \mathbf{x} + \mathbf{w}, \quad ||\mathbf{x}||^2 \le NP$$

▶ as  $N \to \infty$ 

$$\frac{1}{N} \sum_{i=1}^{N} ||\mathbf{w}_i||^2 \to \sigma^2 \Rightarrow ||\mathbf{w}||^2 \to N\sigma^2 \Rightarrow ||\mathbf{y}||^2 = ||\mathbf{x} + \mathbf{w}||^2 \leq NP + N\sigma^2$$

thus

$$||\mathbf{y}||^2 \le N(P + \sigma^2) \Rightarrow \mathbf{y} \in Ball(rad = \sqrt{N(P + \sigma^2)}), \text{ with } Prob \to 1$$

- Also given  $\mathbf{X}_A$  (transmit codeword) and given  $||\mathbf{w}|| \to \sqrt{N\sigma^2}$ , then
- **y** is on the periphery of a sphere, centered on  $\mathbf{X}_A$ , with radius  $\sqrt{N\sigma^2}$



- Try to pack max number of sphere of radius  $\sqrt{N\sigma^2}$  in a bigger sphere of radius  $\sqrt{N(P+\sigma^2)}$
- This max number is

$$\frac{\textit{Vol}(\textit{Ball}(\textit{rad} = \sqrt{\textit{N}(\textit{P} + \sigma^2)}))}{\textit{Vol}(\textit{Ball}(\textit{rad} = \sqrt{\textit{N}\sigma^2}))} \approx \frac{(\sqrt{\textit{N}(\textit{P} + \sigma^2)})^\textit{N}}{(\sqrt{\textit{N}\sigma^2})^\textit{N}} = (\frac{\textit{N}(\textit{P} + \sigma^2)}{\textit{N}\sigma^2})^{\frac{\textit{N}}{2}}$$

- ► Thus max rate  $R = \frac{1}{N} \log(\frac{N(P+\sigma^2)}{N\sigma^2})^{\frac{N}{2}} = \frac{1}{2} \log(1 + \frac{P}{\sigma^2})$
- ▶ The above is per <u>real</u> space. But we have complex space, thus

$$C = \log(1 + \frac{P}{\sigma^2})$$
 bits/complex dimension



1 Parenthetical: |11

- Cap gives the challenge.
- Codes : another Story
- Decoders : another story.
- People relatively happy with various practical codes
  - > turbo codes (interesting story)
  - > LPPC codes (also interesting story)
- Commonly used soft decoders (complicated).



- Capacity analysis helps us allocate resources
- ightharpoonup Total Power  $\bar{P}$  (Watts)
- ► Total bandwidth W (Hz)
- ▶ Thus  $\frac{\bar{P}}{W}$  (J/s/Hz) = (Watts/Hz)
- Noise:  $\sigma_w^2 = \frac{N_0}{2}$
- ► Sample at rate  $\frac{1}{W}$  gives

$$y[m] = x[m] + w[x]$$

- Complex baseband representation (two independent uses of the real channel)
- ▶  $\frac{N_0}{2}$  noise power per real symbol  $\Rightarrow N_0$  power of w[x]
- $ightharpoonup \frac{\bar{P}}{2W}$  power constraint per real symbol.



#### 1 Capacity-based resource allocation

$$C_{real} = \frac{1}{2} \log(1 + \frac{P_{real}}{\sigma_{real}^2}) = \frac{1}{2} \log(1 + \frac{\frac{\bar{P}}{W}}{\frac{N_0}{2}}) = \frac{1}{2} \log(1 + \frac{\bar{P}}{WN_0})$$

$$\Rightarrow C_{AWGN} = 2C_{real} = \log(1 + \frac{\bar{P}}{WN_0})$$

Consider  $SNR = \frac{\bar{P}}{WN_0}$  (note: SNR wrt complex dimension)

$$\Rightarrow C_{complex} = \log(1 + SNR)$$
 (bits/complex symbol)

- CAWGN: called spectral efficiency.
- Total capacity

$$C_{AWGN}(ar{P},W) = WC_{complex} = W \log(1+SNR) = W \log(1+rac{ar{P}}{WN_0}) \;\; bits/sec$$



► Recall

$$C(\bar{P}, w) = W \log(1 + \frac{\bar{P}}{WN_0})$$


- > Choose (invest in)  $\bar{P}$  and/or W
- ► Note:
  - > log is concave, i.e.,  $F''(SNR) \le 0$

>

$$\log(1+x) \approx x \log_2 e$$
, as  $x \to 0$ , (linear)


5

$$\log(1+x) \to \log(x)$$
, as  $x \to \infty$ , (logarithmic)





- ▶ low SNR:  $\bar{P} \uparrow \Rightarrow C \uparrow$  linearly  $\Rightarrow$  invest in  $\bar{P}$
- ▶ high SNR:  $\bar{P} \uparrow \Rightarrow C \uparrow$  logarithmically  $\Rightarrow$  do NOT invest in  $\bar{P}$





- ightharpoons Fix  $\bar{P}$
- C increasing function of W
- ▶ if  $W \text{ small} \Rightarrow \mathsf{SNR} \text{ large} \Rightarrow W \uparrow \Rightarrow \mathsf{log}(\cdot) \downarrow \mathsf{a} \text{ little}$

$$\Rightarrow W \log(\cdot) \uparrow \text{almost linearly} \Rightarrow \text{invest in} W \text{ (bandwidth limited)}$$

▶ if W large  $\Rightarrow$  SNR small

$$\Rightarrow \log(1+x) \downarrow \text{linearly} \Rightarrow \text{compensates for } W \uparrow \text{linearly}$$

$$W \log(1 + \frac{\bar{P}}{N_0 W}) \approx W \log_2 e \frac{\bar{P}}{N_0 W} = \log_2 e \frac{\bar{P}}{N_0}$$

 $\rightarrow$  do not invest in W, but invest in  $\bar{P}$  (linear increase) (power limited)




▶ Minimize  $\frac{E_b}{N_0}$ : Power efficient region  $\bar{P} \to 0$  (turns out)

$$(\frac{E_b}{N_0})_{\min} = \lim_{\bar{P} \to 0} \frac{\bar{P}}{N_0 C_{AWGN}(\bar{P}, W)} = \frac{\bar{P}}{N_0 W \log_2(1 + \frac{\bar{P}}{N_0 W})}$$

$$\approx \frac{\bar{P}}{N_0 W \log_2 e \frac{\bar{P}}{N_0 W}} = \frac{1}{\log_2 e}$$

$$\Rightarrow 10 \log_{10} \frac{1}{\log_2 e} = -1.59 dB$$

- > Minimum possible power to send a single bit
- > Orthogonal codes from Hadamard sequences





# Capacity of LTI Gaussian channels



► The SIMO channel (*L*-receive antennas)

$$y_{\ell}[\textbf{m}] = h_{\ell}x[\textbf{m}] + w_{\ell}[\textbf{m}], \quad \ell = 1,...,L, \quad w_{\ell} \sim \mathbb{C}N(0,N_0)$$

- > Channel vector  $\mathbf{h} = [h_1, ..., h_L]^T$  is fixed
- Capacity achieving policy: receive beamforming

$$\tilde{y}[m] = \frac{\mathbf{h}^{\dagger}}{||\mathbf{h}||} \mathbf{y}[m] = \frac{||\mathbf{h}^{\dagger}||^2}{||\mathbf{h}||} x[m] + \underbrace{\frac{\mathbf{h}^{\dagger}}{||\mathbf{h}||} \mathbf{w}[m]}^{AWGN \sigma^2 = 1}$$

- > x[m] from a capacity achieving AWGN code
- > Optimal since  $\tilde{y}[m]$  is sufficient statistic
- ► Thus

$$SNR = ||\mathbf{h}^{\dagger}||^2 \frac{P}{N_c}, \quad E[||x[m]||^2] \leq P \quad (Watts/symbol)$$

► Thus capacity takes form

$$C_{\mathsf{SIMO}} = \log(1 + \frac{P}{N_0}||\mathbf{h}||^2)$$



► The MISO channel (*L*-transmit antennas)

$$y[m] = \mathbf{h}^T \mathbf{x}[m] + w[m], \quad w[m] \sim \mathbb{C}N(0, N_0), \quad \mathbf{h} = [h_1, ..., h_L]^T$$
 fixed

 Capacity achieving policy: transmit beamforming optimal (proof skipped)

$$\mathbf{x}[m] = \frac{\mathbf{h}^T}{||\mathbf{h}||} \tilde{\mathbf{x}}[m]$$

- $\tilde{x}[m]$  from opt. AWGN code.  $E[||\tilde{x}[m]||^2] \leq P$
- ► Thus

$$y[m] = ||\mathbf{h}||\tilde{x}[m] + w[m]$$

► Thus MISO capacity is

$$C_{tx-beam} = C_{MISO} = \log(1 + \frac{P||\mathbf{h}||^2}{N_0})$$
 bits/s/Hz



$$y[m] = \sum_{\ell=0}^{L-1} h_{\ell}[m-\ell] + w[m], \quad E[|x[m]|^2] \le P \quad (1)$$

- > L taps (convolution)
- ▶ Solution: Convert to  $N_c$  parallel channels ( $N_c$  info symbols + L taps)
- ▶ ith block

$$\tilde{y}_n[i] = \tilde{h}_n \tilde{d}_n[i] + \tilde{w}_n[i] \quad n = 0 \rightarrow N_c - 1 \quad (2)$$

$$\begin{split} \tilde{\mathbf{d}}[i] &= [\tilde{d}_0[i] \to \tilde{d}_{N_c-1}[i]], \quad \text{DFT of input of } i\text{th block}, ||\tilde{\mathbf{d}}[i]||^2 \leq N_c P \text{ (Par } \tilde{\mathbf{w}}[i] &= [\tilde{w}_0[i] \to \tilde{w}_{N_c-1}[i]], \quad \text{DFT of noise: } \tilde{\mathbf{w}}[i] \sim \mathbb{C}N(0, N_0 I) \\ \tilde{\mathbf{y}}[i] &= [\tilde{y}_0[i] \to \tilde{y}_{N_c-1}[i]], \quad \text{DFT of output of } i\text{th block (after some remove } \tilde{\mathbf{h}}_{1 \times N_c} &= [\tilde{h}_0 \to \tilde{h}_{N_c-1}]^T = \mathbf{F}_{fourier}\mathbf{h}, \quad (N_c - \text{point DFT}) \end{split}$$

ightharpoonup As  $N_c o \infty \Rightarrow N_c \gg L$ 

$$\Rightarrow \ C_{(1)} \approx C_{(2)}$$




### 1 Frequency Selective (and parallel) channels


 Power allocation, then use capacity-achieving code over each parallel channel

$$C_{N_c} = \max_{P_0 \to P_{N_c-1}} \sum_{n=0}^{N_c-1} \log(1 + \frac{P_n |\tilde{h}_n|^2}{N_0}), \quad s.t. \ \sum_{n=0}^{N_c-1} P_n = N_c P, \ P_n \ge 0, \forall n$$

▶ Optimal  $\{P_n\}$  via water-filling (y-axis is  $\frac{N_0}{|\tilde{h}_n|^2}$ )







- ▶ Write Lagrangian  $\mathcal{L}(\lambda) = \sum_{n=0}^{N_c-1} \log(1 + \frac{P_n|\tilde{h}_n|^2}{N_0}) \lambda \sum_{n=0}^{N_c-1} P_n$
- ► Then evaluate  $\frac{\delta \mathcal{L}}{\delta P_n} = \begin{cases} 0 & \text{if } P_n > 0 \\ \leq 0 & \text{if } P_n = 0 \end{cases}$
- Optimal power

$$P_n^* = \left(\frac{1}{\lambda} - \frac{N_0}{|\tilde{h}_n|^2}\right)^+, \text{ where } \lambda : \sum_{n=0}^{N_c-1} \underbrace{\left(\frac{1}{\lambda} - \frac{N_0}{|\tilde{h}_n|^2}\right)^+}_{P_n^*} = PN_c$$

- ► Coding across parallel channels does not improve capacity (turns out)
  - > but gives better performance if block length is small



2 Outline |24

- Wireless Channels (AWGN and LTI)
- 2 Fading channels (epsilon, CSIT, freqSelec) Capacity of fading channels
- Multi-user Capacity



# Capacities of Fading Channels



Fading channel

$$y[m] = h[m]x[m] + w[m], \quad w[m] \sim \mathbb{C}N(0, N_0), \quad SNR = \frac{P}{N_0}$$

- ▶ h randomly drawn, with  $E[|h[m]|^2] = 1$
- For now only CSIR (No CSIT)
- Slow fading "channel randomly drawn but here to stay"

$$\Rightarrow y[m] = hx[m] + w[m], \Rightarrow SNR_{Rx} = |h|^2 SNR$$
$$C(h) = \log(1 + SNR|h|^2)$$

- ▶ No lower-limit ( $C(h) \rightarrow 0$  maybe) (NO CSIT)
- Consider outage event



...Consider outage event

Error 
$$\iff$$
 Capacity(h) < Rate

- ▶ Need another measure: P(C(h) < R) = P(outage)
  - > applies when R is fixed

$$P_{out}(R) = P(\log(1 + SNR|h|^2) < R) \Rightarrow P(|h|^2 < \frac{2^R - 1}{SNR})$$

> Note

$$P(|h|^{2} < \epsilon) \xrightarrow{\epsilon \to 0} \epsilon$$

$$\Rightarrow P_{out}(R) = P(|h|^{2} < \frac{2^{R} - 1}{SNR}) \xrightarrow{SNR \to \infty} \frac{2^{R} - 1}{SNR}$$

$$\Rightarrow P_{out}(R) \to \frac{1}{SNR}$$



ightharpoonup Another measure of interest -  $\epsilon$ -outage capacity

$$y = hx + w$$

Recall probability of outage

$$P_{out}(R) = P(\log(1 + \rho |h|^2) < R) = P(|h|^2 < \overbrace{\frac{2^R - 1}{\rho}}) = \epsilon$$

▶ Definition:  $\epsilon$ -outage capacity

$$C_{\epsilon} = \max_{R} : P_{out}(R) \le \epsilon$$



ightharpoonup Evaluate  $C_{\epsilon}$  for any SNR

Let 
$$x \triangleq \frac{2^R - 1}{\rho} \Rightarrow P(|h|^2 < x) = \epsilon \Rightarrow P(|h|^2 \ge x) = 1 - \epsilon$$

and denote

$$F(x) \triangleq P(|h|^2 > x) \Rightarrow F(x) = 1 - \epsilon \Rightarrow x = F^{-1}(1 - \epsilon)$$
$$\Rightarrow \frac{2^R - 1}{\rho} = F^{-1}(1 - \epsilon) \Rightarrow 2^R = 1 + \rho F^{-1}(1 - \epsilon)$$

► Thus

$$C_\epsilon = \log(1 + \mathit{SNR} \cdot \mathit{F}^{-1}(1 - \epsilon))$$



We have

$$C_\epsilon = \log(1 + \mathit{SNR} \cdot F^{-1}(1 - \epsilon))$$

At high SNR

$$C_{\epsilon} pprox \log(\mathsf{SNR} \cdot \mathsf{F}^{-1}(1-\epsilon)) = \log \mathsf{SNR} + \log(\mathsf{F}^{-1}(1-\epsilon))$$

► Thus

$$C_{\epsilon} = \log \mathit{SNR} - \overbrace{\log(rac{1}{F^{-1}(1-\epsilon)})}^{\mathsf{constant offset}}$$



► Low SNR

$$C_{\epsilon} pprox \log_2 eSNR \cdot F^{-1}(1-\epsilon)) pprox F^{-1}(1-\epsilon)C_{AWGN}$$

For Rayleigh fading

$$P(|h|^2 < \epsilon) \approx \epsilon \implies P(|h|^2 > \epsilon) \approx 1 - \epsilon \Rightarrow F(\epsilon) \approx 1 - \epsilon \Rightarrow F^{-1}(1 - \epsilon) \approx \epsilon$$

$$C_{\epsilon} \approx \epsilon SNR \approx \epsilon C_{AWGN}$$

▶ Big problem: Example

$$\epsilonpprox1\%
ightarrow\mathcal{C}_{\epsilon}pproxrac{\mathcal{C}_{AWGN}}{100}$$

► Thus diversity is important



▶ Consider SIMO ( $R_{x^-}$  diversity) to boost  $C_{\epsilon}$  at low SNR

$$P_{out}(R) = P(\log(1+\rho|\mathbf{h}|^2) < R) \xrightarrow{\rho \to 0} P(\log_2 e \cdot SNR \cdot |\mathbf{h}|^2 < R)$$

$$\Rightarrow P_{out}(R) \approx P(|\mathbf{h}|^2 < \overbrace{\frac{R}{SNR \cdot \log_2 e}}) \xrightarrow{\text{want}} \epsilon$$

$$P_{out}(R) \approx P(|h_0|^2 < \frac{R}{SNR}, ..., |h_{L-1}|^2 < \frac{R}{SNR}) = \left(P(|h_0|^2 < \frac{R}{SNR})\right)^L = \epsilon$$

$$\Rightarrow P(|h_0|^2 < \frac{R}{SNR}) = \epsilon^{\frac{1}{L}} =: \delta$$

$$\Rightarrow \frac{R}{SNR} = \delta \quad (\text{since } P(|h_0|^2 < \delta) \approx \delta)$$

$$\frac{R}{SNR} = \epsilon^{\frac{1}{L}} \Rightarrow R = \epsilon^{\frac{1}{L}} SNR \Rightarrow C_{\epsilon} = \epsilon^{\frac{1}{L}} C_{AWGN}$$



$$y_{0}[m] = h_{0}x_{0}[m] + w_{0}[m]$$

$$\vdots$$

$$y_{L-1}[m] = h_{L-1}x_{L-1}[m] + w_{L-1}[m]$$

$$C(\mathbf{h}) = \sum_{\ell=0}^{L-1} \log(1 + |h_{\ell}|^{2}SNR) \to 0$$

$$P_{out}(R) = P\left(\frac{1}{L}\sum_{\ell=0}^{L-1} \log(1 + |h_{\ell}|^{2}SNR) < R\right)$$

▶ Fast Fading:  $T_{code} \gg T_c$   $\Rightarrow L \rightarrow \infty$ 

$$\frac{1}{L} \sum_{\ell=0}^{L-1} \log(1 + |h_{\ell}|^2 SNR) \to E_{\mathbf{h}}[\log(1 + |h|^2 SNR)]$$

► Fast-fading (ergodic) capacity

$$C_{FF} = E_h\{\log(1+|h|^2SNR)\}$$



▶ Employ Jensen's inequality  $E\{f(u)\} \le f(E\{u\})$ 

$$E_h\{\log(1+
ho|h|^2)\} = \log(1+
ho E\{|h|^2\}) \Rightarrow C_{FF} \leq C_{AWGN}$$

- But generally very close
- Low SNR:

$$C_{FF} = E\{\log(1+\rho|h|^2)\} \approx E\{\log_2 e\rho|h|^2\} = \log_2 e\rho E\{|h|^2\} = C_{AWGN}$$

High SNR:

$$C_{FF} \approx E\{\log(\rho|h|^2)\} = \log \rho + E\{\log|h|^2\} \approx C_{AWGN} - 0.83$$



- TDD reciprocity, FDD feedback (expensive)
- ▶ Slow fading: could do channel inversion, or rate adaptation i.e

$$\log(1 + \frac{P_t}{N_0}|h|^2) < R_t$$

 $\Rightarrow$  change  $R_t$  or  $P_t$  (When bad channel)



► Fast Fading: Waterfilling

$$y_{0} = h_{0}x_{0} + w_{0}$$

$$y_{1} = h_{1}x_{1} + w_{1}$$

$$\vdots$$

$$y_{L-1} = h_{L-1}x_{L-1} + w_{L-1}$$

$$\Rightarrow \max_{P_{0} \to P_{L-1}} \frac{1}{L} \sum_{\ell=0}^{L-1} \log(1 + \frac{P_{\ell}}{N_{0}} |h_{\ell}|^{2}), \qquad \sum P_{\ell} = LP$$

Seen

$$P_{\ell}^* = (\frac{1}{\lambda} - \frac{N_0}{|h_{\ell}|^2})^+, \text{ for } \lambda : \frac{1}{L} \sum_{\ell=0}^{L-1} (\frac{1}{\lambda} - \frac{N_0}{|h_{\ell}|^2})^+ = P$$



► Causality an issue, BUT for large *L* 

$$\frac{1}{L} \sum_{\ell=0}^{L-1} (\frac{1}{\lambda} - \frac{N_0}{|h_{\ell}|^2})^+ \to E\{(\frac{1}{\lambda} - \frac{N_0}{|h|^2})^+\}$$

$$\Rightarrow P_{\ell}^*(\mathbf{h}) = (\frac{1}{\lambda} - \frac{N_0}{|h_{\ell}|^2})^+ \text{ for } \lambda : E\{(\frac{1}{\lambda} - \frac{N_0}{|h_{\ell}|^2})^+\} = P$$

$$\Rightarrow C = E\{\log(1 + P^*(h)\frac{|h|^2}{N_0})\}$$


In the end: For most SNR

$$C_{AWGN} \approx C_{FF} \approx C_{CSIT}$$

ightharpoonup except (in theory) at low SNR where  $C_{CSIT} >> C_{AWGN}$  WARNING!!



▶ Send only if  $|h[m]|^2 \approx G_{max}$ , and store power while not sending



$$C pprox Pigg(|h|^2 pprox G_{\sf max}igg) \logig(1 + rac{G_{\sf max}SNR}{Pig(|h|^2 pprox G_{\sf max}ig)}ig) pprox G_{\sf max}
ho \log_2 e pprox G_{\sf max}C_{AWGN}$$

► Would not work in practice!!




3 Outline | 39

- Wireless Channels (AWGN and LTI)
- Pading channels (epsilon, CSIT, freqSelec)
- 3 Multi-user Capacity



► Up-link AWGN (multiple-access channel)



$$y[m] = x_1[m] + x_2[m] + w[m]$$

- $E\{|x_k[m]|^2 = P_k, k = 1, 2, w[m] \sim \mathbb{C}\mathcal{N}(0, N_0) \text{ iid}$
- ightharpoonup Capacity region: Best possible  $R_1$ ,  $R_2$ . First derive outer bounds:

$$R_1 < \log(1+rac{P_1}{N_0})$$
 
$$R_2 < \log(1+rac{P_2}{N_0}) \quad \text{single user bounds}$$

$$R_1 + R_2 < \log(1 + \frac{P_1 + P_2}{N_2})$$
, MISO bound with fixed  $h_1 = h_2 = 1$ 

$$E\{|x|^2\} = P_1 + P_2$$
, where  $x = [x_1, x_2]^T$ .



- Let us achieve these outer bounds.
- ▶ Use capacity-achieving codes for  $x_1[m]_{m=1}^{\dots}$ ,  $x_2[m]_{m=1}^{\dots}$
- ▶ First  $R_x$  decodes message of user 2  $(x_2)$  by treating  $x_1$  as noise:

$$\Rightarrow R_2 = \log(1 + \frac{P_2}{P_1 + N_0})$$

Now  $x_2$  removed from y to decode  $x_1$  without interference


$$\Rightarrow R_1 = \log(1 + \frac{P_1}{N_0})$$
 naturally optimal

but note that

$$R_1 + R_2 = \log[1 + \frac{P_1}{N_0}] + \log[1 + \frac{P_2}{P_1 + N_0}] = \log[1 + \frac{P_1 + P_2}{N_0}]$$

is again optimal


but if  $R_1$  is optimal &  $R_1 + R_2$  is optimal then  $R_2$  is also optimal.



- ► To achieve point  $A = [log(1 + \frac{P_1}{N_0}), log(1 + \frac{P_2}{P_1 + N_0})]$ 
  - > decode  $x_2$  first by treating  $x_1$  as noise  $\log(1 + \frac{P_2}{P_1 + N_0})$
  - > Remove  $x_2$  and decode  $x_1$  without interference
- Similarly (reverse order) for point  $B = [\log(1 + \frac{P_1}{P_2 + N_0}), \log(1 + \frac{P_2}{N_0})]$ 
  - > decode  $x_1$  first by treating  $x_2$  as noise  $\log(1 + \frac{P_1}{P_2 + N_0})$
  - $\rightarrow$  Remove  $x_1$  and decode  $x_2$  without interference
- ► Line AB contains all optimal points (optimal sum-rate)
- ▶ Example  $P_1 = P_2 = 1$



ightharpoonup Considering the non-symmetric setting, say  $P_1 >> P_2$ .




- Whom should we decode first?
  - decode strongest first (small interference from weaker)
  - > then fully decode weaker (point B)
  - > Slightly bother U1, no interference for U2 (Reverse would kill U2)
- Strong users close to BS transmit fast, with no trouble to rest
  - > No power control. Turns near-far issue into advantage.



▶ Orthogonal Multiple access techniques Optimal?  $(\alpha, 1 - \alpha)$ 

$$R_1 = \alpha W \log(1 + \frac{P_1}{\alpha N_0}), \quad R_2 = (1 - \alpha) W \log(1 + \frac{P_2}{(1 - \alpha)N_0}) \text{ bits/s}$$

- ▶  $\exists$  only one optimal  $\alpha$  :  $\alpha = \frac{P_1}{P_1 + P_2}$  that achieves opt sum-capacity
  - Penalizes weak users  $(P_1 \gg P_2 \Rightarrow \alpha \approx 1, \Rightarrow 1 \alpha \approx 0)$
  - > Logarithmic increase vs. linear decrease
  - > Giving high rate to weak user  $\Rightarrow$  entirely sacrifice rate for strong user
  - > Example  $P_2 = 0dB, P_1 = 20dB$ .





$$ightharpoonup$$
 for  $P_i = P_i = P$ 


$$C_{sum} = \log(1 + \frac{kP}{N_0})$$

$$C_{\text{sym}} = rac{1}{k} \log(1 + rac{kP}{N_0})$$
 max rate when all have the same rate

- ▶ achievable with ?? (say k=2 ,  $\alpha = \frac{1}{2}$  ,  $\alpha \log(1 + \frac{P}{\alpha N_0})$  ,  $(1 \alpha) \log(1 + \frac{P}{(1 \alpha)N_0})$  under equal received power
- OFDM ¿ CDMA , CDMA treats all others as noise

$$C_{sum} = k \log(1 + \frac{P}{(k-1)P + N_0}) \approx k \frac{P}{(k-1)P + N_0} \log_2 e \approx l \log_2 e \approx 1.44$$
 
$$\log(1 + \frac{kP}{N_0}) \uparrow \infty$$

- $y_k[m] = h_k \quad x[m] + w_k[m] \quad k = 1?? ?? \text{ k fixed }$
- ▶ assume CSTIR  $|X[m]|^2 \le P$   $\frac{Joules}{symbol}$
- ightharpoonup Capacity region  $R_1, R_2$
- lacksquare  $R_k \leq \log(1+rac{P|h_k|^2}{N_0})$  all power for user K and rate





$$X[m] = X_1[m] + X_2[m] \quad \textit{iid Gaussian codes}$$
 
$$R_1 = \log(1 + \frac{P_1|h_1|^2}{P_2|h_1|^2 + N_0}) = \log(1 + \frac{(P_1 + P_2)|h_1|^2}{N_0}) - \log(1 + \frac{P_2|h_2|^2}{N_0})$$
 
$$R_2 = \log(1 + \frac{P_2|h_2|^2}{N_0})$$



3 AWGN

► User 2 can decode anything ??/


$$x=x_1+x_2$$
  $R_1=\log(1+rac{P_1|h_1|^2}{|h_1|^2P_2+N_0})$  weakerseesinterference  $R_2=\log(1+rac{P_2|h_2|^2}{N_0})$  userseesnointerference

▶ first, decode user 1 data and then Which is generally better than ?? (for all power splits  $P_1 + P_2 = P$ )

$$R_1 = \alpha \log(1 + \frac{P_1|h_1|^2}{\alpha N_0})$$
  $R_2 = (1 - \alpha)\log(1 + \frac{P_2|h_2|^2}{(1 - \alpha)N_0})$ 



3 AWGN | 50



► In General

$$R_k = \log(1 + \frac{P_k |h_k|^2}{N_0 + \sum_{J=k+1}^K P_J |h_k|^2}) \quad P = \sum_{k=1}^K p_k$$

 $\triangleright$  sum capacity here (unlike uplink which all user  $R_x$ )



3 MIMo |51

Have seen that for parallel channel

$$y_1 = h_1 x_1 + w_1$$

$$y_2 = h_2 x_2 + w_2$$

$$R = \log(1+??|h_1|^2) + \log(1+??|h_2|^2) = \log[(1+??|h_1|^2)(1+??|h_2|^2)]$$

$$\binom{y_1}{y_2} = \binom{h_1 \quad 0}{0 \quad h_2} \times \binom{x_1}{x_2} + \binom{w_1}{w_2}$$

$$= \log \det[I_2 + ?? \binom{h_1 \quad 0}{0 \quad h_2} \times \binom{h_1 \quad 0}{0 \quad h_2}^H]$$

Consider the mimo channel

$$\begin{pmatrix} y_1 \\ y_2 \end{pmatrix} = H\underline{x} + \underline{w} = u. \begin{pmatrix} y_1 \\ y_2 \end{pmatrix} u^H\underline{x} + \underline{w}$$
$$\begin{pmatrix} y_1' \\ y_2' \end{pmatrix} = \begin{pmatrix} h_1 & 0 \\ 0 & h_2 \end{pmatrix} \times \underline{x}' + w$$

in General, Mimo capacity is in order of (higher SNR)

$$\log det[I_{n_r}+??HH^H]$$

