

# **Essential Mathematical Methods for Engineers**

Lecture 3: Sampled data systems and the z-transform


#### **Outline**

- analogue and digital processing
- sampled data systems and aliasing
  - sampling theorem the Nyquist criterion
  - practical sampled data systems
- the z-transform
  - the inverse z-transform
  - delay theorem
- digital filters and discrete convolution
- poles and stability
- frequency response of a digital filter
- example of a complete system





an analogue filter x(t)Analogue
filter x(t)Analogue
filter y(t)Analogue
D/A = digital to analogue converter

an alternative discrete or sampled data system




its mathematical model












- analogue output from DAC
- digitisation involves
  - sampling and
  - quantisation



- the input / output characteristic for a 4-bit quantiser
  - quantisation noise





- for analysis and design we use the third model from slide 3 x(t)
- x(t) is multiplied by a periodic impulse train with period  $\Delta t$



- the output is also an impulse train
- y(t) is obtained from  $y_c(t)$  via a ZOH filter whose impulse response is

$$h_{ZOH}(t) = \begin{cases} 1, & 0 \le t < \Delta t \\ 0, & \text{otherwise} \end{cases}$$





#### the sampled signal:

$$x_{c}(t) = x(t) \, \delta_{T}(t)$$

$$= x(t) \left[ \, \delta(t) + \delta(t - \Delta t) + \delta(t - 2\Delta t) + \dots + \, \right]$$

$$= x(t) \, \delta(t) + x(t) \, \delta(t - \Delta t) + x(t) \, \delta(t - 2\Delta t) + \dots$$

$$= x(0) \, \delta(t) + x(\Delta t) \, \delta(t - \Delta t) + x(2\Delta t) \, \delta(t - 2\Delta t) + \dots$$

$$= \sum_{n} x(n\Delta t) \, \delta(t - n\Delta t)$$

• the ZOH is a linear filter so the output y(t) is given by

$$y(t) = h_{ZOH}(t) * y_c(t)$$


$$= h_{ZOH}(t) * \sum_{n} y(n\Delta t) \delta(t - n\Delta t)$$


$$= \sum_{n} y(n\Delta t) [h_{ZOH}(t) * \delta(t - n\Delta t)]$$

$$= \sum_{n} y(n\Delta t) h_{ZOH}(t - n\Delta t)$$

 the frequency response of the ZOH is obtained by taking the Fourier transform of its impulse response

$$H_{ZOH}(\omega) = F[h_{ZOH}(t)]$$
  
=  $\Delta t \exp\left(-\frac{j\omega\Delta t}{2}\right) \operatorname{sa}\left(\frac{\omega\Delta t}{2}\right)$ 





- note that the versions of x(t) and y(t) on slides 4-5 and 7-8 are identical the models are equivalent
- to analyse the effect of sampling on the signal fidelity we consider a DSP which copies data from the A/D filter to the D/A filter without modification
- the sampled signal is given by

$$x_c(t) = x(t) \delta_T(t)$$

and in the frequency domain


$$X_c(\omega) = F[x_c(t)] = \frac{1}{2\pi} X(\omega) * F[\delta_T(t)]$$


the Fourier transform of the impulse train

$$\delta_T(t) = \sum_{n=-\infty}^{\infty} \delta(t - n\Delta t)$$

is

$$F[\delta_T(t)] = \frac{2\pi}{\Delta t} \sum_n \delta \left( \omega - \frac{2\pi n}{\Delta t} \right)$$






 moving the pulses closer together in the time domain increases the separation in the frequency domain


now 
$$X_c(\omega) = \frac{1}{\Delta t} X(\omega) * \sum_n \delta \left( \omega - \frac{2\pi n}{\Delta t} \right)$$
  

$$= \frac{1}{\Delta t} \sum_n X(\omega) \delta \left( \omega - \frac{2\pi n}{\Delta t} \right) = \frac{1}{\Delta t} \sum_n X \left( \omega - \frac{2\pi n}{\Delta t} \right)$$

- the Fourier transform of the analogue signal is assumed to be triangular with maximum frequency component  $\omega_m$
- the Fourier transform of the sampled signal is obtained by convolving the impulse at  $\omega = 0$  to form the primary component at  $\omega = 0$  in  $X_c(\omega)$
- $X(\omega)$  is convolved with the impulse at the sampling frequency  $\omega=2\pi/\Delta t$  rad/s to produce a secondary component at  $\omega=2\pi/\Delta t$  rad/s
- this is repeated for all impulses




•  $X_c(\omega)$  is a periodic function of  $\omega$  with period  $2\pi/\Delta t$ 



- for this example the sampling rate in rad/s  $(2\pi/\Delta t) >> \omega_m$
- is it possible to reconstruct x(t) from  $x_c(t)$ ?
  - the original signal is recovered by passing  $x_c(t)$  through an ideal low-pass filter (LPF) with frequency response  $H_L(\omega)$ , i.e.

$$X(\omega) = H_L(\omega) X_c(\omega)$$


the LPF isolates the primary component





 $X_c(\omega)$ 


 considering a 'just adequate' sampling rate where

$$\frac{2\pi}{\Delta t} = 2\omega_m$$













when the sampling rate is too low the images of  $X(\omega)$  and  $X_c(\omega)$ overlap and we obtain a distorted version of  $X(\omega)$  at the LPF output


#### » ALIASING












### Sampling theorem – the Nyquist criterion

- in the last example the maximum frequency present in the analogue signal was greater than half the sampling frequency
- the sampling theorem states that to prevent aliasing distortion, a bandlimited signal of bandwidth  $\omega_B$  rad/s must be sampled at a rate of at least  $2\omega_B$  rad/s
- a perfect reconstruction is not possible in practice
  - it is impossible to construct an ideal LPF from a finite number of components
  - the frequency response  $H_{ZOH}(\omega)$  of the D/A converter is far from ideal
- in practice
  - reconstruction filters with nominal cut-off  $1/(2\Delta t)$  Hz
  - anti-aliasing filter to attenuate components above half the sampling frequency



- in the analysis and design of discrete-time digital systems the z-transform replaces the Laplace transform
- starting with

$$x_c(t) = \int_{n=0}^{\infty} x(n\Delta t) \delta(t - n\Delta t) \exp\left(-\varsigma t\right)$$

and taking Laplace transforms

$$X_c(s) = L[x_c(t)]$$

$$= \sum_{n=0}^{\infty} x(n\Delta t) \exp(-n\Delta ts)$$

• problems arise for the inverse transform because  $X_c(s)$  is periodic

$$X_c(s) = X_c \left( s + \frac{2\pi j}{\Delta t} \right)$$


•  $X_c(s)$  cannot have an infinite number of poles

s-plane		jω		
			$5\pi/\Delta t$	
		D <b>x</b>		
			$3\pi/\Delta t$	
		В *		
			$\pi/\Delta t$	
		A ×		
			0	σ
		C×	$-\pi/\Delta t$	
			$-3 \pi/\Delta t$	
			-5 π/Δ <i>t</i>	

• the solution is to make a simple substitution  $z = \exp(\Delta t \ s)$ 

and can be viewed as a

- mapping of all points in the s-plane to points in a z-plane
- short-hand notation to save writing many exp terms



defining the z-transform  $X(z) = X_c(s) \mid_{\exp(\Delta t \ s \ ) = z}$   $= \sum_{n=0}^{\infty} x(n\Delta t) z^{-n}$ 

- it can be summarised as
  - the analogue signal, x(t), is sampled by multiplying it by the impulse train  $\delta_T(t)$  to give  $x_c(t)$   $x_c(t) = x(t) \ \delta_T(t)$
  - take the Laplace transform of  $x_c(t)$  to give  $X_c(s) = L[x_c(t)]$
  - replace  $\exp(\Delta t s)$  by z in  $X_c(s)$  to get  $X(z) = X_c(s) \mid_{\exp(\Delta t \ s) = z}$
- alternatively if only a sequence of numbers  $\{x(n\Delta t)\}$  exists where  $n=0,1,2,\ldots$  the z-transform is defined as

$$X(z) = Z[ \{ x(n\Delta t) \} ]$$
$$= \sum_{n=0}^{\infty} x(n\Delta t) z^{-n}$$

#### **Example**


Evaluate the z-transform of a unit pulse  $\delta(n\Delta t)$ : The unit pulse is a discrete sequence with a single sample of value one at time zero.



$$x(n\Delta t) = 1 \quad n = 0$$
$$0 \quad n \neq 0$$

#### **Example**

Evaluate the z-transform of a unit step. A discrete step is a sampled version of the analogue or continuous step.




$$x(n\Delta t) = 1; \quad n \ge 0$$
$$= 0; \quad n < 0$$

$$\sum_{n=0}^{\infty} c^n = \frac{1}{1-c} \quad \text{provided} \quad |c| < 1$$

#### **Example**

Evaluate the z-transform of a sampled exponential.



$$x(n\Delta t) = \exp(-\alpha n\Delta t); n \ge 0$$

#### The inverse z-transform

from the forward transform

$$X(z) = Z[\{x(n)\}]$$
$$= \sum_{n=0}^{\infty} x(n)z^{-n}$$

where  $\Delta t$  has been removed to simplify the notation since it does not affect the summation

the inverse transform may be obtained by taking partial fraction expansions and using a look-up table

$${x(n)} = Z^{-1}[X(z)]$$

#### The inverse z-transform

#### **Example**

The following is a typical example of the type of transform which might be encountered in analysing or designing a sampled data system:

$$X(z) = \frac{3 - \frac{5}{2} z^{-1}}{1 - \frac{3}{2} z^{-1} + \frac{z^{-2}}{2}}$$

$$= \frac{3z^2 - \frac{5}{2} z}{(z^2 - \frac{3}{2} z + \frac{1}{2})}$$

Develop an expression for the nth time sample x(n).

#### The inverse z-transform

#### **Example**

What is the inverse z-transform of  $X(z) = 1 + 2z^{-1} + 3z^{-2}$ ?

## The delay theorem

if we know the z-transform of a sequence


$$Z[ \{ x(n) \} ] = X(z)$$

then the z-transform of the sequence delayed by one sample is

$$Z[ \{ x(n-1) \} ] = z^{-1} X(z)$$


- easy to implement on a microprocessor with clock period  $\Delta t$ 
  - $-z^{-1}$  is often called the delay operator
    - can be extended to two samples etc...

$$Z[ \{ x(n-2) \} ] = z^{-2} X(z)$$



- easily implemented on a DSP
- possible to describe in one of three ways:

$$y(n) = a \ y(n-1) + x(n)$$
  
difference equation



1 read x
y = a \* y + x
write y
go to line 1

pseudo code

- the z-transform can be used for digital filter analysis
  - e.g. a filter with difference equation

$$y(n) = a_0 x(n) + a_1 x(n-1) + a_2 x(n-2) + b_1 y(n-1) + b_2 y(n-2)$$

taking z-transforms of both sides we have

$$Y(z) = Z [ \{ y(n) \} ]$$


$$= a_0 X(z) + a_1 z^{-1} X(z) + a_2 z^{-2} X(z) + b_1 z^{-1} Y(z) + b_2 z^{-2} Y(z)$$

- and by collecting terms in Y(z) and X(z)

$$Y(z) [1 - b_1 z^{-1} - b_2 z^{-2}] = X(z) [a_0 + a_1 z^1 + a_2 z^{-2}]$$

hence the transfer function is given by

$$H(z) = \frac{Y(z)}{X(z)} = \frac{a_o + a_1 z^{-1} + a_2 z^{-2}}{1 - b_1 z^{-1} - b_2 z^{-2}}$$



the general form of the difference equation is given by

$$y(n) = \sum_{i=0}^{N-1} a_i \ x(n-i) + \sum_{i=1}^{M} b_i \ y(n-i)$$

and again taking z-transforms leads to the general form of the transfer function N = 1

$$H(z) = \frac{\sum_{i=0}^{N-1} a_i z^{-i}}{1 - \sum_{i=1}^{M} b_i z^{-i}}$$

- the feedforward and feedback sections influence the impulse response
  - stability issues

- in summary:
  - if  $b_i = 0$  for all values of i, the filter is the finite impulse response (FIR)
  - if any  $b_i \neq 0$ , the filter is the infinite impulse response (IIR)
- to calculate the output of a filter with a given transfer function to an input sequence {x(n)}
  - take the z-transform of the input sequence

$$X(z) = Z[ \{ x(n) \} ]$$

multiply by the transfer function

$$Y(z) = H(z) X(z)$$

take the inverse z-transform

$$\{ y(n) \} = Z^{-1} [ Y(z) ]$$

#### **Example**

A sequence where  $x(n) = 0.2^n$ ,  $n \ge 0$  is applied to a digital filter with difference equation y(n) = 0.5y(n-1) + x(n). Use transform techniques to develop an expression for the output y(n).

#### Digital filters and discrete convolution

#### **Discrete convolution**

 the time-domain description of a discrete-time linear system (digital filter) has two equivalent forms

$$y(n) = \sum_{m=0}^{\infty} x(m) h(n-m)$$

$$y(n) = \sum_{m=0}^{\infty} h(m) x(n-m)$$


$$\{ y(n) \} = \{ h(n) \} * \{ x(n) \}$$

this is discrete-time convolution

# Digital filters and discrete convolution Discrete convolution

#### **Example**

A sequence  $\{1, 2, 3\}$  is applied to an FIR filter with transfer function  $1 + 0.5z^{-1} + 0.25z^{-2}$ . Use discrete convolution to evaluate the output.



#### Poles and stability

- the position of the poles and zeros of a digital filter influence the stability
- consider a system with two poles,  $p_1 = r \exp(j\phi)$  and  $p_2 = r \exp(-j\phi)$  where the transfer function is given by

$$H(z) = \frac{z}{(z - r e^{j\phi})(z - r e^{-j\phi})}$$

making a partial fraction expansion

$$\frac{H(z)}{z} = \frac{A}{(z - r e^{j\phi})} + \frac{B}{(z - r e^{-j\phi})}$$

$$H(z) = \frac{Az}{(z - r e^{j\phi})} + \frac{Bz}{(z - r e^{-j\phi})}$$

#### Poles and stability

and taking inverse z-transforms

$$h(n) = A (r e^{j\phi})^n + B (r e^{-j\phi})^n$$

$$= \frac{r^n e^{j\phi n}}{2j r \sin \phi} - \frac{r^n e^{-j\phi n}}{2j r \sin \phi}$$


$$= \frac{r^{n-1}}{\sin \phi} \left\{ \frac{e^{j\phi n} - e^{-j\phi n}}{2j} \right\} = \frac{r^{n-1}}{\sin \phi} \sin(\phi n)$$

thus the unit pulse or impulse response is given by

$$h(n) = \frac{r^{n-1}}{\sin \phi} \sin(\phi n)$$


- the response will decay to zero if r < 1
  - r is just the distance of the pole from the origin in the z-plane

### Poles and stability



#### Recap

 for continuous signals, the Laplace transform and the s-plane we had the following responses




#### Recap

the simple substitution

$$z = \exp(\Delta t \ s)$$

and can be viewed as a mapping of all points in the s-plane to points in the z-plane



the relationship between the Laplace transform of a sampled signal and the z-transform:

$$X_c(s) = X(z)|_{z = e^{\Delta t s}}$$

• the Fourier transform is obtained from the Laplace transform by replacing s by  $j\omega$ :

$$X_c(\omega) = X_c(s)|_{s = j\omega}$$

 in a similar way the Fourier transform is obtained from the ztransform according to:

$$X(\omega) = X(z) \mid_{z = e^{\Delta t j \omega}}$$

and we can obtain the frequency response from the transfer function:

$$H(\omega) = H(z)|_{z = \exp(\Delta t j\omega)}$$

#### **Example**

The transfer function of a digital filter is

$$H(z) = \frac{z}{z - a}$$

What is its frequency response?

• if we apply a sampled cosine wave x(n) of frequency  $\omega_0$  rad/s, where

$$x(n) = \cos(\omega_0 \Delta t \ n)$$

to a digital filter with frequency response  $H(\omega)$  then the steady-state output y(n) will be

$$y(n) = |H(\omega_0)| \cos(\omega_0 \Delta t \ n + /H(\omega_0))$$


and in the same way as before the positions of the poles and zeros influence the shape of the frequency response


 for the previous example the amplitude and phase responses are given by

$$|H(\omega)| = \frac{1}{|\exp(j\omega\Delta t) - a|}$$
  $\angle H(\omega) = \omega\Delta t - \angle(\exp(j\omega\Delta t) - a)$ 

• we are interested in how the magnitude and phase change with  $\omega$ 

again a vector interpretation is useful





• extending to the case where H(z) has many poles and zeros

$$H(z) = \frac{(z - z_1)(z - z_2) \cdots (z - z_m)}{(z - p_1)(z - p_2) \cdots (z - p_n)}$$

and replacing z with  $\exp(j\omega\Delta t)$ 

$$H(\omega) = \frac{A(e^{j\omega\Delta t} - z_1)(e^{j\omega\Delta t} - z_2)\cdots(e^{j\omega\Delta t} - z_m)}{(e^{j\omega\Delta t} - p_1)(e^{j\omega\Delta t} - p_2)\cdots(e^{j\omega\Delta t} - p_n)}$$

we can calculate the amplitude and phase response for any  $\omega$ 

$$|H(\omega)| = \frac{A|e^{j\omega\Delta t} - z_1||e^{j\omega\Delta t} - z_2|\cdots|e^{j\omega\Delta t} - z_m|}{|e^{j\omega\Delta t} - p_1||e^{j\omega\Delta t} - p_2|\cdots|e^{j\omega\Delta t} - p_n|}$$

$$/H(\omega) = /(e^{j\omega\Delta t} - z_1) + /(e^{j\omega\Delta t} - z_2) + \cdots + /(e^{j\omega\Delta t} - z_m)$$


$$- /(e^{j\omega\Delta t} - p_1) - /(e^{j\omega\Delta t} - p_2) \cdots - /(e^{j\omega\Delta t} - p_n)$$


• the **amplitude** response is obtained by taking the products of the lengths of the various vectors drawn from the zeros to the point on the unit circle  $e^{j\omega\Delta t}$  associated with the frequency  $\omega$ , and dividing this by the product of the lengths of the vectors from the poles

 the phase response is found by summing the phases of the individual vectors from the zeros minus the sum of the phases of the individual vectors

from the poles

e.g. for a transfer function with a complex pair of poles and a zero at the origin we have the following amplitude and phase responses





#### **Example of a complete system**

An analogue signal, x(t), is applied to the sampled data system illustrated in (a) on the next slide, which has a sampling rate of 10 kHz. The sample and hold (S/H) has a high impedance input stage and hence does not draw any current from the RC circuit ( $R = 21 \text{ k}\Omega$  and C = 3 nF). There are two sine waves present in the analogue signal: one has an amplitude of A and frequency of 1 kHz, and the other has a amplitude of A/2 and a frequency of 7.5 kHz. What frequencies are present at the output of the analogue-to-digital (A/D) converter and what are their amplitudes?


The digital signal processing (DSP) unit implements a digital filter which is also illustrated in (b) on the next slide. What frequencies are present at the output of the digital signal processor and what are their amplitudes? It may be assumed that the low-pass filter (LPF) is ideal and has a cut-off frequency of 5 kHz.


What frequencies are present at the output of the system and what are their amplitudes?

### Example of a complete system




#### (b) Digital filter block diagram





### **Summary**



#### **Summary**

#### You should be able to:

- analyse the effect of sampling on the frequency context of a signal;
- evaluate the z-transform of simple sequences;
- evaluate the inverse z-transform using partial fraction expansion and tables;
- move between the difference equation, black diagram and software descriptions of a signal filter;
- identify if a filter is a finite or infinite impulse response;
- evaluate the output of a digital filter using discrete convolution;
- sketch the frequency response of a digital filter from its pole/zero map;
- understand the relationship between the position of the poles and the impulse response.