

Radio Engineering

Lecture 5: Modulation and Diversity


Florian Kaltenberger

This lecture



- Modulation and demodulation
 - Structure of a wireless link
 - Bit error rate
- Diversity
 - Introduction
 - Macrodiversity
 - Microdiversity
 - Time
 - Freq
 - Space
 - Correlation coefficients
 - Combination of signals
 - selection combining
 - diversity combining

Block diagram



RADIO SIGNALS AND COMPLEX NOTATION

Simple model of a radio signal


A transmitted radio signal can be written

$$S(t) = A\cos(2\pi ft + \phi)$$
Amplitude Frequency Phase

- By letting the transmitted information change the amplitude, the frequency, or the phase, we get the tree basic types of digital modulation techniques
 - ASK (Amplitude Shift Keying)
 - FSK (Frequency Shift Keying) —
 - PSK (Phase Shift Keying)

Constant amplitude

The IQ modulator




Take a step into the complex domain:

Complex envelope
$$\tilde{s}(t) = s_I(t) + js_Q(t)$$

Carrier factor $e^{j2\pi f_c t}$
 $s(t) = \text{Re}\left\{\tilde{s}(t)e^{j2\pi f_c t}\right\}$

Interpreting the complex notation

Complex envelope (phasor)



Polar coordinates:

$$\tilde{s}(t) = s_I(t) + js_Q(t) = A(t)e^{j\phi(t)}$$

Transmitted radio signal

$$s(t) = \operatorname{Re}\left\{\tilde{s}(t)e^{j2\pi f_c t}\right\}$$


$$= \operatorname{Re}\left\{A(t)e^{j\phi(t)}e^{j2\pi f_c t}\right\}$$

$$= \operatorname{Re}\left\{A(t)e^{j(2\pi f_c t + \phi(t))}\right\}$$

$$= A(t)\cos(2\pi f_c t + \phi(t))$$

By manipulating the amplitude A(t) and the phase ϕ (t) of the complex envelope (phasor), we can create any type of modulation/radio signal.

Example: Amplitude, phase and frequency modulation



SIGNAL SPACE DIAGRAM

Principle of signal-space diagram (1)

- Represent a continuous signal by a discrete vector
- Choice of expansion functions:
 - In passband, usually

$$\varphi_{\mathrm{BP},1}(t) = \sqrt{\frac{2}{T_{\mathrm{S}}}} \cos(2\pi f_{\mathrm{c}} t)$$
$$\varphi_{\mathrm{BP},2}(t) = \sqrt{\frac{2}{T_{\mathrm{S}}}} \sin(2\pi f_{\mathrm{c}} t) .$$

- In baseband, usually

$$\varphi_1(t) = \sqrt{\frac{1}{T_S}} \cdot 1$$

$$\varphi_2(t) = \sqrt{\frac{1}{T_{\rm S}}} \cdot j.$$

Principle of signal-space diagram (2)

Signal vector for m-th signal

$$s_{m,n} = \int_0^{T_{\rm S}} s_m(t) \varphi_n^*(t) dt$$

Energy contained in signal

$$E_{S,m} = \int_0^{T_S} s_{BP,m}^2(t) dt = \|\mathbf{s}_{BP,m}\|^2$$

$$E_{S,m} \approx \frac{1}{2} \int_0^{T_S} \|s_{LP,m}(t)\|^2 dt = \frac{1}{2} \|\mathbf{s}_{LP,m}\|^2$$

Correlation coefficients between signals k and m


$$\operatorname{Re}\{\rho_{k,m}\} = \frac{\mathbf{s}_{\mathrm{BP},m}\mathbf{s}_{\mathrm{BP},k}}{\|\mathbf{s}_{\mathrm{BP},m}\|\|\mathbf{s}_{\mathrm{BP},k}\|}$$

Take care about normalization BP vs. LP

Modulation example: QAM



- QAM Quadrature Amplitude Modulation
- based on IQ modulation
- modulation oders (bits per symbol): QPSK (2), 16QAM (4), 64QAM (6), 256QAM (8) ...
- modulation symbol = element of signal space diagram




De-Modulation



- Demodulator needs to find most likely transmitted symbol (MAP -Maximum a posteriori detection)
 - in memoryless, uncoded systems with AWGN this is the closest constellation point to the received symbol
- Pairwise error probability: probability of detecting s_i instead of s_i
- Symbol error rate: average pairwise error probability
- Bit error ratio (rate): bit errors / total number of bits


Radio Engineering Lecture 5: Modulation and Diversity

Optimal receiver Bit-error rates (BER)




Gray coding is used when calculating these BER.

Optimal receiver Bit-error rates (BER), cont.





Optimal receiver – BER of QPSK

- Compute via union bound
- Pairwise error probability $Q\left(\sqrt{2\gamma_{\rm B}}\right)$
- Symbol error probability $SER \approx 2Q(\sqrt{2\gamma_{\rm B}})$
- Bit error probability $BER = Q(\sqrt{2\gamma_{\rm B}})$



symbol





Optimal receiver Where do we get E_b and N_0 ?

Where do those magic numbers $E_{\rm h}$ and N_0 come from?

The noise power spectral density N_0 is calculated according to

$$N_0 = kT_0F_0 \iff N_{0|dB} = -204 + F_{0|dB}$$

where F_0 is the noise factor of the "equivalent" receiver noise source.

The bit energy E_b can be calculated from the received power C (at the same reference point as N_0). Given a certain data-rate d_b [bits per second], we have the relation

$$E_b = C/d_b \Leftrightarrow E_{b|dB} = C_{|dB} - d_{b|dB}$$

THESE ARE THE EQUATIONS THAT RELATE DETECTOR PERFORMANCE ANALYSIS TO LINK BUDGET CALCULATIONS!

BER in fading channels



- In an AWGN channel the BER decreases exponentially with SNR
- Example: QPSK

$$\mathsf{BER} = Q(\sqrt{2\gamma})$$

• In a fading channel with SNR distribution pdf(γ) and mean $\bar{\gamma}$


$$\mathsf{BER}_{\mathsf{fading}}(\bar{\gamma}) = \int_0^\infty \mathsf{BER}_{\mathsf{AWGN}}(\gamma) \mathsf{pdf}(\gamma) d\gamma$$

Example: Rayleigh fading channel

$$\mathsf{pdf}(\gamma) = \frac{1}{\gamma} \exp\left(\frac{-\gamma}{\bar{\gamma}}\right)$$

BER in fading channels





Fading is one of the biggest challenges in wireless communications!

Diversity



- Fading can also be used as an advantage if exploited properly
- If the transmitted signal is available on two or more channels (known as diversity branches), the probability that this signal is affected by a deep fade, occurring simultaneously in all branches, is very low.
- With a convenient algorithm (known as combining method) it is possible to obtain a resulting signal where the effects of fading are minimized

Radio Engineering Lecture 5: Modulation and Diversity

Diversity: Example



- Consider a fading channel with 2 states:
 - SNR=13.5dB for 90% of the time \Rightarrow BER = 10^{-10}
 - SNR=0dB for 10% of the time \Rightarrow BER = 0.5
- Average BER is $0.9 \cdot 10^{-10} + 0.1 \cdot 0.5 = 0.05$
- For a two antenna receiver employing selection combining
 - SNR=0dB at both chains for 1% of the time
 - SNR=13.5dB at at least one chain for 99% of the time
- Average BER is $0.99 \cdot 10^{-10} + 0.01 \cdot 0.5 = 0.005$

Lecture 5: Modulation and Diversity

Diversity exponent



More generally we can define

Definition (Diversity exponent)


The diversity exponent is the slope of the Bit Error Rate (BER) for large SNR on a log-log scale

$$d_{\mathsf{div}} = -\lim_{ar{\gamma} o \infty} rac{\log \mathsf{BER}(ar{\gamma})}{\log ar{\gamma}}$$

It depends on the transmission method and the receiver used.

Diversity exponent





Types of diversity



Macrodiversity

- Macrodiversity tries to counteract large scale fading caused by obstruction etc.
- Use of more than one base station strategically positioned so that the mobiles always have a clear radio path to at least one base station
- Examples: Soft handover, simulcast, coordinated multipoint transmission

Types of diversity




Microscopic diversity

- Microscopic diversity tries to conteract small scale fading caused by multipath propagation
- RX exploits multiple independent copies of the same signal (diversity branches)
- Several methods are availiable
 - Spatial diversity
 - Temporal diversity
 - Frequency diversity
 - Polarization diversity

Microscopic diversity





(We also have angular and polarization diversity)

Radio Engineering Lecture 5: Modulation and Diversity

Spatial Diversity: RX




Signal model:

$$\mathbf{r} = \mathbf{h} \mathbf{s} + \mathbf{n}$$


where

- s is the transmitted signal,
- $\mathbf{h} = [h_0, \dots, h_{N-1}]^T$ is the (narrowband) channel response at antenna elements $0, \dots, N-1$,
- $\mathbf{n} = [n_0, \dots, n_{N-1}]^T$ is the i.i.d. noise (AWGN) with variance σ_n^2 and $\mathbf{r} = [r_0, \dots, r_{N-1}]^T$ is the received signal.
- Basic principle of diversity combining







Spatial (antenna) diversity Selection diversity




Spatial (antenna) diversity Selection diversity, cont.



Spatial (antenna) diversity Maximum ratio combining



Spatial (antenna) diversity Equal gain combining



Selection combining (SC)



- Select diversity branch which is "better"
- Possilbe metrics: BER, RSSI
- Combined SNR $\gamma_{SC} = \max \gamma_n$

If each branch has Rayleigh distribution with mean $\bar{\gamma}$,

Combined cdf

$$\mathsf{cdf}_{\mathsf{SC}}(\gamma) = \left(1 - \mathsf{exp}\left(-rac{\gamma^2}{ar{\gamma}^2}
ight)
ight)^N$$

Maximum Ratio Combining (MRC)



- Optimal combining when only disturbance is AWGN
- Each branch is phase corrected and weighted by amplitude
- Combiner weights $\mathbf{w}_{MRC} = \mathbf{h}^*$
- Combined SNR $\gamma_{\text{MRC}} = \sum_{n=0}^{N-1} \gamma_n$

If each branch has Rayleigh distribution with mean $\bar{\gamma}$,

Combined pdf

$$pdf_{MRC}(\gamma) = \frac{1}{(N-1)!} \frac{\gamma^{N-1}}{\bar{\gamma}^N} \exp\left(-\frac{\gamma}{\bar{\gamma}}\right)$$

Combined cdf

$$\operatorname{cdf}(\gamma) = 1 - \exp\left(-rac{\gamma}{2ar{\gamma}}\right) \sum_{i=0}^{N-1} rac{1}{i!} \left(rac{\gamma}{2ar{\gamma}}\right)^i$$

• Combined mean SNR $\bar{\gamma}_{\text{MRC}} = N\bar{\gamma}$

Equal gain combining (EGC)




- Like MRC, but each branch is only phase corrected (not weighted)
- Combiner weights $\mathbf{w}_{EGC} = [h_0^*/|h_0|, \dots, h_{N-1}^*/|h_{N-1}|]$
- Combined SNR $\gamma_{\rm EGC} = \frac{1}{N} \left(\sum_{n=0}^{N-1} \sqrt{\gamma_n} \right)^2$

If each branch has Rayleigh distribution with mean $\bar{\gamma}$,

• Combined mean SNR $\bar{\gamma}_{EGC} = \bar{\gamma} \left(1 + (N-1) \frac{\pi}{4} \right)$

Spatial (antenna) diversity Performance comparison


Comparison of SNR distribution for different number on of antennas *M* and two different diversity techniques.



Copyright: Prentice-Hall

Spatial (antenna) diversity Performance comparison, cont.

Comparison of 2ASK/2PSK BER for different number of antennas *M* and two different diversity techniques.



Example: Fading margin with SC and MRC



 Consider a receiver with N receive antennas that uses either selection combining or maximum ratio combining. Compute the fading margin for an outage probability of 1% in an uncorrelated Rayleigh fading environment for N = 1, 2, 3.

Optimum combining (OC)



- Most systems interference limited
- OC reduces not only fading but also interference
- Each antenna can eliminate one interferer or give one diversity degree for fading reduction (zero-forcing)
- Signal model

$$\mathbf{y}(t) = \mathbf{h}_0 x_0(t) + \sum_{k=1}^K \mathbf{h}_k x_k(t) + \mathbf{n}$$

with
$$\mathcal{E}\{\mathbf{n}\mathbf{n}^H\} = \sigma^2\mathbf{I}$$

Computation of weights for combining

$$\mathbf{w}_{\text{opt}} = \mathbf{R}^{-1} \mathbf{h}_0, \mathbf{R} = \sigma_n \mathbf{I} + \sum_{k=1}^K \mathcal{E} \left\{ \mathbf{h}_k \mathbf{h}_k^H \right\},$$

Spatial diversity: TX



- Method depends on Channel State Information at the Transmitter (CSIT)
- If available, equivalent methods as for RX can be used
 - Antenna selection
 - Beamforming (Equal gain combining)
 - Maximum Ratio Combining
- If no CSIT is available,
 - Alamouti precoding
 - Cyclic delay diversity

Alamouti precoding



• Alamouti code: transmission of two symbols s_1, s_2 over two transmit antennas and two time instances (rate 1 code)

$$egin{aligned} oldsymbol{x}_1 = egin{pmatrix} s_1 \\ s_2 \end{pmatrix}, \quad oldsymbol{x}_2 = egin{pmatrix} -s_2^* \\ s_1^* \end{pmatrix} \end{aligned}$$

Received signal

$$y_1 = \mathbf{h}\mathbf{x}_1 + n_1 = s_1 h_1 + s_2 h_2 + n_1, \quad y_2 = \mathbf{h}\mathbf{x}_2 + n_2 = -s_2^* h_1 + s_1^* h_2 + n_2$$


Diversity combiner

$$\hat{s}_1 = (h_1^* y_1 + h_2 y_2^*)/2, \quad \hat{s}_2 = (h_2^* y_1 - h_1 y_2^*)/2$$

Cyclic Delay Diversity



- Requires OFDM with cyclic prefix
- Transforms spatial diversity into frequency diversity



Temporal and frequency diversity



- Main idea: use coding and interleaving to spread information over multiple symbols
- The symbols can be distributed in time and/or frequency
- Classical frequency diversity methods
 - Spreading (Used in CDMA systems)
 - Frequency hopping (Used in FDMA/TDMA systems)

Temporal diversity



- Transmission over different (uncorrelated) time instances
- Repetition coding: bandwidth inefficient
- Automatic repeat request (ARQ):
 - RX informs TX about (un-)successful reception (ACK/NACK);
 TX repeats if necessary
 - Requires feedback channel
 - Introduces delay (however, several ARQ processes can be pipelined)
- Hybrid ARQ: exploit redundancy in channel code for different retransmissions
- Can also be combined with frequency diversity schemes

References





J. Fuhl, A.F. Molisch, and E. Bonek, "Unified channel model for mobile radio systems with smart antennas,"

Radar, Sonar and Navigation, IEE Proceedings, vol. 145, no. 1, pp. 32–41, Feb. 1998.

Radio Engineering Lecture 5: Modulation and Diversity