


Key notes for OPC communicatio between Emerson DeltaV and Bently System 1

2016-2-3

- 0.set DCOM configuation as usual on both computer
- 1.must install OPC Remote application (provide by Emerson) in system 1 server
- 2.when installing OPC Remote, will be asked to set the password for DeltaVAdmin. The password must be the same as DeltaV OPC server
- 3.build the same user name in both server (system 1 and DeltaV OPC)
- 4. after install OPC remote application, set "DeltaV OPC server" in DCOM, see following.







during system 1 configuration, choose OPC server in local computer

