# Game Boy: Complete Technical Reference

gekkio https://gekkio.fi January 7, 2024 Revision 135

# **Preface**

# Caveat

IMPORTANT: This document focuses at the moment on 1st and 2nd generation devices (models before the Game Boy Color), and some hardware details are very different in later generations.

Be very careful if you make assumptions about later generation devices based on this document!

# How to read this document

# **\*** Speculation

This is something that hasn't been verified, but would make a lot of sense.

# **1** Caveat

This explains some caveat about this documentation that you should know.

# Warning

This is a warning about something.

# 0.1 Formatting of numbers

When a single bit is discussed in isolation, the value looks like this: 0, 1.

Binary numbers are prefixed with 0b like this: 0b0101101, 0b11011, 0b00000000. Values are prefixed with zeroes when necessary, so the total number of digits always matches the number of digits in the value.

Hexadecimal numbers are prefixed with 0x like this: 0x1234, 0xDEADBEEF, 0xFF04. Values are prefixed with zeroes when necessary, so the total number of characters always matches the number of nibbles in the value.

#### Examples:

4-bit	8-bit	16-bit
<b>→</b> -1/11	O-DIL	10-01

Binary 0b0101 0b10100101 0b0000101010100101

Hexadecimal 0x5 0xA5 0x0AA5

# 0.2 Register definitions

Register 0.1: 0x1234 - This is a hardware register definition

R/W-0	R/W-1	U-1	R-0	R-1	R-x	W-1	U-0
VALUE	<1:0>			BIGVAL<7:5>		FLAG	
bit 7	6	5	4	3	2	1	bit 0

# Top row legend:

- **R** Bit can be read.
- **W** Bit can be written. If the bit cannot be read, reading returns a constant value defined in the bit list of the register in question.
- **U** Unimplemented bit. Writing has no effect, and reading returns a constant value defined in the bit list of the register in question.
- -n Value after system reset: 0, 1, or x.
- **1** Bit is set.
- Ø Bit is cleared.
- **x** Bit is unknown (e.g. depends on external things such as user input)

# Middle row legend:

VALUE<1:0>	Bits 1 and 0 of VALUE
	Unimplemented bit
BIGVAL<7:5>	Bits 7, 6, 5 of BIGVAL
FLAG	Single-bit value FLAG

#### In this example:

- After system reset, VALUE is 0b01, BIGVAL is either 0b010 or 0b011, FLAG is 0b1.
- Bits 5 and 0 are unimplemented. Bit 5 always returns 1, and bit 0 always returns 0.
- Both bits of VALUE can be read and written. When this register is written, bit 7 of the written value goes to bit 1 of VALUE.
- FLAG can only be written to, so reads return a value that is defined elsewhere.
- BIGVAL cannot be written to. Only bits 5-7 of BIGVAL are defined here, so look elsewhere for the low bits 0-4.

# **Contents**

Preface	
How to read this document	3
0.1 Formatting of numbers	
0.2 Register definitions	4
Contents	5
I Sharp SM83 CPU core	9
1 CPU core timing	
1.1 Fetch/execute overlap	
Fetch/execute overlap timing example	
2 Sharp SM83 instruction set	
2.1 Overview	
CB opcode prefix	
Undefined opcodes	12
2.2 8-bit load instructions	
LD r, r': Load register (register)	12
LD r, n: Load register (immediate)	12
LD r, (HL): Load register (indirect HL)	13
LD (HL), r: Load from register (indirect HL)	13
LD (HL), n: Load from immediate data (indirect HL)	13
LD A, (BC): Load accumulator (indirect BC)	14
LD A, (DE): Load accumulator (indirect DE)	14
LD (BC), A: Load from accumulator (indirect BC)	14
LD (DE), A: Load from accumulator (indirect DE)	15
LD A, (nn): Load accumulator (direct)	15
LD (nn), A: Load from accumulator (direct)	15
LDH A, (C): Load accumulator (indirect 0xFF00+C)	
LDH (C), A: Load from accumulator (indirect 0xFF00+C)	
LDH A, (n): Load accumulator (direct 0xFF00+n)	17
LDH (n), A: Load from accumulator (direct 0xFF00+n)	
LD A, (HL-): Load accumulator (indirect HL, decrement)	
LD (HL-), A: Load from accumulator (indirect HL, decrement)	18
LD A, (HL+): Load accumulator (indirect HL, increment)	
LD (HL+), A: Load from accumulator (indirect HL, increment)	19
2.3 16-bit load instructions	
LD rr, nn: Load 16-bit register / register pair	
LD (nn), SP: Load from stack pointer (direct)	
LD SP, HL: Load stack pointer from HL	20
PUSH rr: Push to stack	21
POP rr: Pop from stack	21
LD HL,SP+e	
2.4 8-bit arithmetic and logical instructions	21
ADD r: Add (register)	
ADD (HL): Add (indirect HL)	22
ADD n: Add (immediate)	23

	ADC r: Add with carry (register)	. 23
	ADC (HL): Add with carry (indirect HL)	. 24
	ADC n: Add with carry (immediate)	. 24
	SUB r: Subtract (register)	. 25
	SUB (HL): Subtract (indirect HL)	. 25
	SUB n: Subtract (immediate)	. 26
	SBC r: Subtract with carry (register)	. 26
	SBC (HL): Subtract with carry (indirect HL)	. 27
	SBC n: Subtract with carry (immediate)	. 27
	CP r: Compare (register)	
	CP (HL): Compare (indirect HL)	. 28
	CP n: Compare (immediate)	
	INC r: Increment (register)	
	INC (HL): Increment (indirect HL)	
	DEC r: Decrement (register)	
	DEC (HL): Decrement (indirect HL)	
	AND r: Bitwise AND (register)	
	AND (HL): Bitwise AND (indirect HL)	
	AND n: Bitwise AND (immediate)	
	OR r: Bitwise OR (register)	
	OR (HL): Bitwise OR (indirect HL)	
	OR n: Bitwise OR (immediate)	
	XOR r: Bitwise XOR (register)	
	XOR (HL): Bitwise XOR (indirect HL)	
	XOR n: Bitwise XOR (immediate)	
	CCF: Complement carry flag	
	SCF: Set carry flag	
	DAA: Decimal adjust accumulator	
	CPL: Complement accumulator	
2	5 16-bit arithmetic instructions	
_	INC rr	
	DEC rr	
	ADD HL,rr	
	ADD SP, e	
2	6 Rotate, shift, and bit operation instructions	
_	RLCA	
	RRCA	
	RLA	
	RRA	
	RLC r	
	RLC (HL)	
	RRC r	
	RRC (HL)	
	RL r	
	RL (HL)	
	RR r	
	RR (HL)	
	SLA r	
	SLA (HL)	
	JL⊼ (IIL)	. ၁၀

SRA r	38
SRA (HL)	38
SWAP r	38
SWAP (HL)	38
SRL r	38
SRL (HL)	38
BIT b, r	38
BIT b, (HL)	38
RES b, r	
RES b, (HL)	
SET b, r	
SET b, (HL)	
2.7 Control flow instructions	
JP nn: Jump	
JP HL: Jump to HL	
JP cc, nn: Jump (conditional)	
IR e: Relative jump	
JR cc, e: Relative jump (conditional)	
CALL nn: Call function	
CALL cc, nn: Call function (conditional)	
RET: Return from function	
RET cc: Return from function (conditional)	
RETI: Return from interrupt handler	
RST n: Restart / Call function (implied)	
2.8 Miscellaneous instructions	
HALT: Halt system clock	
STOP: Stop system and main clocks	
DI: Disable interrupts	
EI: Enable interrupts	
•	
NOP: No operation	45
II Game Boy SoC peripherals and features	46
3 Boot ROM	
3.1 Boot ROM types	
DMG boot ROM	
MGB boot ROM	
SGB boot ROM	
SGB2 boot ROM	
Early DMG boot ROM ("DMG0")	48
4 DMA (Direct Memory Access)	
4.1 Object Attribute Memory (OAM) DMA	49
OAM DMA address decoding	50
OAM DMA transfer timing	50
OAM DMA bus conflicts	
5 PPU (Picture Processing Unit)	51
6 Port P1 (Joypad, Super Game Boy communication)	52
7 Serial communication	53

# Part I Sharp SM83 CPU core

# **Chapter 1**

# **CPU core timing**

# 1.1 Fetch/execute overlap

Sharp SM83 uses a microprocessor design technique known as *fetch/execute overlap* to improve CPU performance by doing opcode fetches in parallel with instruction execution whenever possible. Since the CPU can only perform one memory access per M-cycle, it is worth it to try to do memory operations as soon as possible. Also, when doing a memory read, the CPU cannot use the data during the same M-cycle so the true minimum effective duration of instructions is 2 machine cycles, not 1 machine cycle.

Every instruction needs one machine cycle for the fetch stage, and at least one machine cycle for the decode/execute stage. However, the fetch stage of an instruction always overlaps with the last machine cycle of the execute stage of the previous instruction. The overlapping execute stage cycle may still do some work (e.g. ALU operation and/or register writeback) but memory access is reserved for the fetch stage of the next instruction.

Since all instructions effectively last one machine cycle longer, fetch/execute overlap is usually ignored in documentation intended for programmers. It is much easier to think of a program as a sequence of non-overlapping instructions and consider only the execute stages when calculating instruction durations. However, when emulating a SM83 CPU core, understanding and emulating the overlap can be useful.


# Warning

Sharp SM831x is a family of single-chip SoCs from Sharp that use the SM83 CPU core, and their datasheet [1] includes a description of fetch/execute overlap. However, the description is not completely correct and can in fact be misleading.

For example, the timing diagram includes an instruction that does not involve opcode fetch at all, and memory operations for two instructions are shown to happen at the same time, which is not possible.

#### Fetch/execute overlap timing example

Let's assume the CPU is executing a program that starts from the address 0x1000 and contains the following instructions:



The following timing diagram shows all memory operations done by the CPU, and the fetch and execute stages of each instruction:




Figure 1.1: Fetch/execute overlap example

# **Chapter 2**

# **Sharp SM83 instruction set**

#### 2.1 Overview

**CB** opcode prefix

**Undefined opcodes** 

#### 2.2 8-bit load instructions

# LD r, r': Load register (register)

Load to the 8-bit register r, data from the 8-bit register r'.

**Opcode** 0b01xxxyyy/various

**Length** 1 byte

**Duration** 1 machine cycle

Flags -

Timing M-cycle — M1 M2/M1 —

 Instruction
 Previous
 LD r, r¹
 →

 Mem R/W
 — R: opcode
 R: next op
 →

 Mem addr
 — PC₀
 → PC₀+1
 →

Pseudocode opcode = read\_memory(addr=PC); PC = PC + 1

# example: LD B, C
if opcode == 0x41:
B = C

# LD r, n: Load register (immediate)

Load to the 8-bit register r, the immediate data n.

**Opcode** 0b00xxx110/various + n

**Length** 2 bytes

**Duration** 2 machine cycles

Flags -

Timing M-cycle (M1) (M2) (M3/M1)

 Instruction
 Previous
 LD r, n

 Mem R/W
 R: opcode
 R: n
 R: next op

 Mem addr
 PCo
 PCo+1
 PCo+2

Pseudocode opcode = read\_memory(addr=PC); PC = PC + 1

```
# example: LD B, n
if opcode == 0x06:
B = read_memory(addr=PC); PC = PC + 1
```

#### LD r, (HL): Load register (indirect HL)

Load to the 8-bit register r, data from the absolute address specified by the 16-bit register HL.

**Opcode** 0b01xxx110/various

**Length** 1 byte

**Duration** 2 machine cycles

Flags -

Timing M-cycle M1 M2 M3/M1

 Instruction
 Previous
 LD r, (HL)

 Mem R/W
 R: opcode
 R: data
 R: next op

 Mem addr
 PCo
 HL
 PCo+1

Pseudocode opcode = read\_memory(addr=PC); PC = PC + 1

# example: LD B, (HL)
if opcode == 0x46:
B = read\_memory(addr=HL)

#### LD (HL), r: Load from register (indirect HL)

Load to the absolute address specified by the 16-bit register HL, data from the 8-bit register r.

**Opcode** 0b01110xxx/various

**Length** 1 byte

**Duration** 2 machine cycles

Flags -

Timing M-cycle (M1) (M2) (M3/M1)

 Instruction
 Previous
 LD (HL), r
 →

 Mem R/W
 R: opcode
 W: data
 R: next op

 Mem addr
 PC₀
 HL
 PC₀+1

Pseudocode opcode = read\_memory(addr=PC); PC = PC + 1

# example: LD (HL), B
if opcode == 0x70:

write\_memory(addr=HL, data=B)

#### LD (HL), n: Load from immediate data (indirect HL)

Load to the absolute address specified by the 16-bit register HL, the immediate data n.

**Opcode** 0b00110110/0x36 + n

**Length** 2 bytes

**Duration** 3 machine cycles

Flags -

Timing M-cycle M1 M2 M3 M4/M1

Instruction Previous (LD (HL), n

 Mem R/W
 R: opcode
 W: n
 R: next op

 Mem addr
 PCo
 PCo+1
 HL
 PCo+2

Pseudocode opcode = read\_memory(addr=PC); PC = PC + 1

if opcode == 0x36:
 n = read\_memory(addr=PC); PC = PC + 1
 write\_memory(addr=HL, data=n)

#### LD A, (BC): Load accumulator (indirect BC)

Load to the 8-bit A register, data from the absolute address specified by the 16-bit register BC.

**Opcode** 0b00001010/0x0A

**Length** 1 byte

**Duration** 2 machine cycles

Flags -

Timing M-cycle M1 M2 M3/M1

 Instruction
 Previous
 LD A, (BC)

 Mem R/W
 R: opcode
 R: data
 R: next op

 Mem addr
 PCo
 BC
 PCo+1

Pseudocode opcode = read\_memory(addr=PC); PC = PC + 1

if opcode == 0x0A:

A = read\_memory(addr=BC)

# LD A, (DE): Load accumulator (indirect DE)

Load to the 8-bit A register, data from the absolute address specified by the 16-bit register DE.

**Opcode** 0b00011010/0x1A

**Length** 1 byte

**Duration** 2 machine cycles

Flags -

Timing M-cycle M1 M2 M3/M1

 Instruction
 Previous
 LD A, (DE)

 Mem R/W
 — (R: opcode)
 (R: data)
 R: next op

 Mem addr
 — (PC₀)
 (DE)
 (PC₀+1)

Pseudocode opcode = read\_memory(addr=PC); PC = PC + 1

if opcode == 0x1A:

A = read\_memory(addr=DE)

# LD (BC), A: Load from accumulator (indirect BC)

Load to the absolute address specified by the 16-bit register BC, data from the 8-bit A register.

**Opcode** 0b0000010/0x02

**Length** 1 byte

**Duration** 2 machine cycles

Flags -

Timing M-cycle — M1 M2 M3/M1 —

 Instruction
 Previous
 LD (BC), A
 —

 Mem R/W
 R: opcode
 W: data
 R: next op
 —

 Mem addr
 PCo
 BC
 PCo+1
 —

Pseudocode opcode = read\_memory(addr=PC); PC = PC + 1

if opcode == 0x02:

write\_memory(addr=BC, data=A)

#### LD (DE), A: Load from accumulator (indirect DE)

Load to the absolute address specified by the 16-bit register DE, data from the 8-bit A register.

**Opcode** 0b00010010/0x12

**Length** 1 byte

**Duration** 2 machine cycles

Flags -

Timing M-cycle (M1) (M2) (M3/M1)

 Instruction
 Previous
 LD (DE), A

 Mem R/W
 R: opcode
 W: data
 R: next op

 Mem addr
 PCo
 DE
 PCo+1

Pseudocode opcode = read\_memory(addr=PC); PC = PC + 1

if opcode == 0x12:

write\_memory(addr=DE, data=A)

#### LD A, (nn): Load accumulator (direct)

Load to the 8-bit A register, data from the absolute address specified by the 16-bit operand nn.

**Opcode** 0b11111010/0xFA + LSB of n + MSB of n

**Length** 3 bytes

**Duration** 4 machine cycles

Flags -

Timing M-cycle (M1) (M2) (M3) (M4) (M5/M1)

 Instruction
 Previous
 LD A, (nn)

 Mem R/W
 -{ R: opcode | R: Isb(nn) | R: msb(nn) | R: data | R: next op | R: next op

Pseudocode opcode = read\_memory(addr=PC); PC = PC + 1

if opcode == 0xFA:

nn\_lsb = read\_memory(addr=PC); PC = PC + 1
nn\_msb = read\_memory(addr=PC); PC = PC + 1
nn = unsigned\_16(lsb=nn\_lsb, msb=nn\_msb)

A = read\_memory(addr=nn)

#### LD (nn), A: Load from accumulator (direct)

Load to the absolute address specified by the 16-bit operand nn, data from the 8-bit A register.

**Opcode** 0b11101010/0xEA + LSB of n + MSB of n

**Length** 3 bytes

**Duration** 4 machine cycles

Flags -

Timing M-cycle (M1 ) M2 ) M3 ) M4 ) M5/M1 )

 Instruction
 Previous
 LD (nn), A

 Mem R/W
 — (R: opcode ) (R: Isb(nn) ) (R: msb(nn) ) (W: data ) (R: next op ) — (

Pseudocode opcode = read\_memory(addr=PC); PC = PC + 1

if opcode == 0xEA:

nn\_lsb = read\_memory(addr=PC); PC = PC + 1
nn\_msb = read\_memory(addr=PC); PC = PC + 1

nn = unsigned\_16(lsb=nn\_lsb, msb=nn\_msb)

write\_memory(addr=nn, data=A)

#### LDH A, (C): Load accumulator (indirect 0xFF00+C)

Load to the 8-bit A register, data from the address specified by the 8-bit C register. The full 16-bit absolute address is obtained by setting the most significant byte to 0xFF and the least significant byte to the value of C, so the possible range is 0xFF00-0xFFFF.

# LDH (C), A: Load from accumulator (indirect 0xFF00+C)

Load to the address specified by the 8-bit C register, data from the 8-bit A register. The full 16-bit absolute address is obtained by setting the most significant byte to 0xFF and the least significant byte to the value of C, so the possible range is 0xFF00-0xFFFF.

```
Opcode
           0b11100010/0xE2
Length
           1 byte
Duration
           2 machine cycles
Flags
Timing
              M-cycle — M1 M2
           Instruction Previous
                                 LDH (C), A
            Mem R/W - R: opcode W: A R: next op
           Pseudocode opcode = read_memory(addr=PC); PC = PC + 1
           if opcode == 0xE2:
            write_memory(addr=unsigned_16(lsb=C, data=msb=0xFF), A)
```

#### LDH A, (n): Load accumulator (direct 0xFF00+n)

Load to the 8-bit A register, data from the address specified by the 8-bit immediate data n. The full 16-bit absolute address is obtained by setting the most significant byte to 0xFF and the least significant byte to the value of n, so the possible range is 0xFF00-0xFFFF.

Opcode 0b11110000/0xF0 Length 2 bytes **Duration** 3 machine cycles **Flags Timing** M-cycle M1 M2 Instruction Previous LDH A, (n) Mem R/W — R: opcode X R: n R: A Mem addr  $\stackrel{\text{PC}_0}{-}$   $\stackrel{\text{PC}_0+1}{-}$   $\stackrel{\text{OxFF00+n}}{-}$   $\stackrel{\text{PC}_0+2}{-}$ Pseudocode opcode = read\_memory(addr=PC); PC = PC + 1 if opcode == 0xF0:  $n = read_memory(addr=PC); PC = PC + 1$ A = read\_memory(addr=unsigned\_16(lsb=n, msb=0xFF))

#### LDH (n), A: Load from accumulator (direct 0xFF00+n)

Load to the address specified by the 8-bit immediate data n, data from the 8-bit A register. The full 16-bit absolute address is obtained by setting the most significant byte to 0xFF and the least significant byte to the value of n, so the possible range is 0xFF00-0xFFFF.

```
Opcode
            0b11100000/0xE0
Length
            2 bytes
Duration
            3 machine cycles
Flags
Timing
               M-cycle — M1 M2
            Instruction Previous
                                          LDH (n), A
             Mem R/W - R: opcode
                                  R: n
                                           W: A
             Mem addr — PCo PCo+1 ( 0xFF00+C PCo+2 )—
Pseudocode opcode = read_memory(addr=PC); PC = PC + 1
            if opcode == 0xE0:
              n = read_memory(addr=PC); PC = PC + 1
              write_memory(addr=unsigned_16(lsb=n, data=msb=0xFF), A)
```

#### LD A, (HL-): Load accumulator (indirect HL, decrement)

Load to the 8-bit A register, data from the absolute address specified by the 16-bit register HL. The value of HL is decremented after the memory read.

Opcode 0b00111010/0x3A Length 1 byte Duration 2 machine cycles Flags **Timing** Instruction Previous LD A, (HL-) Mem R/W — R: opcode R: A R: next op Mem addr <del>PC₀</del> X HL PC<sub>0</sub>+1 Pseudocode opcode = read\_memory(addr=PC); PC = PC + 1 if opcode == 0x3A:  $A = read_memory(addr=HL); HL = HL - 1$ 

#### LD (HL-), A: Load from accumulator (indirect HL, decrement)

Load to the absolute address specified by the 16-bit register HL, data from the 8-bit A register. The value of HL is decremented after the memory write.

Opcode 0b00110010/0x32 Length 1 byte Duration 2 machine cycles Flags Timing M-cycle (M1) (M2) (M3/M1) (M3/M1) Instruction Previous LD (HL-), A Mem R/W — R: opcode W: A R: next op Mem addr — PCo ) HL PCo+1 — Pseudocode opcode = read\_memory(addr=PC); PC = PC + 1 if opcode == 0x32: write\_memory(addr=HL, data=A); HL = HL - 1

#### LD A, (HL+): Load accumulator (indirect HL, increment)

Load to the 8-bit A register, data from the absolute address specified by the 16-bit register HL. The value of HL is incremented after the memory read.

Opcode 0b00101010/0x2A Length 1 byte Duration 2 machine cycles Flags Timing LD A, (HL+) Instruction Previous Mem R/W — R: opcode R: A R: next op Mem addr PCo HL PCo+1 Pseudocode opcode = read\_memory(addr=PC); PC = PC + 1 if opcode == 0x2A:  $A = read_memory(addr=HL); HL = HL + 1$ 

#### LD (HL+), A: Load from accumulator (indirect HL, increment)

Load to the absolute address specified by the 16-bit register HL, data from the 8-bit A register. The value of HL is decremented after the memory write.

Opcode 0b00100010/0x22 Length 1 byte Duration 2 machine cycles Flags M-cycle — M1 **Timing** Instruction Previous LD (HL+), A Mem R/W R: opcode W: A R: next op Mem addr <del>PC₀</del> X Pseudocode opcode = read\_memory(addr=PC); PC = PC + 1 if opcode == 0x32: write\_memory(addr=HL, data=A); HL = HL + 1

#### 2.3 16-bit load instructions

#### LD rr, nn: Load 16-bit register / register pair

Load to the 16-bit register rr, the immediate 16-bit data nn.

**Opcode** 0b00xx0001/various + LSB of nn + MSB of nn

**Length** 3 bytes

**Duration** 3 machine cycles

Flags -

Timing M-cycle M1 M2 M3 M4/M1 —
Instruction Previous D7rr, nn

Pseudocode opcode = read\_memory(addr=PC); PC = PC + 1

# example: LD BC, nn
if opcode == 0x01:

nn\_lsb = read\_memory(addr=PC); PC = PC + 1
nn\_msb = read\_memory(addr=PC); PC = PC + 1
nn = unsigned\_16(lsb=nn\_lsb, msb=nn\_msb)

BC = nn

#### LD (nn), SP: Load from stack pointer (direct)

Load to the absolute address specified by the 16-bit operand nn, data from the 16-bit SP register.

**Opcode** 0b00001000/0x08 + LSB of nn + MSB of nn

**Length** 3 bytes

**Duration** 5 machine cycles

Flags -

 Instruction
 Previous
 LD (nn), SP

 Mem R/W
 — (R: opcode (R: lsb(nn) (R: msb(nn) (W: lsb(SP) (W: msb(SP) (R: next op ) - Mem addr (PCo (PCo+1 (PCo+2 (nn (nn+1) (PCo+3 (nn+1) (

Pseudocode opcode = read\_memory(addr=PC); PC = PC + 1

if opcode == 0x08:
 nn\_lsb = read\_memory(addr=PC); PC = PC + 1
 nn\_msb = read\_memory(addr=PC); PC = PC + 1
 nn = unsigned\_16(lsb=nn\_lsb, msb=nn\_msb)
 write\_memory(addr=nn, data=lsb(SP))
 write\_memory(addr=nn+1, data=msb(SP))

# LD SP, HL: Load stack pointer from HL

Load to the 16-bit SP register, data from the 16-bit HL register.

**Opcode** 0b11111001/0xF9

**Length** 1 byte

**Duration** 2 machine cycles

Flags -

Timing M-cycle (M1) (M2) (M3/M1)

 Instruction
 Previous
 LD SP, HL
 —

 Mem R/W
 R: opcode
 R: next op
 —

 Mem addr
 PCo
 PCo+1
 —

Pseudocode opcode = read\_memory(addr=PC); PC = PC + 1

if opcode == 0xF9: SP = HL

#### **PUSH rr: Push to stack**

Push to the stack memory, data from the 16-bit register rr.


Opcode 0b11xx0101/various

Length 1 byte

**Duration** 4 machine cycles

**Flags** 

**Timing** 



Pseudocode opcode = read\_memory(addr=PC); PC = PC + 1

```
# example: PUSH BC
if opcode == 0xC5:
 SP = SP - 1
 write_memory(addr=SP, data=msb(BC)); SP = SP - 1
 write_memory(addr=SP, data=lsb(BC))
```

# **POP rr: Pop from stack**

Pops to the 16-bit register rr, data from the stack memory.

This instruction does not do calculations that affect flags, but POP AF completely replaces the F register value, so all flags are changed based on the 8-bit data that is read from memory.

М3

M4/M1

Opcode 0b11xx0001/various

Length 1 byte

**Duration** 3 machine cycles

**Flags** See the instruction description

M-cycle — M1 M2 X **Timing** 

> Instruction Previous POP rr Mem R/W — R: opcode R: lsb(rr) R: msb(rr) R: next op SP₀

> Mem addr → PC₀ X

Pseudocode opcode = read\_memory(addr=PC); PC = PC + 1

```
# example: POP BC
if opcode == 0xC1:
  lsb = read_memory(addr=SP); SP = SP + 1
 msb = read_memory(addr=SP); SP = SP + 1
 BC = unsigned_16(lsb=lsb, msb=msb)
```

#### LD HL,SP+e

**TODO** 

#### 2.4 8-bit arithmetic and logical instructions

#### ADD r: Add (register)

Adds to the 8-bit A register, the 8-bit register r, and stores the result back into the A register.

Opcode 0b10000xxx/various Length 1 byte Duration 1 machine cycle Flags  $Z = \bigstar$ , N = 0,  $H = \bigstar$ ,  $C = \bigstar$ **Timing** M-cycle (M1) (M2/M1) Instruction Previous ADD r Mem R/W — R: opcode R: next op Mem addr — PC₀ PC₀+1 PC₀+1 Pseudocode opcode = read\_memory(addr=PC); PC = PC + 1 # example: ADD B if opcode == 0x80: result, carry\_per\_bit = A + BA = resultflags.Z = 1 if result == 0 else 0 flags.N = ∅ flags.H = 1 if carry\_per\_bit[3] else 0 flags.C = 1 if carry\_per\_bit[7] else 0

# ADD (HL): Add (indirect HL)

Adds to the 8-bit A register, data from the absolute address specified by the 16-bit register HL, and stores the result back into the A register.

```
Opcode
           0b10000110/0x86
Length
            1 byte
Duration
            2 machine cycles
Flags
            Z = \bigstar, N = 0, H = \bigstar, C = \bigstar
Timing
               Instruction Previous ADD (HL)
             Mem R/W — R: opcode R: data R: next op
            Mem addr — PCo HL PCo+1 —
Pseudocode opcode = read_memory(addr=PC); PC = PC + 1
            if opcode == 0x86:
             data = read_memory(addr=HL)
             result, carry_per_bit = A + data
             A = result
              flags.Z = 1 if result == 0 else 0
              flags.N = 0
              flags.H = 1 if carry_per_bit[3] else 0
              flags.C = 1 if carry_per_bit[7] else 0
```

#### ADD n: Add (immediate)

Adds to the 8-bit A register, the immediate data n, and stores the result back into the A register.

Opcode 0b11000110/0xC6 Length 1 byte Duration 2 machine cycles Flags  $Z = \bigstar$ , N = 0,  $H = \bigstar$ ,  $C = \bigstar$ Timing M-cvcle (M1) (M2) (M3/M1) Instruction Previous ADD n Mem R/W — R: opcode R: n R: n ext op — Mem addr — PCo PCo+1 PCo+1 PCo+1 Pseudocode opcode = read\_memory(addr=PC); PC = PC + 1 if opcode == 0xC6:  $n = read\_memory(addr=PC); PC = PC + 1$ result, carry\_per\_bit = A + nA = resultflags.Z = 1 if result == 0 else 0 flags.N = ∅ flags.H = 1 if carry\_per\_bit[3] else 0 flags.C = 1 if carry\_per\_bit[7] else 0

# ADC r: Add with carry (register)

Adds to the 8-bit A register, the carry flag and the 8-bit register  $\mathbf{r}$ , and stores the result back into the A register.

```
Opcode
             0b10001xxx/various
Length
             1 byte
Duration
             1 machine cycle
Flags
             Z = \bigstar, N = 0, H = \bigstar, C = \bigstar
Timing
                 M-cycle — M1 M2/M1 —
             Instruction Previous ADC r
              Mem R/W — R: opcode R: next op
              Mem addr — PC<sub>0</sub> PC<sub>0</sub>+1 —
Pseudocode opcode = read_memory(addr=PC); PC = PC + 1
             # example: ADC B
             if opcode == 0x88:
               result, carry_per_bit = A + flags.C + B
               A = result
               flags.Z = 1 if result == 0 else 0
               flags.N = 0
               flags.H = 1 if carry_per_bit[3] else 0
               flags.C = 1 if carry_per_bit[7] else 0
```

#### ADC (HL): Add with carry (indirect HL)

Adds to the 8-bit A register, the carry flag and data from the absolute address specified by the 16-bit register HL, and stores the result back into the A register.

Opcode 0b10001110/0x8E Length 1 byte Duration 2 machine cycles Flags  $Z = \bigstar$ , N = 0,  $H = \bigstar$ ,  $C = \bigstar$ **Timing** M-cycle — M1 M2 Instruction Previous ADC (HL) Mem R/W — R: opcode R: data R: next op Mem addr — PCo HL PCo+1 — Pseudocode opcode = read\_memory(addr=PC); PC = PC + 1 if opcode == 0x8E: data = read\_memory(addr=HL) result, carry\_per\_bit = A + flags.C + data A = resultflags.Z = 1 if result == 0 else 0 flags.N = 0flags.H = 1 if carry\_per\_bit[3] else 0 flags.C = 1 if carry\_per\_bit[7] else 0

# **ADC n: Add with carry (immediate)**

Adds to the 8-bit A register, the carry flag and the immediate data n, and stores the result back into the A register.

```
Opcode
            0b11001110/0xCE + n
Length
            1 byte
Duration
            2 machine cycles
Flags
            Z = \bigstar, N = 0, H = \bigstar, C = \bigstar
Timing
                M-cycle (M1) (M2) (M3/M1)
            Instruction Previous
                                       ADC n
             Mem R/W R: opcode R: n R: next op
             Mem addr — PCo PCo+1 PCo+1 PCo+1
Pseudocode opcode = read_memory(addr=PC); PC = PC + 1
             if opcode == 0xCE:
              n = read_memory(addr=PC); PC = PC + 1
              result, carry_per_bit = A + flags.C + n
              A = result
               flags.Z = 1 if result == 0 else 0
               flags.N = 0
               flags.H = 1 if carry_per_bit[3] else 0
               flags.C = 1 if carry_per_bit[7] else 0
```

# **SUB r: Subtract (register)**

Subtracts from the 8-bit A register, the 8-bit register  ${\bf r}$ , and stores the result back into the A register.

Opcode 0b10010xxx/various Length 1 byte Duration 1 machine cycle  $Z = \bigstar$ , N = 1,  $H = \bigstar$ ,  $C = \bigstar$ Flags Timing M-cycle — M1 ) M2/M1 Instruction Previous SUB r Mem R/W — R: opcode R: next op Mem addr — PCo PCo+1 Pseudocode opcode = read\_memory(addr=PC); PC = PC + 1 # example: SUB B if opcode == 0x90: result, carry\_per\_bit = A - B A = resultflags.Z = 1 if result == 0 else 0 flags.N = 1flags.H = 1 if carry\_per\_bit[3] else 0 flags.C = 1 if carry\_per\_bit[7] else 0

#### **SUB (HL): Subtract (indirect HL)**

Subtracts from the 8-bit A register, data from the absolute address specified by the 16-bit register HL, and stores the result back into the A register.

```
Opcode
            0b10010110/0x96
Length
            1 byte
Duration
            2 machine cycles
Flags
            Z = \bigstar, N = 1, H = \bigstar, C = \bigstar
Timing
                M-cycle (M1) (M2) (M3/M1)
            Instruction Previous SUB (HL)
             Mem R/W R: opcode R: data R: next op
             Mem addr — PCo HL PCo+1 —
Pseudocode opcode = read_memory(addr=PC); PC = PC + 1
            if opcode == 0x96:
              data = read_memory(addr=HL)
              result, carry_per_bit = A - data
              A = result
              flags.Z = 1 if result == 0 else 0
              flags.N = 1
              flags.H = 1 if carry_per_bit[3] else 0
              flags.C = 1 if carry_per_bit[7] else 0
```

#### **SUB n: Subtract (immediate)**

Subtracts from the 8-bit A register, the immediate data n, and stores the result back into the A register.

Opcode 0b11010110/0xD6 + n Length 1 byte Duration 2 machine cycles  $Z = \bigstar$ , N = 1,  $H = \bigstar$ ,  $C = \bigstar$ Flags Timing M-cycle — M1 M2 Instruction Previous SUB n Mem R/W — R: opcode R: n R: next op Mem addr — PC<sub>0</sub> PC<sub>0</sub>+1 PC<sub>0</sub>+1 Pseudocode opcode = read\_memory(addr=PC); PC = PC + 1 if opcode  $== 0 \times D6$ : n = read\_memory(addr=PC); PC = PC + 1 result, carry\_per\_bit = A - n A = resultflags.Z = 1 if result == 0 else 0 flags.N = 1flags.H = 1 if carry\_per\_bit[3] else 0 flags.C = 1 if carry\_per\_bit[7] else 0

#### SBC r: Subtract with carry (register)

Subtracts from the 8-bit A register, the carry flag and the 8-bit register  $\mathbf{r}$ , and stores the result back into the A register.

```
Opcode
             0b10011xxx/various
Length
             1 byte
Duration
             1 machine cycle
Flags
             Z = \bigstar, N = 1, H = \bigstar, C = \bigstar
Timing
                M-cycle M1 M2/M1 —
             Instruction Previous SBC r
              Mem R/W R: opcode R: next op
              Mem addr — PC<sub>0</sub> PC<sub>0</sub>+1 —
Pseudocode opcode = read_memory(addr=PC); PC = PC + 1
             # example: SBC B
             if opcode == 0x98:
               result, carry_per_bit = A - flags.C - B
               A = result
               flags.Z = 1 if result == 0 else 0
               flags.N = 1
               flags.H = 1 if carry_per_bit[3] else 0
               flags.C = 1 if carry_per_bit[7] else 0
```

#### SBC (HL): Subtract with carry (indirect HL)

Subtracts from the 8-bit A register, the carry flag and data from the absolute address specified by the 16-bit register HL, and stores the result back into the A register.

Opcode 0b10011110/0x9E Length 1 byte Duration 2 machine cycles Flags  $Z = \bigstar$ , N = 1,  $H = \bigstar$ ,  $C = \bigstar$ **Timing** M-cycle — M1 M2 Instruction Previous SBC (HL) Mem R/W — R: opcode R: data R: next op Mem addr — PCo HL PCo+1 — Pseudocode opcode = read\_memory(addr=PC); PC = PC + 1 if opcode == 0x9E: data = read\_memory(addr=HL) result, carry\_per\_bit = A - flags.C - data A = resultflags.Z = 1 if result == 0 else 0 flags.N = 1flags.H = 1 if carry\_per\_bit[3] else 0 flags.C = 1 if carry\_per\_bit[7] else 0

# SBC n: Subtract with carry (immediate)

Subtracts from the 8-bit A register, the carry flag and the immediate data n, and stores the result back into the A register.

```
Opcode
            0b11011110/0xDE + n
Length
            1 byte
Duration
            2 machine cycles
Flags
            Z = \bigstar, N = 1, H = \bigstar, C = \bigstar
Timing
               M-cycle M1 M2 (M3/M1)
            Instruction Previous
                                      SBC n
             Mem R/W R: opcode R: n R: next op
             Mem addr — PCo HL PCo+1 —
Pseudocode opcode = read_memory(addr=PC); PC = PC + 1
            if opcode == 0xDE:
              n = read_memory(addr=PC); PC = PC + 1
              result, carry_per_bit = A - flags.C - n
              A = result
              flags.Z = 1 if result == 0 else 0
              flags.N = 1
              flags.H = 1 if carry_per_bit[3] else 0
              flags.C = 1 if carry_per_bit[7] else 0
```

#### **CP r: Compare (register)**

Subtracts from the 8-bit A register, the 8-bit register r, and updates flags based on the result. This instruction is basically identical to SUB r, but does not update the A register.

Opcode 0b10111xxx/various Length 1 byte Duration 1 machine cycle  $Z = \bigstar$ , N = 1,  $H = \bigstar$ ,  $C = \bigstar$ **Flags Timing** M-cycle M1 M2/M1 Instruction Previous CPr Mem R/W R: opcode R: next op Mem addr — PC<sub>0</sub> PC<sub>0</sub>+1 Pseudocode opcode = read\_memory(addr=PC); PC = PC + 1 # example: CP B if opcode == 0xB8: result, carry\_per\_bit = A - B flags.Z = 1 if result == 0 else 0 flags.N = 1flags.H = 1 if carry\_per\_bit[3] else 0 flags.C = 1 if carry\_per\_bit[7] else 0

#### **CP (HL): Compare (indirect HL)**

Subtracts from the 8-bit A register, data from the absolute address specified by the 16-bit register HL, and updates flags based on the result. This instruction is basically identical to SUB (HL), but does not update the A register.

```
Opcode
             0b10011110/0x9E
Length
             1 byte
Duration
             2 machine cycles
Flags
             Z = \bigstar, N = 1, H = \bigstar, C = \bigstar
Timing
                M-cycle — ( M1 ) M2 ) M3/M1
             Instruction Previous
                                       CP (HL)
              Mem R/W — R: opcode R: data R: next op
             Mem addr — PCo HL PCo+1 —
Pseudocode opcode = read_memory(addr=PC); PC = PC + 1
             if opcode == 0xBE:
               data = read_memory(addr=HL)
               result, carry_per_bit = A - data
               flags.Z = 1 if result == 0 else 0
               flags.N = 1
               flags.H = 1 if carry_per_bit[3] else 0
               flags.C = 1 if carry_per_bit[7] else 0
```

#### **CP n: Compare (immediate)**

Subtracts from the 8-bit A register, the immediate data n, and updates flags based on the result. This instruction is basically identical to SUB n, but does not update the A register.

Opcode 0b11111110/0xFE + n Length 1 byte Duration 2 machine cycles  $Z = \bigstar$ , N = 1,  $H = \bigstar$ ,  $C = \bigstar$ Flags **Timing** M-cycle — M1 M2 Instruction Previous CP n Mem R/W — R: opcode R: n R: next op Mem addr — PC<sub>0</sub> PC<sub>0</sub>+1 PC<sub>0</sub>+1 Pseudocode opcode = read\_memory(addr=PC); PC = PC + 1 if opcode == 0xFE: n = read\_memory(addr=PC); PC = PC + 1 result,  $carry_per_bit = A - n$ flags.Z = 1 if result == 0 else 0 flags.N = 1flags.H = 1 if carry\_per\_bit[3] else 0 flags.C = 1 if carry\_per\_bit[7] else 0

#### **INC r: Increment (register)**

Increments data in the 8-bit register r.

```
Opcode
            0b00xxx100/various
Length
            1 byte
Duration
            1 machine cycle
Flags
            Z = 4, N = 0, H = 4
Timing
               Instruction Previous INCr
             Mem R/W R: opcode R: next op
             Mem addr — PC<sub>0</sub> PC<sub>0</sub>+1 —
Pseudocode opcode = read_memory(addr=PC); PC = PC + 1
            # example: INC B
            if opcode == 0x04:
              result, carry_per_bit = B + 1
              B = result
              flags.Z = 1 if result == 0 else 0
              flags.N = ∅
              flags.H = 1 if carry_per_bit[3] else 0
```

#### **INC (HL): Increment (indirect HL)**

Increments data at the absolute address specified by the 16-bit register HL.

**Opcode** 0b00110100/0x34

**Length** 1 byte

**Duration** 3 machine cycles Flags  $Z = \bigstar$ , N = 0,  $H = \bigstar$ 

Timing M-cycle (M1 ) M2 ) M3 ) M4/M1

 Instruction
 Previous
 INC (HL)
 INC (HL)

 Mem R/W
 R: opcode
 R: data
 W: data
 R: next op

 Mem addr
 PCo
 HL
 HL
 PCo+1

Pseudocode opcode = read\_memory(addr=PC); PC = PC + 1

if opcode == 0x34:
 data = read\_memory(addr=HL)
 result, carry\_per\_bit = data + 1
 write\_memory(addr=HL, data=result)
 flags.Z = 1 if result == 0 else 0
 flags.N = 0
 flags.H = 1 if carry\_per\_bit[3] else 0

# **DEC r: Decrement (register)**

Increments data in the 8-bit register r.

**Opcode** 0b00xxx101/various

**Length** 1 byte

**Duration** 1 machine cycle Flags  $Z = \bigstar$ , N = 1,  $H = \bigstar$ 

Timing M-cycle  $-\frac{M_1}{M_2/M_1}$ 

 Instruction
 Previous
 DEC r
 →

 Mem R/W
 — R: opcode
 R: next op
 →

 Mem addr
 — PC₀
 PC₀+1
 →

Pseudocode opcode = read\_memory(addr=PC); PC = PC + 1

# example: DEC B
if opcode == 0x05:
 result, carry\_per\_bit = B - 1
 B = result
 flags.Z = 1 if result == 0 else 0
 flags.N = 1
 flags.H = 1 if carry\_per\_bit[3] else 0

#### **DEC (HL): Decrement (indirect HL)**

Decrements data at the absolute address specified by the 16-bit register HL.

Opcode 0b00110101/0x35 Length 1 byte Duration 3 machine cycles **Flags**  $Z = \frac{1}{100}$ , N = 1, H =  $\frac{1}{100}$ Timing M-cycle — M1 ) M2 ) M4/M1 M3 Instruction Previous DEC (HL) Mem R/W — R: opcode R: data W: data R: next op Mem addr — PCo HL PCo+1 Pseudocode opcode = read\_memory(addr=PC); PC = PC + 1 if opcode == 0x35: data = read\_memory(addr=HL) result, carry\_per\_bit = data - 1 write\_memory(addr=HL, data=result) flags.Z = 1 if result == 0 else 0 flags.N = 1flags.H = 1 if carry\_per\_bit[3] else 0


# AND r: Bitwise AND (register)

Performs a bitwise AND operation between the 8-bit A register and the 8-bit register r, and stores the result back into the A register.

```
Opcode
             0b10100xxx/various
Length
             1 byte
Duration
             1 machine cycle
Flags
             Z = \bigstar, N = 0, H = 1, C = 0
Timing
                M-cycle — M1 ) M2/M1
             Instruction Previous (AND r
              Mem R/W R: opcode R: next op
              Mem addr — PC<sub>0</sub> PC<sub>0</sub>+1 —
Pseudocode opcode = read_memory(addr=PC); PC = PC + 1
             # example: AND B
             if opcode == 0xA0:
               result = A & B
               A = result
               flags.Z = 1 if result == 0 else 0
               flags.N = 0
               flags.H = 1
               flags.C = 0
```

#### AND (HL): Bitwise AND (indirect HL)

Performs a bitwise AND operation between the 8-bit A register and data from the absolute address specified by the 16-bit register HL, and stores the result back into the A register.




#### AND n: Bitwise AND (immediate)

Performs a bitwise AND operation between the 8-bit A register and immediate data n, and stores the result back into the A register.

```
Opcode
            0b11100110/0xE6 + n
Length
            1 byte
Duration
            2 machine cycles
Flags
            Z = \frac{1}{100}, N = 0, H = 1, C = 0
Timing
               M-cycle (M1) (M2) (M3/M1)
            Instruction Previous
                                      AND n
             Mem R/W R: opcode R: n R: next op
             Mem addr — PCo PCo+1 PCo+1 PCo+1
Pseudocode opcode = read_memory(addr=PC); PC = PC + 1
            if opcode == 0xE6:
              n = read_memory(addr=PC); PC = PC + 1
              result = A & n
              A = result
              flags.Z = 1 if result == 0 else 0
              flags.N = 0
              flags.H = 1
              flags.C = 0
```

# **OR r: Bitwise OR (register)**

Performs a bitwise OR operation between the 8-bit A register and the 8-bit register r, and stores the result back into the A register.




#### **OR (HL): Bitwise OR (indirect HL)**

Performs a bitwise OR operation between the 8-bit A register and data from the absolute address specified by the 16-bit register HL, and stores the result back into the A register.

```
Opcode
           0b10110110/0xB6
Length
           1 byte
Duration
           2 machine cycles
Flags
           Z = +, N = 0, H = 0, C = 0
Timing
              Instruction Previous OR (HL)
            Mem R/W R: opcode R: data R: next op
           Mem addr — PCo HL PCo+1 —
Pseudocode opcode = read_memory(addr=PC); PC = PC + 1
           if opcode == 0xB6:
             data = read_memory(addr=HL)
             result = A | data
             A = result
             flags.Z = 1 if result == 0 else 0
             flags.N = 0
             flags.H = 0
             flags.C = ∅
```

#### **OR n: Bitwise OR (immediate)**

Performs a bitwise OR operation between the 8-bit A register and immediate data n, and stores the result back into the A register.




#### **XOR r: Bitwise XOR (register)**

Performs a bitwise XOR operation between the 8-bit A register and the 8-bit register r, and stores the result back into the A register.

```
Opcode
            0b10101xxx/various
Length
            1 byte
Duration
            1 machine cycle
Flags
            Z = +, N = 0, H = 0, C = 0
Timing
                M-cycle M1 M2/M1 —
            Instruction Previous XORr
              Mem R/W R: opcode R: next op
             Mem addr — PC<sub>0</sub> PC<sub>0</sub>+1 —
Pseudocode opcode = read_memory(addr=PC); PC = PC + 1
             # example: XOR B
             if opcode == 0xB8:
               result = A ^ B
               A = result
               flags.Z = 1 if result == 0 else 0
               flags.N = 0
               flags.H = ∅
               flags.C = ∅
```

#### **XOR (HL): Bitwise XOR (indirect HL)**

Performs a bitwise XOR operation between the 8-bit A register and data from the absolute address specified by the 16-bit register HL, and stores the result back into the A register.



#### **XOR n: Bitwise XOR (immediate)**

Performs a bitwise XOR operation between the 8-bit A register and immediate data n, and stores the result back into the A register.

```
Opcode
            0b11101110/0xEE + n
Length
            1 byte
Duration
            2 machine cycles
Flags
            Z = +, N = 0, H = 0, C = 0
Timing
               M-cycle (M1) (M2) (M3/M1)
            Instruction Previous
                                     XOR n
             Mem R/W R: opcode R: n R: next op
            Mem addr — PCo PCo+1 PCo+1 PCo+1
Pseudocode opcode = read_memory(addr=PC); PC = PC + 1
            if opcode == 0xEE:
              n = read_memory(addr=PC); PC = PC + 1
              result = A ^ n
              A = result
              flags.Z = 1 if result == 0 else 0
              flags.N = 0
              flags.H = ∅
              flags.C = 0
```

# **CCF: Complement carry flag**

Flips the carry flag, and clears the N and H flags.

**Opcode** 0b001111111/0x3F

**Length** 1 byte

**Duration** 1 machine cycle **Flags**  $N = 0, H = 0, C = \bigstar$ 

Timing M-cycle — M1 M2/M1 —

Instruction Previous CCF

Mem R/W R: opcode R: next op

Mem addr PCo PCo+1

Pseudocode opcode = read\_memory(addr=PC); PC = PC + 1

if opcode == 0x3F:
 flags.N = 0
 flags.H = 0
 flags.C = ~flags.C

# **SCF: Set carry flag**

Sets the carry flag, and clears the N and H flags.

**Opcode** 0b00110111/0x37

**Length** 1 byte

**Duration** 1 machine cycle **Flags** N = 0, H = 0, C = 1

Timing M-cycle — M1 M2/M1 —

Instruction Previous SCF — Mem R/W — R: opcode R: next op — Mem addr — PCo PCo+1 — PCo+1

Pseudocode opcode = read\_memory(addr=PC); PC = PC + 1

if opcode == 0x37:
 flags.N = 0
 flags.H = 0
 flags.C = 1

# **DAA: Decimal adjust accumulator**

TODO

**Opcode** 0b00100111/0x27

**Length** 1 byte

**Duration** 1 machine cycle **Flags**  $Z = \bigstar$ , H = 0,  $C = \bigstar$ 

Timing M-cycle M1 M2/M1 —

 Instruction
 Previous
 DAA

 Mem R/W
 — R: opcode
 — R: next op

 Mem addr
 — PC₀
 — PC₀+1

Pseudocode TODO

#### **CPL: Complement accumulator**

Flips all the bits in the 8-bit A register, and sets the N and H flags.

Opcode 0b00101111/0x2F

Length 1 byte

Duration 1 machine cycle

Flags N = 1, H = 1Timing M-cycle M1 M2/M1 M2/M1

Instruction Previous CPL —

Mem R/W R: opcode R: next op —

Mem addr PCo PCo+1 —

Pseudocode opcode = read\_memory(addr=PC); PC = PC + 1
 if opcode == 0x2F:
 A = ~A
 flags.N = 1
 flags.H = 1

#### 2.5 16-bit arithmetic instructions

INC rr

TODO

**DEC rr** 

TODO

ADD HL,rr

**TODO** 

ADD SP, e

TODO

#### 2.6 Rotate, shift, and bit operation instructions

**RLCA** 

**TODO** 

**RRCA** 

**TODO** 

**RLA** 

TODO

RRA

TODO

RLC r

TODO

RLC (HL)

**TODO** 

TODO
RL r
TODO
RL (HL)
TODO
RR r
TODO
RR (HL)
TODO
SLA r
TODO
SLA (HL)
TODO
SRA r
TODO
SRA (HL)
TODO
SWAP r
TODO
SWAP (HL)
SWAP (HL) TODO SRL r
SWAP (HL) TODO
SWAP (HL) TODO SRL r TODO SRL (HL)
SWAP (HL) TODO SRL r TODO SRL (HL) TODO
SWAP (HL) TODO SRL r TODO SRL (HL) TODO BIT b, r
SWAP (HL) TODO SRL r TODO SRL (HL) TODO BIT b, r TODO
SWAP (HL) TODO SRL r TODO SRL (HL) TODO BIT b, r TODO BIT b, (HL)
SWAP (HL) TODO SRL r TODO SRL (HL) TODO BIT b, r TODO BIT b, (HL) TODO
SWAP (HL) TODO SRL r TODO SRL (HL) TODO BIT b, r TODO BIT b, (HL)

RRC r TODO

RRC (HL)

```
RES b, (HL)
```

TODO

SET b, r

**TODO** 

SET b, (HL)

TODO

#### 2.7 Control flow instructions

#### JP nn: Jump

Unconditional jump to the absolute address specified by the 16-bit immediate operand nn.


**Opcode** 0b11000011/0xC3 + LSB of nn + MSB of nn

**Length** 3 bytes

**Duration** 4 machine cycles

Flags -

Timing



```
Pseudocode opcode = read_memory(addr=PC); PC = PC + 1
    if opcode == 0xC3:
        nn_lsb = read_memory(addr=PC); PC = PC + 1
        nn_msb = read_memory(addr=PC); PC = PC + 1
        nn = unsigned_16(lsb=nn_lsb, msb=nn_msb)
        PC = nn
```

#### JP HL: Jump to HL

Unconditional jump to the absolute address specified by the 16-bit register HL.

**Opcode** 0b11101001/0xE9

**Length** 1 byte

**Duration** 1 machine cycle

Flags -

Timing M-cycle — M1 (M2/M1)—

Instruction Previous (JPHL)

Mem R/W R: opcode R: next op

Mem addr PCo HL

Pseudocode opcode = read\_memory(addr=PC); PC = PC + 1
 if opcode == 0xE9:

PC = HL


#### Warning

In some documentation this instruction is written as JP <code>[HL]</code>. This is very misleading, since brackets are usually used to indicate a memory read, and this instruction simply copies the value of HL to PC.

#### JP cc, nn: Jump (conditional)

Conditional jump to the absolute address specified by the 16-bit operand nn, depending on the condition cc.

Note that the operand (absolute address) is read even when the condition is false!



#### JR e: Relative jump


Unconditional jump to the relative address specified by the signed 8-bit operand e.

```
Opcode
            0b00011000/0x18 + offset e
Length
            2 bytes
Duration
            3 machine cycles
Flags
Timing
               M-cycle — M1
                                   M2
                                           М3
            Instruction Previous
                                          JR e
             Mem R/W — R: opcode R: e
             Mem addr — PCo (PCo+1)
Pseudocode opcode = read_memory(addr=PC); PC = PC + 1
            if opcode == 0x18:
              e = signed_8(read_memory(addr=PC); PC = PC + 1)
              PC = PC + e
```

#### JR cc, e: Relative jump (conditional)

Conditional jump to the relative address specified by the signed 8-bit operand e, depending on the condition cc.

Note that the operand (relative address offset) is read even when the condition is false!



#### **CALL nn: Call function**

Unconditional function call to the absolute address specified by the 16-bit operand nn.

**Opcode** 0b11001101/0xCD + LSB of nn + MSB of nn

**Length** 3 bytes

**Duration** 6 machine cycles

Flags -

Timing M-cycle (M1) (M2) (M3) (M4) (M5) (M6) (M7/M1) (Instruction Previous (CALL nn)

 Mem R/W
 — (R: opcode | R: lsb(nn) | R: msb(nn) | (W: msb(PC<sub>0</sub>+3) | W: lsb(PC<sub>0</sub>+3) | R: next op | PC<sub>0</sub>+1 | PC<sub>0</sub>+2 | SP<sub>0</sub> | SP<sub>0</sub>-1 | SP<sub>0</sub>-2 | nn | PC<sub>0</sub>+2 | SP<sub>0</sub> | SP<sub>0</sub>-1 | SP<sub>0</sub>-2 | Nn | PC<sub>0</sub>+2 | SP<sub>0</sub> | SP<sub>0</sub>-1 | SP<sub>0</sub>-2 | Nn | PC<sub>0</sub>+2 | SP<sub>0</sub> | SP<sub>0</sub>-1 | SP<sub>0</sub>-2 | SP<sub>0</sub> | SP<sub>0</sub>-2 | SP<sub>0</sub>-1 | SP<sub>0</sub>-2 | SP<sub>0</sub>-2 | SP<sub>0</sub>-1 | SP<sub>0</sub>-1 | SP<sub>0</sub>-2 | SP<sub>0</sub>-

Pseudocode opcode = read\_memory(addr=PC); PC = PC + 1

```
if opcode == 0xCD:
    nn_lsb = read_memory(addr=PC); PC = PC + 1
    nn_msb = read_memory(addr=PC); PC = PC + 1
    nn = unsigned_16(lsb=nn_lsb, msb=nn_msb)
    SP = SP - 1
    write_memory(addr=SP, data=msb(PC)); SP = SP - 1
    write_memory(addr=SP, data=lsb(PC))
    PC = nn
```

#### **CALL cc, nn: Call function (conditional)**

Conditional function call to the absolute address specified by the 16-bit operand nn, depending on the condition cc.

Note that the operand (absolute address) is read even when the condition is false!

```
Opcode
               0b110xx100/various + LSB of nn + MSB of nn
Length
               3 bytes
Duration
               3 machine cycles (cc=false), or 6 machine cycles (cc=true)
Flags
Timing
                   M-cycle — M1
                                          M2
                                                    М3
cc=false
               Instruction Previous
                                                  CALL cc, nn
                Mem R/W — R: opcode
                                      R: Isb(nn)
                                                  R: msb(nn)
               Mem addr → PC₀
Timing
                   M-cycle — M1
                                                    М3
                                                              M4
                                                                                        M7/M1
                                          M2
                                                                                М6
cc=true
               Instruction Previous
                                                                CALL cc, nn
                Mem R/W — R: opcode (R: lsb(nn) (R: msb(nn) (W: msb(PC<sub>0</sub>+3) (W: lsb(PC<sub>0</sub>+3) (R: next op
               Mem addr \stackrel{PC_0}{-} \stackrel{PC_0+1}{-} \stackrel{PC_0+2}{-} \stackrel{SP_0}{-} \stackrel{SP_0-1}{-} \stackrel{SP_0-2}{-}
Pseudocode opcode = read_memory(addr=PC); PC = PC + 1
               if opcode in [0xC4, 0xD4, 0xCC, 0xDC]:
                 nn_lsb = read_memory(addr=PC); PC = PC + 1
                 nn_msb = read_memory(addr=PC); PC = PC + 1
                 nn = unsigned_16(lsb=nn_lsb, msb=nn_msb)
                 if F.check_condition(cc):
                    SP = SP - 1
                    write_memory(addr=SP, data=msb(PC)); SP = SP - 1
                    write_memory(addr=SP, data=lsb(PC))
                    PC = nn
```

#### **RET: Return from function**

Unconditional return from a function.

Opcode0b11001001/0xC9Length1 byteDuration4 machine cycles

Flags -

Timing M-cycle (M1 ) M2 ) M3 ) M4 ) M5/M1 )
Instruction Previous (RET )

Mom P/W (Propost on Market Control of Market Co

 Mem R/W
 R: opcode
 R: lsb(PC)
 R: msb(PC)
 R: next op

 Mem addr
 PCo
 SPo
 SPo+1
 PC from stack

Pseudocode opcode = read\_memory(addr=PC); PC = PC + 1
 if opcode == 0xC9:

lsb = read\_memory(addr=SP); SP = SP + 1
msb = read\_memory(addr=SP); SP = SP + 1
PC = unsigned\_16(lsb=lsb, msb=msb)

#### **RET cc: Return from function (conditional)**

Conditional return from a function, depending on the condition cc.

Opcode 0b110xx000/various Length 1 byte Duration 2 machine cycles (cc=false), or 5 machine cycles (cc=true) Flags Timing M-cycle - ✓ M1 M2 M3/M1 cc=false Instruction Previous RET cc Mem R/W — R: opcode **Timing** M-cycle — M1 М3 M2 M4 M6/M1 Instruction Previous cc=true RET cc Mem R/W — R: opcode R: Isb(PC) R: msb(PC) Pseudocode opcode = read\_memory(addr=PC); PC = PC + 1 if opcode in [0xC0, 0xD0, 0xC8, 0xD8]: if F.check\_condition(cc): lsb = read\_memory(addr=SP); SP = SP + 1 msb = read\_memory(addr=SP); SP = SP + 1 PC = unsigned\_16(lsb=lsb, msb=msb)

#### **RETI: Return from interrupt handler**

Unconditional return from a function. Also enables interrupts by setting IME=1.

**Opcode** 0b11011001/0xD9

**Length** 1 byte

**Duration** 4 machine cycles

Flags -

Timing M-cycle — M1 X M2 X M3 X M4 X M5/M1 —

 Instruction
 Previous
 RETI

 Mem R/W
 — R: opcode
 — R: Isb(PC)
 — R: msb(PC)

 Mem addr
 — PCo
 — SPo
 — SPo+1
 — PC from stack

Pseudocode opcode = read\_memory(addr=PC); PC = PC + 1

if opcode == 0xD9:

lsb = read\_memory(addr=SP); SP = SP + 1
msb = read\_memory(addr=SP); SP = SP + 1
PC = unsigned\_16(lsb=lsb, msb=msb)

IME = 1

#### RST n: Restart / Call function (implied)

Unconditional function call to the absolute fixed address defined by the opcode.

Opcode 0b11xxx111/various Length 1 byte **Duration** 4 machine cycles Flags **Timing** M-cycle — M1 M2 М3 Y M4 M5/M1 Instruction Previous RST n Mem addr — PCo SPo SPo SPo-1 SPo-2 Pseudocode opcode = read\_memory(addr=PC); PC = PC + 1 if opcode in [0xC7, 0xCF, 0xD7, 0xDF, 0xE7, 0xEF, 0xF7, 0xFF]: address 0x00, 0x08, 0x10, 0x18, 0x20, 0x28, 0x30, 0x38 n = rst\_address(opcode) SP = SP - 1write\_memory(addr=SP, data=msb(PC)); SP = SP - 1

write\_memory(addr=SP, data=lsb(PC))
PC = unsigned\_16(lsb=n, msb=0x00)

#### 2.8 Miscellaneous instructions

#### **HALT: Halt system clock**

TODO

#### STOP: Stop system and main clocks

**TODO** 

#### **DI: Disable interrupts**

Disables interrupt handling by setting IME=0 and cancelling any scheduled effects of the EI instruction if any.

#### **EI: Enable interrupts**

Schedules interrupt handling to be enabled after the next machine cycle.

#### **NOP: No operation**

No operation. This instruction doesn't do anything, but can be used to add a delay of one machine cycle and increment PC by one.

## Part II Game Boy SoC peripherals and features

#### **Boot ROM**

The Game Boy SoC includes a small embedded boot ROM, which can be mapped to the 0x0000-0x00FF memory area. While mapped, all reads from this area are handled by the boot ROM instead of the external cartridge, and all writes to this area are ignored and cannot be seen by external hardware (e.g. the cartridge MBC).

The boot ROM is enabled by default, so when the system exits the reset state and the CPU starts execution from address  $0 \times 0 \times 0 \times 0$ , it executes the boot ROM instead of instructions from the cartridge ROM. The boot ROM is responsible for showing the initial logo, and checking that a valid cartridge is inserted into the system. If the cartridge is valid, the boot ROM unmaps itself before execution of the cartridge ROM starts at  $0 \times 0 \times 1 \times 0$ . The cartridge ROM has no chance of executing any instructions before the boot ROM is unmapped, which prevents the boot ROM from being read byte by byte in normal conditions.

#### Warning

Don't confuse the boot ROM with the additional SNES ROM in SGB/SGB2 that is executed by the SNES CPU.

Register 3.1: 0xFF50 - BOOT - Boot ROM lock register

U	U	U	U	U	U	U	R/W-0
							BOOT_OFF
bit 7	6	5	4	3	2	1	bit 0

#### **bit 7-1 Unimplemented**: Ignored during writes, reads are undefined

#### **bit 0 BOOT OFF**: Boot ROM lock bit

0b1 = Boot ROM is disabled and 0x0000-0x00FF works normally.

0b0 = Boot ROM is active and intercepts accesses to 0x0000-0x00FF.

BOOT\_OFF can only transition from 0b0 to 0b1, so once 0b1 has been written, the boot ROM is permanently disabled until the next system reset. Writing 0b0 when BOOT\_OFF is 0b0 has no effect and doesn't lock the boot ROM.

The 1-bit BOOT register controls mapping of the boot ROM. Once 0b1 has been written to it to unmap the boot ROM, it can only be mapped again by resetting the system.

#### 3.1 Boot ROM types

Туре	CRC32	MD5	SHA1
DMG	59c8598e	32fbbd84168d3482956eb3c5051637f5	4ed31ec6b0b175bb109c0eb5fd3d193da823339f
MGB	e6920754	71a378e71ff30b2d8a1f02bf5c7896aa	4e68f9da03c310e84c523654b9026e51f26ce7f0
SGB	ec8a83b9	d574d4f9c12f305074798f54c091a8b4	aa2f50a77dfb4823da96ba99309085a3c6278515
SGB2	53d0dd63	e0430bca9925fb9882148fd2dc2418c1	93407ea10d2f30ab96a314d8eca44fe160aea734
DMG0	c2f5cc97	a8f84a0ac44da5d3f0ee19f9cea80a8c	8bd501e31921e9601788316dbd3ce9833a97bcbc

Table 3.1: Summary of boot ROM file hashes

#### **DMG boot ROM**

The most common boot ROM is the DMG boot ROM used in almost all original Game Boy units. If a valid cartridge is inserted, the boot ROM scrolls a logo to the center of the screen, and plays a "di-ding" sound recognizable by most people who have used Game Boy consoles.

This boot ROM was originally dumped by neviksti in 2003 by decapping the Game Boy SoC and visually inspecting every single bit.

#### MGB boot ROM

This boot ROM was originally dumped by Bennvenn in 2014 by using a simple clock glitching method that only requires one wire.

#### **SGB boot ROM**

This boot ROM was originally dumped by Costis Sideris in 2009 by using an FPGA-based clock glitching method [2].

#### SGB2 boot ROM

This boot ROM was originally dumped by gekkio in 2015 by using a Teensy 3.1 -based clock glitching method [3].

#### Early DMG boot ROM ("DMG0")

Very early original Game Boy units released in Japan (often called "DMG0") included the launch version "DMG-CPU" SoC chip, which used a different boot ROM than later units.

This boot ROM was originally dumped by gekkio in 2016 by using a clock glitching method invented by BennVenn.

## **DMA (Direct Memory Access)**

#### 4.1 Object Attribute Memory (OAM) DMA

OAM DMA is a high-throughput mechanism for copying data to the OAM area (a.k.a. Object Attribute Memory, a.k.a. sprite memory). It can copy one byte per machine cycle without involving the CPU at all, which is much faster than the fastest possible memory routine that can be written with the SM83 instruction set. However, a transfer cannot be cancelled and the transfer length cannot be controlled, so the DMA transfer always updates the entire OAM area (= 160 bytes) even if you actually want to just update the first couple of bytes.

The Game Boy CPU chip contains a DMA controller that coordinates transfers between a **source area** and the **OAM area** independently of the CPU. While a transfer is in progress, it takes control of the source bus and the OAM area, so some precaution is needed with memory accesses (including instruction fetches) to avoid OAM DMA bus conflicts. OAM DMA uses a different address decoding scheme than normal memory accesses, so the source bus is always either the external bus or the video RAM bus, and the contents normally visible to the CPU in the 0xFE00-0xFFFF address range cannot be used as a source for OAM DMA transfers.

The upper 8 bits of the OAM DMA source address are stored in the DMA register, while the lower 8 bits used by both the source and target address are stored in the DMA controller and are not accessible directly. A transfer always begins with 0x00 in the lower bits and copies exactly 160 bytes, so the lower bits are never in the 0xA0-0xFF range.

Writing to the DMA register updates the upper bits of the DMA source address and also triggers an OAM DMA transfer request, although the DMA transfer does not begin immediately.

Register 4.1: 0xFF46 - DMA - OAM DMA control register

R/W-x	R/W-x	R/W-x	R/W-x	R/W-x	R/W-x	R/W-x	R/W-x		
	DMA<7:0>								
bit 7 6 5 4 3 2 1 bit 0									

#### **bit 7-0 DMA<7:0>**: OAM DMA source address

Specifies the top 8 bits of the OAM DMA source address.

Writing to this register requests an OAM DMA transfer, but it's just a request and the actual DMA transfer starts with a delay.

Reading this register returns the value that was previously written to the register. The stored value is not cleared on reset, so the initial value before the first write is unknown and should not be relied on.

#### Warning

Avoid writing 0xE0-0xFF to the DMA register, because some poorly designed flash carts can trigger bus conflicts or other dangerous behaviour.

#### **OAM DMA address decoding**

The OAM DMA controller uses a simplified address decoding scheme, which leads to some addresses being unusable as source addresses. Unlike normal memory accesses, OAM DMA transfers interpret all accesses in the 0xA000-0xFFFF range as external RAM transfers. For example, if the OAM DMA wants to read 0xFF00, it will output 0xFF00 on the external address bus and will assert the external RAM chip select signal. The P1 register which is normally at 0xFF00 is not involved at all, because OAM DMA address decoding only uses the external bus and the video RAM bus. Instead, the resulting behaviour depends on several factors, including the connected cartridge. Some flash carts are not prepared for this unexpected scenario, and a bus conflict or worse behaviour can happen.

DMA register value	Used bus	Asserted chip select signal
0x00-0x7F	external bus	external ROM (A15)
0x80-0x9F	video RAM bus	video RAM (MCS)
0xA0-0xFF	external bus	external RAM (CS)

Table 4.1: OAM DMA address decoding scheme

#### **OAM DMA transfer timing**

**TODO** 

#### **OAM DMA bus conflicts**

**TODO** 

## **PPU (Picture Processing Unit)**

#### Register 5.1: 0xFF40 - LCDC - PPU control register

R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0
LCD_EN	WIN_MAP	WIN_EN	TILE_SEL	BG_MAP	OBJ_SIZE	OBJ_EN	BG_EN
bit 7	6	5	4	3	2	1	bit 0

#### Register 5.2: 0xFF41 - STAT - PPU status register

U	R/W-0	R/W-0	R/W-0	R/W-0	R-0	R-0	R-0
	INTR_LYC	INTR_M2	INTR_M1	INTR_M0	LYC_STAT	LCD_MOI	DE <1:0>
bit 7	6	5	4	3	2	1	bit 0

#### Register 5.3: 0xFF42 - SCY - Vertical scroll register

R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0		
	SCY <7:0>								
bit 7 6 5 4 3 2 1 bit 0									

#### Register 5.4: 0xFF43 - SCX - Horizontal scroll register

R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	
	SCX <7:0>							
bit 7 6 5 4 3 2 1 bit 0								

#### Register 5.5: 0xFF44 - LY - Scanline register

R-0	R-0	R-0	R-0	R-0	R-0	R-0	R-0	
	LY<7:0>							
bit 7 6 5 4 3 2 1 bit 0								

#### Register 5.6: 0xFF45 - LYC - Scanline compare register

R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	
	LYC<7:0>							
bit 7 6 5 4 3 2 1 bit 0								

## Port P1 (Joypad, Super Game Boy communication)

Register 6.1: 0xFF00 - P1 - Joypad/Super Game Boy communication register

U	U	W-0	W-0	R-x	R-x	R-x	R-x
		P15	P14	P13	P12	P11	P10
bit 7	6	5	4	3	2	1	bit 0

bit 7-6 Unimplemented: Ignored during writes, reads are undefined

bit 5 P15

bit 4 P14

bit 3 P13

bit 2 P12

bit 1 P11

bit 0 P10

## **Serial communication**

Register 7.1: 0xFF01 - SB - Serial data register

R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0
SB<7:0>							
bit 7	6	5	4	3	2	1	bit 0

**bit 7-0 SB<7:0>**: Serial data

Register 7.2: 0xFF02 - SC - Serial control register

R/W-0	U	U	U	U	U	U	R/W-0
SIO_EN							SIO_CLK
bit 7	6	5	4	3	2	1	bit 0

bit 7 SIO\_EN

bit 6-1 Unimplemented: Ignored during writes, reads are undefined

bit 0 SIO\_CLK

# Part III Game Boy game cartridges

## **MBC1** mapper chip

The majority of games for the original Game Boy use the MBC1 chip. MBC1 supports ROM sizes up to 16 Mbit (128 banks of 0x4000 bytes) and RAM sizes up to 256 Kbit (4 banks of 0x2000 bytes). The information in this section is based on my MBC1 research, Tauwasser's research notes [4], and Pan Docs [5].

#### 8.1 MBC1 registers

#### Caveat

These registers don't have any standard names and are usually referred to using their address ranges or purposes instead. This document uses names to clarify which register is meant when referring to one.

The MBC1 chip includes four registers that affect the behaviour of the chip. Of the cartridge bus address signals, only A13-A15 are connected to the MBC, so lower address bits don't matter when the CPU is accessing the MBC and all registers are effectively mapped to address ranges instead of single addresses. All registers are smaller than 8 bits, and unused bits are simply ignored during writes. The registers are not directly readable.

Register 8.1: 0x0000-0x1FFF - RAMG - MBC1 RAM gate register

U	U	U	U	W-0	W-0	W-0	W-0
					RAMG	(3:0>	
bit 7	6	5	4	3	2	1	bit 0

bit 7-4 Unimplemented: Ignored during writes

**bit 3-0 RAMG<3:0>**: RAM gate register

0b1010 = enable access to chip RAM

All other values disable access to chip RAM

The RAMG register is used to enable access to the cartridge SRAM if one exists on the cartridge circuit board. RAM access is disabled by default but can be enabled by writing to the 0x0000-0x1FFF address range a value with the bit pattern 0b1010 in the lower nibble. Upper bits don't matter, but any other bit pattern in the lower nibble disables access to RAM.

When RAM access is disabled, all writes to the external RAM area 0xA000-0xBFFF are ignored, and reads return undefined values. Pan Docs recommends disabling RAM when it's not being accessed to protect the contents [5].

#### **\*** Speculation

We don't know the physical implementation of RAMG, but it's certainly possible that the <code>0b1010</code> bit pattern check is done at write time and the register actually consists of just a single bit.

Register 8.2: 0x2000-0x3FFF - BANK1 - MBC1 bank register 1

U	U	U	W-0	W-0	W-0	W-0	W-1
					BANK1<4:0>		
bit 7	6	5	4	3	2	1	bit 0

**bit 7-5 Unimplemented**: Ignored during writes

**bit 4-0 BANK1<4:0>**: Bank register 1

Never contains the value 0600000.

If 0b00000 is written, the resulting value will be 0b00001 instead.

The 5-bit BANK1 register is used as the lower 5 bits of the ROM bank number when the CPU accesses the 0x4000-0x7FFF memory area.

MBC1 doesn't allow the BANK1 register to contain zero (bit pattern 0b00000), so the initial value at reset is 0b00001 and attempting to write 0b00000 will write 0b00001 instead. This makes it impossible to read banks 0x00, 0x20, 0x40 and 0x60 from the 0x4000-0x7FFF memory area, because those bank numbers have 0b000000 in the lower bits. Due to the zero value adjustment, requesting any of these banks actually requests the next bank (e.g. 0x21 instead of 0x20).

Register 8.3: 0x2000-0x3FFF - BANK1 - MBC1 bank register 2

U	U	U	U	U	U	W-0	W-0
						BANK2	<1:0>
bit 7	6	5	4	3	2	1	bit 0

**bit 7-2 Unimplemented**: Ignored during writes

**bit 1-0 BANK2<1:0>**: Bank register 2

The 2-bit BANK2 register can be used as the upper bits of the ROM bank number, or as the 2-bit RAM bank number. Unlike BANK1, BANK2 doesn't disallow zero, so all 2-bit values are possible.

Register 8.4: 0x6000-0x7FFF - MODE - MBC1 mode register

U	U	U	U	U	U	U	W-0
							MODE
bit 7	6	5	4	3	2	1	bit 0

#### **bit 7-1 Unimplemented**: Ignored during writes

#### **bit 0 MODE**: Mode register

0b1 = BANK2 affects accesses to 0x0000-0x3FFF, 0x4000-0x7FFF, 0xA000-0xBFFF

0b0 = BANK2 affects only accesses to 0x4000-0x7FFF

The MODE register determines how the BANK2 register value is used during memory accesses.

#### Warning

Most documentation, including Pan Docs [5], calls value 0b0 ROM banking mode, and value 0b1 RAM banking mode. This terminology reflects the common use cases, but "RAM banking" is slightly misleading because value 0b1 also affects ROM reads in multicart cartridges and cartridges that have a 8 or 16 Mbit ROM chip.

#### 8.2 ROM in the 0x0000-0x7FFF area

In MBC1 cartridges, the A0-A13 cartridge bus signals are connected directly to the corresponding ROM pins, and the remaining ROM pins (A14-A20) are controlled by the MBC1. These remaining pins form the ROM bank number.

When the 0x0000-0x3FFF address range is accessed, the effective bank number depends on the MODE register. In MODE 0b0 the bank number is always 0, but in MODE 0b1 it's formed by shifting the BANK2 register value left by 5 bits.

When the 0x4000-0x7FFF addess range is accessed, the effective bank number is always a combination of BANK1 and BANK2 register values.

If the cartridge ROM is smaller than 16 Mbit, there are less ROM address pins to connect to and therefore some bank number bits are ignored. For example, 4 Mbit ROMs only need a 5-bit bank number, so the BANK2 register value is always ignored because those bits are simply not connected to the ROM.

		ROM a	ddress bits
Accessed address	Bank ı	number	Address within bank
	20-19	18-14	13-0
0x0000-0x3FFF, MODE = 0b0	0b00	0b00000	A<13:0>
0x0000-0x3FFF, MODE = 0b1	BANK2	0b00000	A<13:0>
0x4000-0x7FFF	BANK2	BANK1	A<13:0>

Table 8.1: Mapping of physical ROM address bits in MBC1 carts

#### **ROM banking example 1**

Let's assume we have previously written 0x12 to the BANK1 register and 0b01 to the BANK2 register. The effective bank number during ROM reads depends on which address range we read and on the value of the MODE register:

Value of the BANK 1 register 0b10010

Value of the BANK 2 register ∅b<mark>∅1</mark>

Effective ROM bank number 0b0110010 (= 50 = 0x32)

(reading 0x4000–0x7FFF)

Effective ROM bank number (reading 0x0000-0x3FFF, MODE = 0b00000000 (= 0 = 0x00)

Effective ROM bank number (reading  $0 \times 0000 - 0 \times 3$  FFF, MODE = 0b1)  $(= 32 = 0 \times 20)$ 

#### **ROM banking example 2**

Let's assume we have previously requested ROM bank number 68, MBC1 mode is 0b0, and we are now reading a byte from 0x72A7. The actual physical ROM address that will be read is going to be 0x1132A7 and is constructed in the following way:

 Value of the BANK 1 register
 0b00100 

 Value of the BANK 2 register
 0b10 

 ROM bank number
 0b1000100 (=68 = 0x44) 

 Address being read
 0b0111 0010 1010 0111 (=0x72A7) 

 Actual physical ROM address
 0b1 0001 0011 0010 0101 0111 (=0x1132A7) 

#### 8.3 RAM in the 0xA000-0xBFFF area

Some MBC1 carts include SRAM, which is mapped to the 0xA000-0xBFFF area. If no RAM is present, or RAM is not enabled with the RAMG register, all reads return undefined values and writes have no effect.

On boards that have RAM, the A0-A12 cartridge bus signals are connected directly to the corresponding RAM pins, and pins A13-A14 are controlled by the MBC1. Most of the time the RAM size is 64 Kbit, which corresponds to a single bank of  $0 \times 2000$  bytes. With larger RAM sizes the BANK2 register value can be used for RAM banking to provide the two high address bits.

In MODE 0b0 the BANK2 register value is not used, so the first RAM bank is always mapped to the 0xA000–0xBFFF area. In MODE 0b1 the BANK2 register value is used as the bank number.

	RAM	address bits
Accessed address	Bank number	Address within bank
	14-13	12-0
0xA000-0xBFFF, MODE = 0b0	0b00	A<12:0>
0xA000-0xBFFF, MODE = 0b1	BANK2	A<12:0>

Table 8.2: Mapping of physical RAM address bits in MBC1 carts

#### **RAM banking example 1**

Let's assume we have previously written 0b10 to the BANK2 register, MODE is 0b1, RAMG is 0b1010 and we are now reading a byte from 0xB123. The actual physical RAM address that will be read is going to be 0x5123 and is constructed in the following way:

Value of the BANK 2 register 0b10

**Address being read** 0b1011 0001 0010 0011 (= 0xB123)

Actual physical RAM address 0b101 0001 0010 0011 (= 0x5123)

#### 8.4 MBC1 multicarts ("MBC1M")

MBC1 is also used in a couple of "multicart" cartridges, which include more than one game on the same cartridge. These cartridges use the same regular MBC1 chip, but the circuit board is wired a bit differently. This alternative wiring is sometimes called "MBC1M", but technically the mapper chip is the same. All known MBC1 multicarts use 8 Mbit ROMs, so there's no definitive wiring for other ROM sizes.

In MBC1 multicarts bit 4 of the BANK1 register is not physically connected to anything, so it's skipped. This means that the bank number is actually a 6-bit number. In all known MBC1 multicarts the games reserve 16 banks each, so BANK2 can actually be considered "game number", while BANK1 is the internal bank number within the selected game. At reset BANK2 is 0b00, and the "game" in this slot is actually a game selection menu. The menu code selects MODE 0b1 and writes the game number to BANK2 once the user selects a game.

From a ROM banking point of view, multicarts simply skip bit 4 of the BANK1 register, but otherwise the behaviour is the same. MODE 0b1 guarantees that all ROM accesses, including accesses to 0x0000-0x3FFF, use the BANK2 register value.

		ROM add	ress bits
Accessed address	Ban	k number	Address within bank
	19-18	17-14	13-0
0x0000-0x3FFF, MODE = 0b0	0b00	0b0000	A<13:0>
0x0000-0x3FFF, MODE = 0b1	BANK2	0b0000	A<13:0>
0x4000-0x7FFF	BANK2	BANK1<3:0>	A<13:0>

Table 8.3: Mapping of physical ROM address bits in MBC1 multicarts

#### **ROM banking example 1**

Value of the BANK 2 register

Let's assume we have previously requested "game number" 3 (= 0b11) and ROM bank number 29 (= 0x1D), MBC1 mode is 0b1, and we are now reading a byte from 0x6C15. The actual physical ROM address that will be read is going to be 0xF6C15 and is constructed in the following way:

0b11

Value of the BANK 1 register 0b11101

**ROM bank number**  $0b_{11}^{11}101$  (= 61 = 0x3D)

Address being read 0b0110 1100 0001 0101 (= 0x6C15)

Actual physical ROM address 0b1111 0110 1100 0001 0101 (= 0xF6C15)

#### **Detecting multicarts**

MBC1 multicarts are not detectable by simply looking at the ROM header, because the ROM type value is just one of the normal MBC1 values. However, detection is possible by going through BANK2 values and looking at "bank 0" of each multicart game and doing some heuristics based

on the header data. All the included games, including the game selection menu, have proper header data. One example of a good heuristic is logo data verification.

So, if you have a 8 Mbit cart with MBC1, first assume that it's a multicart and bank numbers are 6-bit values. Set BANK1 to zero and loop through the four possible BANK2 values while checking the data at 0x0104-0x0133. In other words, check logo data starting from physical ROM locations 0x00104, 0x40104, 0x80104, and 0x00104. If proper logo data exists with most of the BANK2 values, the cart is most likely a multicart. Note that multicarts can just have two actual games, so one of the locations might not have the header data in place.

#### 8.5 Dumping MBC1 carts

MBC1 cartridge dumping is fairly straightforward with the right hardware. The total number of banks is read from the header, and each bank is read one byte at a time. However, BANK1 register zero-adjustment and multicart cartridges need to be considered in ROM dumping code.

Banks 0x20, 0x40 and 0x60 can only be read from the 0x0000-0x3FFF memory area and only when MODE register value is 0b1. Using MODE 0b1 has no undesirable effects when doing ROM dumping, so using it at all times is recommended for simplicity.

Multicarts should be detected using the logo check described earlier, and if a multicart is detected, BANK1 should be considered a 4-bit register in the dumping code.

```
BANK1 = 0x2000
BANK2 = 0x4000
MODE = 0x6000
write_byte(MODE, 0x01)
for bank in range(0, num_banks):
    write_byte(BANK1, bank)
    if is_multicart:
        write_byte(BANK2, bank >> 4)
        bank_start = 0x4000 if bank & 0x0f else 0x0000
else:
        write_byte(BANK2, bank >> 5)
        bank_start = 0x4000 if bank & 0x1f else 0x0000
for addr in range(bank_start, bank_start + 0x4000):
        buf += read_byte(addr)
```

Listing 8.1: Python pseudo-code for MBC1 ROM dumping

## **MBC2** mapper chip

MBC2 supports ROM sizes up to 2 Mbit (16 banks of 0x4000 bytes) and includes an internal 512x4 bit RAM array, which is its unique feature. The information in this section is based on my MBC2 research, Tauwasser's research notes [6], and Pan Docs [5].

#### **\*** Speculation

MBC1 is strictly more powerful than MBC2 because it supports more ROM and RAM. This raises a very important question: why does MBC2 exist? It's possible that Nintendo tried to integrate a small amount of RAM on the MBC chip for cost reasons, but it seems that this didn't work out very well since all later MBCs revert this design decision and use separate RAM chips.

#### 9.1 MBC2 registers

#### **6** Caveat

These registers don't have any standard names and are usually referred to using one of their addresses or purposes instead. This document uses names to clarify which register is meant when referring to one.

The MBC2 chip includes two registers that affect the behaviour of the chip. The registers are mapped a bit differently compared to other MBCs. Both registers are accessible within 0x0000-0x3FFF, and within that range, the register is chosen based on the A8 address signal. In practice, this means that the registers are mapped to memory in an alternating pattern. For example, 0x0000, 0x2000 and 0x3000 are RAMG, and 0x0100, 0x2100 and 0x3100 are ROMB. Both registers are smaller than 8 bits, and unused bits are simply ignored during writes. The registers are not directly readable.

Register 9.1: 0x0000-0x3FFF when A8=0b0 - RAMG - MBC2 RAM gate register

U	U	U	U	W-0	W-0	W-0	W-0
					RAMG	<3:0>	
bit 7	6	5	4	3	2	1	bit 0

bit 7-4 Unimplemented: Ignored during writes

bit 3-0 RAMG<3:0>: RAM gate register

0b1010 = enable access to chip RAM

All other values disable access to chip RAM

The 4-bit MBC2 RAMG register works in a similar manner as MBC1 RAMG, so the upper bits don't matter and only the bit pattern 0b1010 enables access to RAM.

When RAM access is disabled, all writes to the external RAM area 0xA000-0xBFFF are ignored, and reads return undefined values. Pan Docs recommends disabling RAM when it's not being accessed to protect the contents [5].

#### **\*** Speculation

We don't know the physical implementation of RAMG, but it's certainly possible that the 0b1010 bit pattern check is done at write time and the register actually consists of just a single bit.

Register 9.2: 0x0000-0x3FFF when A8=0b1 - ROMB - MBC2 ROM bank register

U	U	U	U	W-0	W-0	W-0	W-1
					ROMB	(3:0>	
bit 7	6	5	4	3	2	1	bit 0

#### **bit 3-0 ROMB<3:0>**: ROM bank register

Never contains the value 0b0000.

If 0b0000 is written, the resulting value will be 0b0001 instead.

The 4-bit ROMB register is used as the ROM bank number when the CPU accesses the 0x4000-0x7FFF memory area.

Like MBC1 BANK1, the MBC2 ROMB register doesn't allow zero (bit pattern 0b0000) in the register, so any attempt to write 0b0000 writes 0b0001 instead.

#### 9.2 ROM in the 0x0000-0x7FFF area

In MBC2 cartridges, the A0-A13 cartridge bus signals are connected directly to the corresponding ROM pins, and the remaining ROM pins (A14-A17) are controlled by the MBC2. These remaining pins form the ROM bank number.

When the 0x0000-0x3FFF address range is accessed, the effective bank number is always 0.

When the 0x4000-0x7FFF address range is accessed, the effective bank number is the current ROMB register value.

	ROM address bits				
Accessed address	Bank number	Address within bank			
	17-14	13-0			
0x0000-0x3FFF	0b0000	A<13:0>			
0x4000-0x7FFF	ROMB	A<13:0>			

Table 9.1: Mapping of physical ROM address bits in MBC2 carts

#### 9.3 RAM in the 0xA000-0xBFFF area

All MBC2 carts include SRAM, because it is located directly inside the MBC2 chip. These cartridges never use a separate RAM chip, but battery backup circuitry and a battery are optional. If RAM is not enabled with the RAMG register, all reads return undefined values and writes have no effect.

MBC2 RAM is only 4-bit RAM, so the upper 4 bits of data do not physically exist in the chip. When writing to it, the upper 4 bits are ignored. When reading from it, the upper 4 data signals are not driven by the chip, so their content is undefined and should not be relied on.

MBC2 RAM consists of 512 addresses, so only A0-A8 matter when accessing the RAM region. There is no banking, and the 0xA000-0xBFFF area is larger than the RAM, so the addresses wrap around. For example, accessing 0xA000 is the same as accessing 0xA200, so it is possible to write to the former address and later read the written data using the latter address.

	RAM address bits
Accessed address	
	8-0
0xA000-0xBFFF	A<8:0>

Table 9.2: Mapping of physical RAM address bits in MBC2 carts

#### 9.4 Dumping MBC2 carts

MBC2 cartridges are very simple to dump. The total number of banks is read from the header, and each bank is read one byte at a time. ROMB zero adjustment must be considered in the ROM dumping code, but this only means that bank 0 should be read from 0x0000-0x3FFF and not from 0x4000-0x7FFF like other banks.

```
ROMB = 0x2100
for bank in range(0, num_banks):
    write_byte(ROMB, bank)
    bank_start = 0x4000 if bank > 0 else 0x0000
    for addr in range(bank_start, bank_start + 0x4000):
        buf += read_byte(addr)
```

Listing 9.2: Python pseudo-code for MBC2 ROM dumping

## **MBC3** mapper chip

MBC3 supports ROM sizes up to 16 Mbit (128 banks of 0x4000 bytes), and RAM sizes up to 256 Kbit (4 banks of 0x2000 bytes). It also includes a real-time clock (RTC) that can be clocked with a quartz crystal on the cartridge even when the Game Boy is powered down. The information in this section is based on my MBC3 research, and Pan Docs [5].

## MBC30 mapper chip

MBC30 is a variant of MBC3 used by Japanese Pokemon Crystal to support a larger ROM chip and a larger RAM chip. Featurewise MBC30 is almost identical to MBC3, but supports ROM sizes up to 32 Mbit (256 banks of 0x4000 bytes), and RAM sizes up to 512 Kbit (8 banks of 0x2000 bytes). Information in this section is based on my MBC30 research.

#### Warning

The circuit board of Japanese Pokemon Crystal includes a 1 Mbit RAM chip, but MBC30 is limited to 512 Kbit RAM. One of the RAM address pins is unused, so half of the RAM is wasted and is inaccessible without modifications. So, the game only uses 512 Kbit and there is a mismatch between accessible and the physical amounts of RAM.

## **MBC5** mapper chip

The majority of games for Game Boy Color use the MBC5 chip. MBC5 supports ROM sizes up to 64 Mbit (512 banks of 0x4000 bytes), and RAM sizes up to 1 Mbit (16 banks of 0x2000 bytes). The information in this section is based on my MBC5 research, and The Cycle-Accurate Game Boy Docs [7].

#### 12.1 MBC5 registers

Register 12.1: 0x0000-0x1FFF - RAMG - MBC5 RAM gate register

W-0	W-0	W-0	W-0	W-0	W-0	W-0	W-0
RAMG<7:0>							
bit 7	6	5	4	3	2	1	bit 0

#### **bit 7-0 RAMG<7:0>**: RAM gate register

0b00001010 = enable access to cartridge RAM All other values disable access to cartridge RAM

The 8-bit MBC5 RAMG register works in a similar manner as MBC1 RAMG, but it is a full 8-bit register so upper bits matter when writing to it. Only <code>0b00001010</code> enables RAM access, and all other values (including <code>0b10001010</code> for example) disable access to RAM.

When RAM access is disabled, all writes to the external RAM area 0xA000-0xBFFF are ignored, and reads return undefined values. Pan Docs recommends disabling RAM when it's not being accessed to protect the contents [5].

#### ★ Speculation

We don't know the physical implementation of RAMG, but it's certainly possible that the <code>0b00001010</code> bit pattern check is done at write time and the register actually consists of just a single bit.

Register 12.2: 0x2000-0x2FFF - ROMB0 - MBC5 lower ROM bank register

W-0	W-0	W-0	W-0	W-0	W-0	W-0	W-1
ROMB0<7:0>							
bit 7	6	5	4	3	2	1	bit 0

bit 7-0 ROMB0<7:0>: Lower ROM bank register

The 8-bit ROMB0 register is used as the lower 8 bits of the ROM bank number when the CPU accesses the 0x4000-0x7FFF memory area.

Register 12.3: 0x3000-0x3FFF - ROMB1 - MBC5 upper ROM bank register

U	U	U	U	U	U	U	W-0
							ROMB1
bit 7	6	5	4	3	2	1	bit 0

#### **bit 7-1 Unimplemented**: Ignored during writes

#### **bit 0 ROMB1**: Upper ROM bank register

The 1-bit ROMB1 register is used as the most significant bit (bit 9) of the ROM bank number when the CPU accesses the 0x4000-0x7FFF memory area.

Register 12.4: 0x4000-0x5FFF - RAMB - MBC5 RAM bank register

U	U	U	U	W-0	W-0	W-0	W-0	
				RAMB<3:0>				
bit 7	6	5	4	3	2	1	bit 0	

#### bit 7-4 Unimplemented: Ignored during writes

#### **bit 3-0 RAMB<3:0>**: RAM bank register

The 4-bit RAMB register is used as the RAM bank number when the CPU accesses the 0x-A000-0xBFFF memory area.

## **MBC6** mapper chip

MBC6 supports ROM sizes up to 16 Mbit (256 banks of 0x2000 bytes), and RAM sizes up to 4 Mbit (128 banks of 0x1000 bytes). The information in this section is based on my MBC6 research.

## MBC7

TODO.

## **HuC-1 mapper chip**

HuC-1 supports ROM sizes up to 8 Mbit (64 banks of 0x4000 bytes), and RAM sizes up to 256 Kbit (4 banks of 0x2000 bytes). It also includes a sensor and a LED for infrared communication. The information in this section is based on my HuC-1 research.

## **HuC-3 mapper chip**

HuC-3 supports ROM sizes up to 16 Mbit (128 banks of 0x4000 bytes), and RAM sizes up to 1 Mbit (16 banks of 0x2000 bytes). Like HuC-1, it includes support for infrared communication, but also includes a real-time-clock (RTC) and output pins used to control a piezoelectric buzzer. The information in this section is based on my HuC-3 research.

## **MMM01**

TODO.

## **Chapter 18**

## TAMA5

TODO.

# **Appendices**

## **Appendix A**

#### **Instruction set tables**

These tables include all the opcodes in the Sharp SM83 instruction set. The style and layout of these tables was inspired by the opcode tables available at pastraiser.com [8].

	ж0	<b>x1</b>	<b>x</b> 2	<b>x</b> 3	х4	ж5	жб	ж7	x8	ж9	ха	жb	жc	жđ	хe	хf
0x	NOP	LD BC,nn	LD (BC),A	INC BC	INC B	DEC B	LD B,n	RLCA	LD (nn),SP	ADD HL,BC	LD A,(BC)	DEC BC	INC C	DEC C	LD C,n	RRCA
1x	STOP	LD DE,nn	LD (DE),A	INC DE	INC D	DEC D	LD D,n	RLA	JR e	ADD HL,DE	LD A,(DE)	DEC DE	INC E	DEC E	LD E,n	RRA
2x	JR NZ,e	LD HL,nn	LD (HL+),A	INC HL	INC H	DEC H	LD H,n	DAA	JR Z,e	ADD HL,HL	LD A,(HL+)	DEC HL	INC L	DEC L	LD L,n	CPL
3x	JR NC,e	LD SP,nn	LD (HL-),A	INC SP	INC (HL)	DEC (HL)	LD (HL),n	SCF	JR C,e	ADD HL,SP	LD A,(HL-)	DEC SP	INC A	DEC A	LD A,n	CCF
4x	LD B,B	LD B,C	LD B,D	LD B,E	LD B,H	LD B,L	LD B,(HL)	LD B,A	LD C,B	LD C,C	LD C,D	LD C,E	LD C,H	LD C,L	LD C,(HL)	LD C,A
5x	LD D,B	LD D,C	LD D,D	LD D,E	LD D,H	LD D,L	LD D,(HL)	LD D,A	LD E,B	LD E,C	LD E,D	LD E,E	LD E,H	LD E,L	LD E,(HL)	LD E,A
6x	LD H,B	LD H,C	LD H,D	LD H,E	LD H,H	LD H,L	LD H,(HL)	LD H,A	LD L,B	LD L,C	LD L,D	LD L,E	LD L,H	LD L,L	LD L,(HL)	LD L,A
7x	LD (HL),B	LD (HL),C	LD (HL),D	LD (HL),E	LD (HL),H	LD (HL),L	HALT	LD (HL),A	LD A,B	LD A,C	LD A,D	LD A,E	LD A,H	LD A,L	LD A,(HL)	LD A,A
8x	ADD B	ADD C	ADD D	ADD E	ADD H	ADD L	ADD (HL)	ADD A	ADC B	ADC C	ADC D	ADC E	ADC H	ADC L	ADC (HL)	ADC A
9x	SUB B	SUB C	SUB D	SUB E	SUB H	SUB L	SUB (HL)	SUB A	SBC B	SBC C	SBC D	SBC E	SBC H	SBC L	SBC (HL)	SBC A
ax	AND B	AND C	AND D	AND E	AND H	AND L	AND (HL)	AND A	XOR B	XOR C	XOR D	XOR E	XOR H	XOR L	XOR (HL)	XOR A
bx	OR B	OR C	OR D	OR E	OR H	OR L	OR (HL)	OR A	CP B	CP C	CP D	CP E	CP H	CP L	CP (HL)	CP A
сx	RET NZ	POP BC	JP NZ,nn	JP nn	CALL NZ,nn	PUSH BC	ADD n	RST 0x00	RET Z	RET	JP Z,nn	СВ ор	CALL Z,nn	CALL nn	ADC n	RST 0x08
dx	RET NC	POP DE	JP NC,nn	-	CALL NC,nn	PUSH DE	SUB n	RST 0x10	RET C	RETI	JP C,nn	-	CALL C,nn	-	SBC n	RST 0x18
ex	LDH (n),A	POP HL	LDH (C),A	-	-	PUSH HL	AND n	RST 0x20	ADD SP,e	JP HL	LD (nn),A	-	-	-	XOR n	RST 0x28
fx	LDH A,(n)	POP AF	LDH A,(C)	DI	-	PUSH AF	OR n	RST 0x30	LD HL,SP+e	LD SP,HL	LD A,(nn)	EI	-	-	CP n	RST 0x38

Table A.1: Sharp SM83 instruction set

#### Legend:

8-bit loads	16-bit loads	8-bit arithmetic/logical	16-bit arithmetic	Rotates, shifts, and bit operations	Control flow	Miscellaneous
Undefined						

- **n** unsigned 8-bit immediate data
- **nn** unsigned 16-bit immediate data
- e signed 8-bit immediate data

	х0	<b>x1</b>	ж2	ж3	x4	<b>x</b> 5	ж6	<b>x</b> 7	ж8	ж9	ха	жb	жc	хd	хe	xf
0x	RLC B	RLC C	RLC D	RLC E	RLC H	RLC L	RLC (HL)	RLC A	RRC B	RRC C	RRC D	RRC E	RRC H	RRC L	RRC (HL)	RRC A
1x	RL B	RL C	RL D	RL E	RL H	RL L	RL (HL)	RL A	RR B	RR C	RR D	RR E	RR H	RR L	RR (HL)	RR A
2x	SLA B	SLA C	SLA D	SLA E	SLA H	SLA L	SLA (HL)	SLA A	SRA B	SRA C	SRA D	SRA E	SRA H	SRA L	SRA (HL)	SRA A
3x	SWAP B	SWAP C	SWAP D	SWAP E	SWAP H	SWAP L	SWAP (HL)	SWAP A	SRL B	SRL C	SRL D	SRL E	SRL H	SRL L	SRL (HL)	SRL A
4x	BIT 0,B	BIT 0,C	BIT 0,D	BIT 0,E	BIT 0,H	BIT 0,L	BIT 0,(HL)	BIT 0,A	BIT 1,B	BIT 1,C	BIT 1,D	BIT 1,E	BIT 1,H	BIT 1,L	BIT 1,(HL)	BIT 1,A
5x	BIT 2,B	BIT 2,C	BIT 2,D	BIT 2,E	BIT 2,H	BIT 2,L	BIT 2,(HL)	BIT 2,A	BIT 3,B	BIT 3,C	BIT 3,D	BIT 3,E	BIT 3,H	BIT 3,L	BIT 3,(HL)	BIT 3,A
6x	BIT 4,B	BIT 4,C	BIT 4,D	BIT 4,E	BIT 4,H	BIT 4,L	BIT 4,(HL)	BIT 4,A	BIT 5,B	BIT 5,C	BIT 5,D	BIT 5,E	BIT 5,H	BIT 5,L	BIT 5,(HL)	BIT 5,A
7x	BIT 6,B	BIT 6,C	BIT 6,D	BIT 6,E	BIT 6,H	BIT 6,L	BIT 6,(HL)	BIT 6,A	BIT 7,B	BIT 7,C	BIT 7,D	BIT 7,E	BIT 7,H	BIT 7,L	BIT 7,(HL)	BIT 7,A
8x	RES 0,B	RES 0,C	RES Ø,D	RES Ø,E	RES 0,H	RES 0,L	RES 0,(HL)	RES 0,A	RES 1,B	RES 1,C	RES 1,D	RES 1,E	RES 1,H	RES 1,L	RES 1,(HL)	RES 1,A
9x	RES 2,B	RES 2,C	RES 2,D	RES 2,E	RES 2,H	RES 2,L	RES 2,(HL)	RES 2,A	RES 3,B	RES 3,C	RES 3,D	RES 3,E	RES 3,H	RES 3,L	RES 3,(HL)	RES 3,A
ax	RES 4,B	RES 4,C	RES 4,D	RES 4,E	RES 4,H	RES 4,L	RES 4,(HL)	RES 4,A	RES 5,B	RES 5,C	RES 5,D	RES 5,E	RES 5,H	RES 5,L	RES 5,(HL)	RES 5,A
bx	RES 6,B	RES 6,C	RES 6,D	RES 6,E	RES 6,H	RES 6,L	RES 6,(HL)	RES 6,A	RES 7,B	RES 7,C	RES 7,D	RES 7,E	RES 7,H	RES 7,L	RES 7,(HL)	RES 7,A
сх	SET 0,B	SET 0,C	SET 0,D	SET 0,E	SET 0,H	SET 0,L	SET 0,(HL)	SET 0,A	SET 1,B	SET 1,C	SET 1,D	SET 1,E	SET 1,H	SET 1,L	SET 1,(HL)	SET 1,A
dx	SET 2,B	SET 2,C	SET 2,D	SET 2,E	SET 2,H	SET 2,L	SET 2,(HL)	SET 2,A	SET 3,B	SET 3,C	SET 3,D	SET 3,E	SET 3,H	SET 3,L	SET 3,(HL)	SET 3,A
ex	SET 4,B	SET 4,C	SET 4,D	SET 4,E	SET 4,H	SET 4,L	SET 4,(HL)	SET 4,A	SET 5,B	SET 5,C	SET 5,D	SET 5,E	SET 5,H	SET 5,L	SET 5,(HL)	SET 5,A
fx	SET 6,B	SET 6,C	SET 6,D	SET 6,E	SET 6,H	SET 6,L	SET 6,(HL)	SET 6,A	SET 7,B	SET 7,C	SET 7,D	SET 7,E	SET 7,H	SET 7,L	SET 7,(HL)	SET 7,A

Table A.2: Sharp SM83 CB-prefixed instructions

## **Appendix B**

## **Memory map tables**

	bit 7	6	5	4	3	2	1	bit 0					
0xFF00 P1			P15 buttons	P14 d-pad	P13 🖸 start	P12 o select	Р11 <b>⊘</b> в	P10 <b>⊘</b> A					
0xFF01 SB		•	•		7:0>								
0xFF02 SC	SIO_EN						SIO_FAST	SIO_CLK					
0xFF03					•	'							
0xFF04 DIV				DIVH	l<7:0>								
0xFF05 TIMA	TIMA<7:0>												
0xFF06 TMA				TMA	<7:0>								
0xFF07 TAC						TAC_EN	TAC_C	LK<1:0>					
0xFF08													
0xFF09													
0xFF0A													
0xFF0B													
0xFF0C													
0xFF0D													
0xFF0E					1								
0xFF0F IF				IF_JOYPAD	IF_SERIAL	IF_TIMER	IF_STAT	IF_VBLANK					
0xFF10 NR10													
0xFF11 NR11													
0xFF12 NR12													
0xFF13 NR13													
0xFF14 NR14													
0xFF15													
0xFF16 NR21													
0xFF17 NR22													
0xFF18 NR23													
0xFF19 NR24													
0xFF1A NR30													
0xFF1B NR31													
0xFF1C NR32													
0xFF1D NR33													
0xFF1E NR34													
0xFF1F													
	bit 7	6	5	4	3	2	1	bit 0					

Table B.3: 0xFFxx registers: 0xFF00-0xFF1F

	bit 7	6	5	4	3	2	1	bit 0
0xFF20 NR41								
0xFF21 NR42								
0xFF22 NR43								
0xFF23 NR44								
0xFF24 NR50								
0xFF25 NR51								
0xFF26 NR52								
0xFF27								
0xFF28								
0xFF29								
0xFF2A								
0xFF2B								
0xFF2C								
0xFF2D								
0xFF2E								
0xFF2F								
0xFF30 WAV00								
0xFF31 WAV01								
0xFF32 WAV02								
0xFF33 WAV03								
0xFF34 WAV04								
0xFF35 WAV05								
0xFF36 WAV06								
0xFF37 WAV07								
0xFF38 WAV08								
ØxFF39 WAV09								
ØxFF3A WAV10								
0xFF3B WAV11								
0xFF3C WAV12								
0xFF3D WAV13								
0xFF3E WAV14								
0xFF3F WAV15								
	bit 7	6	5	4	3	2	1	bit 0

Table B.4: 0xFFxx registers: 0xFF20-0xFF3F

	bit 7	6	5	4	3	2	1	bit 0
0xFF40 LCDC	LCD_EN	WIN_MAP	WIN_EN	TILE_SEL	BG_MAP	OBJ_SIZE	OBJ_EN	BG_EN
0xFF41 STAT		INTR_LYC	INTR_M2	INTR_M1	INTR_M0	LYC_STAT	LCD_M0	DDE<1:0>
0xFF42 SCY								
0xFF43 SCX								
0xFF44 LY								
0xFF45 LYC								
0xFF46 DMA				DMA	<7:0>		!	•
0xFF47 BGP								
0xFF48 OBP0								
0xFF49 OBP1								
0xFF4A WY								
0xFF4B WX								
0xFF4C ????								
0xFF4D KEY1	KEY1_FAST							KEY1_EN
0xFF4E								
0xFF4F VBK							VBK	<1:0>
0xFF50 BOOT								BOOT_OFF
0xFF51 HDMA1								
0xFF52 HDMA2								
0xFF53 HDMA3								
0xFF54 HDMA4								
0xFF55 HDMA5								
0xFF56 RP								
0xFF57					•	•		
0xFF58								
0xFF59								
0xFF5A								
0xFF5B								
0xFF5C								
0xFF5D								
0xFF5E								
0xFF5F								
	bit 7	6	5	4	3	2	1	bit 0

Table B.5: 0xFFxx registers: 0xFF40-0xFF5F

	bit 7	6	5	4	3	2	1	bit 0
0xFF60 ????								
0xFF61								
0xFF62								
0xFF63								
0xFF64								
0xFF65								
0xFF66								
0xFF67								
0xFF68 BCPS								
0xFF69 BPCD								
0xFF6A OCPS								
0xFF6B OCPD								
0xFF6C ????								
0xFF6D								
0xFF6E								
0xFF6F								
0xFF70 SVBK							SVBK	<1:0>
0xFF71		<u> </u>			•			
0xFF72 ????								
0xFF73 ????								
0xFF74 ????								
0xFF75 ????								
0xFF76 PCM12		PCM1	2_CH2			PCM1	2 CH1	
0xFF77 PCM34			 4_CH4			PCM3		
0xFF78								
0xFF79								
0xFF7A								
0xFF7B								
0xFF7C								
0xFF7D								
0xFF7E								
0xFF7F								
0xFFFF IE		IE_UNUSED<2:0>		IE_JOYPAD	IE_SERIAL	IE_TIMER	IE_STAT	IE_VBLANK
	bit 7	6	5	4	3	2	1	bit 0

Table B.6: 0xFFxx registers: 0xFF60-0xFF7F, 0xFFFF

#### **Appendix C**

## **Game Boy external bus**

#### **C.1 Bus timings**




Figure C.2: External bus idle machine cycle




Figure C.3: External bus CPU read machine cycles




Figure C.4: External bus CPU write machine cycles




Figure C.5: External bus timings for OAM DMA read machine cycles

<sup>&</sup>lt;sup>1</sup>Does not apply to 0x0000-0x00FF reads while the boot ROM is enabled. Boot ROM accesses do not affect the external bus, so it is in the idle state.

 $<sup>^2</sup>$ Does not apply to 0x0000-0x00FF reads while the boot ROM is enabled. Boot ROM accesses do not affect the external bus, so it is in the idle state.

 $<sup>^3</sup>$ Does not apply to 0x0000-0x00FF reads while the boot ROM is enabled. Boot ROM accesses do not affect the external bus, so it is in the idle state.

#### **Appendix D**

### **Chip pinouts**

#### **D.1 CPU chips**




Figure D.6: DMG/SGB CPU (Sharp QFP080-P-1420)




Figure D.7: MGB/SGB2 CPU (Sharp QFP080-P-1420)

#### **D.2 Cartridge chips**




Figure D.8: MBC1 (Sharp SOP24-P-450) [4]




Figure D.9: MBC2 (Sharp SOP28-P-450) [6]




Figure D.10: MBC5 (Sharp QFP32-P-0707)

#### **Bibliography**

- [1] "SM8311/SM8313/SM8314/SM8315 8-Bit Single-Chip Microcomputers (Controllers For Home Appliances)". Sharp Corporation.
- [2] Costis Sideris, "The quest for dumping GameBoy Boot ROMs!". [Online]. Available: http://www.its.caltech.edu/~costis/sgb\_hack/
- [3] gekkio, "Dumping the Super Game Boy 2 boot ROM". [Online]. Available: https://gekkio.fi/blog/2015/dumping-the-super-game-boy-2-boot-rom/
- [4] Tauwasser, "MBC1 Tauwasser's Wiki". [Online]. Available: https://wiki.tauwasser.eu/view/MBC1
- [5] Pan of ATX, M. Fayzullin, P. Felber, P. Robson, and M. Korth, "Pan Docs Everything You Always Wanted To Know About GAMEBOY". [Online]. Available: http://bgb.bircd.org/pandocs.
- [6] Tauwasser, "MBC2 Tauwasser's Wiki". [Online]. Available: https://wiki.tauwasser.eu/view/MBC2
- [7] Antonio Niño Díaz (AntonioND), "The Cycle-Accurate Game Boy Docs". [Online]. Available: https://github.com/AntonioND/giibiiadvance/tree/master/docs
- [8] "Gameboy CPU (LR35902) instruction set". [Online]. Available: http://www.pastraiser.com/cpu/gameboy/gameboy\_opcodes.html