



5 PULL BACK 12/C FROM CABINET TO NEAREST PULL BOX. EXTEND 12/C TO NEW CABINET PER WIRING SCHEDULE.

- AT LEAST 6 WEEKS IN ADVANCE OF CONSTRUCTION, COORDINATE WITH THE MTA TRAFFIC ENGINEER TO HAVE THE TRAFFIC SIGNAL SHOP REMOVE TRANSIT SIGNAL PRIORITY WIRING AND EQUIPMENT ON POLE, WHERE APPLICABLE.
- AT LEAST 6 WEEKS IN ADVANCE OF CONSTRUCTION, COORDINATE WITH THE MTA TRAFFIC ENGINEER TO HAVE THE TRAFFIC SIGNAL SHOP REMOVE ITS CAMERA WIRING AND EQUIPMENT, WHERE APPLICABLE.
- AT LEAST 6 WEEKS IN ADVANCE OF CONSTRUCTION, COORDINATE WITH THE MTA TRAFFIC ENGINEER TO HAVE DTIS DISCONNECT FIBER OPTIC IN CABINET AND REMOVE DTIS SECURITY CAMERAS FROM POLES.
- ONCE THE TRAFFIC SIGNAL MOUNTINGS ARE REMOVED, ADJUST EXTERNAL CONDUIT ON THE (E) STREETLIGHT PER SFDPW STANDARD PLAN 87,213.









ESH JO: 1171i **CONTRACT NO. 10035213**