WORK IN EXISTING PASSENGER LOADING AND UNLOADING ZONE. THE SFMTA MAY TEMPORARILY

9) THE CONTRACTOR SHALL NOT PREVENT OR DELAY THE OPERATION OF MASS TRANSIT VEHICLES AT ANY TIME.

AUTHORIZE THE RELOCATION OF THESE ZONES.

3450 3RD ST #3G

415-206-1700 PHONE

INFO@CMCTRAFFIC.COM


415-206-1711 FAX

SAN FRANCISCÖ, CA 94124 CLASS A, 31, C21

LICENSE NO 792059

WWW.CMCTRAFFIC.COM

WBE/SBE/LBE/DBE CERTIFIED



NS Towaway/No Stopping

Curing Concrete

900

For speeds of 40 mph or less, L = WS<sup>2</sup>/60

Where: L = taper length in feet

W = width of offset in feet

For speeds of 45 mph or more, L = WS

- For other offsets use the following merging taper length formula for L

\* - Maximum downstream taper length is 100 feet. See Section 6C.08.

450

- Posted speed limit, off-peak 85th-percentile speed prior to work starting, or the anticipated operating speed in mph.

S = posted speed limit, off-peak 85th-percentile speed prior to work, or the anticipated operating

50

All other tapers are as shown.

pavement markings and channelizing devices.

\* Maximum channelizing device spacing for all speeds on one-lane/two-way tapers is 20 feet.

Maximum channelizing device spacing for all speeds on downstream tapers is 20 feet.

\*\* Use on intermediate and short-term projects for taper and tangent sections where

there are no pavement markings or where there is a conflict between existing

100

25

Plan Scale

1" = 50'